

## HOW TO USE THIS MANUAL

E01BAAV

### SCOPE OF MAINTENANCE, REPAIR AND SERVICING EXPLANATIONS

This manual provides explanations, etc. concerning procedures for the inspection, maintenance, repair and servicing of the subject model. Note, however, that for engine and transmission-related component parts, this manual covers only on-vehicle inspections, adjustments, and the removal and installation procedures for major components. For detailed information concerning the inspection, checking, adjustment, disassembly and reassembly of the engine, transmission and major components after they have been removed from the vehicle, please refer to the separate manuals covering the engine and the transmission.

### SERVICE ADJUSTMENT PROCEDURES

“Service adjustment procedures” are procedures for performing inspections and adjustments of particularly important locations with regard to the construction and for maintenance and servicing, but other inspections (for looseness, play, cracking, damage, etc.) must also be performed.

### INSPECTION

Under this title are presented inspection and checking procedures to be performed by using special tools and measuring instruments and by feeling, but, for actual maintenance and servicing procedures, visual inspections should always be performed as well.

### DEFINITION OF TERMS

#### STANDARD VALUE

Indicates the value used as the standard for judging the quality of a part or assembly on inspection or the value to which the part or assembly is corrected and adjusted. It is given by tolerance.

#### LIMIT

Shows the standard for judging the quality of a part or assembly on inspection and means the maximum or minimum value within which the part or assembly must be kept functionally or in strength. It is a value established outside the range of standard value.

#### REFERENCE VALUE

Indicates the adjustment value prior to starting the work (presented in order to facilitate assembly and adjustment procedures, and so they can be completed in a shorter time).

#### CAUTION

Indicates the presentation of information particularly vital to the worker during the performance of maintenance and servicing procedures in order to avoid the possibility of injury to the worker, or damage to component parts, or a reduction of component or vehicle function or performance, etc.

### INDICATION OF TIGHTENING TORQUE

The tightening torque shown in this manual is a basic value with a tolerance of  $\pm 10\%$  except the following cases when the upper and lower limits of tightening torque are given.

- (1) The tolerance of the basic value is within  $\pm 10\%$ .
- (2) Special bolts or the like are in use.
- (3) Special tightening methods are used.

### MODEL INDICATIONS

The following abbreviations are used in this manual for classification of model types.

M/T: Indicates the manual transmission, or models equipped with the manual transmission.

A/T: Indicates the automatic transmission, or models equipped with the automatic transmission.

2WD: Indicates the front wheel-drive vehicles.


4WD: Indicates the 4 wheel-drive vehicles.

MPI: Indicates the multi-point injection, or engines equipped with the multi-point injection.

MAJOR SPECIFICATIONS <Vehicles built up to May, 1992>

E01FA--

<SPACE RUNNER>




66C0031

Items	Model	N11W			N21W
		SNJEL6/R6	SNUEL6/R6 SNUEBR6	SRUEL6/R6 SRUEBR6	SNUEL6/R6
Dimensions	mm (in.)				
Overall length	①	4,290 (168.9)			4,290 (168.9)
Overall width	②	1,695 (66.7)			1,695 (66.7)
Overall height (unladen)	③	1,625 (64.0) or 1,640 (64.6)* <sup>1</sup>			1,640 (64.6) or 1,680 (66.1)* <sup>1</sup>
Wheelbase	④	2,520 (99.2)			2,520 (99.2)
Track – front	⑤	1,460 (57.5)			1,455 (57.3)
Track – rear	⑥	1,460 (57.5)			1,460 (57.5)
Ground clearance (laden)	⑦	120 (4.7)			120 (4.7)
Overhang – front	⑧	895 (35.2)			895 (35.2)
Overhang – rear	⑨	875 (34.4)			875 (34.4)
Weight	kg (lbs.)				
Kerb weight* <sup>2</sup>		1,175–1,279 (2,590–2,820)	1,185–1,288 (2,612–2,840)	1,205–1,308 (2,657–2,884)	1,280–1,379 (2,822–3,040)
Gross vehicle weight		1,720 (3,792)			1,800 (3,968)
Max. axle weight					
front		930 (2,050)			950 (2,094)
rear		910 (2,006)			980 (2,161)
Seating capacity		5			
Engine					
Model		4G93			
Total displacement cm <sup>3</sup> (cu. in.)		1,834 (111.9)			
Transmission					
Model		F5M22			W5M31
Type		5-speed manual			5-speed manual

NOTE

\*<sup>1</sup>: with roof rail

\*<sup>2</sup>: without optional parts – with full optional parts



## SERVICE POINTS OF REMOVAL

E11GBHA

### 5. REMOVAL OF CRANKSHAFT BOLT /6. CRANKSHAFT PULLEY

Use the special tool to stop the crankshaft pulley from turning, and remove the crankshaft bolt.

#### Caution



Hold the special tool securely so that it doesn't move.

### 10. REMOVAL OF TIMING BELT

- (1) Turn the crankshaft clockwise (right turn) to align each timing mark and to set the No. 1 cylinder at compression top dead centre.

#### Caution

The crankshaft should always be turned only clockwise.








- (2) Loosen the timing belt tensioner bolt.
- (3) Set a screwdriver to the timing belt tensioner and press it fully back in the direction of the arrow.
- (4) Provisionally tighten the timing belt tensioner bolt.
- (5) Remove the timing belt.










#### Caution

If the timing belt is to be re-used, use chalk to mark the flat side of the belt with an arrow indicating the direction of rotation (right turn).

**HARNES INSPECTION**

<p><b>1</b></p> <p>(A) Harness side connector</p>  <p style="text-align: right; font-size: small;">01A0521</p>	<p>Measure the power supply voltage of the control relay.</p> <ul style="list-style-type: none"> <li>Control relay connector: Disconnected</li> </ul> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 10px;"> <thead> <tr> <th style="width: 50%;">Ignition switch</th> <th style="width: 50%;">Voltage (V)</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">OFF</td> <td style="text-align: center;">0 – 1</td> </tr> <tr> <td style="text-align: center;">ON</td> <td style="text-align: center;">SV</td> </tr> </tbody> </table>	Ignition switch	Voltage (V)	OFF	0 – 1	ON	SV	<p style="text-align: center; font-size: 2em;"><b>OK</b></p> <p style="text-align: center;">→ <b>2</b></p> <p>Repair the harness. (Ignition switch – (A)8) or check the Ignition switch.</p> <p style="text-align: center; font-size: 2em;"><del><b>OK</b></del></p> <p style="text-align: center;">→</p>
Ignition switch	Voltage (V)							
OFF	0 – 1							
ON	SV							
<p><b>2</b></p> <p>(A) Harness side connector</p>  <p style="text-align: right; font-size: small;">3FU0296</p>	<p>Measure the power supply voltage of the control relay.</p> <ul style="list-style-type: none"> <li>Control relay connector: Disconnected</li> </ul> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 10px;"> <thead> <tr> <th style="width: 100%;">Voltage (V)</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">SV</td> </tr> </tbody> </table>	Voltage (V)	SV	<p style="text-align: center; font-size: 2em;"><b>OK</b></p> <p style="text-align: center;">→ <b>3</b></p> <p style="text-align: center; font-size: 2em;"><del><b>OK</b></del></p> <p style="text-align: center;">→</p> <p>Repair the harness. (Battery – (A)4)</p>				
Voltage (V)								
SV								
<p><b>3</b></p> <p>(A) Harness side connector</p>  <p style="text-align: right; font-size: small;">01A0369</p>	<p>Check for continuity of the earth circuit.</p> <ul style="list-style-type: none"> <li>Control relay connector: Disconnected</li> </ul>	<p style="text-align: center; font-size: 2em;"><b>OK</b></p> <p style="text-align: center;">→ <b>4</b></p> <p style="text-align: center; font-size: 2em;"><del><b>OK</b></del></p> <p style="text-align: center;">→</p> <p>Repair the harness. ((A)6 – Earth)</p>						
<p><b>4</b></p> <p>Engine control unit harness side connector</p>  <p style="text-align: right; font-size: small;">01A0374</p>	<p>Check for open-circuit, or short-circuit to earth, between the engine control unit and the control relay.</p> <ul style="list-style-type: none"> <li>Engine control unit connector: Disconnected</li> <li>Control relay connector: Disconnected</li> </ul>	<p style="text-align: center; font-size: 2em;"><b>OK</b></p> <p style="text-align: center;">→ <b>5</b></p> <p style="text-align: center; font-size: 2em;"><del><b>OK</b></del></p> <p style="text-align: center;">→</p> <p>Repair the harness.                  (12 – (A)3)                  (25 – (A)3)</p>						
<p><b>5</b></p> <p>(A) Harness side connector</p>  <p style="text-align: right; font-size: small;">6FU1751</p>	<p>Measure the power voltage to the actuator.</p> <ul style="list-style-type: none"> <li>Control relay connector: Connected</li> <li>ECU connector: Connected</li> </ul> <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 10px;"> <thead> <tr> <th style="width: 50%;">Engine</th> <th style="width: 50%;">Voltage [V]</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Cranking</td> <td style="text-align: center;">8V or more</td> </tr> <tr> <td style="text-align: center;">Racing</td> <td style="text-align: center;">SV</td> </tr> </tbody> </table>	Engine	Voltage [V]	Cranking	8V or more	Racing	SV	<p style="text-align: center; font-size: 2em;"><b>OK</b></p> <p style="text-align: center;">→ <b>STOP</b></p> <p style="text-align: center; font-size: 2em;"><del><b>OK</b></del></p> <p style="text-align: center;">→</p> <p>Replace the control relay.</p>
Engine	Voltage [V]							
Cranking	8V or more							
Racing	SV							

17-16-4 EMISSION CONTROL <4G63, 4G64> - Service Adjustment Procedures




**SERVICE ADJUSTMENT PROCEDURES****REAR AXLE TOTAL BACKLASH CHECK**


E27FCAG

If the vehicle vibrates and produces a booming sound due to an imbalance of the driving system, measure the rear axle total backlash by the following procedures to see if the differential carrier assembly requires removal.

- (1) Place the gearshift lever in the neutral position, apply the parking brake and jack up the vehicle.




- (2) Manually turn the propeller shaft clockwise as far as it will go and make mating marks on the companion flange dust cover and the differential carrier.



- (3) Manually turn the propeller shaft counterclockwise as far as it will go and measure the movement of the mating marks.

**Limit: 5 mm (0.2 in.)**


- (4) If the backlash exceeds the limit, remove the differential carrier assembly and adjust the backlash. (Refer to P.27-27 and 28.)

**GEAR OIL LEVEL CHECK**

E27FGAG

1. Remove the filler plug, and check the oil level.
2. The oil level is sufficient if it reaches the filler plug hole.

**Specified gear oil: Hypoid gear oil SAE No. 90 conforming to API GL-5 or higher [0.7 dm<sup>3</sup>(0.74 U.S.qts., 0.62 Imp.qts.)]**

**WHEEL BEARING END PLAY CHECK**

E27FHAЕ




- (1) Release the parking brake.
- (2) Remove the brake drum.
- (3) For vehicles with ABS, remove the caliper assembly and brake disc.
- (4) Place a dial gauge as shown in the figure and then measure the end play when the axle hub is moved in the axial direction.

**Limit: 0.05 mm (0.002 in.)**

- (5) If the play exceeds the limit, replace the wheel bearing.

**REAR DOOR ASSEMBLY <SPACE WAGON>**

**REMOVAL AND INSTALLATION**



**Door assembly removal steps**


1. Door harness connector
2. Pin
3. Door assembly
4. Door upper hinge
5. Door lower hinge
- ◆◆ 6. Door check strap

**Door switch removal steps**

9. Door switch cap
10. Door switch

**Striker removal steps**

7. Striker
8. Striker shim



**Adjustment of the door stepping and the door latch linkage**

**INSPECTION**

**DOOR SWITCH**

Operate the switch, and check the continuity between the terminals.

	Terminal	
Switch position	1	2
Open (ON)	○—○	
Depressed (OFF)		

**NOTE**



○—○ indicates there is continuity between the terminals.

**SERVICE POINTS OF INSTALLATION**

**6. INSTALLATION OF DOOR CHECK STRAP**

Install the door check strap so that the identification mark faces upwards.

Applicable location	Identification mark
R H	K L
L H	K R





## LIST OF EFFECTIVE PAGES

Group/ Page	Revision code	Date	Remarks	Group/ Page	Revision code	Date	Remarks
<b>LIST OF EFFECTIVE PAGES</b>				16	B	May 1993	REVISED
1 thru 2	B	May 1993	ADDED	17 thru 19	A	Jan. 1993	
<1993 models>				19-1 thru 19-4	B	May 1993	ADDED
Foreword		Jun. 1992		20	B	May 1993	REVISED
<b>1-HOW TO READ THE WIRING DIAGRAMS</b>				21 thru 22	A	Jan. 1993	
1	B	May 1993	REVISED	23		Jun. 1992	
2 thru 3		Jun. 1992		23-1 thru 23-4	B	May 1993	ADDED
4 thru 7	B	May 1993	REVISED	24	B	May 1993	REVISED
8		Jun. 1992		25 thru 28	A	Jan. 1993	
9 thru 12	B	May 1993	REVISED	28-1 thru 28-6	B	May 1993	ADDED
13	B	May 1993	ADDED	29	B	May 1993	REVISED
<b>2-WIRING HARNESS CONFIGURATION DIAGRAMS</b>				30 thru 33	A	Jan. 1993	
1 thru 12		Jun. 1992		33-1 thru 33-6	B	May 1993	ADDED
13	A	Jan. 1993		34 thru 37		Jun. 1992	
14 thru 15		Jun. 1992		38	A	Jan. 1993	
16	A	Jan. 1993		39		Jun. 1992	
17 thru 19	B	May 1993	REVISED	40 thru 43	A	Jan. 1993	
20 thru 21		Jun. 1992		44 thru 45		Jun. 1992	
22 thru 23	A	Jan. 1993		46 thru 49	A	Jan. 1993	
24 thru 25		Jun. 1992		50 thru 51		Jun. 1992	
26 thru 27	A	Jan. 1993		52	A	Jan. 1993	
28 thru 30		Jun. 1992		53		Jun. 1992	
<b>3-SINGLE PART INSTALLATION POSITION</b>				54	A	Jan. 1993	
1	A	Jan. 1993		55 thru 56		Jun. 1992	
2 thru 6		Jun. 1992		57	A	Jan. 1993	
7 thru 11	A	Jan. 1993		58		Jun. 1992	
11-1 thru 11-2	A	Jan. 1993		59 thru 60	A	Jan. 1993	
12	A	Jan. 1993		61		Jun. 1992	
13 thru 18		Jun. 1992		62	A	Jan. 1993	
<b>4-CIRCUIT DIAGRAM</b>				63 thru 64		Jun. 1992	
1 thru 2	B	May 1993	REVISED	65 thru 66	A	Jan. 1993	
3 thru 6		Jun. 1992		67		Jun. 1992	
7	A	Jan. 1993		68	A	Jan. 1993	
8 thru 9		Jun. 1992		69 thru 70		Jun. 1992	
10	A	Jan. 1993		71 thru 76	A	Jan. 1993	
11 thru 12		Jun. 1992		77 thru 78		Jun. 1992	
13 thru 14	A	Jan. 1993		79	A	Jan. 1993	
15		Jun. 1992		80		Jun. 1992	




## ENGINE AND TRANSMISSION


### 4G63 and 4G64 MPI engine



B-01	Engine coolant temperature sensor (for engine control)	B-21	Power steering oil pressure switch
B-02	—	B-22	Magnetic clutch <A/C>
B-03	Engine coolant temperature gauge unit	B-23 } Starter	
B-04	Idle speed control actuator	B-24 }	
B-05	Throttle position sensor	B-25	—
B-06	Injector No. 4	B-26	Oxygen sensor
B-07	Injector No. 3	B-27	Oil pressure switch
B-08	Injector No. 2	B-28 } Distributor assembly	
B-09	—	B-29 }	
B-10	Injector No. 1	B-30	Capacitor
B-11	Detonation sensor <4G63>	B-31	—
B-12 } —		B-32	Engine oil level sensor
thru } —		B-33	—
B-18 } —		B-34	Oxygen sensor sub wiring harness and control wiring harness combination
B-19 } Alternator		B-35	EGR temperature sensor <4G64>
B-20 }			



Wire colour code  
 B:Black    LG:Light green    G:Green    L:Blue  
 BR:Brown    O:Orange    GR:Gray    R:Red  
 W:White    SB:Sky blue    P:Pink    Y:Yellow  
 V:Violet



ELC-4A/T CONTROL UNIT

Remarks  
 \*C:4G93 engine  
 \*D:4G63 engine

Wire colour code  
 B:Black LG:Light green G:Green L:Blue W:White Y:Yellow SB:Sky blue  
 BR:Brown O:Orange GR:Gray R:Red P:Pink V:Violet

**HEADLAMP <Vehicles with daytime running lamp> (See P. 4-52.)****OPERATION**

Headlamp Relay ON Conditions

Ignition switch	Lighting switch	Dimmer/passing switch	Headlamp relay
"ON"	—	—	ON
—	"HEAD"	—	ON
—	—	"PASS"	ON

**<Daytime running lamp operation>**

- Turning the ignition switch to the ON position causes the headlamp relay, daytime running lamp relay 1, and tail lamp relay to be energized, which causes the headlamps, tail lamps, etc. to come on.

**<Low-beam operation>**

- Placing the lighting switch in the HEAD position causes the headlamp relay and daytime running lamp relay 2 to be energized.
- If the dimmer/passing switch is placed in the LO position at this time, the headlamps light up in low beam.

**<Upper-beam operation>**

- Placing the lighting switch in the HEAD position causes the headlamp relay and daytime running lamp relay 2 to be energized.
- If the dimmer/passing switch is placed in the HI position at this time, the headlamps light up in upper beam.

**<Upper-beam indicator lamp>**

- This lamp lights up when the upper/passing beams are on, indicating that the headlamps are on in upper beam.

**TROUBLESHOOTING HINTS**

1. Headlamps don't come on.
  - (1) But the tail lamps do illuminate.
    - Check the headlamp relay.
    - Check the lighting switch.
  - (2) The tail lamps also don't illuminate.
    - Check the sub fusible link No. ④.
2. The low beam at both sides doesn't illuminate.
  - Check the dimmer switch LO contacts.
3. The upper beam at both sides doesn't illuminate.
  - (1) The passing signal functions OK.
    - Check the dimmer switch HI contacts.
  - (2) The passing signal doesn't function.
    - Check the dimmer switch.
    - Check the daytime running lamp relay 2.
    - Check the daytime running lamp control unit.
4. One headlamp doesn't illuminate.
  - Check the bulb.
5. Can't switch from low to upper beam or vice-versa.
  - Check the dimmer switch.
6. With the ignition switch at the "ON" position, the headlamps' low beam does not illuminate.
  - Check the daytime running lamp relay 1.
  - Check the daytime running lamp control unit.
7. Upper-beam indicator lamp does not come on.
  - (1) Headlamp upper beams are operational.
    - Check the dedicated fuse No. ④.
    - Check the indicator lamp bulb.

**Remark**

- The head lamp circuit has a lighting monitor buzzer system. For operation and troubleshooting hints, refer to LIGHTING MONITOR BUZZER (P. 4-84).

**SUNROOF (See P. 4-142.)****OPERATION****〈Tilt operation〉**

- When the UP side of the tilt switch is depressed with the roof lid in fully-closed position and ignition switch in ON, the open/close position detecting circuit of the sunroof control relay turns ON Tr<sub>2</sub> causing relay 2 to be energized. This results in the sunroof motor being rotated causing the rear end to raise approx. 30 mm (1.18 in.).
- When the DOWN side of the tilt switch is depressed, relay 1 is energized causing the roof lid to close down.
- When the roof lid is fully closed, limit switch 1 turns ON causing relay 1 to deenergized. As a result, the motor stops rotating.

**〈Slide operation〉**

- When the OPEN side of the slide switch is depressed with the ignition switch in ON position, the open/close position detecting circuit of the sunroof control relay turns ON Tr<sub>1</sub> causing relay 1 to be energized. This results in the sunroof motor being rotated and the roof lid opens as long as the switch is held down.
- As when the OPEN side is held down, holding down the CLOSE side energizes relay 2 causing the roof lid to close. If the switch is held down with the roof lid opened more than half, the limit switch turns OFF just before the lid is fully closed, which deenergizes relay 2. As a result, the motor stops rotating and the roof lid stops in mid-motion. If the switch is released and then depressed and held down, the restart timer turns ON Tr<sub>2</sub> causing relay 2 to be energized. This in turn causes the sunroof motor to start.
- When the roof lid is fully closed, limit switch 2 turns OFF, deenergizing relay 2. Then, the motor stops rotating.

**TROUBLESHOOTING HINTS**

1. Sunroof is not operative at all.
  - (1) Power window is inoperative also.
    - Check the multi-purpose fuse No. ③.
  - (2) Power window is operative.
    - Check the multi-purpose fuse No. ⑮.
    - Check the sunroof relay.



**CENTRALIZED JUNCTION**

**MAIN FUSIBLE LINK (Connected directly to battery positive terminal)**

No.	Circuit	Housing colour	Rated capacity (A)
1	ABS circuit (hydraulic unit power source)	Yellow	60
2	—	—	—
3	Grow circuit	Black	80

〈Petrol-powered vehicles with ABS and Diesel-powered vehicles without ABS〉

〈Diesel-powered vehicles with ABS〉




**SUB-FUSIBLE LINK (Relay box in engine compartment)**

No.	Circuit	Housing colour	Rated capacity (A)
1	Junction block (Multi-purpose fuse ⑥, ⑭, ⑮, ⑯, ⑰, ⑱), A/C compressor circuit	Yellow	60
2	Sub-fusible link No. ①, ⑨, alternator circuit	Black	80
3	MPI circuit <Petrol>	Blue	20
	Starting circuit <Diesel>	Pink	30
4	Headlamp and tail lamp circuit	Pink	30
5	Radiator fan motor and condenser fan motor circuit	Pink	30 <Petrol>
		Green	40 <Diesel>
6	Ignition switch and alternator circuit	Pink	30
7	—	—	—
8	—	—	—
9	Power window circuit	Pink	30

NOTE

- (1) \*1: Petrol-powered vehicles
- (2) \*2: Diesel-powered vehicles




Sub-fusible link ①~⑨

16C0425

# 4A-88 CIRCUIT DIAGRAM — Tail Lamp, Position Lamp and Licence Plate Lamp

## TAIL LAMP, POSITION LAMP AND LICENCE PLATE LAMP Vehicles with SRS



**KX35-AC-Z0840-EC** Wire colour code  
 B:Black LG:Light green G:Green L:Blue W:White Y:Yellow SB:Sky blue  
 BR:Brown O:Orange GR:Gray R:Red P:Pink V:Violet