
TABLE OF CONTENTS

GENERAL INFORMATION

1

SPECIFICATIONS

2

**PERIODIC CHECKS AND
ADJUSTMENTS**

3

CHASSIS

4

ENGINE

5

COOLING SYSTEM

6

FUEL SYSTEM

7

ELECTRICAL SYSTEM

8

TROUBLESHOOTING

9

EAS20008

FEATURES

EAS30005


OUTLINE OF THE FI SYSTEM

The main function of a fuel supply system is to provide fuel to the combustion chamber at the optimum air-fuel ratio in accordance with the engine operating conditions and the atmospheric temperature. In the conventional carburetor system, the air-fuel ratio of the mixture that is supplied to the combustion chamber is created by the volume of the intake air and the fuel that is metered by the jet used in the respective carburetor.



Despite the same volume of intake air, the fuel volume requirement varies by the engine operating conditions, such as acceleration, deceleration, or operating under a heavy load. Carburetors that meter the fuel through the use of jets have been provided with various auxiliary devices, so that an optimum air-fuel ratio can be achieved to accommodate the constant changes in the operating conditions of the engine.

As the requirements for the engine to deliver more performance and cleaner exhaust gases increase, it becomes necessary to control the air-fuel ratio in a more precise and finely tuned manner. To accommodate this need, this model has adopted an electronically controlled fuel injection (FI) system, in place of the conventional carburetor system. This system can achieve an optimum air-fuel ratio required by the engine at all times by using a microprocessor that regulates the fuel injection volume according to the engine operating conditions detected by various sensors.

The adoption of the FI system has resulted in a highly precise fuel supply, improved engine response, better fuel economy, and reduced exhaust emissions.



- | | |
|---|-------------------------------|
| 1. Engine trouble warning light | 14. ECU (Engine Control Unit) |
| 2. ABS ECU | 15. Fuel injector |
| 3. Front wheel sensor | 16. Ignition coil |
| 4. VVA (variable valve actuator) solenoid | |
| 5. O ₂ sensor | |
| 6. Spark plug | |
| 7. Coolant temperature sensor | |
| 8. Crankshaft position sensor | |
| 9. Intake air temperature sensor | |
| 10. Intake air pressure sensor | |
| 11. Throttle position sensor | |
| 12. ISC (Idle Speed Control) unit | |
| 13. Battery | |



- | | |
|--------------------------|--------------------------|
| 1. Brake master cylinder | 8. Brake caliper |
| 2. Brake light switch | 9. Wheel sensor |
| 3. ABS motor | 10. ABS ECU |
| 4. Hydraulic pump | 11. ABS warning light |
| 5. Buffer chamber | 12. Brake fluid pressure |
| 6. Outlet solenoid valve | 13. Time |
| 7. Inlet solenoid valve | |

EAS30712

ABS WARNING LIGHT AND OPERATION

ABS warning light

- If the ABS warning light comes on while riding, stop the vehicle, and then turn the main switch to “OFF”, then back to “ON”. The ABS operation is normal if the ABS warning light goes off after the vehicle starts off.
- If the rear wheel is raced with the vehicle on a centerstand, the ABS warning light may flash or come on. If this occurs, turn the main switch to “OFF”, then back to “ON”. The ABS operation is normal if the ABS warning light goes off after the vehicle starts off.
- The ABS operation is normal if the ABS warning light flashes.
- Even if the ABS warning light remains on and does not go off, or if it comes on after riding, conventional braking performance of the vehicle is maintained.



























LUBRICATION POINTS AND LUBRICANT TYPES

EAS20018

LUBRICATION POINTS AND LUBRICANT TYPES


EAS30018

ENGINE

Lubrication point	Lubricant
Bearings	
O-rings	
O-rings (cam shaft)	
Oil seals	
Rocker arm stopper pin	
Cylinder head nut contact face and stud bolt thread	
Camshaft lobes	
Decompression cam	
Rocker arm shafts	
Valve stems and valve guide (intake and exhaust)	
Valve stem seals	
Valve stem ends (intake and exhaust)	
Rocker arm valve inner surface	
Camshaft sprocket	
Connecting rod big end face	
Piston pin outer surface	
Piston, piston ring, and cylinder inner surface	
Crank pin	
Cam chain sprocket inner surface	
Oil pump drive gear inner surface	
Oil pump shaft	
O-ring (fuel injector)	
Starter wheel and bearing	
Starter clutch idle gear inner surface	
Drive axle and bearings	
Crankshaft threads and conical spring washer outer mating surface	
Timing chain tensioner bolts	Yamaha bond No.1215®
Crankcase mating surfaces	Yamaha bond No.1215®
Crankcase bolt	Yamaha bond No.1215®

PERIODIC MAINTENANCE

2. Disassemble:
 - Secondary sheave assembly
Refer to "V-BELT AUTOMATIC TRANSMISSION" on page 5-34.
3. Lubricate:
 - Spring seat "1"
 - O-rings "2"
 - Oil seals "3"
 - Secondary sliding sheave "4"
 - Secondary fixed sheave "5"



4. Assemble:
 - Secondary sheave assembly
Refer to "V-BELT AUTOMATIC TRANSMISSION" on page 5-34.
5. Install:
 - Secondary sheave assembly
Refer to "V-BELT AUTOMATIC TRANSMISSION" on page 5-34.
 - Air filter case
Refer to "AIR FILTER CASE" on page 7-7.

EAS30658

CHECKING THE BRAKE LIGHT SWITCHES

1. Check:
 - Front brake light switch operation
 - Rear brake light switch operation
When operating the brake levers, confirm that the brake light comes on.

Faulty → Refer to "CHECKING THE SWITCHES" on page 8-95.

EAS30660

CHECKING AND LUBRICATING THE CABLES

The following procedure applies to all of the inner and outer cables.

EWA13270



Damaged outer cable may cause the cable to corrode and interfere with its movement. Replace damaged outer cable and inner cables as soon as possible.

1. Check:
 - Outer cable
Damage → Replace.
2. Check:
 - Cable operation
Rough movement → Lubricate.



TIP

Hold the cable end upright and pour a few drops of lubricant into the cable sheath or use a suitable lubricating device.

EAS30861

CHECKING THE THROTTLE GRIP OPERATION

1. Check:
 - Throttle cables
Damage/deterioration → Replace.
 - Throttle cable installation
Incorrect → Reinstall the throttle cables.
Refer to "HANDLEBAR" on page 4-69.
2. Check:
 - Throttle grip movement
Rough movement → Lubricate or replace the defective part(s).



TIP


With the engine stopped, turn the throttle grip slowly and release it. Make sure that the throttle grip turns smoothly and returns properly when released.

Repeat this check with the handlebar turned all the way to the left and right.

EAS20029

REAR WHEEL

Removing the rear wheel and brake disc




Order	Job/Parts to remove	Q'ty	Remarks
	Battery		Refer to "GENERAL CHASSIS (1)" on page 4-1.
	Front side covers		Refer to "GENERAL CHASSIS (2)" on page 4-4.
	Fuel tank cover		Refer to "GENERAL CHASSIS (3)" on page 4-7.
	Storage box		Refer to "GENERAL CHASSIS (4)" on page 4-9.
	Muffler		Refer to "ENGINE REMOVAL" on page 5-3.
	Radiator cover		Refer to "RADIATOR" on page 6-1.
	Air filter case		Refer to "AIR FILTER CASE" on page 7-7.
	Swingarm assembly		Refer to "REAR SHOCK ABSORBER ASSEMBLIES AND SWINGARM" on page 4-88.
1	Rear wheel	1	
2	Rear wheel sensor rotor	1	
3	Rear brake disc	1	

REAR BRAKE

TIP

Put the end of the brake hose into a container and pump out the brake fluid carefully.




EAS30187

DISASSEMBLING THE REAR BRAKE CALIPER

1. Remove:

- Brake caliper piston “1”
- Brake caliper piston dust seal “2”
- Brake caliper piston seal “3”




a. Blow compressed air into the brake hose joint opening “a” to force out the piston from the brake caliper.

EWA13550

WARNING

- Cover the brake caliper piston with a rag. Be careful not to get injured when the piston is expelled from the brake caliper.
- Never try to pry out the brake caliper piston.



b. Remove the brake caliper piston dust seal and brake caliper piston seal.



EAS30188

CHECKING THE REAR BRAKE CALIPER

Recommended brake component replacement schedule	
Brake pads	If necessary
Piston seal	Every two years
Piston dust seal	Every two years
Brake hose	Every four years
Brake fluid	Every two years and whenever the brake is disassembled


1. Check:

- Brake caliper piston “1”
Rust/scratches/wear → Replace the brake caliper piston.
- Brake caliper cylinder “2”
Scratches/wear → Replace the brake caliper assembly.
- Brake caliper body “3”
Cracks/damage → Replace the brake caliper assembly.
- Brake fluid delivery passages (brake caliper body)
Obstruction → Blow out with compressed air.

EWA17070

WARNING

Whenever a brake caliper is disassembled, replace the brake caliper piston dust seal and brake caliper piston seal.



2. Check:


- Brake caliper bracket
Cracks/damage → Replace.

REAR SHOCK ABSORBER ASSEMBLIES AND SWINGARM

EAS20189

REAR SHOCK ABSORBER ASSEMBLIES AND SWINGARM

Removing the rear shock absorber assemblies and swingarm




Order	Job/Parts to remove	Q'ty	Remarks
	Battery		Refer to "GENERAL CHASSIS (1)" on page 4-1.
	Front side covers		Refer to "GENERAL CHASSIS (2)" on page 4-4.
	Fuel tank cover		Refer to "GENERAL CHASSIS (3)" on page 4-7.
	Storage box		Refer to "GENERAL CHASSIS (4)" on page 4-9.
	Muffler		Refer to "ENGINE REMOVAL" on page 5-3.
	Radiator cover		Refer to "RADIATOR" on page 6-1.
	Air filter case		Refer to "AIR FILTER CASE" on page 7-7.
1	Rear wheel axle nut	1	
2	Rear brake hose holder (rear side)	1	
3	Rear wheel sensor	1	

CYLINDER AND PISTON

EAS20046

CYLINDER AND PISTON

Removing the cylinder and piston




Order	Job/Parts to remove	Q'ty	Remarks
	Cylinder head		Refer to "CYLINDER HEAD" on page 5-9.
1	Timing chain guide (exhaust side)	1	
2	Cylinder	1	
3	Cylinder gasket	1	
4	Dowel pin	2	
5	Piston pin clip	2	
6	Piston pin	1	
7	Piston	1	
8	Top ring	1	
9	2nd ring	1	
10	Oil ring	1	
11	Coolant drain bolt (cylinder side)	1	

EAS20067

FUEL TANK

Removing the fuel tank



Order	Job/Parts to remove	Q'ty	Remarks
	Front side covers		Refer to "GENERAL CHASSIS (2)" on page 4-4.
	Fuel tank cover		Refer to "GENERAL CHASSIS (3)" on page 4-7.
	Center lower cover		Refer to "GENERAL CHASSIS (5)" on page 4-12.
1	Fuel tank cap	1	
2	Fuel tank overflow tray	1	
3	Fuel tank overflow hose	1	
4	Fuel sender coupler	1	Disconnect.
5	Fuel pump coupler	1	Disconnect.
6	Fuel hose	1	Disconnect.
7	Fuel tank	1	
8	Fuel pump bracket	1	
9	Fuel pump	1	
10	Fuel pump gasket	1	
11	Fuel filter	1	

SIGNALING SYSTEM

4. Check the entire signaling system wiring.
Refer to "CIRCUIT DIAGRAM" on page 8-19.

NG →

Properly connect or replace the wire harness.

OK ↓

Replace the meter assembly.

The coolant temperature warning light fails to come on.

1. Check the coolant temperature sensor.
Refer to "CHECKING THE COOLANT TEMPERATURE SENSOR" on page 8-108.

NG →

Replace the coolant temperature sensor.

OK ↓

2. Check the entire signaling system wiring.
Refer to "CIRCUIT DIAGRAM" on page 8-19.

NG →

Properly connect or replace the wire harness.

OK ↓

Replace the meter assembly or ECU.
Refer to "REPLACING THE ECU (engine control unit)" on page 8-99.

The fuel meter, fuel level warning light, or both fails to come on.

1. Check the fuel sender.
Refer to "CHECKING THE FUEL SENDER" on page 8-107.

NG →

Replace the fuel pump.

OK ↓

2. Check the entire signaling system wiring.
Refer to "CIRCUIT DIAGRAM" on page 8-19.

NG →

Properly connect or replace the wire harness.

OK ↓

Replace the meter assembly.

The speedometer, V-belt replacement indicator, engine oil change indicator, instantaneous fuel consumption meter fails to operate.

1. Check the front wheel sensor.
Refer to "MAINTENANCE OF THE FRONT WHEEL SENSOR AND SENSOR ROTOR" on page 4-28.

NG →

Replace the front wheel sensor.

OK ↓

FUEL INJECTION SYSTEM

Fault code No.		13	
Item		Intake air pressure sensor: open or short circuit detected.	
5	Defective intake air pressure sensor.	<p>Execute the diagnostic mode. (Code No. 03)</p> <p>When engine is stopped: Atmospheric pressure at the current altitude and weather conditions is indicated.</p> <p>At sea level: Approx. 101 kPa (757.6 mmHg, 29.8 inHg) 1000 m (3300 ft) above sea level: Approx. 90 kPa (675.1 mmHg, 26.6 inHg) 2000 m (6700 ft) above sea level: Approx. 80 kPa (600.0 mmHg, 23.6 inHg) 3000 m (9800 ft) above sea level: Approx. 70 kPa (525.0 mmHg, 20.7 inHg)</p> <p>When engine is cranking: Make sure that the indication value changes. The value does not change when engine is cranking. → Replace the throttle body if defective. Refer to "THROTTLE BODY" on page 7-10.</p>	<p>Turn the main switch to "ON". Fault code number is not displayed → Service is finished. Fault code number is displayed → Go to item 6.</p>
6	Malfunction in ECU.	<p>Replace the ECU. Refer to "REPLACING THE ECU (engine control unit)" on page 8-99.</p>	

Fault code No. 14

ECA20500

NOTICE

Do not remove the throttle body sensor assembly from the throttle body.

TIP

If fault code numbers "13" and "14" are both indicated, take the actions specified for fault code number "13" first.


Fault code No.		14	
Item		Intake air pressure sensor: system malfunction (clogged hole or detached).	
Fail-safe system		Able to start engine	
		Able to drive vehicle	
Diagnostic code No.		03	
Tool display		Displays the intake air pressure.	
Procedure		Operate the throttle while pushing the start switch "⊗". (If the display value changes, the performance is OK.)	
Item	Probable cause of malfunction and check	Maintenance job	Confirmation of service completion

EAS20081

FUEL PUMP SYSTEM

EAS30513

CIRCUIT DIAGRAM



ABS (ANTI-LOCK BRAKE SYSTEM)

Fault code No.		17 45
Item		Front wheel sensor (missing pulses)
Symptom		Front wheel sensor signal is not received properly. (Missing pulses are detected in the signal while the vehicle is traveling.)
Order	Item/components and probable cause	Check or maintenance job
1	Foreign material adhered around the front wheel sensor	Check the surface of the sensor rotor and wheel sensor for foreign material, such as metal particles. Clean the sensor rotor and wheel sensor if necessary.
2	Incorrect installation of the front wheel	Check the components for looseness, distortion, and bends. Refer to "CHECKING THE FRONT WHEEL" on page 4-27.
3	Defective sensor rotor or incorrect installation of the rotor	Check the surface of the sensor rotor for damage. Replace the sensor rotor if there is visible damage. Refer to "MAINTENANCE OF THE FRONT WHEEL SENSOR AND SENSOR ROTOR" on page 4-28.
4	Defective front wheel sensor or incorrect installation of the sensor	Check the wheel sensor for damage and the installed condition of the sensor. Repair or replace the wheel sensor if necessary. Refer to "MAINTENANCE OF THE FRONT WHEEL SENSOR AND SENSOR ROTOR" on page 4-28.

Fault code No. 18, 46

TIP

If pulse gaps are detected when the vehicle is traveling at a speed of 30 km/h (19 mi/h) or more, fault code No. 18 will be recorded. If the vehicle is traveling at a speed of 29 km/h (18 mi/h) or less, fault code No. 46 will be recorded first and fault code No. 18 will be recorded if the condition continues.

Fault code No.		18 46
Item		Rear wheel sensor (missing pulses)
Symptom		Rear wheel sensor signal is not received properly. (Missing pulses are detected in the signal while the vehicle is traveling.)
Order	Item/components and probable cause	Check or maintenance job
1	Foreign material adhered around the rear wheel sensor	Check the surface of the sensor rotor and wheel sensor for foreign material, such as metal particles. Clean the sensor rotor and wheel sensor if necessary.
2	Incorrect installation of the rear wheel	Check the components for looseness, distortion, and bends. Refer to "CHECKING THE REAR WHEEL" on page 4-34.
3	Defective sensor rotor or incorrect installation of the rotor	Check the surface of the sensor rotor for damage. Replace the sensor rotor if there is visible damage. Refer to "MAINTENANCE OF THE REAR WHEEL SENSOR ROTOR" on page 4-34.
4	Defective rear wheel sensor or incorrect installation of the sensor	Check the wheel sensor for damage and the installed condition of the sensor. Repair or replace the wheel sensor if necessary. Refer to "MAINTENANCE OF THE REAR WHEEL SENSOR ROTOR" on page 4-34.

