

# WIRING DIAGRAMS

## CONTENTS

	page		page
8W-01 GENERAL INFORMATION—WIRING DIAGRAMS .....	8W-01-1	8W-44 INTERIOR LIGHTING .....	8W-44-1
8W-10 FUSE BLOCK .....	8W-10-1	8W-47 AUDIO SYSTEM .....	8W-47-1
8W-11 POWER DISTRIBUTION .....	8W-11-1	8W-49 OVERHEAD CONSOLE .....	8W-49-1
8W-15 GROUND DISTRIBUTION .....	8W-15-1	8W-50 FRONT LIGHTING .....	8W-50-1
8W-20 CHARGING SYSTEM .....	8W-20-1	8W-51 REAR LIGHTING .....	8W-51-1
8W-21 STARTING SYSTEM .....	8W-21-1	8W-52 TURN SIGNALS .....	8W-52-1
8W-30 FUEL/IGNITION .....	8W-30-1	8W-53 WIPERS .....	8W-53-1
8W-31 TRANSMISSION CONTROLS ....	8W-31-1	8W-54 TRAILER TOW .....	8W-54-1
8W-32 ANTI-LOCK BRAKES .....	8W-32-1	8W-60 POWER WINDOWS .....	8W-60-1
8W-33 VEHICLE SPEED CONTROL ....	8W-33-1	8W-61 POWER DOOR LOCKS .....	8W-61-1
8W-40 INSTRUMENT CLUSTER .....	8W-40-1	8W-62 POWER MIRRORS .....	8W-62-1
8W-41 HORN/CIGAR LIGHTER .....	8W-41-1	8W-70 SPLICE INFORMATION .....	8W-70-1
8W-42 AIR CONDITIONING/HEATER ....	8W-42-1	8W-80 CONNECTOR PIN OUTS .....	8W-80-1
8W-43 AIRBAG SYSTEM .....	8W-43-1	8W-90 CONNECTOR LOCATIONS .....	8W-90-1
		8W-95 SPLICE LOCATIONS .....	8W-95-1

### HOW TO USE THIS GROUP

The purpose of this group is to show the electrical circuits in a clear, simple fashion and to make troubleshooting easier. Components that work together are shown together. All electrical components used in a specific system are shown on one diagram. The feed for a system is shown at the top of the page. All wires, connectors, splices, and components are shown in the flow of current to the bottom of the page. Wiring which is not part of the circuit represented is referenced to another page/section, where the complete circuit is shown. In addition, all switches, components, and modules are shown in the **at rest position with the doors closed and the key removed from the ignition.**

If a component is part of several different circuits, it is shown in the diagram for each. For example, the headlamp switch is the main part of the exterior lighting, but it also affects the interior lighting and the chime warning system.

**It is important to realize that no attempt is made on the diagrams to represent components and wiring as they appear on the vehicle. For example, a short piece of wire is treated the same as a long one. In addition, switches and other components are shown as simply as possible, with regard to function only.**

Both the standard cab and club cab models are shown in this section. If there is a difference in sys-

tems or components between the models, an identifier is placed next to the component.

### SECTION IDENTIFICATION

Sections in Group 8W are organized by sub-systems. The sections contain circuit operation descriptions, helpful information, and system diagrams. The intention is to organize information by system, consistently from year to year.

### CONNECTOR LOCATIONS


Section 8W-90 contains Connector Location illustrations. The illustrations contain the connector number and component identification. Connector Location charts in Section 8W-90 reference the illustration number for components and connectors.

Section 8W-80 shows each connector and the circuits involved with that connector. The connectors are identified using the number on the Diagram pages.

### SPLICE LOCATIONS

Splice Location charts in Section 8W-70 show the entire splice, and provide references to other sections the splice serves.


Section 8W-95 contains illustrations that show the general location of the splices in each harness. The illustrations show the splice by number, and provide a written location.



**Fig. 8 Testing for Voltage**

#### TESTING FOR CONTINUITY

- (1) Remove the fuse for the circuit being checked or, disconnect the battery.
- (2) Connect one lead of the ohmmeter to one side of the circuit being tested (Fig. 9).
- (3) Connect the other lead to the other end of the circuit being tested. Low or no resistance means good continuity.



**Fig. 9 Testing for Continuity**

#### TESTING FOR A SHORT TO GROUND


- (1) Remove the fuse and disconnect all items involved with the fuse.
- (2) Connect a test light or a voltmeter across the terminals of the fuse.
- (3) Starting at the fuse block, wiggle the wiring harness about six to eight inches apart and watch the voltmeter/test lamp.
- (4) If the voltmeter registers voltage or the test lamp glows, there is a short to ground in that general area of the wiring harness.

#### TESTING FOR A SHORT TO GROUND ON FUSES POWERING SEVERAL LOADS

- (1) Refer to the wiring diagrams and disconnect or isolate all items on the fused circuit.
- (2) Replace the blown fuse.
- (3) Supply power to the fuse by turning ON the ignition switch or re-connecting the battery.
- (4) Start connecting the items in the fuse circuit one at a time. When the fuse blows the circuit with the short to ground has been isolated.

#### TESTING FOR A VOLTAGE DROP

- (1) Connect the positive lead of the voltmeter to the side of the circuit closest to the battery (Fig. 10).
- (2) Connect the other lead of the voltmeter to the other side of the switch or component.
- (3) Operate the item.
- (4) The voltmeter will show the difference in voltage between the two points.




**Fig. 10 Testing for Voltage Drop**

#### TROUBLESHOOTING WIRING PROBLEMS

When troubleshooting wiring problems there are six steps which can aid in the procedure. The steps

# 8W-10-3 FUSE/FUSE BLOCK




# 8W-11-6 POWER DISTRIBUTION


**BATTERY  
POSITIVE  
TERMINAL**

**POWER  
DISTRIBUTION  
CENTER**

▶ **HOT AT ALL TIMES** ◀









# 8W-21-5 STARTING SYSTEM 3.9L & 5.2L ENGINES





# 8W-42-8 AIR CONDITIONING-HEATER 3.9L & 5.2L ENGINES

**BATTERY  
POSITIVE  
TERMINAL**



# FRONT LIGHTING

## INDEX

	page		page
Daytime Running Lamp (DRL) Module .....	2	Headlamps .....	1
Diagram Index .....	2	Off-Road Lamps .....	2
Fog Lamps .....	2	Parking Lamps .....	1

## HEADLAMPS

The headlamp switch has three positions: ON, PARK (parking lamps) and OFF. Two circuits, L2 and L20, connect the headlamp switch to the headlamp dimmer/optical horn switch located in the multi-function switch. The multi-function switch feeds the low and high beams of the headlamps.

### HEADLAMP SWITCH IN OFF OR PARKING LAMP POSITION

Circuit A3 from fuse G in the Power Distribution Center (PDC) supplies battery voltage to the headlamp switch. The headlamp switch has an internal circuit breaker that connects circuit A3 to circuit L20.

In the OFF and PARK positions, the headlamp switch feeds circuit L20 which connects to the multi-function switch. Circuit L20 powers the high-beam circuit when the operator flashes the headlamps with the turn signal stalk of the multi-function switch. The multi-function switch connects circuit L20 to circuit L3. Circuit L3 feeds the high beam of the headlamps.

### HEADLAMP SWITCH IN ON POSITION

When the headlamp switch is in the ON position, the A3 circuit from the Power Distribution Center (PDC) connects to circuit L2. Circuit L2 connects to the multi-function switch and feeds the L4 circuit. The L4 circuit powers the low beam of the headlamps.

When the operator selects high beam operation, with the turn signal stalk of the multi-function switch, circuit L2 connects to the L3 circuit. Circuit L3 powers high beam operation.

### HEADLAMP GROUND

Although circuit Z1 provides ground for both the right and left headlamps, it has different termination points for each. For the right headlamp, the Z1 circuit terminates at the dash panel, near the blower motor resistor block. For the left headlamp, the Z1 circuit terminates at the left fender side shield.

### HELPFUL INFORMATION

- Check fuse G in the PDC.

- The headlamp switch has an internal circuit breaker.
- For the left front parking lamp, turn signal, side marker lamp, and left headlamp, the Z1 circuit grounding point is on the dash panel, near the blower motor resistor block.
- For the right front parking lamp, turn signal, side marker lamp, and right headlamp, the Z1 circuit grounding point is on the right fender side shield.
- For the left and rear parking lamps, turn signals, side marker lamps, and the rear license plate lamp, the Z1 circuit grounding point is the left inner fender panel. The Z1 circuit also provides ground for the fuel level sensor.

## PARKING LAMPS

Circuit A3 in the Power Distribution Center (PDC) connects to a bus bar in the fuse block. One of the four circuits powered by the bus bar is circuit F33. Circuit F33 connects to the headlamp switch. Fuse G in the PDC protects the A3 circuit. Fuse 8 in the fuse block protects circuit F33.

The headlamp switch has three positions: ON, PARK (parking lamps) and OFF, plus a dimmer switch. When the headlamp switch is in the PARK or ON position, the switch connects circuit F33 to circuit L7. From the headlamp switch, circuit L7 branches to power the front parking lamps and rear tail lamps, side marker lamps, and rear license plate lamps.

### GROUND CIRCUIT


Circuit Z1 provides a ground for the parking lamps, tail lamps, and rear license plate lamps. The grounding point for circuit Z1 is the dash panel, left of the brake master cylinder.

### HELPFUL INFORMATION

- If the vehicle is equipped with factory installed fog lamps, circuit L7 splices to feed the park lamp relay.
- Check fuse G in PDC.
- Check fuse 8 in the fuse block.
- Circuit L7 also feeds the radio, if equipped.
- When the headlamp switch is in the PARK or ON position, the dimmer circuit, F33, also connects to circuit E1. Circuit E1 feeds circuit E2, which powers




# 8W-52-2 TURN SIGNALS






# 8W-70-7 SPLICE INFORMATION

1995 AN Dakota  
 Publication No. 81-370-5110  
 TSB 08-55-94 October 14, 1994




# 8W-80-7 CONNECTOR PIN-OUTS

## C117




CAV	CIRCUIT	FUNCTION
1	B120 12BR/WT	ABS POWER RELAY OUTPUT
2	B18 20VT/LG	RIGHT FRONT RESET SWITCH SENSE
3	B248 16DG/WT	RIGHT FRONT DUMP VALVE CONTROL
4	B249 18WT/TN	RIGHT FRONT ISOLATION VALVE CONTROL
5	B60 12LB/BK	PUMP MOTOR CONTROL
6	B120 12BR/WT	ABS POWER RELAY OUTPUT
7	B245 18WT/LG	LEFT FRONT ISOLATION VALVE CONTROL
8	B243 16DG/BK	LEFT FRONT DUMP VALVE CONTROL
9	B5 20VT/RD	LEFT FRONT RESET SWITCH SENSE
10	B120 12BR/WT	ABS POWER RELAY OUTPUT

## C118



CAV	CIRCUIT	FUNCTION
* 1	B113 20RD/VT	REAR WHEEL SPEED SENSOR (+)
* 2	B7 20WT	RIGHT FRONT WHEEL SPEED SENSOR (+)
* 3	B9 20RD	LEFT FRONT WHEEL SPEED SENSOR (+)
4	B116 20GY	ABS POWER RELAY CONTROL
5	B5 20VT/RD	LEFT FRONT RESET SWITCH SENSE
6	—	—
7	A20 18RD/DB	FUSED IGNITION SWITCH OUTPUT (RUN)
8	G107 20BK/GY	4WD SENSE
9	V40 20WT/PK	BRAKE SWITCH SENSE
10	D12 20OR	SCI TRANSMIT
11	D11 20WT/LB	SCI RECEIVE
12	A20 18RD/DB	FUSED IGNITION SWITCH OUTPUT (RUN)
13	B47 20RD/LB	ABS WARNING LAMP RELAY CONTROL
* 14	B114 20WT/VT	REAR WHEEL SPEED SENSOR (-)
* 15	B6 20WT/DB	RIGHT FRONT WHEEL SPEED SENSOR (-)
* 16	B8 20RD/GY	LEFT FRONT WHEEL SPEED SENSOR (-)
17	—	—
18	B18 20VT/LG	RIGHT FRONT RESET SWITCH SENSE
19	B19 20LB	REAR RESET SWITCH SENSE
20	Z7 18BK/RD	GROUND
21	—	—
22	—	—
23	—	—
24	G19 20LG/RD	ABS WARNING LAMP DRIVER
25	G9 20GY/BK	RED BRAKE WARNING LAMP DRIVER
26	B254 16DG/OR	REAR DUMP VALVE CONTROL
27	—	—
28	B252 18BR/TN	REAR ISOLATION VALVE CONTROL
29	—	—
30	B248 16DG/WT	RIGHT FRONT DUMP VALVE CONTROL
31	—	—
32	—	—
33	B249 18WT/TN	RIGHT FRONT ISOLATION VALVE CONTROL
34	B120 14BR/WT	ABS POWER RELAY OUTPUT
35	B243 16DG/BK	LEFT FRONT DUMP VALVE CONTROL
36	—	—
37	B245 18WT/LG	LEFT FRONT ISOLATION VALVE CONTROL

## C119




CAV	CIRCUIT	FUNCTION
1	Z8 12BK/PK	GROUND
2	B60 12LB/BK	PUMP MOTOR CONTROL

\* — INDICATES TWISTED PAIRS  
(B6 & B7, B8 & B9, B113 & B114)

# 8W-80-22 CONNECTOR PIN-OUTS


## C214



AIRBAG  
CONTROL  
MODULE

CAV	CIRCUIT	FUNCTION
1	R47 18DB/LB	LEFT IMPACT SENSOR LINE 1
2	R49 18LB	LEFT IMPACT SENSOR LINE 2
3	D2 18WT/BK	CCD BUS (-)
4	D1 18VT/BR	CCD BUS (+)
5	F20 18WT	FUSED IGN SWITCH OUTPUT (RUN)
6	F14 18LG/YL	FUSED IGN SWITCH OUTPUT (RUN/START)
7	R41 18BK/TN	AIRBAG WARNING LAMP DRIVER
8	—	—
9	—	—
10	—	—
11	Z6 18BK/PK	GROUND
12	R48 18TN	RIGHT IMPACT SENSOR LINE 2
13	R46 18BR/LB	RIGHT IMPACT SENSOR LINE 1


## C215



CIGAR  
LIGHTER  
LAMP

CAV	CIRCUIT	FUNCTION
1	Z1 20BK	GROUND
2	E2 200R	PANEL LAMPS DRIVER


## C216



HVAC SWITCH

CAV	CIRCUIT	FUNCTION
1	E2 200R	PANEL LAMPS DRIVER
2	C21 20DB/OR	A/C SWITCH SENSE
3	C4 16TN	LOW BLOWER MOTOR DRIVER
4	C5 16LG	M1 BLOWER MOTOR DRIVER
5	C6 14LB	M2 BLOWER MOTOR DRIVER
6	C7 12GY	HIGH BLOWER MOTOR DRIVER
7	Z1 12BK	GROUND


## C217



RADIO CHOKE  
RELAY

CAV	CIRCUIT	FUNCTION
1	Z1 20BK	GROUND
2	X60 20DG/RD	RADIO 12-VOLT OUTPUT
3	X13 16BK/RD	AMPLIFIED SPEAKER (+)
4	X1 16RD/LG	FUSED B(+)

## C218




STOP LAMP  
SWITCH

CAV	CIRCUIT	FUNCTION
1	V32 20YL/RD	SPEED CONTROL ON/OFF SWITCH SENSE
2	L50 18WT/TN	STOP LAMP SWITCH OUTPUT
3	V40 18WT/PK	STOP LAMP SWITCH SENSE
3	V40 18WT/PK	STOP LAMP SWITCH SENSE
4	Z1 20BK	GROUND
5	F32 18PK/DB	FUSED B(+)
5	F32 20PK/DB	FUSED B(+)
6	V30 22DB/RD	SPEED CONTROL ON/OFF SWITCH OUTPUT


# 8W-80-34 CONNECTOR PIN-OUTS

## C335




CAV	CIRCUIT	FUNCTION
1	Z1 18BK	GROUND
2	F39 16PK/LG	FUSED B(+)
3	L31 16DB/YL	OFF-ROAD LAMP SWITCH OUTPUT

## C336



CAV	CIRCUIT	FUNCTION
1	L39 16LB	HIGH BEAM RELAY OUTPUT
2	L35 18BR/WT	PARK LAMP RELAY CONTROL
3	Z1 18BK	GROUND

## C337




CAV	CIRCUIT	FUNCTION
1	L7 18BK/YL	PARK LAMP SWITCH OUTPUT
2	L35 18BR/WT	PARK LAMP RELAY CONTROL
3	F39 16PK/LG	FUSED B(+)
4	—	—
5	L36 16LG	PARK LAMP RELAY OUTPUT

## C338




CAV	CIRCUIT	FUNCTION
1	L3 16RD/OR	DIMMER SWITCH HIGH BEAM OUTPUT
2	Z1 18BK	GROUND
3	L36 16LG	PARK LAMP RELAY OUTPUT
4	L39 18LB	HIGH BEAM RELAY OUTPUT
5	—	—



J958W-42

**Fig. 3 Engine Compartment Wiring Connectors—Left Side**



J958W-43

**Fig. 4 Starter Motor Wiring Connectors**