

2000 SPORTAGE

ELECTRICAL TROUBLESHOOTING AND VACUUM HOSE ROUTING MANUAL

CONTENTS

Air Bag	47
Air Conditioner:	
Blower Controls.....	60
Compressor Controls	63
Audio System	150
Anti-Lock Braking System.....	44
A/T Gear Selection Indicator	89
A/T Shift Interlock System	138
Automatic Transmission.....	39
Back-up Lights	112
Brake Warning System.....	71
Cargo Light.....	114
Charging System	30-1
Cigarette Lighter.....	155
Cruise Control	34
Digital Clock	154
Dome Light.....	114
Electronic Time and Alarm	
Control Module.....	70
Engine Coolant Temperature	
Gauge.....	81-4
Exterior Lights.....	110
Fasten Belts Indicator.....	73
Front Wiper/Washer.....	91
Fuel Gauge	81-4
Fuse Box Details	11
Fuse/Relay Information.....	6
Gauge Cluster.....	81-4
Ground Distribution	14
Hazard Lights	110
Headlights.....	100
Heater (Blower Controls)	60
Horn.....	40
How To Use This Manual	2
Connector Classification	2-13
General Service	2-14
Troubleshooting.....	2-9
Ignition Key Warning, Fasten Belts Indicator, and Light On Warning	73
Indicators	81
Interior Lights.....	114
Interior Lights Dimming	117
License Light.....	110-3

CONTENTS (Continued)

Light On Warning.....	73
Light Switch Details.....	12
Oil Pressure Warning.....	72
Park Lights	110-3
Power Distribution.....	10
Power Door Locks.....	130
Power Mirrors	141
Power Windows.....	120
Rear Window Defroster.....	61
Rear Wiper/Washer.....	92
Sequential Multiport Fuel Injection (2.0L DOHC).....	25
Speedometer.....	81-4
Starting System.....	30
Stoplights.....	110-2
Tachometer	81-4
Tail Lights.....	110-3
Theft Deterrent System	133
Turn Lights	110
Vacuum Hose Routing.....	160
Vehicle Speed Sensor	33

HOW TO USE THIS MANUAL

Power Distribution


The Power Distribution schematic shows the wiring from the Battery and Generator to the Starter Solenoid, Fuse Box, Ignition Switch and Light Switch. The first component after a fuse is also shown.

The Power Distribution schematic refers to Fuse Box Details and Light Switch Details schematics. By using these three (3) schematics, power distribution wiring can be

followed from the Battery and Generator to the first component after a Maxi Fuse, Fuse and Light Switch. The ability to follow the power distribution wiring to the first component in each circuit is extremely helpful in locating short circuits which cause fuses to open.

The fuses in the sample schematic below are "Hot At All Times," since Battery voltage is always applied to them.

POWER DISTRIBUTION



KIA163A-2-5-S

FIVE-STEP TROUBLESHOOTING

1. Verify the Problem

Turn on all the components in the problem circuit to check the accuracy of the customer complaint. Note the symptoms. Do not begin disassembly or testing until you have narrowed down the problem area.

2. Analyze the Circuit Schematic

Look up the schematic for the problem circuit. Determine how the circuit is supposed to work by tracing the current paths from the power source through the circuit components to ground. Also, trace circuits that share wiring with the problem circuit. The names of circuits or components that share the same fuse, ground, or switch, and so on, are referred to in each circuit schematic. Try to operate any shared circuits you didn't check in step 1. If the shared circuits work, the shared wiring is OK, and the cause must be in the wiring used only by the problem circuit. If several circuits fail at the same time, the fuse or ground is a likely cause.

Based on the symptoms and your understanding of the circuit's operation, identify one or more possible causes.

3. Find the Cause

Make circuit tests to check the diagnosis you made in step 2. Keep in mind that a logical, simple procedure is the key to efficient troubleshooting. Test for the most likely cause of failure first. Try to make tests at points that are easily accessible.

4. Repair the Problem

Once the specific problem is identified, make the repair. Be sure to use proper tools and safe procedures.

5. Check the Repair

Turn on all components in the repaired circuit in all modes to make sure you've fixed the entire problem. If the problem was an open fuse, be sure to test all of the circuits on that fuse. Make sure no new problems turn up and the original problem does not recur.

TEST EQUIPMENT

NOTICE

Most circuits include solid-state devices. Test the voltages in these circuits only with a 10-megaohm or higher impedance digital multimeter. Never use a test light or analog meter on circuits that contain solid-state devices. Damage to the devices may result.


Test Light and DVOM

On circuits without solid-state devices, use a test light to check for voltage. A test light is made up of a 12-volt bulb with a pair of leads attached. After grounding one lead, touch the other lead to various points along the circuit where voltage should be present. The bulb will go on if there is voltage at the point being tested. If you need to know how much voltage is present, use a digital volt/ohmmeter (DVOM).

Self-Powered Test Light and DVOM

Use a self-powered test light to check for continuity. This tool is made up of a light bulb, battery, and two leads. To test it, touch the leads together; the light should go on.

Use a self-powered test light only on an unpowered circuit. First, disconnect the battery, or remove the fuse that feeds the circuit you are working on. Select two points in the circuit between which you want to check continuity. Connect one lead of the self-powered test light to each point. If there is continuity, the test light's circuit will be completed, and the light will go on.



REPLACEMENT OF TERMINALS


Use the appropriate tools to remove the terminal, as shown in the illustrations.

*NOTICE

When installing a terminal, be sure to press it in until it locks securely.


Female Type

Insert a push-tool, or thin piece of metal such as a small screwdriver, from the terminal side of the connector, and then, with the locking tabs pressed down, pull the terminal out from the rear side of the connector.




Male Type


Refer to female type procedure.



FUSE BOX DETAILS




FUSE/RELAY INFORMATION



Engine Compartment Fuse/Relay Box

Fuse	Color	Protected Circuit
FUEL INJ (30A)	BLK/RED	Fuel injection system
BTN (60A)	BLK/YEL	Power distribution
MAIN (80A)	BLK	For protection of all circuits
P/WIN (40A)	BLK/BLU	Power windows
IGN (40A)	BLK	Ignition
HEAD (20A)	GRN	Headlights
MAIN (15A)	RED	Fuel pump, EGI relays
ABS (30A)	PNK	ABS power
ADD (30A)	BLU	A/C relay



Passenger Compartment Fuse Box


Fuse	Color	Protected Circuit
SRARTER (10A)	WHT	Starter
ROOM (10A)	LT GRN	Interior lights
HAZARD (15A)	RED	Hazard lights
HEATER (30A)	BLU	Blower
WIPER (15A)	RED/BLK	Wiper
REAR WIPER (10A)	YEL	Air Conditioner, rear wiper
METER (10A)	GRN/RED	Instrument panel, automatic transmission
ENG (15A)	BLK/WHT	Data link connector
TAIL (10A)	BLK/BLU	Tail light, parking light
D/LOCK(30A)	GRN/BLU	Door locks
STOP (15A)	YEL	Brake switch, horn relay
P/W (30A)	WHT/GRN	Power window relay
DEF (20A)	LT GRN	Rear defroster
TURN (10A)	BLU	Light assembly, cruise control switch
RADIO (10A)	BLK/YEL	Radio, clock
ECU (10A)	GRN	Engine control module
FRONT O ₂ SEN-SOR (10A)	GRN/BLU	Oxygen sensor
CIGAR (15A)	WHT/RED	Cigarette lighter, power mirror
FUEL PUMP (10A)	GRN/YEL	Fuel pump, data link connector
REAR O ₂ SEN-SOR (10A)	LT GRN/RED	Oxygen sensor
AIR BAG (10A)	WHT/GRN	Air bag
MEMORY (15A)	LT GRN/BLK	Interior lights
HORN (10A)	YEL/RED	


COMPONENT LOCATION INDEX

(Refer to Section 201 for photographs.)


Component	Location	Photo No.
ABS Control Unit	Left side of I/P	26
A/C Cut Relay	Behind right side of I/P, near audio system	60
Air Bag Diagnostic Unit	Inside front of center console	92
A/T Shift Interlock Control Unit	Below right side of I/P	63
Back-Up Light Switch	Right side of transmission	36
Blower Motor	Behind right side of I/P	60
Brake Pedal Switch	Under I/P, below steering column	49
Cargo Light	Right side panel, rear of cargo area	111
Center Switch	Behind center of I/P	114
Cigarette Lighter	Lower left side of center console	117
Cruise Control Unit	At right kick panel	65
Cruise Control Main Switch	Lower far left side of I/P	96
Data Link Connector (DLC)	Left rear of engine compartment	27
Dome Light	Center of headliner	112
Electronic Time and Alarm Control Module	Right side of I/P, above globe box	67
Engine Control Module	Behind lower right side of I/P, under floor carpet	62
Flasher Module	In relay box, behind left side of I/P	50
Front Heated Oxygen Sensor	Left rear of engine compartment	24
Front washer Motor	Right side of engine compartment	5
Front Wiper Motor	Right rear side of engine compartment	18
Fuel Tank Unit	Underneath of rear seat, top of fuel tank	83
Horn Relay	In relay box, behind left side of I/P	50
Key-In Ignition Switch	Behind left side of I/P, below steering column	51
Key Lock Solenoid	Top of steering column	53
Power Window Relay	In relay box, behind left side of I/P	50
Power Mirror Switch	Left side of steering column, below I/P	116
Radio/Cassette Player	Center of console, below I/P	113
Rear Heated Oxygen Sensor	Under side of vehicle, behind three-way catalytic converter	19
Rear washer Motor	Right rear of vehicle, behind combination light	86
Rear Window Defroster Relay	In relay box, behind left side of I/P	50
Rear Wiper Motor	Behind trim on tailgate	87
Tail Door Lock	Rear hatch (Inside)	125
Transmission Control Module	Below left side of I/P	50
Transmission Range Switch	Right side of transmission	35
Vehicle Speed Sensor	Left rear side of engine compartment	38
C159	Left rear of engine compartment	26
C201	Right side of fender	110
C205	Behind right center of I/P	57
C209	Behind right center of I/P	58
C213	Behind right side of I/P	59
C219	In steering column, internal to ignition switch	53
C224	Top of steering column	58
C225	Top of steering column	53
C227	Top of steering column	53
C230	Above left kick panel	43
C231	Above left kick panel	43
C234	Left kick panel	44








FRONT WIPER/WASHER





Power Mirror Switch

1. Remove the power mirror switch.
2. Check for continuity between the power mirror switch terminals using an ohmmeter.

Position	Operation	1	2	3	4	5	6	7
DRIVER	Up		○	○	○		○	
	Down		○	○	○		○	
	Left		○	○			○	○
	Right		○	○			○	○
PASS	Up		○	○	○		○	
	Down		○	○	○		○	
	Left	○	○	○			○	
	Right	○	○	○			○	

○ — ○ : Indicates continuity

3. If the continuity is not as specified, replace the power mirror switch.



Power Mirror Motor

1. Disconnect the power mirror motor electrical connector.
2. Check for continuity between the power mirror motor terminals using an ohmmeter.

Power mirror motor terminal		
1	2	3
○	○	○

○ — ○ : Indicates continuity

3. If the continuity is not as specified, replace the power mirror motor.



CIRCUIT TESTING

Driver's and passenger's door lock cylinder contact switch

1. Disconnect the door lock cylinder contact switch connector.
2. Check for continuity between the connector terminals using an ohmmeter.

Position of door lock switch \ Connector terminal	1	2	3
LOCKED			
UNLOCKED			

 —  : Indicates continuity

3. If not as indicated, replace the door lock switch.

Door Lock Motor

1. Disconnect the door lock motor connector (C503, C603, C701, C801).
2. Check the operation of the door lock motor by connecting 12V to connector terminals as indicated.

Polarity of connection		Position of door lock switch
12V	Ground	
2	4	LOCKED
4	2	UNLOCKED

3. If not as indicated, replace the door lock motor.

