

# ELECTRICAL SYSTEM

## SECTION EL

### CONTENTS

<b>PRECAUTIONS</b> .....	4	GI
Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	4	MA
Wiring Diagrams and Trouble Diagnosis .....	4	EM
<b>PREPARATION</b> .....	5	LC
Special Service Tools .....	5	EC
<b>HARNESS CONNECTOR</b> .....	6	FE
Description .....	6	CL
<b>STANDARDIZED RELAY</b> .....	8	MT
Description .....	8	AT
<b>POWER SUPPLY ROUTING</b> .....	10	TF
Circuit Diagram .....	10	PD
Wiring Diagram - POWER - .....	12	AX
Inspection.....	17	SU
<b>GROUND</b> .....	18	BR
Ground Distribution.....	18	ST
<b>COMBINATION SWITCH</b> .....	32	RS
Check.....	32	BT
Replacement.....	33	SC
<b>STEERING SWITCH</b> .....	34	EL
Check.....	34	IDX
<b>HEADLAMP (FOR USA)</b> .....	35	
System Description.....	35	
Wiring Diagram - H/LAMP - .....	36	
Trouble Diagnoses.....	37	
Bulb Replacement .....	38	
Aiming Adjustment.....	38	
<b>HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM</b> - .....	40	
System Description (For Canada) .....	40	
Circuit Diagram .....	42	
Wiring Diagram - DTRL - .....	43	
Trouble Diagnoses.....	46	
Bulb Replacement .....	47	
Aiming Adjustment.....	47	
<b>PARKING, LICENSE AND TAIL LAMPS</b> .....	48	
Wiring Diagram - TAIL/L - .....	48	
<b>STOP LAMP</b> .....	49	
Wiring Diagram - STOP/L - .....	49	
<b>BACK-UP LAMP</b> .....	50	
Wiring Diagram - BACK/L - .....	50	
<b>FRONT FOG LAMP</b> .....	51	
System Description.....	51	
Wiring Diagram - F/FOG - .....	52	
Aiming Adjustment.....	53	
Removal and Installation .....	54	
Bulb and Lens Replacement .....	54	
<b>TURN SIGNAL AND HAZARD WARNING LAMPS</b> .....	55	
System Description.....	55	
Wiring Diagram - TURN - .....	57	
Trouble Diagnoses.....	59	
Electrical Components Inspection .....	60	
<b>ILLUMINATION</b> .....	61	
System Description.....	61	
Wiring Diagram - ILL - .....	62	
<b>INTERIOR ROOM LAMP</b> .....	64	
Component Parts and Harness Connector .....		
Location .....	64	
System Description.....	65	
Wiring Diagram - ROOM/L - .....	68	
Trouble Diagnosis.....	72	
<b>METERS AND GAUGES</b> .....	74	
Component Parts and Harness Connector .....		
Location .....	74	
System Description.....	75	
Combination Meter .....	77	
Wiring Diagram - METER - .....	79	
Meter/Gauge Operation and Odo/Trip Meter .....		
Segment Check in Diagnosis Mode .....	80	
Trouble Diagnoses.....	81	
Electrical Components Inspection .....	87	
<b>COMPASS AND THERMOMETER</b> .....	89	
System Description.....	89	
Wiring Diagram - COMPAS - .....	90	
Trouble Diagnoses.....	92	
Calibration Procedure for Compass .....	93	
<b>WARNING LAMPS</b> .....	94	
Circuit Diagram .....	94	

# CONTENTS (Cont'd)

Wiring Diagram - WARN - .....	95	Trouble Diagnoses.....	184
Electrical Components Inspection .....	103	<b>POWER DOOR LOCK</b> .....	186
<b>WARNING CHIME</b> .....	104	Component Parts and Harness Connector	
Component Parts and Harness Connector		Location .....	186
Location .....	104	System Description.....	187
System Description.....	105	Circuit Diagram.....	189
Wiring Diagram - CHIME - .....	107	Wiring Diagram - D/LOCK -.....	190
Trouble Diagnoses.....	109	Trouble Diagnoses.....	193
<b>FRONT WIPER AND WASHER</b> .....	118	<b>REMOTE KEYLESS ENTRY SYSTEM</b> .....	200
System Description.....	118	Component Parts and Harness Connector	
Wiring Diagram - WIPER - .....	120	Location .....	200
Removal and Installation .....	122	System Description.....	201
Washer Nozzle Adjustment .....	123	Wiring Diagram - KEYLES - .....	204
Washer Tube Layout .....	123	Trouble Diagnoses.....	206
<b>HORN</b> .....	124	ID Code Entry Procedure .....	215
Wiring Diagram - HORN - .....	124	Keyfob Battery Replacement.....	216
<b>CIGARETTE LIGHTER</b> .....	125	<b>VEHICLE SECURITY (THEFT WARNING) SYSTEM</b> .....	217
Wiring Diagram - CIGAR - .....	125	Component Parts and Harness Connector	
<b>REAR WINDOW DEFOGGER</b> .....	126	Location .....	217
Component Parts and Harness Connector		System Description.....	219
Location .....	126	Circuit Diagram.....	222
System Description.....	127	Wiring Diagram - VEHSEC - .....	223
Wiring Diagram - DEF - .....	129	Trouble Diagnoses.....	226
Trouble Diagnoses.....	131	<b>SMART ENTRANCE CONTROL UNIT</b> .....	240
Electrical Components Inspection .....	135	Description .....	240
Filament Check.....	136	Circuit Diagram .....	241
Filament Repair .....	137	Smart Entrance Control Unit Inspection Table .....	243
<b>AUDIO</b> .....	138	<b>ELECTRICAL UNITS LOCATION</b> .....	245
System Description.....	138	Engine Compartment.....	245
Schematic - With Audio Amplifier .....	140	Passenger Compartment.....	246
Wiring Diagram - AUDIO - .....	141	<b>HARNESS LAYOUT</b> .....	248
Trouble Diagnoses.....	149	How to Read Harness Layout .....	248
Inspection.....	150	Outline.....	249
<b>AUDIO ANTENNA</b> .....	153	Main Harness (KA24DE Models) .....	250
Location of Antenna.....	153	Main Harness (VG33E and VG33ER Models) .....	252
Fixed Antenna Rod Replacement.....	153	Engine Room Harness (KA24DE Models) .....	254
<b>DOOR MIRROR</b> .....	154	Engine Room Harness (VG33E and VG33ER Models) .....	257
Wiring Diagram - MIRROR - .....	154	Engine Control Harness (KA24DE Models) .....	260
<b>AUTOMATIC SPEED CONTROL DEVICE (ASCD)</b> .....	155	Engine No. 2 Harness (KA24DE Models) .....	262
Component Parts and Harness Connector		Engine Control Harness (VG33E Models) .....	263
Location .....	155	Engine Control Harness (VG33ER Models) .....	265
System Description.....	157	Engine No. 2 Harness (VG33E and VG33ER Models) .....	267
Circuit Diagram .....	159	Chassis and Tail Harness (KA24DE Models) .....	268
Wiring Diagram - ASCD - .....	160	Chassis and Tail Harness (VG33E and VG33ER Models) .....	269
Fail-safe System.....	163	Room Lamp Harness .....	270
Trouble Diagnoses.....	164	Front Door Harness .....	271
Electrical Component Inspection .....	172	Rear Door Harness .....	273
ASCD Wire Adjustment .....	174	<b>BULB SPECIFICATIONS</b> .....	275
<b>POWER WINDOW</b> .....	176		
System Description.....	176		
Circuit Diagram .....	179		
Wiring Diagram - WINDOW - .....	180		

# HARNESS CONNECTOR

Description

## Description

### HARNESS CONNECTOR (TAB-LOCKING TYPE)

NEEL0003


NEEL0003S01

- The tab-locking type connectors help prevent accidental looseness or disconnection.
- The tab-locking type connectors are disconnected by pushing or lifting the locking tab(s). Refer to the illustration below.  
Refer to EL-7 for description of the slide-locking type connector.

#### CAUTION:

Do not pull the harness when disconnecting the connector.


[Example]



SEL769D

# POWER SUPPLY ROUTING

Circuit Diagram (Cont'd)





Preceding page

Preceding page

# GROUND

*Ground Distribution (Cont'd)*

## Body ground



CONNECTOR NUMBER	CONNECT TO
(M6)	Vehicle security relay (Terminal No. 4) (with power door locks)
(E1)	Headlamp RH
(E17)	Daytime light control unit (Terminal No. 9) (for Canada)
(E19)	Front combination lamp RH (Terminal No. 2) • Parking lamp • Turn signal lamp
(E22)	Vehicle security lamp relay (Terminal No. 2)
(E27)	Park/neutral position (PNP) relay (Terminal No. 1) (with A/T)
(E27)	Park/neutral position (PNP) relay (Terminal No. 6) (with A/T)
(E42)	Front wiper motor (Terminal No. E)
(E57)	Front fog lamp RH (Terminal No. 2) (with fog lamps)

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

WEL851A HA

SC

EL

IDX

# HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Trouble Diagnoses

## Trouble Diagnoses

### DAYTIME LIGHT CONTROL UNIT INSPECTION TABLE

NEEL0021

NEEL0021S01

Terminal No.	Wire color	Item	Condition	Voltage (Approx.)
1	L/OR	Ignition switch start signal	Ignition switch in START position	12
			All other conditions	0
2	Y/G	Power source for head-lamp RH	—	12
3	Y/B	Power source for head-lamp LH	—	12
4	R/B	Lighting switch headlamp RH low beam output	Lighting switch in the headlamp ON (2ND) position and LOW BEAM (B) position	12
			All other conditions	0
5	R/G	Lighting switch headlamp LH high beam output	Lighting switch in the FLASH TO PASS (C) position or headlamp ON (2ND) position and HIGH BEAM (A) position	12
			All other conditions	0
6	R/Y	Headlamp LH high beam	Lighting switch in the FLASH TO PASS (C) position or headlamp ON (2ND) position and HIGH BEAM (A) position	12
			With parking brake released, engine running and lighting switch in OFF or parking and tail lamp ON (1ST) positions <b>CAUTION:</b> <b>Block wheels and ensure selector lever is in P or N position.</b>	12
			All other conditions	0
7	B/W	Headlamp LH control (ground)	Lighting switch in the FLASH TO PASS (C) position or headlamp ON (2ND) position	0
			All other conditions	6
8	R/W	Lighting switch headlamp RH high beam output	Lighting switch in the FLASH TO PASS (C) position or headlamp ON (2ND) position and HIGH BEAM (A) position	12
			With parking brake released, engine running and lighting switch in OFF or parking and tail lamp ON (1ST) positions <b>CAUTION:</b> <b>Block wheels and ensure selector lever is in P or N position.</b>	6
			All other conditions	0
9	B	Ground	—	—
10	Y	Parking brake switch	Parking brake released	12
			Parking brake set	0
11	Y/B	Generator (L terminal)	When engine is running	12
			All other conditions	0

# INTERIOR ROOM LAMP

Trouble Diagnosis


## Trouble Diagnosis

**SYMPTOM:** Room lamp does not turn on or off properly.

NEEL0225

<b>1</b>	<b>CHECK ROOM LAMP FUSE</b>			
Check 7.5 A fuse [No. 26 (without power door locks), 28 (with power door locks), located in fuse block].				
<b>OK or NG</b>				
OK	►	GO TO 2.		
NG	►	Replace fuse and check harness for short between fuse and room lamp.		

<b>2</b>	<b>CHECK ROOM LAMP SWITCH SIGNALS</b>			
1. Close all doors, turn ON room lamp switch. <b>Do room lamps turn on?</b>				
2. Turn off room lamp switch. <b>Do room lamps turn off?</b>				
<b>OK or NG</b>				
OK	►	GO TO 3.		
NG	►	<b>Check the following.</b> <ul style="list-style-type: none"> <li>● Room lamp switch</li> <li>● Room lamp switch ground circuit</li> <li>● Harness for open or short between room lamp switch and smart entrance control unit (models with power door locks)</li> </ul>		

<b>3</b>	<b>CHECK ROOM LAMP POWER SUPPLY</b>			
Check voltage between room lamp connector R4 terminal + (R/G) and ground.				
 <b>Battery voltage should exist.</b>				
<b>OK or NG</b>				
OK	►	GO TO 4.		
NG	►	Check harness for open between fuse and room lamp.		

<b>4</b>	<b>CHECK INTERIOR ROOM LAMP BULB</b>			
Check interior room lamp bulb.				
<b>OK or NG</b>				
OK	►	<ul style="list-style-type: none"> <li>● For models without power door locks, inspection end.</li> <li>● For models with power door locks, GO TO 5.</li> </ul>		
NG	►	Replace bulb.		

# COMPASS AND THERMOMETER


Wiring Diagram — COMPAS —

## Wiring Diagram — COMPAS — KING CAB

NEEL0229




NEEL0229S01

**EL-COMPAS-01**



Refer to the following.

(M65, E43) - SUPER  
MULTIPLE JUNCTION (SMJ)




LEL762A


## WARNING CHIME

Trouble Diagnoses (Cont'd)

### SEAT BELT BUCKLE SWITCH CHECK Models without Power Door Locks

=NEEL0055S05  
NEEL0055S0501

1 CHECK SEAT BELT BUCKLE SWITCH INPUT SIGNAL	
1. Turn ignition switch ON.	
2. Check voltage between warning chime unit terminal 2 and ground.	
	
Voltage [V]:	
Condition of seat belt buckle switch: FASTENED	Approx. 12
Condition of seat belt buckle switch: UNFASTENED	0
	OK or NG
OK	► Seat belt buckle switch is OK.
NG	► GO TO 2.

2 CHECK SEAT BELT BUCKLE SWITCH	
Check continuity between terminals 1 and 2 when seat belt is fastened and unfastened.	
	
Continuity:	
Seat belt is fastened.	No
Seat belt is unfastened.	Yes
	OK or NG
OK	► Check the following. ● Seat belt buckle switch ground circuit ● Harness for open or short between warning chime unit and seat belt buckle switch
NG	► Replace seat belt buckle switch.

# REAR WINDOW DEFOGGER

Wiring Diagram — DEF —

## Wiring Diagram — DEF — WITHOUT POWER DOOR LOCKS

NEEL0217

NEEL0217S01

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA








SC

EL

WEL747A

IDX







**EL-DEF-01**



# AUDIO

Wiring Diagram — AUDIO — (Cont'd)

**EL-AUDIO-03**



\* : This connector is not shown in "HARNESS LAYOUT" of EL section.

LEL752A

**EL**

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)



Wiring Diagram — ASCD —

## Wiring Diagram — ASCD —

NEEL0097

NEEL0097S01

FIG. 1






WEL759A

# POWER WINDOW

Wiring Diagram — WINDOW — (Cont'd)

## EL-WINDOW-04



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC

# REMOTE KEYLESS ENTRY SYSTEM

System Description

## System Description

### POWER SUPPLY AND GROUND

Power is supplied at all times

- through 30A fusible link [letter f, located in the fuse and fusible link box (with KA24DE)] or
- through 40A fusible link [letter f, located in the fuse and fusible link box (with VG33E and VG33ER)]
- to circuit breaker terminal +
- through circuit breaker terminal –
- to smart entrance control unit terminal 51.

NEEL0112

NEEL0112S03

GI

With the ignition switch in the ACC or ON position, power is supplied

- through 7.5A fuse [No. 20, located in the fuse block (J/B)]
- to smart entrance control unit terminal 26.

MA

Power is supplied at all times

- through 7.5A fuse [No. 28, located in the fuse block (J/B)]
- to key switch terminal 1 and
- to smart entrance control unit terminal 49.

EM

Power is supplied at all times

- through 15A fuse (No. 37, located in the fuse and fusible link box)
- to vehicle security lamp relay terminal 7.

EC

Power is supplied at all times

- through 15A fuse (No. 38, located in the fuse and fusible link box)
- to vehicle security lamp relay terminal 5.

FE

Power is supplied at all times

- through 15A fuse (No. 32, located in the fuse and fusible link box)
- to horn relay terminal 1
- through horn relay terminal 2

CL

Ground is supplied

- to smart entrance control unit terminals 43 and 64
- through body grounds M14 and M68.

MT

### INPUTS

With the key switch in the INSERTED (key is in ignition key cylinder) position, power is supplied

NEEL0112S01

- through key switch terminal 2
- to smart entrance control unit terminal 25.

AX

With front door LH open, ground is supplied

- to smart entrance control unit terminal 1
- through front door switch LH terminal 2
- through front door switch LH terminal 3
- through body grounds M14 and M68.

SU

With front door RH open, ground is supplied

- to smart entrance control unit terminal 2
- through front door switch RH terminal +.

BR

With rear door LH or RH (Crew Cab) open, ground is supplied

ST

- to smart entrance control unit terminal 3 (with vehicle security system), or
- to smart entrance control unit terminal 2 (without vehicle security system)
- through rear door switch LH or RH terminal +.

RS

Keyfob signal input

- through internal antenna.

BT

The remote keyless entry system controls operation of the

- power door locks

HA

- interior lamp

- panic alarm

SC

EL

# VEHICLE SECURITY (THEFT WARNING) SYSTEM

System Description

NEEL0197

NEEL0197S01

GI

NEEL0197S0101

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC


EL

IDX

## System Description

### DESCRIPTION

#### 1. Operation Flow



#### 2. Setting the Vehicle Security System

##### Initial condition

- 1) Close all doors.
- 2) Close hood.

##### Disarmed phase

The vehicle security system is in the disarmed phase when any door(s) or hood is opened. The security indicator lamp blinks every second.

##### Pre-armed phase and armed phase

The vehicle security system turns into the "pre-armed" phase when hood and all doors are closed and the doors are locked by key or keyfob. (The security indicator lamp illuminates.)

After about 30 seconds, the system automatically shifts into the "armed" phase (the system is set). (The security indicator lamp blinks every 2.6 seconds.)

#### 3. Canceling the Set Vehicle Security System

When the doors are unlocked with the key or keyfob, the armed phase is canceled.

NEEL0197S0103

BR

#### 4. Activating the Alarm Operation of the Vehicle Security System

NEEL0197S0104

ST

Make sure the system is in the armed phase. (The security indicator lamp blinks every 2.6 seconds.) When the following operation 1) or 2) is performed, the horn and headlamps operate intermittently for about 50 seconds. (At the same time, the system disconnects the starting system circuit.)

- 1) Engine hood or any door is opened before unlocking door with key or keyfob.
- 2) Door is opened without first using key or keyfob.

#### POWER SUPPLY AND GROUND

Power is supplied at all times

NEEL0197S02

BT

- through 7.5A fuse [No. 28, located in the fuse block (J/B)]
- to smart entrance control unit terminal 49
- to key switch terminal 1 and
- to security indicator lamp terminal 1.

HA

With the ignition switch in the ACC or ON position, power is supplied

- through 7.5A fuse [No. 20, located in the fuse block (J/B)]
- to smart entrance control unit terminal 26.

SC

With the ignition switch in the ON or START position, power is supplied