

ELECTRICAL SYSTEM	8
STARTER-CURRENT SUPPLY-CC.....	8
BATTERY.....	8
<i>Battery handling instructions</i>	8
<i>Inspecting electrolyte level.....</i>	8
<i>Measuring voltage under load</i>	9
<i>Basics.....</i>	9
<i>Work sequence when disconnecting and connecting the battery.....</i>	10
<i>Check the battery</i>	10
<i>Measure no-load voltage</i>	11
<i>Charging batteries.....</i>	12
<i>Removing and installing the battery</i>	12
<i>Removing and installing the battery tray.....</i>	14
BATTERY WITH A MAGIC EYE AND BATTERY PLUGS COVERED IN ADHESIVE TAPE	15
<i>Checking the battery using the magic eye</i>	15
BATTERY WITH A MAGIC EYE WITHOUT BATTERY PLUGS COVERED IN ADHESIVE TAPE (MAINTENANCE-FREE).....	16
<i>Checking the battery using the magic eye</i>	16
REMOVING AND INSTALLING THE AC GENERATOR	17
<i>Vehicles with petrol engine</i>	17
<i>Vehicles with diesel engine.....</i>	17
<i>Removing and installing belt pulley of AC generator</i>	19
<i>Removing and installing belt pulley of AC generator with free wheel</i>	19
REMOVING AND INSTALLING THE STARTER	21
INSTRUMENTS, GCI.....	22
DASH PANEL INSERT (? MY 00)	22
<i>Self-diagnosis</i>	22
<i>Initiating self-diagnosis of the dash panel insert.....</i>	23
<i>Interrogating fault memory</i>	24
<i>Fault table</i>	25
<i>Actuator diagnosis</i>	27
<i>Erasing fault memory</i>	28
<i>Ending output.....</i>	29
<i>Coding control unit</i>	29
<i>Reading measured value block.....</i>	30
<i>Adjustment.....</i>	32
<i>Adapt service interval display - SID</i>	35
<i>Input values when changing the dash panel insert</i>	37
<i>Resetting service interval display (SID) without -V.A.G 1552- / -V.A.G 1551 -</i>	38
<i>Resetting service interval display (SID) with -V.A.G 1552- / -V.A.G 1551 -.....</i>	39
<i>Removing and installing the dash panel insert</i>	40
<i>Lamp assignment on the dash panel insert.....</i>	41
<i>Contact assignment of plug connections on the dash panel insert</i>	41
<i>Test signal from fuel gauge sender -G-</i>	44
<i>Contact assignment on the fuel gauge sender - G-</i>	44
<i>Check coolant temperature sender</i>	45
<i>Testing the speed signal.....</i>	45
TAXIMETER AND PRINTER	46
<i>Removing and installing taximeter HALE</i>	46
<i>Removing and installing printer HALE.....</i>	46
DASH PANEL INSERT (MY 01 ?)	48

<i>Self-diagnosis</i>	48
<i>Initiating self-diagnosis of the dash panel insert</i>	49
<i>Interrogating fault memory</i>	50
<i>Fault table</i>	50
<i>Actuator diagnosis</i>	50
<i>Erasing fault memory</i>	52
<i>Ending output</i>	52
<i>Coding dash panel insert</i>	52
<i>Reading measured value block</i>	54
<i>Adaptation</i>	56
<i>Adapting the service interval display when replacing the dash panel insert</i>	58
<i>Input values when changing the dash panel insert</i>	61
SELF-DIAGNOSIS OF THE GATEWAY	63
<i>Initiating self-diagnosis</i>	63
<i>Interrogating fault memory</i>	64
<i>Fault table</i>	64
<i>Erasing fault memory</i>	67
<i>Ending output</i>	67
<i>Coding control unit</i>	67
<i>Reading measured value block</i>	68
<i>Removing and installing the dash panel insert</i>	70
<i>Contact assignment of plug connections on the dash panel insert</i>	70
<i>Test signal from fuel gauge sender -G-</i>	73
<i>Contact assignment on the fuel gauge sender -G-</i>	73
<i>Check coolant temperature sender</i>	73
<i>Testing the speed signal</i>	73
<i>Outside temperature sensor -G17 -</i>	73
<i>Check oil level and oil temperature sender -G266-</i>	73
CAN DATABUS	75
<i>Checking the data BUS drive</i>	75
<i>Check the terminating resistances of the control units</i>	77
<i>Test CAN databus for short-circuit</i>	79
<i>Checking the data BUS Comfort version</i>	80
INFOTAINMENT	81
RADIO SYSTEM	81
<i>General Instructions</i>	81
<i>Radio system with 4 loudspeakers</i>	81
<i>Radio system with 8 loudspeakers</i>	82
<i>Overview of radio system</i>	85
<i>Removing and installing radio</i>	87
<i>Removing and installing loudspeakers</i>	87
<i>Removing and installing radio sets "Gamma (MS 501), MS 303, Symphony"</i>	89
REMOVING AND INSTALLING THE ROOF AERIAL	91
REMOVING AND INSTALLING ROOF AERIAL FOR RADIO AS OF MY 2002	93
REMOVING AND INSTALLING ROOF AERIAL FOR RADIO AND TELEPHONE AS OF MY 2002	94
REMOVING AND INSTALLING ROOF AERIAL FOR RADIO, TELEPHONE AND NAVIGATION SYSTEM AS OF MY 2002	95
TELEPHONE SYSTEMS	96
<i>Telephone system - overall view</i>	96
<i>Telephone preinstallation 1</i>	98
<i>Telephone preinstallation 2 - Cullmann</i>	98
<i>Telephone system</i>	99
REMOVING AND INSTALLING THE CONTROL UNIT FOR THE MOBILE PHONE OPERATING ELECTRONICS -J412- (INTERFACE BOX)	101
OVERVIEW OF THE MOUNT FOR THE MOBILE PHONE 1	103

OVERVIEW OF THE MOUNT FOR THE MOBILE PHONE 2	104
REMOVING AND INSTALLING THE MICROPHONE FOR THE TELEPHONE -R38- ? 08.00	106
REMOVING AND INSTALLING THE MICROPHONE FOR THE TELEPHONE -R38- 09.00 ?	108
SELF-DIAGNOSIS OF RADIO SYSTEM "GAMMA (MS 501), MS 303 AND SYMPHONY"	109
<i>Connecting vehicle system tester -V.A.G 1552- and selecting the control unit for the radio set</i>	109
<i>Interrogating and erasing fault memory</i>	110
<i>Fault table</i>	111
<i>Actuator diagnosis</i>	112
<i>Code radio</i>	113
<i>Reading measured value block</i>	116
REMOVING AND INSTALLING CD CHANGER	120
NAVIGATION SYSTEM.....	120
<i>General description</i>	121
<i>Self-diagnosis of radio unit in RNS</i>	121
<i>Self-diagnosis of navigation unit in RNS</i>	121
<i>Interrogating and erasing fault memory</i>	123
<i>Fault table</i>	123
<i>Actuator diagnosis</i>	125
<i>Reading measured value block</i>	125
<i>Measured value block 006 (as of SG 3B0919887 D)</i>	127
<i>Code control unit for RNS</i>	130
<i>Electronic anti-theft lock</i>	130
<i>Plug connections at Radio-Navigation System</i>	131
<i>Removing and installing Radio-Navigation System</i>	134
MULTI-FUNCTIONAL STEERING WHEEL	136
<i>General description</i>	136
<i>Interrogating and erasing fault memory</i>	137
<i>Fault table</i>	138
<i>Coding multi-functional steering wheel control unit -J453-</i>	139
<i>Actuator diagnosis</i>	140
<i>Reading measured value block</i>	141
<i>Removing and installing the key units of the multi-function steering wheel</i>	142
<i>Contact assignment of the 18-pin plug connection for the CU multi-functional steering wheel -J453-</i>	143
WINDSCREEN WIPE/WASH SYSTEM	144
WINDSCREEN WIPER AND WASHER SYSTEM	144
<i>Removing and installing the windscreen wiper and washer system</i>	144
<i>Setting park position of windscreen wiper blades</i>	145
REPAIRING WINDSCREEN WASHER SYSTEM	147
<i>Removing and installing washer reservoir</i>	147
<i>Removing and installing washer nozzles</i>	148
<i>Setting the washer nozzles</i>	148
REPAIRING HEADLAMP CLEANING SYSTEM.....	150
<i>Removing and installing the spray nozzles of the headlamp cleaning system</i>	150
<i>Adjusting the spray nozzles</i>	150
<i>Removing and installing washer fluid reservoir</i>	150
REAR WINDOW WIPER AND WASHER SYSTEM	151
<i>Rear window wiper system - Summary of components</i>	151
<i>Removing and installing rear window wiper</i>	152
<i>Setting park position of rear window wiper</i>	153
<i>Adjusting spray nozzle</i>	153
<i>Replacing spray nozzle (Octavia Combi)</i>	153
<i>Replacing spray nozzle (Octavia)</i>	154
<i>Removing and installing wiper rubber</i>	154

<i>Removing and installing the rain sensor</i>	155
LIGHTS, LAMPS, SWITCHES OUTSIDE	157
REPAIRING HEADLIGHT.....	157
<i>Overall view ? 07.00</i>	157
<i>Overall view 08.00 ?</i>	158
<i>Removing and installing headlight.....</i>	158
<i>Setting the headlight beam.....</i>	159
<i>Unglueing a halogen headlight</i>	161
<i>Changing light bulbs of headlight</i>	162
<i>Removing and installing the headlight range control motor</i>	163
REPAIRING TURN SIGNAL LIGHTS	165
<i>Removing and installing turn signal lights</i>	165
<i>Removing and installing light bulb for the turn signal light</i>	165
REMOVING AND INSTALLING SIDE TURN SIGNAL LIGHTS.....	165
REPAIRING REAR LIGHTS.....	167
<i>A general overview.....</i>	167
<i>Removing and installing the light bulb from the lamp holder.....</i>	168
<i>Removing and installing rear light</i>	168
REMOVING AND INSTALLING THE LICENCE PLATE ILLUMINATION	169
REPAIRING STEERING COLUMN SWITCH	170
<i>Removing and installing steering column switch.....</i>	170
<i>Contact assignment on the steering column switch - up to MY 98</i>	172
<i>Contact assignment on the steering column switch - as of MY 99.....</i>	173
REPAIRING LOCK CYLINDER AND IGNITION STARTER SWITCH	175
<i>Removing and installing lock cylinder</i>	175
<i>Removing and installing the ignition switch</i>	176
<i>Contact assignment on the ignition starter switch</i>	177
REMOVING AND INSTALLING REAR LIGHTS OCTAVIA COMBI.....	177
ADDITIONAL BRAKE LIGHT.....	179
<i>Additional brake light for OCTAVIA</i>	179
<i>Additional brake light for OCTAVIA Combi.....</i>	180
ANTI-THEFT WARNING SYSTEM.....	182
<i>Bonnet contact switch -F120- (-F266-)</i>	182
<i>Horn for anti-theft alarm system -H8.....</i>	182
<i>Horn for anti-theft alarm system -H8.....</i>	182
<i>Replace emergency battery for alarm horn</i>	183
PARKING AID - OVERALL VIEW	184
<i>Removing and installing parking aid control unit -J446-</i>	184
<i>Removing and installing the parking aid warning buzzer</i>	185
<i>Removing and installing parking aid senders.....</i>	185
SELF-DIAGNOSIS OF THE PARKING AID	187
<i>General Instructions</i>	187
<i>Initiating self-diagnosis of the parking aid</i>	187
<i>Interrogating and erasing fault memory.....</i>	189
<i>Fault table</i>	189
<i>Coding park aid control unit.....</i>	190
<i>Reading measured value block.....</i>	191
<i>Adaptation</i>	192
ROOF SIGN "TAXI"	194
<i>Removing and installing bracket for "TAXI" roof sign</i>	194
SELF DIAGNOSIS FOR THE XENON HEADLIGHTS WITH AUTOMATIC REGULATION (SYSTEM LITRONIC 4.1)	195
<i>Interrogating fault memory</i>	196
<i>Fault table</i>	197

<i>Actuator diagnosis</i>	198
<i>Initiating basic setting</i>	199
<i>Erasing fault memory</i>	200
<i>Ending output</i>	200
<i>Coding control unit</i>	200
<i>Reading measured value block</i>	201
XENON HEADLIGHTS WITH AUTOMATIC REGULATION (SYSTEM LITRONIC 4.1) - OVERALL VIEW	203
<i>Headlight with control unit</i>	203
<i>Removing and installing front Xenon headlights</i>	204
<i>Changing light bulbs in the headlight</i>	205
<i>Removing and installing the D2S discharge lamp</i>	206
<i>Removing and installing the ignition/high voltage unit BOSCH 2.3</i>	206
<i>Removing and installing stepper motor</i>	206
<i>Removing and installing front sender</i>	207
<i>Removing and installing rear sender</i>	207
<i>Removing and installing control unit</i>	208
<i>Possibilities of sender adjustment</i>	208
<i>Connection identification of the Xenon headlamps</i>	209
<i>Switch over the inner aperture in the Xenon headlight</i>	211
LIGHTS, LAMPS, SWITCHES INSIDE, ANTI-THEFT SYSTEM	212
DIAGNOSIS OF THE ELECTRONIC IMMOBILISER	212
<i>Self-diagnosis of the 1st generation immobiliser</i>	212
<i>Initiating self-diagnosis</i>	212
<i>Interrogating control unit version</i>	214
<i>Interrogating fault memory</i>	214
<i>Fault table</i>	214
<i>Erasing fault memory</i>	216
<i>Ending output</i>	216
<i>Reading measured value block</i>	217
<i>Adaptation</i>	218
<i>Adapt ignition key</i>	218
<i>Adaptation after changing the engine control unit</i>	221
<i>Adaptation after changing the immobiliser control unit</i>	222
<i>Emergency start function with -V.A.G 1552-</i>	222
<i>Requirements</i>	222
<i>Emergency start function without V.A.G 1552</i>	223
<i>Requirements</i>	223
<i>Transponder defective and/or key loss</i>	224
<i>Replacing reader coil</i>	224
<i>Procedure when changing the lock set or the immobiliser control unit</i>	224
1. 2-part sticker of the lock set	225
2. 3-part sticker of the immobiliser control unit in the dash panel insert	226
<i>System check</i>	226
REPAIRING SWITCH	228
<i>Removing and installing switches in centre console</i>	228
<i>Removing and installing light switch</i>	228
<i>Removing and installing the headlight range control adjuster</i>	228
<i>Removing and installing the door contact switch</i>	229
<i>Removing and installing electrical switch for sun roof and interior light</i>	229
<i>Removing and installing the mirror adjustment switch</i>	230
<i>Removing and installing the switch for the power window lifter</i>	231
REPAIRING INTERIOR LIGHTS	232
<i>Removing and installing glove box light</i>	232
<i>Removing and installing the reading light (rear)</i>	232

<i>Removing and installing front ashtray illumination</i>	233
<i>Removing and installing make-up mirror lamp</i>	233
<i>Removing and installing door warning lamp</i>	233
<i>Removing and installing warning light for airbag switch-off function</i>	234
REPAIRING THE HORN	235
<i>Removing and installing horn</i>	235
<i>Removing and installing luggage compartment light</i>	235
<i>Removing and installing switch for remote release/fuel tank cap</i>	236
REMOVING AND INSTALLING THE LUGGAGE COMPARTMENT POWER SOCKET	238
SENSOR FOR INTERIOR MONITORING -G273-	239
<i>Removing and installing</i>	239
<i>Inspection</i>	239
<i>Regulate sensitivity</i>	240
ALARM SYSTEM	241
<i>Removing and installing foot switch for alarm system</i>	241
SELF-DIAGNOSIS OF THE 2ND GENERATION IMMOBILISER MY 01 ?	241
SELF-DIAGNOSIS OF THE 3RD GENERATION IMMOBILISER MY 01 ?	242
<i>Carry out self-diagnosis of immobiliser</i>	242
<i>Interrogating fault memory</i>	243
<i>Fault table</i>	243
<i>Erasing fault memory</i>	243
<i>Ending output</i>	244
<i>Reading measured value block</i>	244
<i>Performing the log-in procedure</i>	245
<i>Adapt ignition key</i>	245
<i>Adaptation after changing the new engine control unit</i>	245
<i>Adaptation after insertion of a used engine control unit</i>	246
<i>Adaptation after changing the new immobiliser control unit</i>	247
<i>Adaptation after insertion of an already used dash panel insert</i>	248
<i>Requirements</i>	248
WIRING	250
RELAY HOLDER, FUSE HOLDER	250
<i>Removing and installing relay and fuse holder</i>	250

Removing:

Note

If necessary, determine the anti-theft code of the radio set before disconnecting the battery.

- First of all disconnect the battery earth strap [→ Chapter](#).
- Unscrew nut -3- and remove cable strap.
- Remove insulating cap, unscrew nut -1- and disconnect cable B+.
- Unplug connector -2-.

Note

Mark the direction of rotation for re-installation before removing the V-ribbed belt.

- Remove V-ribbed belt [→ Engine, Mechanics → Rep. Gr.13](#).
- Remove tensioning element for V-ribbed belt.

Vehicles with air conditioning system and vane pump for power-assisted steering located at the top:

Note

Do not open the hydraulic circuit when removing the vane pump.

- Remove the vane pump for the power-assisted steering from the bracket and place it with the connected lines to the right [→ Chassis → Rep. Gr.48](#).

Vehicles with increased cooling:

- Remove right auxiliary fan [→ Engine, Mechanics → Rep. Gr.19](#).

Note


Protect the radiator e.g. with cardboard from damage.

All vehicles:

- Screw out the fixing screws for the generator and carefully remove the generator upwards.

Installing:

The generator is installed in the reverse order of removal.



Note

Knock back the threaded bushings of the fixing screws for the generator approx. 1 mm before the re-installation.

Note

Observe the instructions when reconnecting the battery [→ Chapter](#).

Tightening torques:

Readout on display: Vehicle system test HELP

- Enter 11. Select function XX

Readout on display: Vehicle system test Q

- Confirm the entry with key Q. 11 – Login procedure

Readout on display: Login procedure

- Enter code number 13861 and confirm entry with key Q. Enter code number XXXXX

Readout on display: Vehicle system test HELP

- Enter function 10 and confirm with key Q. Select function XX

Readout on display: Adjustment

- Enter 09 (channel number) and confirm entry with key Q. Enter channel number XX

Readout on display:

Note	Channel 09	Adaptation
	0 →	
Only a direct entry is possible using the keypad of the vehicle system tester -V.A.G 1552 -!	<↑ ↓→	
– Move forward in test program with key →.		

Readout on display:

Example: Channel 09 AAdaptation 0 Q

Kilometre reading = 89627 Enter adaptation value XXXXX

0 8 9 6 3

X		Hundred thousands: 100000 ... 900000 km
X		Ten thousands: 10000 ... 90000 km
X		Thousands: 1000 ... 9000 km
X		Hundreds: 100 ... 900 km
X		Tens: 10 ... 90 km
		Ones: rounded up to the next ten

- Enter adaptation values with the keypad.

Readout on display: Channel 09 Adaptation 0 Q

- Confirm the entry with key Q. Enter adaptation value 08963

Readout on display:

The km reading entered now appears in the display of the dash panel insert.

If the displayed km reading is not O.K., e.g. because an incorrect entry was made:

Channel 09	Adaptation	8963
Q		<–

- Press key C and repeat the entry with the correct adaptation value.

↑ ↓→

If the displayed km reading in the display of the dash panel insert is O.K.:

- Confirm the entry with key Q.

Readout on display: Channel 09 Adaptation 8963 Q

- Confirm the entry with key Q. Store changed value?

Readout on display:

- End the adjustment of the kilometre reading on the display with the key →.
- | | | |
|----------------------|------------|------|
| Channel 09 | Adaptation | 8963 |
| -> | | |
| Changed value stored | | |

the odometer. Then the dash panel insert must be replaced [→ Chapter](#).

Initiating self-diagnosis of the dash panel insert

Special tools and workshop equipment required

- t Vehicle system tester -V.A.G 1552-
- t Diagnostic cable -V.A.G 1551/3, 3A, 3B oder 3C-

Test requirements:


- t Test fuses according to current flow diagram.
- t Code dash panel insert [→ Chapter](#).

Vehicle system tester -V.A.G 1552-

Test conditions

- | Battery voltage at least 11.5 volts
- | Earth connection to engine and gearbox O.K.
- | Fuses O.K.

The diagnostic connection is located in the storage compartment on the driver's side.



Readout on display:

Note

If there is no readout on the display: [→ Operating instructions of vehicle system tester](#).

Vehicle system test

HELP

Enter address word XX

- Enter address word 17 “dash panel insert” and confirm with key Q.

After approx. 5 secs the display will show e.g.:

- t 1U0920810A: Number of the dash panel insert
- t COMBI+IMMOBILISER: Designation of component
- t VDO: Manufacturer's identification
- t X06: Software version of dash panel insert (other readouts are possible)
- t Coding 05112: Coding of the dash panel insert
- t WSC 00123: Workshop code

1U0920810A COMBI+IMMOBILISER
VDO X06

Coding 05112
00123

WSC

Reading measured value block

Readout on display:

- Select function 08 “Read measured value block” and confirm with Q.

Vehicle system test
HELP
Select function XX

Readout on display:

- Enter display group number and confirm the entry with the key Q.

Read measured value block
HELP
Enter display group
number XXX

Note

If a control element has not been fitted in accordance with the equipment, the relevant value is not displayed.

Measured value block 125

Reading measured value block 125 →			← Readout on display
Engine 1	Gearbox 1	ABS 1	
			not assigned
			ABS control unit 1 ABS 1 - CAN databus communication O.K. 1 ABS 0 - CAN databus communication N.O.K.
			Automatic gearbox control unit 1 Gearbox 1 - CAN databus communication O.K. 1 Gearbox 0 - CAN databus communication N.O.K.
			Engine control unit 1 Engine 1 - CAN databus communication O.K. 1 Engine 0 - CAN databus communication N.O.K.

Measured value block 126

Reading measured value block 126 →			← Readout on display
Steering angle 1	Airbag 1		
			not assigned
			not assigned
			Airbag control unit 1 Airbag 1 - CAN databus communication O.K. 1 Airbag 0 - CAN databus communication N.O.K.
			Steering angle 1 Steering angle 1 - CAN databus communication O.K. 1 Steering angle 0 - CAN databus communication N.O.K.

Measured value block 127

Reading measured value block 127 →			← Readout on display
FWD 1			
			not assigned

Infotainment Radio system

General Instructions

WARNING

Disconnect earth strap from the battery before commencing work on the electrical system.

Note

Additional information

[→ Operating instruction for car radio](#)

t When retrofitting equipment, carrying out repair work or fault finding

[→ Current Flow Diagrams, Electrical Fault Finding and Fitting Locations](#)

[→ Installation instruction for car radio](#)

t Detailed assembly information, e.g. detaching and attaching trim panels [→ Body Work](#).

t All radio systems are equipped with the “Key-Card” anti-theft code or “Quick-out” mounting.

Radio system with 4 loudspeakers

Bass speaker front right -3- and left -2-


t installed in the door pocket

t Diameter 168 mm


Treble speaker front right -4- and left -1-

t installed in the door at the top in the exterior
mirror trim panel

t Diameter 36 mm



S91-0009



S91-0025

- 1 - Radio
 - q removing and installing [Chapter](#)
- 2 - Cable from interface box to radio
 - q Mute
 - q Signal for door loudspeaker
- 3 - Telephone microphone -R38-
 - q in the left trim panel of pillar A
 - q removing and installing [Chapter](#)
- 4 - Treble speaker
 - q in exterior mirror trim panel on inside
 - q removing and installing [Chapter](#)
- 5 - Roof aerial for radio and mobile phone
 - q with aerial amplifier for radio
 - q removing and installing [Chapter](#)
- 6 - Aerial cable for telephone
 - q Routing along the left B pillar up to the centre console
- 7 - Bass speaker
 - q installed in door trim panel
 - q removing and installing [Chapter](#)
- 8 - Aerial cable for radio
 - q Routing along the left A pillar up to the middle of the dash panel
- 9 - Control unit for the mobile phone operating electronics -J412- (interface box)
 - q under the centre console next to the handbrake lever

X			Coding number for the country
0			Europe and other countries
X			Coding number for sound tuning
0			Basic setting
	X		Coding number for number of passive rear loudspeakers
	2		2 passive front loudspeakers
	4		4 passive loudspeakers
	X		Coding number for sound system correction
	0		no correction
	2		with correction
	X		Coding number for radio configuration
	1		Radio with active roof aerial
	3		Radio with CD changer and active roof aerial
	5		Radio with second display in dash panel insert and active roof aerial
	7		Radio with second display in dash panel insert, active roof aerial and CD changer

Table of codes (as of MY02)			
X			Coding number for the country
0			Europe
1			other countries
X			Coding number for sound tuning
0			Basic setting
X			Coding number for number of passive loudspeakers ¹⁾
0			no loudspeakers
1			1 passive loudspeaker - front left
2			2 passive loudspeakers - front
3			2 passive loudspeakers - rear
4			4 passive loudspeakers
X			Coding number for sound system correction
0			no correction
X			Coding number for radio configuration
0			Radio without active roof aerial, CD changer and CAN databus communication
1			Radio with active roof aerial (without CD changer and CAN databus communication)
2			Radio with CD changer (without active roof aerial and CAN databus communication)
3			Radio with CD changer and active roof aerial (without CAN databus communication)
4			Radio with CAN databus communication (without active roof aerial and CD changer)
5			Radio with active roof aerial and CAN databus communication (without CD changer)
6			Radio with CD changer and CAN databus communication (without active roof aerial)
7			Radio with active roof aerial, CD changer and CAN databus communication

¹⁾ at present only code numbers 2 and 4 are valid

Code radio

- Connect vehicle system tester -V.A.G 1552- and select the radio (address word 56); ignition is switched on
[→ Chapter](#).

Readout on display:

Vehicle system test

HELP

- Enter 07 for the function “Code control unit”.

Select function XX

Readout on display:

Vehicle system test

Q

- Confirm the entry with the key Q.

07 Coding control unit

coded		
	incorrect or no coding of the multi-functional steering wheel control unit - J453-	<ul style="list-style-type: none"> – Code the control unit → Chapter.

Display -V.A.G 1552-	Possible cause of fault	Rectifying fault
01336 Group convenience data bus		
t Open circuit/short-circuit to earth	t Line interruption or short-circuit	<ul style="list-style-type: none"> – Test CAN databus - Comfort → Chapter.
01341 CU in dash panel insert on CAN Comfort -J285 -		
t Open circuit/short-circuit to positive	t Wiring or plug connections defective	<ul style="list-style-type: none"> – Check wiring and plug connections according to the current flow diagram → Current flow diagrams and Fitting locations.
t Implausible signal	t Control unit in dash panel insert - J218- defective	<ul style="list-style-type: none"> – Test CAN databus → Chapter, if necessary replace control unit in dash panel insert.
01426 Operating unit in the steering wheel -E221-		
t Open circuit/short-circuit to earth	t Line interruption or short-circuit between - E221- and multi-functional steering wheel control unit - J453-	<ul style="list-style-type: none"> – Check wiring and plug connections to the multi-functional steering wheel control unit according to the current flow diagram → Current flow diagrams and Fitting locations.
65535 Control unit defective		
	t Multi-functional steering wheel control unit -J453- defective	<ul style="list-style-type: none"> – Replace multi-functional steering wheel control unit.
	t Wiring or plug connections defective	<ul style="list-style-type: none"> – Check wiring and plug connections according to the current flow diagram → Current flow diagrams and Fitting locations.

Coding multi-functional steering wheel control unit -J453-

Conduct coding

- Connect vehicle system tester -V.A.G 1552- with corresponding cable and switch on ignition.
- Enter address word 16 “Steering wheel electronics” and confirm with the key Q.

Readout on display:

- Enter function 07.
- | | |
|--------------|------------------------------------|
| 1J0907487 A | Steering wheel electronics 0002 -> |
| Coding 00119 | WSC 00000 |
- Confirm the entry with the key Q.

Readout on display:

- Enter code number by referring to table of codes and confirm the entry with the key Q.

Code control unit
 Q
 Enter code number XXXXX
 (032000)

Table of codes

Coding	Vehicle equipment
00008	Radio/cruise control system without CAN databus

Measured value block 002

Reading measured value block 2		→	← Readout on display
50 cm	20km/h	Signal off	Light OFF
			Warning light Light ON Light OFF ¹⁾
			Warning buzzer Signal on Signal off
		Vehicle speed	0 ... 300 km/h
	Minimum distance	Minimum distance of the four distances measured	

¹⁾ Also displayed if warning light not fitted.

Measured value block 003

Reading measured value block 3		→	← Readout on display
12.0 V	Rev. yes	Tr. no	activated
			Function button activated ¹⁾ not activated
			Trailer display Tr. yes Tr. no
		Reverse gear display	Rev. yes Rev. no
	Supply voltage sensors	0 ... 15 V	

¹⁾ Also displayed if function button not fitted.

Adaptation

The volume of the warning signal can be altered with the Adaptation function (channel 01):

Performing function “10 - Adaptation”

Readout on display:

- Enter address word 10 and confirm the entry with the key Q.

Vehicle system test
HELP
Select function XX

Readout on display:

- Enter 10 (channel number).

Adaptation
Enter channel number XX