



















# B HOW TO USE THIS MANUAL

\* The system shown here is an EXAMPLE ONLY. It is different to the actual circuit shown in the SYSTEM CIRCUITS SECTION.



50 — [M]

|  |   |
|--|---|
|  <p><b>RELAY</b><br/>Basically, an electrically operated switch which may be normally closed (1) or open (2). Current flow through a small coil creates a magnetic field which either opens or closes an attached switch.</p> <p><b>1. NORMALLY CLOSED</b></p> <p><b>2. NORMALLY OPEN</b></p> |  <p><b>SPEAKER</b><br/>An electromechanical device which creates sound waves from current flow.</p>  |
|  <p><b>RELAY, DOUBLE THROW</b><br/>A relay which passes current through one set of contacts or the other.</p>   | <p><b>SWITCH, MANUAL</b><br/>Opens and closes circuits, thereby stopping (1) or allowing (2) current flow.</p>  <p><b>1. NORMALLY OPEN</b></p> <p><b>2. NORMALLY CLOSED</b></p>  |
|  <p><b>RESISTOR</b><br/>An electrical component with a fixed resistance, placed in a circuit to reduce voltage to a specific value.</p>   | <p><b>SWITCH, DOUBLE THROW</b><br/>A switch which continuously passes current through one set of contacts or the other.</p>   |
|  <p><b>RESISTOR, TAPPED</b><br/>A resistor which supplies two or more different non adjustable resistance values.</p>  | <p><b>SWITCH, IGNITION</b><br/>A key operated switch with several positions which allows various circuits, particularly the primary ignition circuit, to become operational.</p>   |
|  <p><b>RESISTOR, VARIABLE or RHEOSTAT</b><br/>A controllable resistor with a variable rate of resistance. Also called a potentiometer or rheostat.</p>  | <p><b>SWITCH, WIPER PARK</b><br/>Automatically returns wipers to the stop position when the wiper switch is turned off.</p>    |
|  <p><b>SENSOR (Thermistor)</b><br/>A resistor which varies its resistance with temperature.</p>   | <p><b>TRANSISTOR</b><br/>A solidstate device typically used as an electronic relay; stops or passes current depending on the voltage applied at "base".</p>   |
|  <p><b>SENSOR, SPEED</b><br/>Uses magnetic impulses to open and close a switch to create a signal for activation of other components.<br/>(Reed Switch Type)</p>  | <p><b>WIRES</b><br/>Wires are always drawn as straight lines on wiring diagrams. Crossed wires (1) without a black dot at the junction are not joined; crossed wires (2) with a black dot or octagonal (○) mark at the junction are spliced (joined) connections.</p>  <p><b>(1) NOT CONNECTED</b></p> <p><b>(2) SPLICED</b></p> |
|  <p><b>SHORT PIN</b><br/>Used to provide an unbroken connection within a junction block.</p>  |   |
|  <p><b>SOLENOID</b><br/>An electromagnetic coil which forms a magnetic field when current flows, to move a plunger, etc.</p>  |   |



CAMRY SOLARA (EWD628U)

## System Outline

### Key Reminder System

With the ignition key inserted in the key cylinder (Unlock warning SW on), the ignition SW still off and driver's door open (Door courtesy SW on), when a signal is input to TERMINAL (A) 10 of the combination meter, the combination meter operates, current flows from TERMINAL (A) 1 of the combination meter to TERMINAL (A) 20 GROUND and key reminder buzzer sounds.

### ○ : Parts Location

| Code |   | See Page | Code |   | See Page | Code |          | See Page |
|------|---|----------|------|---|----------|------|----------|----------|
| C7   | A | 44 (C/P) | D5   |   | 50 (*1)  | J12  | A        | 45 (C/P) |
|      |   | 46 (*1)  |      |   | A        |      | 45 (C/P) | B        |
| C8   | B | 44 (C/P) | J10  | A | 47 (*1)  | U1   | 45 (C/P) |          |
|      |   | 46 (*1)  |      |   | 45 (C/P) |      | 47 (*1)  |          |
| D5   |   | 48 (C/P) | J11  | B | 47 (*1)  |      |          |          |

### ○ : Junction Block and Wire Harness Connector

| Code | See Page | Junction Block and Wire Harness (Connector Location)                     |
|------|----------|--|
| 2F   | 30       | Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)           |
| 2G   | 31       |  |
| 3A   | 36 (*2)  | Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH) |
|      | 37 (*3)  |  |
| 3B   | 36 (*2)  |  |
| 3C   | 37 (*3)  |  |

### □ : Connector Joining Wire Harness and Wire Harness


| Code | See Page | Joining Wire Harness and Wire Harness (Connector Location)                  |
|------|----------|---|
| IC1  | 56 (C/P) | Instrument Panel Wire and Floor No.1 Wire (Left Kick Panel)                 |
|      | 58 (*1)  |   |
| IF1  | 56 (C/P) | Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Brace LH) |
|      | 58 (*1)  |   |

### ▽ : Ground Points

| Code | See Page | Ground Points Location            |
|------|----------|-----------------------------------|
| IJ   | 56 (C/P) | Instrument Panel Brace LH         |
|      | 58 (*1)  |                                   |
| IM   | 56 (C/P) | Instrument Panel Reinforcement RH |
|      | 58 (*1)  |                                   |

\* 1 : Convertible    \* 2 : C/P, Convertible w/ VSC    \* 3 : Convertible w/o VSC

# Convertible Roof and Power Window



# VSC and Tire Pressure Warning System

## : Junction Block and Wire Harness Connector

| Code | See Page | Junction Block and Wire Harness (Connector Location)                |
|------|----------|---|
| 1A   | 27       | Engine Room Main Wire and Engine Room J/B (Engine Compartment Left) |
| 1B   |          |   |
| 1C   |          |   |
| 1G   |          |   |
| 2C   | 30       | Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)      |
| 2F   | 30       | Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)      |
| 2H   | 31       |   |
| 2M   | 30       |   |
| 3A   | 36 (*2)  |   |
| 3B   |          |   |

## : Connector Joining Wire Harness and Wire Harness


| Code | See Page            | Joining Wire Harness and Wire Harness (Connector Location)                    |
|------|---------------------|---|
| ID1  | 56 (C/P)<br>58 (*1) | Engine Room Main Wire and Floor No.1 Wire (Left Side of Driver Side J/B)      |
| IG4  | 56 (C/P)<br>58 (*1) | Engine Room Main Wire and Instrument Panel Wire (Behind the Radio and Player) |
| IG7  | 56 (C/P)<br>58 (*1) |   |
| IG8  | 56 (C/P)<br>58 (*1) |   |
| IM1  | 57 (C/P)<br>59 (*1) |   |
| IM2  | 57 (C/P)<br>59 (*1) |   |
| IO2  | 57 (C/P)            | Instrument Panel Wire and Floor No.2 Wire (Right Kick Panel)                  |
| IR1  | 59 (*1)             |   |

## : Ground Points

| Code | See Page            | Ground Points Location            |
|------|---------------------|-----------------------------------|
| EB   | 54 (3MZ-FE)         | Right Fender                      |
| ED   | 54 (3MZ-FE)         | Left Fender                       |
| IJ   | 56 (C/P)<br>58 (*1) | Instrument Panel Brace LH         |
| IM   | 56 (C/P)<br>58 (*1) | Instrument Panel Reinforcement RH |

\* 1 : Convertible    \* 2 : C/P, Convertible w/ VSC    \* 3 : Convertible w/o VSC

- \* 1 : C/P, Convertible w/ VSC
- \* 2 : Convertible w/o VSC
- \* 3 : w/ VSC
- \* 4 : w/o VSC



## System Outline

The cruise control system is a constant vehicle speed controller in which control of the switch on the instrument panel makes it possible to automatically adjust the opening of the engine throttle valve without depressing of the accel. pedal.

### 1. Set Operation

When the ON-OFF SW is turned on, the system starts preparations necessary for the cruise control and turns on the indicator light in the combination meter.

### 2. Set Speed Control

When the - SET SW is operated with the cruise control SW turned on during travelling, the constant vehicle speed is controlled.

### 3. Coast Control

When the - SET SW is kept turned on during cruise control travelling, the engine control module controls the throttle valve to decelerate the vehicle. Every time the - SET SW is turned on instantaneously, the vehicle speed is decelerated approximately 1.6 km/h.

### 4. Accel Control

When the + RES SW is kept turned on during cruise control travelling, the engine control module controls the throttle valve to accelerate the vehicle. Every time the + RES SW is turned on instantaneously, the vehicle speed is accelerated approximately 1.6 km/h.

### 5. Resume Control

When the vehicle speed is within the low speed limit (Approximately 40 km/h, 25 mph) if the cruise control is cancelled, use of the + RES SW accelerates the vehicle to the speed level used before canceling the cruise control.

### 6. Manual Cancel Mechanism

If any of the following signals is input during cruise control travelling, the cruise control is cancelled.

- \* The stop light SW is turned on.
- \* The CANCEL SW is turned on.
- \* The ON-OFF SW is turned off.
- \* The clutch pedla depressed (M/T).
- \* Gear is shifted from D position to N position. (A/T)
- \* Gear is shifted from 4 to 3 in S mode.

### 7. Auto Cancel Function

If any of the following conditions is encountered, the cruise control is automatically cancelled.

- \* The stop light SW wiring is faulty or short-circuited.
- \* The vehicle speed signal is faulty.
- \* The electronically controlled throttle malfunctions.

## ○ : Parts Location

| Code | See Page    | Code     | See Page | Code     | See Page |    |             |
|------|-------------|----------|----------|----------|----------|----|-------------|
| A3   | 42 (2AZ-FE) | E4       | A        | 44 (C/P) | J10      | A  | 45 (C/P)    |
| A17  | 44 (C/P)    | E5       | B        | 44 (C/P) | J11      | B  | 45 (C/P)    |
| C7   | A           | 44 (C/P) | E7       | D        | 44 (C/P) | S2 | 43 (2AZ-FE) |
| C10  | 44 (C/P)    | E8       | E        | 44 (C/P) | S12      |    | 45 (C/P)    |
| C12  | 44 (C/P)    |          | J1       | 45 (C/P) | T2       |    | 43 (2AZ-FE) |
| D3   | 44 (C/P)    |          | J2       | 45 (C/P) |          |    |             |


## ○ : Junction Block and Wire Harness Connector


| Code | See Page | Junction Block and Wire Harness (Connector Location)                     |
|------|----------|--|
| 1B   | 27       | Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)      |
| 1C   |          |  |
| 2C   | 30       | Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)           |
| 2F   | 30       | Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)           |
| 2M   |          |  |
| 3A   | 36 (*2)  | Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH) |
| 3B   |          |  |

\* 1 : Convertible    \* 2 : C/P, Convertible w/ VSC    \* 3 : Convertible w/o VSC



# ECT and A/T Indicator for 2AZ-FE





# Engine Control for 2AZ-FE

## System Outline

The engine control system utilizes a microcomputer and maintains overall control of the engine, transaxle etc. An outline of the engine control is given here.

### 1. Input Signals

(1) Engine coolant temp. signal circuit

The engine coolant temp. sensor detects the engine coolant temp. and has a built-in thermistor with a resistance, which varies according to the engine coolant temp.. The engine coolant temp. which is input into TERMINAL THW of the engine control module as a control signal.

(2) Intake air temp. signal circuit

The intake air temp. sensor is installed in the mass air flow meter and detects the intake air temp. which is input as a control signal to TERMINAL THA of the engine control module.

(3) Oxygen density signal circuit

The oxygen density in the exhaust emission is detected by the heated oxygen sensor and input as a control signal to TERMINAL OX1B of the engine control module (HT1B)

(4) RPM signal circuit

Camshaft position and crankshaft position are detected by the camshaft position sensor and crankshaft position sensor. Camshaft position is input as a control signal to TERMINAL G2+ of the engine control module, and engine RPM is input into TERMINAL NE+.

(5) Throttle position signal circuit

The throttle position sensor detects the throttle valve opening angle as a control signal, which is input into TERMINALS VTA1 and VTA2 of the engine control module.

(6) Battery signal circuit

Voltage is constantly applied to TERMINAL BATT of the engine control module. With the ignition SW turned on, the voltage for engine control module start-up power supply is applied to TERMINAL +B of the engine control module via the EFI relay.

(7) Stop light SW signal circuit

The stop light SW is used to detect whether the vehicle is braking or not and the signal is input into TERMINAL STP of the engine control module as a control signal.

(8) Starter signal circuit

To confirm whether the engine is cranking, the voltage is applied to the starter motor during cranking is detected and the signal is input into TERMINAL STA of the engine control module as a control signal.

(9) Engine knock signal circuit

Engine knocking is detected by knock sensor and the signal is input into TERMINAL KNK1 as a control signal.

(10) Air fuel ratio signal system

The air fuel ratio is detected and input as a control signal into TERMINAL A1A+ of the engine control module.

**○ : Parts Location**

| Code |   | See Page    | Code |   | See Page    | Code |   | See Page    |
|------|---|-------------|------|---|-------------|------|---|-------------|
| A1   |   | 40 (3MZ-FE) | F8   |   | 48 (C/P)    | R2   | A | 45 (C/P)    |
|      |   | 42 (2AZ-FE) |      |   | 50 (*1)     |      |   | 47 (*1)     |
| A11  | A | 44 (C/P)    | I7   | A | 41 (3MZ-FE) | R3   | B | 45 (C/P)    |
|      |   | 46 (*1)     |      | B | 43 (2AZ-FE) |      |   | 47 (*1)     |
| C5   |   | 44 (C/P)    | J2   |   | 45 (C/P)    | R6   | B | 45 (C/P)    |
|      |   | 46 (*1)     |      |   | 47 (*1)     |      |   | 47 (*1)     |
| C7   | A | 44 (C/P)    | J10  | A | 45 (C/P)    | R7   | C | 45 (C/P)    |
|      |   | 46 (*1)     |      |   | 47 (*1)     |      |   | 47 (*1)     |
| C8   | B | 44 (C/P)    | J11  | B | 45 (C/P)    | S1   |   | 41 (3MZ-FE) |
|      |   | 46 (*1)     |      |   | 47 (*1)     | S2   |   | 41 (3MZ-FE) |
| C10  |   | 44 (C/P)    | J12  | A | 45 (C/P)    |      |   | 43 (2AZ-FE) |
|      |   | 46 (*1)     |      | B | 47 (*1)     |      |   |             |

**○ : Relay Blocks**

| Code | See Page | Relay Blocks (Relay Block Location)       |
|------|----------|---|
| 1    | 24       | Engine Room R/B (Engine Compartment Left) |

**○ : Junction Block and Wire Harness Connector**


| Code | See Page | Junction Block and Wire Harness (Connector Location)                     |
|------|----------|--|
| 1L   | 27       | Engine Wire and Engine Room J/B (Engine Compartment Left)                |
| 2A   | 30       | Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)           |
| 2F   | 30       | Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)           |
| 2G   | 31       |  |
| 2K   | 30       |  |
| 3A   | 36 (*2)  |  |
|      | 37 (*3)  | Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH) |
| 3B   | 36 (*2)  |  |
| 3C   | 37 (*3)  |  |

**□ : Connector Joining Wire Harness and Wire Harness**


| Code | See Page | Joining Wire Harness and Wire Harness (Connector Location)                          |
|------|----------|---|
| IC1  | 56 (C/P) | Instrument Panel Wire and Floor No.1 Wire (Left Kick Panel)                         |
|      | 58 (*1)  |   |
| IF1  | 56 (C/P) | Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Brace LH)         |
|      | 58 (*1)  |   |
| IG6  | 56 (C/P) | Engine Room Main Wire and Instrument Panel Wire (Behind the Radio and Player)       |
|      | 58 (*1)  |   |
| IG7  | 56 (C/P) |   |
|      | 58 (*1)  |   |
| IG9  | 56 (C/P) |   |
| IH1  | 57 (C/P) | Instrument Panel No.2 Wire and Instrument Panel Wire (Behind the Radio and Player)  |
|      | 59 (*1)  |   |
| IK1  | 57 (C/P) | Instrument Panel Wire and Instrument Panel Wire (Instrument Panel Reinforcement RH) |
|      | 59 (*1)  |   |
| IK2  | 57 (C/P) |   |
| IM1  | 57 (C/P) | Engine Wire and Instrument Panel Wire (Behind the Glove Box)                        |
|      | 59 (*1)  |   |
| IM2  | 57 (C/P) |   |
|      | 59 (*1)  |   |

\* 1 : Convertible    \* 2 : C/P, Convertible w/ VSC    \* 3 : Convertible w/o VSC

# Audio System for Separate Type Amplifier without Navigation



# Engine Immobiliser System



- \* 1 : C/P, Convertible w/ VSC
- \* 2 : Convertible w/o VSC
- \* 3 : C/P
- \* 4 : Convertible
- \* 5 : 3MZ-FE
- \* 6 : 2AZ-FE

| Fuse                                 |        | System  | Page |
|--------------------------------------|--------|---|------|
| 10A                                  | ECU-B  | Seat Belt Warning   | 228  |
|                                      |        | SRS   | 185  |
|                                      |        | Theft Deterrent and Door Lock Control                             | 144  |
|                                      |        | VSC and Tire Pressure Warning System                              | 170  |
|                                      |        | Wireless Door Lock Control  | 150  |
| 10A                                  | ECU-IG | ABS and Tire Pressure Warning System                              | 178  |
|                                      |        | Automatic Glare-Resistant EC Mirror with Compass                  | 234  |
|                                      |        | Automatic Light Control   | 118  |
|                                      |        | Convertible Roof and Power Window (Convertible)                   | 164  |
|                                      |        | Fog Light   | 116  |
|                                      |        | Headlight   | 112  |
|                                      |        | Interior Light  | 122  |
|                                      |        | Light Auto Turn Off System  | 120  |
|                                      |        | Moon Roof   | 158  |
|                                      |        | Multiplex Communication System (BEAN 2AZ-FE)                      | 110  |
|                                      |        | Multiplex Communication System (CAN 3MZ-FE)                       | 104  |
|                                      |        | Power Window (Coupe)  | 160  |
|                                      |        | Theft Deterrent and Door Lock Control                             | 144  |
| VSC and Tire Pressure Warning System | 170    |   |      |
| Wireless Door Lock Control           | 150    |   |      |
| 10A                                  | FOG    | Fog Light   | 116  |
| 10A                                  | GAUGE1 | ABS and Tire Pressure Warning System                              | 178  |
|                                      |        | Back-Up Light   | 140  |
|                                      |        | Charging  | 76   |
|                                      |        | Clock   | 246  |
|                                      |        | Combination Meter   | 266  |
|                                      |        | Convertible Roof and Power Window (Convertible)                   | 164  |
|                                      |        | Cruise Control (2AZ-FE)   | 198  |
|                                      |        | Cruise Control (3MZ-FE)   | 192  |
|                                      |        | Electronically Controlled Transmission and A/T Indicator (2AZ-FE) | 212  |
|                                      |        | Electronically Controlled Transmission and A/T Indicator (3MZ-FE) | 204  |
|                                      |        | Key Reminder  | 142  |
|                                      |        | Navigation System and Audio System                                | 252  |
|                                      |        | Seat Belt Warning   | 228  |
|                                      |        | Shift Lock  | 220  |
| Turn Signal and Hazard Warning Light | 132    |   |      |
| VSC and Tire Pressure Warning System | 170    |   |      |
| 10A                                  | HTR    | Automatic Air Conditioning  | 278  |
|                                      |        | Engine Control (2AZ-FE)   | 90   |
|                                      |        | Engine Control (3MZ-FE)   | 78   |
|                                      |        | Manual Air Conditioning   | 286  |
|                                      |        | Radiator Fan and Condenser Fan                                    | 272  |
|                                      |        | Rear Window Defogger and Mirror Heater                            | 244  |

\* These are the page numbers of the first page on which the related system is shown.