

# SYSTEM INDEX

## 00 GENERAL INFORMATION

<b>R READING WIRING DIAGRAMS</b>	
VEHICLE IDENTIFICATION NUMBER (VIN) CODE.....	2
VEHICLE IDENTIFICATION NUMBERS (VIN).....	3
CONTENTS OF WIRING DIAGRAMS .....	4
GROUND POINTS .....	5
SYSTEM CIRCUIT DIAGRAM/CONNECTOR DIAGRAM .....	6
ROUTING DIAGRAM .....	8
HARNESS SYMBOLS.....	9
WIRING COLOR CODE.....	9
SYMBOLS .....	10
ABBREVIATIONS USED IN THIS MANUAL .....	12

## P ELECTRICAL SYSTEM GENERAL PROCEDURES..... 14

### POWER, GROUND & COMMON CONNECTOR

<b>E ELECTRICAL WIRING SCHEMATIC .....</b>	<b>18</b>
<b>F FUSE BOX .....</b>	<b>20</b>
<b>C COMMON CONNECTOR LIST .....</b>	<b>22</b>
<b>G GROUND POINT.....</b>	<b>30</b>

### DATA LINK CONNECTOR

<b>D DATA LINK CONNECTOR .....</b>	<b>34</b>
------------------------------------	-----------

## 01 ENGINE

<b>12 COOLING SYSTEM .....</b>	<b>38</b>
<b>14 FUEL SYSTEM .....</b>	<b>40</b>
<b>17 CHARGING SYSTEM .....</b>	<b>42</b>
<b>19 STARTING SYSTEM.....</b>	<b>44</b>
<b>20 CRUISE CONTROL SYSTEM .....</b>	<b>46</b>
<b>40 CONTROL SYSTEM .....</b>	<b>48</b>

## 03 DRIVELINE/AXLE

<b>18 4-WHEEL DRIVE</b>	
ELECTRONIC AWD CONTROL SYSTEM.....	68

## 04 BRAKES

<b>15 DYNAMIC STABILITY CONTROL (DSC) .....</b>	<b>70</b>
---	-----------

## 05 TRANSMISSION/TRANSAXLE

<b>17 AUTOMATIC TRANSAXLE</b>	
EC-AT CONTROL SYSTEM.....	74

## 07 HEATER, VENTILATION & AIR CONDITIONING (HVAC)

<b>40 CONTROL SYSTEM</b>	
HEATER AND AIR CONDITIONER SYSTEM	
MANUAL A/C .....	76
AUTO A/C .....	82
A/C COMPRESSOR CONTROL .....	88

## 08 RESTRAINTS

<b>10 AIR BAG SYSTEM</b>	
AIR BAG SYSTEM SERVICE CAUTIONS/ SERVICE WARNINGS .....	90
AIR BAG SYSTEM (INCLUDES PRE-TENSIONER SEAT BELT INFORMATION) .....	92

## 09 BODY & ACCESSORIES

<b>12 GLASS/WINDOWS/MIRRORS</b>	
REAR WINDOW DEFROSTER (INCLUDES HEATED OUTER MIRROR INFORMATION) .....	102
POWER WINDOW SYSTEM.....	104
POWER OUTER MIRROR .....	112

<b>13 SEATS</b>	
SEAT WARMER.....	114
POWER SEAT .....	116

<b>14 SECURITY AND LOCKS</b>	
IMMOBILIZER SYSTEM.....	118
KEYLESS ENTRY SYSTEM	
WITHOUT ADVANCED KEYLESS SYSTEM.....	120
WITH ADVANCED KEYLESS SYSTEM .....	122

<b>15 SUNROOF .....</b>	<b>128</b>
-------------------------	------------

<b>18 LIGHTING SYSTEMS</b>	
HEADLIGHT	
WITHOUT DRL .....	130
WITH DRL.....	134
AUTO LIGHT SYSTEM.....	140
LICENSE PLATE LIGHT .....	142
PARKING LIGHT .....	142
TAILLIGHT .....	142
FRONT FOG LIGHT .....	146
BACK-UP LIGHT .....	148
BRAKE LIGHT .....	150
HIGH-MOUNT BRAKE LIGHT.....	150
CARGO COMPARTMENT LIGHT .....	152
INTERIOR LIGHT .....	152
MAP LIGHT .....	152
HEADLIGHT LEVELING SYSTEM.....	154
ILLUMINATION LIGHT .....	156
TRAILER TOW .....	160

<b>19 WIPER/WASHER SYSTEM</b>	
WINDSHIELD WIPER AND WASHER .....	162
REAR WIPER AND WASHER.....	164

<b>20 ENTERTAINMENT</b>	
ACCESSORY SOCKET.....	166
AUDIO SYSTEM	
STANDARD TYPE AUDIO	
WITHOUT CAR-NAVIGATION SYSTEM .....	168
WITH CAR-NAVIGATION SYSTEM .....	172
Bose® TYPE AUDIO	
WITHOUT CAR-NAVIGATION SYSTEM .....	182
WITH CAR-NAVIGATION SYSTEM .....	192

<b>22 INSTRUMENTATION/DRIVER INFO.</b>	
INSTRUMENT CLUSTER.....	206
HORN .....	216
INFORMATION DISPLAY .....	218

<b>40 CONTROL SYSTEM</b>	
BCM (BODY CONTROL MODULE).....	220

## AI ALPHABETICAL INDEX

ALPHABETICAL INDEX .....	242
--------------------------	-----


## CONTENTS OF WIRING DIAGRAMS

- This manual comprises the sections shown below.

NEW						PREVIOUS	
GENERAL INFORMATION	00	R	Reading wiring diagrams	A how-to on using and reading wiring diagrams, using test equipment, checking harness and connectors, and finding trouble spots	GI	General information of wiring diagrams	
		P	Electrical system general procedures				
		E	Electrical wiring schematic	Shows main fuses and other fuses for each system	W	Electrical wiring schematic	
		F	Fuse box complete wiring system	Shows internal circuits and connectors	FB	Fuse block complete wiring system	
		J	Joint box/Junction box complete wiring system		JB	Joint box complete wiring system	
		C	Common connector list	Shows connectors common throughout system	X	Common connector list	
		G	Ground point	Ground routes from and to the battery	Y	Ground point	
		D	Data link connector		U	Data link connector	
		ENGINE	01	12	Cooling system	Shows circuit and connector diagrams and component and connector location diagrams	A
14	Fuel system			B	Engine control system		
17	Charging system			C	Gauge control system		
18	Ignition system			D	Wiper system		
19	Starting system			E	Lighting system		
20	Cruise control system			F	Signal system		
40	Control system						
SUSPENSION	02	12	Wheel and tires	G	Air-conditioning system		
DRIVELINE/AXLE	03	18	4-Wheel drive	H	Transmission control/Key interlock/Shift-lock system		
BRAKES	04	13	Antilock brake system	I	Interior light system		
		14	Traction control system	J	Audio/Radio system		
		15	Dynamic stability control	K	Power window/Power door lock system		
TRANSMISSION/TRANSAXLE	05	13	Automatic transmission		L		Remote control mirror system
		14	Automatic transmission shift mechanism		M		Sliding sunroof system
		17	Automatic transaxle		O		Anti-lock brake system
		18	Automatic transaxle shift mechanism		N	Electric power steering (EPS)	
STEERING	06	13	Electric power steering (EPS)		P	Power seat/Seat warmer system	
		14	Power steering		Q	Auto cruise control system	
HEATER, VENTILATION & AIR CONDITIONING (HVAC)	07	40	Control system		S	Air bag system	
					T	Others	
RESTRAINTS	08	10	Air bag system		Gives page number of circuit diagram for each component	AI	Alphabetical Index
		11	Seat belt				
BODY & ACCESSORIES	09	12	Glass/Windows/Mirrors				
		13	Seats				
		14	Security and locks				
		15	Sunroof				
		18	Lighting systems				
		19	Wiper/Washer system				
		20	Entertainment				
		21	Power systems				
		22	Instrumentation/Driver info.				
AI	Alphabetical Index						

Depending on the vehicle model, the actual sections may be different.


- Connectors can be disconnected by pressing or pulling the lock lever as shown.



WGIWXX0042E

## Locking Connector


- When locking connectors, listen for a click indicating they are securely locked.



X3U000WB1

## Inspection

- When a tester is used to inspect for continuity or measuring voltage, insert the tester probe from the wiring harness side.




WGIWXX0044E

- Inspect the terminals of waterproof connectors from the connector side since they cannot be accessed from the wiring harness side.


## Caution

- To prevent damage to the terminal, wrap a thin wire around the tester probe before inserting into terminal.




WGIWXX0045E


\* : VACANT



<div>0918-701</div> <div>BRAKE SWITCH NO.2(F)</div> <div></div>	<div>0922-202</div> <div>CLOCK SPRING(I)</div> <div></div>	<div>0922-203</div> <div>CRUISE CONTROL SWITCH(CLOCK SPRING)</div> <div></div>	

Refer to 00F section and 00C section for FUSE BOX and COMMON CONNECTOR LIST.






## AIR BAG SYSTEM

### AIR BAG SYSTEM SERVICE WARNINGS

id081000800200

#### Air Bag Module Inspection


- Inspecting an air bag module using a tester can operate (deploy) the air bag module, which may cause serious injury. Do not use a tester to inspect an air bag module. Always use the on-board diagnostic function to diagnose the air bag module for malfunctions.



acxuuvw00001174


#### Air Bag Module Handling

- Before removing the air bag module or disconnecting the air bag module connector, always turn the ignition switch to the LOCK position, disconnect the negative battery cable, and then wait for 1 min or more to allow the backup power supply of the SAS control module to deplete its stored power.
- Handling a live (undeployed) air bag module that is pointed toward your body could result in serious injury if the air bag module were to accidentally operate (deploy). When carrying a live (undeployed) air bag module, point the deployment surface away from your body to lessen the chance of injury in case it operates (deploys).



acxuuvw00001175

- A live (undeployed) air bag module placed with its deployment surface to ground is dangerous. If the air bag module were to accidentally operate (deploy), it could cause serious injury. Always place a live (undeployed) air bag module with its deployment surface up.



acxuuvw00001176

#### Side Air Bag Module Handling

- Before removing the side air bag module or disconnecting the side air bag module connector, always turn the ignition switch to the LOCK position, disconnect the negative battery cable, and then wait for 1 min or more to allow the backup power supply of the SAS control module to deplete its stored power.
- When a side air bag module operates (deploys) due to a collision, the interior of the seat back (pad, frame, trim) may become damaged. If a side air bag does not operate (deploy) normally from a seat back that has been reused, a serious accident may result. After a side air bag has operated (deployed), always replace both the side air bag module and the seat back (pad, frame, trim) with new parts. After servicing, verify that the seat operates normally and that the wiring harness is not caught.

#### Seat Weight Sensor Handling

- The passenger-side seat and the seat weight sensor may become deformed or otherwise damaged due to operation (deployment) of the front or side air bag in an accident. This may cause the passenger sensing function to operate improperly and result in a serious accident. Always replace the passenger seat and seat weight sensor with new ones after the front or side air bags have operated (deployed). After servicing, verify that the seat operates normally and that the wiring harness is not caught. If the collision is not hard enough to cause the front or side air bags to operate (deploy), inspect the seat weight sensor and replace it if there is any malfunction.

#### SAS Control Module Handling


- Removing the SAS control module or disconnecting the SAS control module connector with the ignition switch at the ON position can activate the sensor in the SAS control module and operate (deploy) the air bags and pre-tensioner seat belts, which may cause serious injury. Before removing the SAS control module or disconnecting the SAS control module connector, always turn the ignition switch to the LOCK position, disconnect the negative battery cable, and then wait for 1 min or more to allow the backup power supply of the SAS control module to deplete its stored power.
- Connecting the SAS control module connector with the SAS control module not securely fixed to the vehicle is dangerous. The sensor in the SAS control module could send an electrical signal to the air bag modules and pre-tensioner seat belts. This will operate (deploy) the air bags and pre-tensioner seat belts, which may result in serious injury. Therefore, before connecting the connector, securely fix the SAS control module to the vehicle.
- Because a sensor is built into the SAS control module, once the air bags and pre-tensioner seat belts have operated (deployed) due to a collision or other causes, the SAS control module must be replaced with a new one even if the used one does not have any visible external damage or deformation. The used SAS control module may have been damaged internally, which may cause improper operation. If the SAS control module is reused, the air bags and pre-tensioner seat belts may not operate (deploy) normally, which could result in a serious accident. Always replace the SAS control module with a new one. The SAS control module cannot be bench-checked or self-checked.

#### Crash Zone Sensor Handling

- Removing the crash zone sensor or disconnecting the crash zone sensor connector with the ignition switch at the ON position can activate the crash zone sensor and operate (deploy) the air bags and pre-tensioner seat belts, which may cause serious injury. Before removing the crash zone sensor or disconnecting the crash zone sensor connector, always turn the ignition switch to the LOCK position, disconnect the negative battery cable, and then wait for 1 min or more to allow the backup power supply of the SAS control module to deplete its stored power.
- If the crash zone sensor is subjected to shock or the sensor is disassembled, the air bags and pre-tensioner seat belts may accidentally operate (deploy) and cause injury, or the system may fail to operate normally and cause a serious accident. Do not subject the crash zone sensor to shock or disassemble the sensor.
- Because a sensor is built into the crash zone sensor, once the air bags and pre-tensioner seat belts have operated (deployed) due to a collision or other causes, the crash zone sensor must be replaced with a new one even if the used one does not have any visible external damage or deformation. If the crash zone sensor is reused, the air bags and pre-tensioner seat belts may not operate (deploy) normally, which could result in a serious accident. Always replace the crash zone sensor with a new one. The crash zone sensor cannot be bench-checked or self-checked.

REAR WINDOW DEFROSTER (INCLUDES HEATED OUTER MIRROR INFORMATION)

0912-1




0912-102 FILAMENT(R2)	0912-103 HEATED OUTER MIRROR RH(DR2)	0912-104 HEATED OUTER MIRROR LH(DR1)	

Refer to 00F section and 00C section for FUSE BOX and COMMON CONNECTOR LIST.









SEAT WARMER

0913-1



\* : VACANT

114


0913-101	0913-102																				
SEAT WARMER SWITCH LH(SHORT CORD)	SEAT WARMER SWITCH RH(SHORT CORD)																				
<table><tr><td>O/Y</td><td></td><td>B/L</td></tr><tr><td>H</td><td>P</td><td>*</td></tr><tr><td>P</td><td></td><td>B</td></tr></table>	O/Y		B/L	H	P	*	P		B	<table><tr><td>O/L</td><td></td><td>B/Y</td></tr><tr><td>H</td><td>P/W</td><td>*</td></tr><tr><td>P/W</td><td></td><td>B</td></tr></table>	O/L		B/Y	H	P/W	*	P/W		B		
O/Y		B/L																			
H	P	*																			
P		B																			
O/L		B/Y																			
H	P/W	*																			
P/W		B																			

Refer to 00F section and 00C section for FUSE BOX and COMMON CONNECTOR LIST.

HEADLIGHT (WITHOUT DRL)


0918-1b

\*: VACANT








Refer to 00F section and 00C section for FUSE BOX and COMMON CONNECTOR LIST.

HARNESS SYMBOL :  (F)  (R)




\* : VACANT



<div>0918-1001</div> <div>SPOT LIGHT(IN)</div> <div></div> <div>(WITH SPOT LIGHT)</div>	<div>0415-02</div> <div>TCS OFF SWITCH ILLUMINATION(I)</div> <div></div>	<div>0922-202</div> <div>CLOCK SPRING(I)</div> <div></div>	<div>0922-203</div> <div>AUDIO CONTROL SWITCH ILLUMINATION/ CRUISE CONTROL SWITCH ILLUMINATION(CLOCK SPRING)</div> <div></div> <div>TERMINALS OF THIS CONNECTOR ARE INDICATED BY NUMBERS.</div>

Refer to 00F section and 00C section for FUSE BOX and COMMON CONNECTOR LIST.

HARNESS SYMBOL :  (F)  (R)



HARNESS SYMBOL :  (F)  (R)

