

ENGINE


4M40

CONTENTS

GENERAL INFORMATION	11A- 0- 3	14. CAMSHAFT AND VALVES	11A-14- 1
1. SPECIFICATIONS	11A- 1- 1	15. OIL COOLER AND OIL FILTER	11A-15- 1
GENERAL SPECIFICATIONS	11A- 1- 1	16. OIL PAN, OIL STRAINER	
SERVICE SPECIFICATIONS	11A- 1- 2	AND OIL JET	11A-16- 1
TORQUE SPECIFICATIONS	11A- 1- 6	17. VACUUM PUMP	11A-17- 1
SEALANT	11A- 1-10	18. TIMING GEAR CASE	11A-18- 1
2. SPECIAL TOOLS	11A- 2- 1	19. TIMING GEAR AND	
3. GENERATOR ASSEMBLY	11A- 3- 1	BALANCE SHAFT	11A-19- 1
4. COOLING FAN, V-BELT		20. OIL PUMP	11A-20- 1
AND WATER PUMP	11A- 4- 1	21. FUEL INJECTION NOZZLE	11A-21- 1
5. THERMOSTAT	11A- 5- 1	22. FUEL INJECTION	
6. WATER HOSES AND PIPES	11A- 6- 1	PUMP ASSEMBLY	11A-22- 1
7. COOLANT TEMPERATURE		23. FUEL INJECTION PUMP GEAR	11A-23- 1
SENSOR	11A- 7- 1	24. PISTON AND CONNECTING	
8. GLOW PLUG	11A- 8- 1	ROD ASSEMBLY	11A-24- 1
9. TURBOCHARGER ASSEMBLY	11A- 9- 1	25. PISTON AND PISTON PIN	11A-25- 1
10. TURBOCHARGER	11A-10- 1	26. FLYWHEEL	11A-26- 1
11. INTAKE MANIFOLD	11A-11- 1	27. DRIVE PLATE	11A-27- 1
12. EXHAUST MANIFOLD	11A-12- 1	28. CRANKSHAFT AND	
13. ROCKER COVER AND		CRANKCASE	11A-28- 1
CYLINDER HEAD ASSEMBLY	11A-13- 1		

GENERAL INFORMATION

SECTIONAL VIEW








TORQUE SPECIFICATION

	Torque		
	Nm	kgm	ft.lbs.
Cooling fan V-belt and water pump			
Cooling fan nut	10	1.0	7
Auto-cooling fan coupling nut	24	2.4	17
Water pump bolt	24	2.4	17
Water hoses and pipes			
Turbocharger water outlet pipe.....	26	2.6	19
Turbocharger water inlet pipe	26	2.6	19
Engine coolant temperature sensor.....	9	0.9	7
Coolant temperature sensor			
Coolant temperature sensor	40	4.0	29
Glow plug			
Connection plate	10*1, 1.8*2	1.0*1, 0.18*2	7*1, 1.3*2
Glow plug	18	1.8	13
Turbocharger assembly			
Eyebolt.....	20	2.0	14
Coupler insulator nut	50	5.0	36
Turbocharger nut	50	5.0	36
Turbocharger bolt	55	5.5	40
Turbocharger water outlet pipe.....	26	2.6	19
Turbocharger water inlet pipe	26	2.6	19
Turbocharger			
Coupling nut.....	4.5	0.45	3.3
Intake manifold			
Relief valve.....	48	4.8	35
Exhaust manifold			
Exhaust manifold bolt.....	30	3.0	22
Exhaust manifold nut.....	31	3.1	22
Rocker cover and cylinder head assembly			
Rocker cover bolt	4	0.4	3
Cam sprocket bolt	Left-hand thread	9.0	65
Cylinder head bolt			
M12	50 + 1/4 turns + 1/4 turns	5.0 + 1/4 turns + 1/4 turns	36 + 1/4 turns + 1/4 turns
M8	24	2.4	17
Camshaft and valve			
Camshaft cap bolt.....	20	2.0	14
Glow plug	18	1.8	13
Fuel injection nozzle	55	5.5	40
Water joint.....	48	4.8	35
Oil cooler and oil filter			
Oil cooler element nut.....	20	2.0	14
Bypass plug.....	45	4.5	33
Regulator plug	45	4.5	33
Turbocharger water inlet pipe	26	2.6	19

NOTE

*1: Except PAJERO 2001 Model

*2: PAJERO 2001 Model



INSPECTION

AUTO-COOLING FAN COUPLING

- (1) Check the auto-cooling fan coupling **4**, and replace if any of the following conditions exists:
 - (a) Hydraulic fluid is leaking from the hermetically sealed housing.
 - (b) The coupling turns irregularly or produces an abnormal sound when rotated by hand due to defective inside bearing.
 - (c) The coupling has an excessive axial play when moved with the engine in a cold state.

V-BELT

- (1) Push the V-belt **5** at its midpoint with a force of approximately 98 N (10 kg, 22 lbs.) as shown and read the amount of deflection **A**.
- (2) If the reading deviates from the specified standard value, accomplish the following adjustment.
- (3) Loosen the bolt and nut **B** holding the generator, and adjust the tension of the V-belt **5** using the adjusting bolt **C**.

Caution


- Be sure to retighten the bolt and nut securely after the adjustment.
- Excessive tension damages not only the V-belt **5** itself but bearings elsewhere.
- Be sure to replace the V-belt **5**, when necessary, in pairs and keep it slush-free.

CLEANING

- (1) Remove foreign matters, if any, from the bimetal **A** using care not to apply unnecessary force to it.

6. WATER HOSES AND PIPES

REMOVAL AND INSTALLATION (FOR L200 and PAJERO except 1998– model for Europe)




Removal steps

1. Heater return pipe
- ◆A◆ 2. O-ring
3. Water inlet hose
4. Water inlet pipe
5. Water hose <with W-CSD>
6. Water pipe <with W-CSD>
7. Water hose <with W-CSD>
8. Water hose <with W-CSD>
9. Water outlet pipe
10. Gasket

NOTE
W-CSD: Wax type cold start device

04291

REMOVAL AND INSTALLATION (FOR CHALLENGER)



Removal steps


- | | |
|-----------------------------------|---|
| 1. Turbocharger water outlet pipe | ◆B◆ 8. Water hose |
| 2. Turbocharger water inlet pipe | 9. Water outlet pipe |
| 3. Heater return pipe | 10. Gasket |
| ◆A◆ 4. O-ring | *1: Injection pump assembly |
| ◆B◆ 5. Water hose | *2: Thermostat assembly (See page 11A-5-1.) |
| 6. Water pipe | *3: Turbocharger assembly (See page 11A-9-2.) |
| ◆B◆ 7. Water hose | *4: Oil cooler assembly (See page 11A-15-1.) |

4ME0069


11. INTAKE MANIFOLD REMOVAL AND INSTALLATION

<Turbo: EXCEPT PAJERO 2001MODEL>

<Non-turbo>



04317



04316

Removal steps


1. Vacuum hose <with EGR>
2. Vacuum pipe <with EGR>
3. EGR pipe <with EGR>
4. EGR valve <with EGR>
Cover <without EGR>
5. Relief valve
6. Intake manifold
7. Gasket

- *1. Vacuum pipe
- *2. Exhaust manifold

◀B▶ CYLINDER HEAD GASKET REMOVAL

Caution

- Remove the cylinder head gasket **14** using care not to scratch the cylinder head assembly **13**, crankcase assembly ***5** and timing gear case assembly ***4**.



INSTALLATION SERVICE POINTS

▶A▶ CYLINDER HEAD GASKET INSTALLATION

- Choose a cylinder head gasket **14** having an appropriate thickness that meets the piston protrusion. The following thicknesses of gaskets are available. They are identified by the notches at an end of the gasket.

Measure the piston protrusions and calculate their average, and select an appropriate gasket thickness from the following table.


If a piston protrudes 0.03 mm larger than the average, use one-size thicker gasket.

PAJERO

Piston protrusion		Cylinder head gasket	
Average piston protrusion	Crankcase identification mark	Classification	Thickness when tightened
0.475 ± 0.028 mm (0.0187 ± 0.0011 in.)	A	A (1 notch)	1.35 ± 0.03 mm (0.0531 ± 0.0012 in.)
0.532 ± 0.028 mm (0.0209 ± 0.011 in.)	B	B (2 notches)	1.40 ± 0.03 mm (0.0551 ± 0.0012 in.)
0.589 ± 0.028 mm (0.0232 ± 0.011 in.)	C	C (3 notches)	1.45 ± 0.03 mm (0.0571 ± 0.0012 in.)
0.646 ± 0.028 mm (0.0254 ± 0.011 in.)	D	D (4 notches)	1.50 ± 0.03 mm (0.0591 ± 0.0012 in.)


L200

Piston protrusion		Cylinder head gasket	
Average piston protrusion	Crankcase identification mark	Classification	Thickness when tightened
0.575 ± 0.028 mm (0.0226 ± 0.0011 in.)	A	A (1 notch)	1.35 ± 0.03 mm (0.0531 ± 0.0012 in.)
0.632 ± 0.028 mm (0.0249 ± 0.011 in.)	B	B (2 notches)	1.40 ± 0.03 mm (0.0551 ± 0.0012 in.)
0.689 ± 0.028 mm (0.0271 ± 0.011 in.)	C	C (3 notches)	1.45 ± 0.03 mm (0.0571 ± 0.0012 in.)
0.746 ± 0.028 mm (0.0293 ± 0.011 in.)	D	D (4 notches)	1.50 ± 0.03 mm (0.0591 ± 0.0012 in.)



VALVE AND VALVE GUIDE

- (1) If the clearance exceeds the specified service limit, replace the defective part.




VALVE AND VALVE SEAT

- (1) Apply an even coat of minium to the valve seating surface **A** of the valve seat **25, 26**.
- (2) Strike the valve **16, 17** against the valve seat **25, 26** once while taking care that the valve is not rotated.

B: Valve Lapper


NOTE

Before proceeding with the contact check, examine the valve **16, 17** and valve guide **23, 24** in detail to see if they are in normal condition. (See 11A-14-5,6.)



- (3) Determine the valve seating condition from minium pattern printed on the valve **16, 17**. If any abnormal contact is found, take the following corrective action.

	Corrective action
Minor defect	Lap valve for better seating.
Major defect	Correct or replace valve and valve seat.



VALVE SEAT


Valve Seat Width

- (1) If the specified service limit is exceeded, replace the valve seat **25, 26**.

D: Valve seat width

NOTE

When the valve seat **25, 26** has been corrected or replaced, lap it and the valve **16, 17** for proper seating. (See page 11A-14-6.)




Valve Sinkage from Cylinder Head Bottom

- (1) If the specified service limit is exceeded, correct or replace the defective part.

E: Valve sinkage

REMOVAL AND INSTALLATION (1998- PAJERO for Europe)




Removal steps

- 1. Air hose
- ▶A 2. Oil pressure switch
- 3. Connector
- 4. Eyebolt
- 5. Oil pipe
- 6. O-ring
- 7. Vacuum pump assembly


- 8. Cylinder assembly
- 9. O-ring
- 10. Vane
- 11. Rotor
- 12. Flange assembly

*: Timing gear case (See 11A-18-1.)

21. FUEL INJECTION NOZZLE REMOVAL AND INSTALLATION



Part Assembly Sequence for Fuel Injection Nozzle Assembly 5.



04008

INSPECTION

FUEL INJECTION NOZZLE ASSEMBLY


- (1) Install the nozzle tester to the fuel injection nozzle assembly 5 and perform the following checks:


Caution

- Prior to proceeding with the checks, bleed air from the fuel injection nozzle by pumping the nozzle tester lever two or three times.

28. CRANKSHAFT AND CRANKCASE

REMOVAL AND INSTALLATION



 Apply engine oil to all moving parts before installation.

Removal steps

1. Bolt
- ◆G◆ 2. Front plate
3. Stiffener
4. Stiffener RH
5. Stiffener LH
6. Bolt
7. Rubber spacer
8. Dust cover
9. Rear plate
10. Bolt
- ◆H◆ 11. Rear oil seal
- ◆H◆ 12. Rear oil seal case
13. Crankcase assembly
- ◇A◇ ◆F◆ 14. Bolt
- ◇A◇ ◆F◆ 15. Main bearing cap bolt
- ◆D◆ 16. Lower main bearing


- ◆E◆ 17. Lower crankcase
- ◆C◆ 18. Lower thrust plate
19. Crankshaft assembly
20. Front oil seal slinger
- ◇B◇ ◆B◆ 21. Crankshaft gear
22. Key
- ◆A◆ 23. Rear oil seal slinger
24. Crankshaft
- ◆C◆ 25. Upper thrust plate
- ◆D◆ 26. Upper main bearing
27. O-ring
28. Upper crankcase

*1: Check valve (See page 11A-16-1.)


*2: Oil jet (See page 11A-16-1.)

*3: Idler shaft (See page 11A-19-1.)

A: Dowel pin

**UPPER CRANKCASE TOP DISTORTION**


- (1) If the measured value exceeds the limit, replace the upper crankcase.

**MAIN BEARING****Caution**


- Be sure not to use the main bearings **16** and **26** expanded forcibly.
- When either the main bearing **16** or **26** is defective, replace them in pairs.

Free Span

- (1) Measure the free span of each of the main bearings **16** and **26**. If the reading for either bearing or both exceeds the specified service limit, replace them in pairs.

**Main Bearing-to-Crankshaft Clearance**



- (1) If the reading is less than the specified service limit, replace defective part.

**INSTALLATION SERVICE POINTS****▶▶ REAR OIL SEAL SLINGER INSTALLATION**

- (1) Drive the rear oil seal slinger **23** onto the crankshaft **24** using the special tool until it completely contacts the rear end of the crankshaft.

▶B▶ CRANKSHAFT GEAR INSTALLATION

- (1) Before installing, heat the crankshaft gear **21** to approximately 100°C (212°F) with a piston heater or the like.



▶C▶ THRUST PLATE INSTALLATION

- (1) Install the thrust plates **18** and **25** to the crankshaft assembly **19** at No.5 journal only.

Caution

- Install the thrust plates **18** and **25** with the oil groove **A** oriented outward.
- If the oversize thrust plates are to be used, be sure to use the same size of upper thrust plate **25** and lower thrust plate **18** at one side. However, using the same size of upper (or lower) thrust bearings on both sides is not necessary.

▶D▶ MAIN BEARING INSTALLATION

- (1) The main bearings **16** and **25** must have a proper plate thickness that matches the difference between the bearing mounting hole I.D. of the crankcase assembly **13** and the journal O.D. of the crankshaft **24**.

- (a) Measure the bearing mounting hole I.D. of the crankcase assembly **13** and the journal O.D. of the crankshaft **24**.
A: Measuring point (One point in vertical direction for crankcase)

Caution

- Tighten the main bearing cap bolts **15** by specified procedure before measuring the bearing mounting hole I.D. of the crankcase assembly **13**. (Refer to 11A-28-1.)
- For the service parts, the above dimensions can be identified by the identification colors or identification marks on the crankcase and crankshaft.

B: Identification color position

C: Identification mark position

D: Identification mark position (rear right of the crankcase)

- (b) Select an appropriate thickness of the main bearings **16** and **26** from the following table.

E: Identification color position (side)

F: Lug

G: Oil hole

Caution

- The main bearing **16** and **26** must be installed in the specified direction. The main bearings for No. 3 journal are different in thickness from the others.
- The upper main bearing **26** for No. 3 journal is different in shape from the others.

Unit: mm (in.)

Crankshaft		Crankcase		Main bearing			
Identification color (Identification mark)	Journal O.D.	Size mark	Bearing mounting hole I.D.	Identification color (L/U)	Journal No.	Plate Thickness	Oil Clearance
None (1)	68 (2.68) -0.022 (-0.0009) -0.030 (-0.0012)	A	72 (2.83) +0.019 (0.0007) +0.010 (0.0004)	Black/ Black	No. 1,2,4,5	2 (0.08) -0.004 (-0.0002) -0.008 (-0.0003)	0.040 – 0.065 (0.0016 – 0.0026)
					No. 3	2 (0.08) -0.014 (-0.0006) -0.018 (-0.0007)	0.060 – 0.085 (0.0024 – 0.0033)
		B	72 (2.83) +0.010 (+0.0004) +0 (+0)	Blue/Blue	No. 1,2,4,5	2 (0.08) -0.008 (-0.0003) -0.012 (-0.0005)	0.038 – 0.064 (0.0015 – 0.0025)
					No. 3	2 (0.08) -0.018 (-0.0007) -0.022 (-0.0009)	0.058 – 0.084 (0.0023 – 0.0033)
Blue (2)	68 (2.68) -0.030 (-0.0012) -0.039 (-0.0015)	A	72 (2.83) +0.019 (0.0007) +0.010 (0.0004)	Yellow/ Yellow	No. 1,2,4,5	2 (0.08) -0 (-0) -0.004 (-0.0002)	0.040 – 0.066 (0.0016 – 0.0026)
					No. 3	2 (0.08) -0.010 (-0.0004) -0.014 (-0.0006)	0.060 – 0.086 (0.0024 – 0.0034)
		B	72 (2.83) +0.010 (+0.0004) +0 (+0)	Black/ Black	No. 1,2,4,5	2 (0.08) -0.004 (-0.0002) -0.008 (-0.0003)	0.038 – 0.065 (0.0015 – 0.0026)
					No. 3	2 (0.08) -0.014 (-0.0006) -0.018 (-0.0007)	0.058 – 0.085 (0.0023 – 0.0033)

L: Lower main bearing U: Upper main bearing

⇨E⇩ LOWER CRANKCASE INSTALLATION

- Apply an even bead of sealant **A** to the illustrated position of the upper crankcase **28**. [Bead diameter: 2 ± 1 mm (0.08 ± 0.04 in.)]
- Install the lower crankcase **17** to the upper crankcase **28** within 15 minutes after the application of sealant **A**.

Caution

- Be sure that the surface to be coated with sealant **A** is clean and free of slush and other foreign matters.
- When installing the lower crankcase, be sure that sealant **A** does not smear the surroundings.
- After the lower crankcase is installed, wait for at least one hour before starting the engine.
- Remove and reinstall the lower crankcase with fresh bead of sealant **A** whenever the main bearing cap bolts **15** were loosened or removed after the installation.

- After installing the lower crankcase **17**, verify the following:
Smooth rotation of the crankshaft assembly **19**
End play of the crankshaft assembly **19** within specified service limit (See page 11A-28-5.)

