


SERVICE MANUAL FOR ENGINE

VOLVO D13F



- General information
- Engine
- Cylinder head
- Valve mechanism

MOTO
RIST

Table of contents

03 SPECIFICATIONS

030 General

Tightening torque, cylinder head	6
Engine, specification	6
General	6
Cylinder block, specifications	7
Engine transmission, tightening torque	7
Tightening torques	7
Timing gear casing	9
Tightening torques, flywheel housing WLO/EXC	11
Tightening torques, timing gear plate	11
Engine transmission, specification	12
Rocker arm shaft, tightening torques	13
Valve mechanism, specifications	14
Valve mechanism, tightening torques	16
Tightening torques, valve cover	16
Oil sump, tightening torque	16
Oil cooler, tightening torques	17
Oil cooler	17
Oil cooler, cover	17
Cylinder block, tightening torques	18
Engine mount incl. bracket	18
Ladder frame	19
Inlet	19
Tightening torque, fuel system	21
Exhaust manifold, tightening torques	21
Turbocharger, tightening torques	21
Crank mechanism, specifications	23
Crankshaft, tightening torques	25
Flywheel, tightening torques	26
Belt pulley/vibration damper, tightening torques	27

21 ENGINE

210 General, common info about 211 - 218

Engine, mounting in work stand	28
Engine, dismantling	32
Cylinder liners, removing	39
Engine, assembling	40
Cylinder liners, installing	41
Crankshaft, installing	43
Pistons, installing	44
Installing timing gear plate	45
Flywheel housing	49
Crankshaft seal, rear	50
Front crankshaft seal	51
Speed (rpm) sensor, adjusting	54
Engine, removing from work stand	56

211 Cylinder head

Cylinder head, removing	59
Cylinder head, reconditioning	62
Installing in work stand	62
Valves, removing	63
Sleeve for unit injector, removing	64
Tap out with drift	65
Pull out with puller	65
Valve guide, checking	67
Valve guides, changing	68

Injector sleeve, installing	69
Cylinder head, checking for leaks	71
Valve seat, checking	73
Valve seat, cleaning soot and grinding	73
Valve seat, changing	73
Valves, grinding	74
Cylinder head, assembling	74
Cylinder head, fitting	76
212 Cylinder block with crankcase ventilation	
Cylinder block, liners removed, milling of all liner locations	82
214 Valve mechanism	
Valves, adjusting	88
Inlet valves, checking and adjusting	89
Unit injectors, adjusting	89
Exhaust valves, checking and adjusting	90
22 LUBRICATING SYSTEM	
223 Oil cooler	
Oil cooler, leakage check	91

Tightening torque, cylinder head




Fig.1 Cylinder head, D13

NOTE!


Tighten the bolts in the sequence shown in the figure.

Step 1	100±5Nm(74±3.7 lbf ft)
Step 2	120±5° Angle-tightening
Step 3	90±5° Angle-tightening

Engine, specification

General

	D13 F
Number of cylinders	6
Cylinder bore	131 mm (5.16 in)
Stroke	158 mm (6.22 in)
Displacement	12.78 litres (3.38 US gal)
Injection order	1-5-3-6-2-4
Compression ratio	18, 5:1
Low idle EXC WLO	13.33 r/s (800 rpm) 11.67 r/s (700 rpm)
High idle EXC WLO	28.33 r/s (1700 rpm) 31.67 r/s (1,900 rpm)
Max. full load rpm EXC WLO	31.67 r/s (1,900 rpm) 35 r/s (2,100 rpm)
Weight, engine EXC WLO	1,330 kg (3,042 lbs) 1,330 kg (3,042 lbs)
Total length EXC WLO	1 585 mm (62.4 in) 1460 mm (57.5 in)



V1071860

Fig.2

Gears:	Tightening torque:
1. Drive gear, crankshaft	24±4 Nm (18±3 lbf ft)
2. Transfer gear, outer gear:	
step 1:	25±3 Nm (18.4±2.2 lbf ft)
step 2:	angle-tightening 110±5°
3. Transfer gear, adjustable:	
step 1:	35±4 Nm (25.8±2.95 lbf ft)
step 2:	angle-tightening 120° ±5°
4. Gear, camshaft: Vibration damper's 8.8-bolts may not be reused.	
temporarily:	10 Nm (7.5 lbf ft)
step 1:	45±5 Nm (33±4 lbf ft)
step 2: Angle-tightening	90° ±5°
5. Transfer gear	140±10 Nm (103±7.4 lbf ft)
6. Drive gear, lubrication oil pump for power take-off and fuel feed pump	100±10 Nm (74±7.4 lbf ft)

Cylinder block, tightening torques

Engine mount incl. bracket




Fig.14 Front engine mount bracket

Front engine mount bracket, cylinder block:	
Step 1: Tighten bolt 1.	80 ±15 Nm (59 ±11 lbf ft)
Step 2: Tighten bolts 2 — 4.	105±15 Nm (77.4±11 lbf ft)
Step 3: Angle-tighten bolts 2 — 4 in numerical order	60 ±5°
Step 4: Tighten bolt 1	105±15 Nm (77.4±11 lbf ft)
Step 5: Angle-tighten bolt 1	60 ±5°
Step 6: Tighten bolt 5	Standard bolt tightening torque
Front engine mount to frame	140±25 Nm (103.3±18.4 lbf ft)
Rear engine mount, flywheel housing:	
EXC	262±26 Nm (193.2±19 lbf ft)





Fig.15 Front engine mount

Front engine mount to engine mount bracket	
Step 1: Tighten bolts 6 – 11	5 ±2 Nm (3.7 ±1.5 lbf ft)
Step 1: Tighten bolts 6 – 11	275 ±45 Nm (203 ±33 lbf ft)

Ladder frame



V1099956

Fig.16 Ladder frame

Ladder frame	
Step 1: Tighten bolts 1 — 24 in numerical order	45±5 Nm (33.19±3.69 lbf ft)
Step 2: Tighten bolts in numerical order 1 — 24 (angle-tightening)	60 ±5°
Timing gear plate:	
M8-bolts	28±4 Nm (20.7±2.95 lbf ft)
Main bearing caps:	
Step 1	150±20 Nm (110.6±14.8 lbf ft)
Step 2 (angle-tightening)	120 ±5°
Connecting rod (big-end) caps:	
Step 1	20±3 Nm (14.8±2.2 lbf ft)
Step 2	60±3 Nm (44.3±2.2 lbf ft)
Step 3 (angle-tightening)	90 ±5°
Press tool for measuring liner height	40 Nm (29.5 ft lbf)

Inlet

NOTE!

Tighten the bolts according to the numerical order in the figure.
The bolts shall not be reused.




Fig.38

- 1 Sling 1 metre
- 2 M10 Lifting eye




Fig.39

- 1 Ladder frame
- 2 Pipes for lubrication oil pump
- 3 Strainer




Fig.40

- 1 Oil cooler



Fig.41

- 19 Remove the flywheel.
Weight:
WLO **approx. 40 kg (88 lbs)**
EXC **approx. 75 kg (165 lbs)**
- 20 Install lifting eyes on the flywheel housing and secure it.
- 21 Loosen the bolts on the flywheel housing and then lift away the flywheel housing.
Flywheel housing, weight: **approx. 200 kg (441 lbs)**
- 22 Rotate the engine 180°.
- 23 - Remove the strainer and the pipes for the lubrication oil pump.
- Remove the ladder frame.
- 24 Rotate back the engine 180°.
- 25 Remove the oil cooler.
- 26 Rotate the engine 180°.
- 27 Remove the casing with the front crankshaft seal.
- 28 Remove the lubrication oil pump.
- 29 Remove the transfer gear for the fuel pump.
- 30 Loosen and remove the bolts that hold the double gear (6 pcs.). Remove the double gear.




Fig.42

1 Internal puller

- 31
- Remove the rest of the bolts for the crankshaft gear.
 - Install an internal puller as shown in the figure.
 - Pull out and remove the gear.




Fig.43

1 9998267 Guide.
2 Bracket

- 32
- Install 9998267 Guide (2 pcs.) and remove the bracket and bolts (23 pcs.) that hold the timing gear plate.
 - Carefully remove the timing gear plate.




Fig.44

1 Piston cooling nozzle

- 33 Remove the piston cooling nozzles.




Fig.45

V1022057

- 34 - Remove the bolts (4 pcs.), the caps, and carefully tap loose the piston and connecting rod.

NOTE!

Avoid striking on the connecting rod's mating surfaces.

- Repeat for the rest of the pistons and connecting rods.




Fig.46

V1090912

- 35 - Remove the bolt and remove the main bearing cap.
- Repeat for the rest of the main bearing caps. Note position of the main bearing caps for reinstalling later on.

NOTE!

Save and keep track of the thrust bearings located on the 4th cylinder's main bearing.

- 1 9996400 Impact puller, 9990114 Puller and 9990262 Adapter



Fig.47

V1095362

- 36 Turn the crankshaft so that the 1st cylinder's and 6th cylinder's bellcranks are positioned straight up. Secure with lift slings in the lifting device and lift away the shaft.
Crankshaft, weight: **approx. 125 kg (275 lbs).**
Remove the main bearings.




Fig.93

- 1 Bracket for AC-compressor and alternator




Fig.94

- 1 Seal




Fig.95 Inlet manifold with preheating coil, oil filler pipe, oil dipstick.

66 Install the bracket for the AC-compressor and the alternator.

67 Change seals and install the fuel pump.

68 Change seal on the inlet manifold.
Install the inlet manifold and connect to the mixing chamber.
Tightening torques, see *Cylinder block, tightening torques page 18*

69 Install the oil filler pipe and oil dipstick.

70 Remove the engine from the work stand according to
Engine, removing from work stand page 56.

Engine, removing from work stand

Op. no. 210-082

Tools:

9986485 Support

88800345 Fixture

88800123 Fixture

Lifting eye, 2 pcs.

Sling 3 m (118 in)

Ratchet block 1,500 kg (3307 lbs)

NOTE!

Since the engine illustrations in the service publications are reused for different engine versions, some parts may vary from the version in question. However, the essential information in the illustrations is always correct.

Engine D13F, weight:

WLO approx. 1,330 kg (3,932 lbs)




Fig.102

- 1 Rocker arm bridge
- 2 88800352 Lifting tool

- 3 Connect 88800352 Lifting tool and remove the rocker arm bridge.
Rocker arm bridge, weight: **approx. 48 kg (106 lbs).**




Fig.103

1. Lifting tool

- 4
 - Rotate the engine to reach the bolt behind the adjustable transfer gear.
 - Put some paper in place to prevent dropping bolts down in the timing gear.
 - Remove the bolts from the plate.
 - Remove the bolts from the adjustable transfer gear.




Fig.104

- 1 Bolt behind adjustable transfer gear
- 2 Paper
- 3 Plate




Fig.106

- 1 88800058 Fixture
- 2 9986485 Support

2

WARNING

Risk of crushing injuries

Lift up the cylinder head with 9996239 Lifting chain and secure it to 9986485 Support.
Cylinder head, weight **approx. 240 kg (530 lbs)**

NOTICE

It is important that the greatest cleanliness is exercised when working with the cylinder head.
Dirt particles in fuel and oil ducts may cause breakdown of the unit injectors.

- 3 Connect 9998264 Lifting tool to the camshaft and lift away the camshaft.
Camshaft, weight: **approx. 34 kg (75 lbs)**.
- 4 Remove the thermostat cover and the thermostat.
- 5 Remove the unit injectors.




Fig.107

- 1 Thermostat
- 2 Thermostat cover




Fig.108

- 1 Manifold

- 6 Remove the manifold.
Manifold, weight: **approx. 15 kg (33 lbs)**

Valves, removing

- 7 Remove 9998251 Sealing plug from the cylinder head.




Fig.109

1 9990210 Valve spring compressor




Fig.110

- 8 Install 9990210 Valve spring compressor in the sleeve and fasten it in the holes for the unit injector's attaching bolts.
- 9 Press down the valve washer and remove the collets.
- 10 Remove the valve washer, springs, and valves.
- 11 Remove the rest of the valves in the same way.

NOTE!

Place the valves together with their associated springs so that they can be reinstalled in the same place in the cylinder head when assembling.

- 12 Remove the valve seals.


Sleeve for unit injector, removing

NOTE!

The injector sleeve must be free from soot.

There are two methods for removing the injector sleeve.

1. Tap out with drift
2. Pull out with 88800342 Puller and 9986173 Puller.



V1104835

Fig.111

Sleeve for unit injector

Tap out with drift

- 13 Tap out the injector sleeve with a 10 mm (0.394 in) drift.




Fig.112




Fig.113

- 1 9998250 Ring

- 14 Install two 9998250 Ring in the cylinder head's fuel channel to protect against dirt.




Fig.114

- 1 Puller, included in kit 88800342 Puller.
2 Support ring, included in kit 88800342 Puller.

Pull out with puller

- 15 Install 88800342 Puller and press down so that it bottoms out in the sleeve, a 'click' sound can be heard. On the tool there is a line marking at a depth of 66 mm. If the tool sinks down so deep that the line cannot be seen, it may be difficult to pull up the sleeve since it indicates that it has been deformed. Tighten down the tool. Tighten the expander by tightening the nut until it stops.



V1092175

Fig.168 Centring roller

- 5 Press down the lock clamp and place the centring roller against the liner seat's wall, where the distance to the wall is the longest.
- 6 Lock the lock clamp and set the switch between position 1 and 2.



V1092150

Fig.169

- 7 Centre the tool by turning the crank clockwise while holding the horizontal feed ring in place.
- 8 The centring roller shall always have contact with the liner position's wall.
If the tool loses contact with the wall:
Turn the crank backwards (counter-clockwise) while holding the horizontal feed ring in place.
- 9 The tool is centred when it stops moving.
- 10 Then set the switch to position 1.
- 11 Press down the lock clamp.



V1092151

Fig.170

- 12 Move the cutter so that it passes over the liner shelf without touching the liner wall.