

TROUBLE DIAGNOSIS — INDEX

Alphabetical & P No. Index for DTC

Alphabetical & P No. Index for DTC

NDEC0001

NDEC0001S01

ALPHABETICAL INDEX FOR DTC

| Items (CONSULT-II screen terms) | DTC*1 | Reference page |
|------------------------------------|---------|----------------|
| Unable to access ECM | — | EC-103 |
| ABSL PRES SEN/CIRC | P0105 | EC-143 |
| AIR TEMP SEN/CIRC | P0110 | EC-154 |
| A/T 1ST GR FNCTN | P0731 | AT-127 |
| A/T 2ND GR FNCTN | P0732 | AT-133 |
| A/T 3RD GR FNCTN | P0733 | AT-139 |
| A/T 4TH GR FNCTN | P0734 | AT-145 |
| A/T COMM LINE | P0600*2 | EC-377 |
| A/T DIAG COMM LINE | P1605 | EC-474 |
| ATF TEMP SEN/CIRC | P0710 | AT-110 |
| A/T TCC S/V FNCTN | P0744 | AT-159 |
| CLOSED LOOP-B1 | P1148 | EC-396 |
| CLOSED TP SW/CIRC | P0510 | EC-369 |
| CMP SEN/CIRCUIT | P0340 | EC-302 |
| COOLANT T SEN/CIRC*3 | P0115 | EC-160 |
| *COOLANT T SEN/CIRC | P0125 | EC-177 |
| CKP SENSOR COG | P1336 | EC-421 |
| CKP SEN/CIRCUIT | P0335 | EC-296 |
| CYL 1 MISFIRE | P0301 | EC-285 |
| CYL 2 MISFIRE | P0302 | EC-285 |
| CYL 3 MISFIRE | P0303 | EC-285 |
| CYL 4 MISFIRE | P0304 | EC-285 |
| CYL 5 MISFIRE | P0305 | EC-285 |
| CYL 6 MISFIRE | P0306 | EC-285 |
| ECM | P0605 | EC-382 |
| ENGINE SPEED SIG | P0725 | AT-123 |
| ENG OVER TEMP | P1217 | EC-398 |
| EVAP GROSS LEAK | P0455 | EC-348 |
| EVAP PURG FLOW/MON | P1447 | EC-444 |
| EVAP SMALL LEAK | P0440 | EC-315 |
| EVAP SMALL LEAK | P1440 | EC-427 |
| EVAP SYS PRES SEN | P0450 | EC-340 |
| FUEL SYS-LEAN/BK1 | P0171 | EC-265 |
| FUEL SYS-RICH/BK1 | P0172 | EC-273 |
| FUEL TEMP SEN/CIRC | P0180 | EC-280 |

GI

MA

EM

LC

EC

FE

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION

Fuel Cut Control (at no load & high engine speed)

Fuel Cut Control (at no load & high engine speed)

DESCRIPTION

Input/Output Signal Chart

NDEC0017

NDEC0017S01

| Sensor | Input Signal to ECM | ECM function | Actuator |
|-----------------------------------|----------------------------|------------------|-----------|
| Vehicle speed sensor | Vehicle speed | Fuel cut control | Injectors |
| Park/Neutral position switch | Neutral position | | |
| Throttle position sensor | Throttle position | | |
| Engine coolant temperature sensor | Engine coolant temperature | | |
| Camshaft position sensor | Engine speed | | |

If the engine speed is above 2,500 rpm with no load (for example, in neutral and engine speed over 2,500 rpm) fuel will be cut off after some time. The exact time when the fuel is cut off varies based on engine speed. Fuel cut will operate until the engine speed reaches 2,000 rpm, then fuel cut is cancelled.


NOTE:

This function is different from deceleration control listed under “Multiport Fuel Injection (MFI) System”, EC-24.

Evaporative Emission System

DESCRIPTION

NDEC0018



The evaporative emission system is used to reduce hydrocarbons emitted into the atmosphere from the fuel system. This reduction of hydrocarbons is accomplished by activated charcoals in the EVAP canister. The fuel vapor in the sealed fuel tank is led into the EVAP canister which contains activated carbon and the vapor is stored there when the engine is not operating or when refueling to the fuel tank.

The vapor in the EVAP canister is purged by the air through the purge line to the intake manifold when the engine is operating. EVAP canister purge volume control solenoid valve is controlled by ECM. When the engine operates, the flow rate of vapor controlled by EVAP canister purge volume control solenoid valve is proportionally regulated as the air flow increases.

EVAP canister purge volume control solenoid valve also shuts off the vapor purge line during decelerating and idling.

- IACV-AAC valve
- e. Water hoses for
- Throttle body
- Air relief plug
- f. EVAP canister purge hose
- 5. Remove injector fuel tube assembly.
The following parts should be disconnected or removed.
- Vacuum hose for fuel pressure regulator
- Fuel feed and return hose
- All injectors harness connectors
- **Push injector tail piece.**
- **Do not pull on connector.**
- **Do not extract injector by pinching.**

GI

MA

EM

LC

EC

FE

AT

AX

SU

BR

ST

RS


BT

HA


SC

EL

IDX




6. Push out any malfunctioning injector from injector fuel tube.
7. Replace or clean injector as necessary.
- **Always replace O-rings with new ones.**
- **Lubricate O-rings with engine oil.**
8. Install injector to injector fuel tube assembly.



9. Install injectors with fuel tube assembly to intake manifold.
Tighten in numerical order shown in the figure.
 - a. First, tighten all bolts to 4.9 to 6.0 N-m (0.5 to 0.61 kg-m, 3.6 to 4.4 ft-lb).
 - b. Then, tighten all bolts to 10.8 to 14.7 N-m (1.1 to 1.5 kg-m, 8 to 11 ft-lb).
10. Reinstall any part removed in reverse order of removal.

CAUTION:

After properly connecting fuel hose to injector and fuel tube, check connection for fuel leakage.



Fast Idle Cam (FIC)

INSPECTION AND ADJUSTMENT

With CONSULT-II



1. Turn ignition switch "ON".
2. See "COOLAN TEMP/S" in "DATA MONITOR" mode with CONSULT-II.

NDEC0026

NDEC0026S01

BASIC SERVICE PROCEDURE

Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment (Cont'd)

| | | |
|---|---|----------------|
| 10 | CHECK HEATED OXYGEN SENSOR 1 (FRONT) SIGNAL | |
| <div><div></div><div>With CONSULT-II</div></div> <div><div>1. Start engine and warm it up to normal operating temperature.</div><div>2. Run engine at about 2,000 rpm for about 2 minutes under no-load.</div><div>3. See “HO2S1 MNTR (B1)” in “DATA MONITOR” mode.</div><div>4. Running engine at 2,000 rpm under no-load , check that the monitor fluctuates between “LEAN” and “RICH” more than 5 times during 10 seconds.</div></div> <div><div>1 time: RICH → LEAN → RICH</div><div>2 times: RICH → LEAN → RICH → LEAN → RICH</div></div> | | |
| <div><div></div><div>Without CONSULT-II</div></div> <div><div>1. Start engine and warm it up to normal operating temperature.</div><div>2. Run engine at approx. 2,000 rpm for approx. 2 minutes under no-load.</div><div>3. Set voltmeter probe between ECM terminal 50 and ground.</div><div>4. Make sure that the voltage fluctuates between 0 - 0.3V and 0.6 - 1.0V more than 5 times during 10 seconds at 2,000 rpm.</div></div> <div><div>1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V</div><div>2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V</div></div> <div>OK or NG</div> | | |
| OK | ▶ | INSPECTION END |
| NG | ▶ | GO TO 11. |

| | | |
|---|--|--|
| 11 | CHECK HEATED OXYGEN SENSOR 1 (FRONT) HARNESS | |
| <div>1. Turn off engine and disconnect battery ground cable.</div> <div>2. Disconnect ECM harness connector.</div> <div>3. Disconnect heated oxygen sensor 1 (front) harness connector.</div> <div>4. Check harness continuity between ECM terminal 50 and heated oxygen sensor 1 (front) harness connector. Refer to Wiring Diagram, EC-186.</div> <div>Continuity should exist.</div> <div>OK or NG</div> | | |
| OK | ▶ | <div>1. Connect ECM harness connector.</div> <div>2. GO TO 13.</div> |
| NG | ▶ | GO TO 12. |

| | | |
|---|---------------------|----------|
| 12 | FIX THE MALFUNCTION | |
| <div>1. Repair or replace harness between ECM and heated oxygen sensor 1 (front).</div> <div>2. Connect ECM harness connector.</div> <div>3. Disconnect throttle position sensor harness connector.</div> <div>4. Start engine.</div> | | |
| | ▶ | GO TO 5. |

DTC P0120 THROTTLE POSITION SENSOR

Description

Description

NDEC0073

NOTE:


If DTC P0120 is displayed with DTC P0510, first perform the trouble diagnosis for DTC P0510, refer to EC-369.

COMPONENT DESCRIPTION

NDEC0073S01

The throttle position sensor responds to the accelerator pedal movement. This sensor is a kind of potentiometer which transforms the throttle position into output voltage, and emits the voltage signal to the ECM. In addition, the sensor detects the opening and closing speed of the throttle valve and feeds the voltage signal to the ECM.

Idle position of the throttle valve is determined by the ECM receiving the signal from the throttle position sensor. This sensor controls engine operation such as fuel cut. On the other hand, the "Wide open and closed throttle position switch", which is built into the throttle position sensor unit, is not used for engine control.



CONSULT-II Reference Value in Data Monitor Mode

NDEC0074

Specification data are reference values.

| MONITOR ITEM | CONDITION | | SPECIFICATION |
|---------------|---|------------------------------|--------------------|
| THRTL POS SEN | <ul style="list-style-type: none">Engine: After warming upIgnition switch: ON (Engine stopped) | Throttle valve: fully closed | 0.15 - 0.85V |
| | | Throttle valve: fully opened | Approx. 3.5 - 4.7V |
| ABSOL TH-P/S | <ul style="list-style-type: none">Engine: After warming upIgnition switch: ON (Engine stopped) | Throttle valve: fully closed | 0.0% |
| | | Throttle valve: fully opened | Approx. 80% |

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION


Emission-related Diagnostic Information (Cont'd)

Driving Pattern

NDEC0030S0303

Note: Always drive vehicle in safe manner according to traffic conditions and obey all traffic laws. Refer to next page for more information and explanation of chart.

Driving pattern



GI
MA
EM
LC
EC
FE
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Emission-related Diagnostic Information (Cont'd)

maximum or minimum value and is compared with the test value being monitored.

Items for which these data (test value and test limit) are displayed are the same as SRT code items (30 test items).

These data (test value and test limit) are specified by Test ID (TID) and Component ID (CID) and can be displayed on the GST screen.

X: Applicable —: Not applicable

| SRT item | Self-diagnostic test item | Test value (GST display) | | Test limit | Application |
|------------------|---|--------------------------|-----|------------|-------------|
| | | TID | CID | | |
| CATALYST | Three way catalyst function | 01H | 01H | Max. | X |
| | | 02H | 81H | Min. | X |
| EVAP SYSTEM | EVAP control system (Small leak) | 05H | 03H | Max. | X |
| | EVAP control system purge flow monitoring | 06H | 83H | Min. | X |
| O2 SENSOR | Heated oxygen sensor 1 (front) | 09H | 04H | Max. | X |
| | | 0AH | 84H | Min. | X |
| | | 0BH | 04H | Max. | X |
| | | 0CH | 04H | Max. | X |
| | | 0DH | 04H | Max. | X |
| | Heated oxygen sensor 2 (rear) | 19H | 86H | Min. | X |
| | | 1AH | 86H | Min. | X |
| | | 1BH | 06H | Max. | X |
| | | 1CH | 06H | Max. | X |
| O2 SENSOR HEATER | Heated oxygen sensor 1 heater (front) | 29H | 08H | Max. | X |
| | | 2AH | 88H | Min. | X |
| | Heated oxygen sensor 2 heater (rear) | 2DH | 0AH | Max. | X |
| | | 2EH | 8AH | Min. | X |


EMISSION-RELATED DIAGNOSTIC INFORMATION ITEMS

X: Applicable —: Not applicable NDEC0030S05

| Items (CONSULT-II screen terms) | DTC*1 | SRT code | Test value/ Test limit (GST only) | 1st trip DTC*1 | Reference page |
|---|--------------|----------|---|----------------|----------------|
| NO SELF DIAGNOSTIC FAILURE INDICATED | P0000 | — | — | — | — |
| MAF SEN/CIRCUIT | P0100 | — | — | X | EC-134 |
| ABSL PRES SEN/CIRC | P0105 | — | — | X | EC-143 |
| AIR TEMP SEN/CIRC | P0110 | — | — | X | EC-154 |
| COOLANT T SEN/CIRC | P0115 | — | — | X | EC-160 |
| THRTL POS SEN/CIRC | P0120 | — | — | X | EC-166 |
| *COOLAN T SEN/CIRC | P0125 | — | — | X | EC-177 |
| HO2S1 (B1) | P0130 | X | X | X*2 | EC-183 |
| HO2S1 (B1) | P0131 | X | X | X*2 | EC-191 |
| HO2S1 (B1) | P0132 | X | X | X*2 | EC-197 |

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Generic Scan Tool (GST)




Generic Scan Tool (GST) DESCRIPTION

=NDEC0034

NDEC0034S01

Generic Scan Tool (OBDII scan tool) complying with SAE J1978 has 8 different functions explained on the next page. ISO9141 is used as the protocol.


The name "GST" or "Generic Scan Tool" is used in this service manual.



GST INSPECTION PROCEDURE


NDEC0034S02

1. Turn ignition switch OFF.
2. Connect "GST" to data link connector for GST. (Data link connector for GST is located under LH dash panel near the fuse box cover.)



3. Turn ignition switch ON.
4. Enter the program according to instruction on the screen or in the operation manual.

(*: Regarding GST screens in this section, sample screens are shown.)




5. Perform each diagnostic mode according to each service procedure.

For further information, see the GST Operation Manual of the tool maker.

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION


Major Sensor Reference Graph in Data Monitor Mode (Cont'd)




- "THRTL POS SEN" should increase while depressing the accelerator pedal and should decrease while releasing it.



- "HO2S2 (B1)" may increase immediately after depressing the accelerator pedal and may decrease after releasing the pedal.



- "HO2S1 (B1)" may increase immediately after depressing the accelerator pedal and may decrease after releasing the pedal.




- "INJ PULSE-B1" should increase when depressing the accelerator pedal and should decrease when the pedal is released.


SEF242YA

TROUBLE DIAGNOSIS FOR POWER SUPPLY

Main Power Supply and Ground Circuit (Cont'd)

| | |
|--|------------------------------|
| 6 | CHECK POWER SUPPLY-II |
| 1. Stop engine. 2. Check voltage between ECM terminal 80 and ground with CONSULT-II or tester. | |
|  <p>Voltage: Battery voltage</p> <p>OK or NG</p> | |
| OK | ▶ GO TO 8. |
| NG | ▶ GO TO 7. |

| | |
|---|-----------------------------------|
| 7 | DETECT MALFUNCTIONING PART |
| Check the following. <ul style="list-style-type: none"> ● Harness connectors E53, F2 ● 10A fuse ● Harness for open or short between ECM and fuse | |
| | ▶ Repair harness or connectors. |

| | |
|---|-------------------------------|
| 8 | CHECK POWER SUPPLY-III |
| 1. Turn ignition switch "ON" and then "OFF". 2. Check voltage between ECM terminals 67, 72, 117 and ground with CONSULT-II or tester. | |
|  <p>Voltage: After turning ignition switch "OFF", battery voltage will exist for a few seconds, then drop to approximately 0V.</p> <p>OK or NG</p> | |
| OK | ▶ GO TO 14. |
| NG (Battery voltage does not exist.) | ▶ GO TO 9. |
| NG (Battery voltage exists for more than a few seconds.) | ▶ GO TO 13. |

DTC P0105 ABSOLUTE PRESSURE SENSOR

DTC Confirmation Procedure

DTC Confirmation Procedure

Perform "PROCEDURE FOR MALFUNCTION A" first. If the 1st trip DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION B".

If the 1st trip DTC is not confirmed on "PROCEDURE FOR MALFUNCTION B", perform "PROCEDURE FOR MALFUNCTION C".

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

| | | |
|---|--------------|---------|
| 3 | DATA MONITOR | |
| | MONITOR | NO DTC |
| | ENG SPEED | XXX rpm |
| | | |

SEF058Y

| | | |
|---|---------------|---------|
| 4 | DATA MONITOR | |
| | MONITOR | NO DTC |
| | ENG SPEED | XXX rpm |
| | COOLAN TEMP/S | XXX °C |

SEF174Y

| | | |
|---|---------------|----------|
| 7 | DATA MONITOR | |
| | MONITOR | NO DTC |
| | ENG SPEED | XXX rpm |
| | VHCL SPEED SE | XXX km/h |
| | B/FUEL SCHDL | XXX msec |
| | ABSOL PRES/SE | XXX V |

SEF936Z

PROCEDURE FOR MALFUNCTION A

NDEC0057S01

With CONSULT-II

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT-II.
- 3) Wait at least 6 seconds.
- 4) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-147.

With GST

- Follow the procedure "With CONSULT-II".

PROCEDURE FOR MALFUNCTION B

NDEC0057S02

With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch "OFF" and wait at least 5 seconds.
- 3) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
- 4) Start engine and let it idle.
- 5) Wait at least 15 seconds.
- 6) If 1st trip DTC is detected, go to "Diagnostic Procedure", EC-147.

With GST

- Follow the procedure "With CONSULT-II".

PROCEDURE FOR MALFUNCTION C

NDEC0057S03

CAUTION:

Always drive vehicle at a safe speed.

With CONSULT-II

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT-II.
The voltage of "ABSOL PRES/SE" should be more than 1.74 [V].
If the check result is NG, go to "Diagnostic Procedure", EC-147.
If the check result is OK, go to following step.



DTC P0105 ABSOLUTE PRESSURE SENSOR

Wiring Diagram


Wiring Diagram

NDEC0058

EC-AP/SEN-01



Refer to the following.
(F12), (F201) - SUPER MULTIPLE JUNCTION (SMJ)



WEC062

DTC P0110 INTAKE AIR TEMPERATURE SENSOR



Wiring Diagram

Wiring Diagram

NDEC0064

EC-IATS-01

— : Detectable line for DTC
 — : Non-detectable line for DTC



AEC602A

DTC P0120 THROTTLE POSITION SENSOR

Diagnostic Procedure (Cont'd)

| | | |
|--|--------------------------------|-----------------------------------|
| 13 | CHECK CAMSHAFT POSITION SENSOR | |
| Refer to “Component Inspection”, EC-308. | | |
| OK or NG | | |
| OK | ▶ | GO TO 14. |
| NG | ▶ | Replace camshaft position sensor. |

GI

MA

EM

| | | |
|--|---------------------|------------------------|
| 14 | CHECK FUEL INJECTOR | |
| Refer to “Component Inspection”, EC-489. | | |
| OK or NG | | |
| OK | ▶ | GO TO 15. |
| NG | ▶ | Replace fuel injector. |

LC

EC

| | | |
|--|----------------------|-----------|
| 15 | CHECK SHIELD CIRCUIT | |
| 1. Disconnect harness connectors F12, F201. 2. Check harness continuity between harness connector F201 and engine ground. Continuity should exist. 3. Also check harness for short to power. | | |
| OK or NG | | |
| OK | ▶ | GO TO 17. |
| NG | ▶ | GO TO 16. |

FE

AT

AX

SU

| | | |
|---|----------------------------|---|
| 16 | DETECT MALFUNCTIONING PART | |
| Check the following. <ul style="list-style-type: none">● Harness connectors F12, F201● Harness for open or short between harness connector F12 and engine ground | | |
| | ▶ | Repair open circuit or short to power in harness or connectors. |

BR

ST

RS

| | | |
|---|-----------------------------|----------------|
| 17 | CHECK INTERMITTENT INCIDENT | |
| Refer to "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT", EC-126. | | |
| | ▶ | INSPECTION END |

BT

HA

SC

EL

IDX

| DATA MONITOR | |
|---------------|---------|
| MONITOR | NO DTC |
| ENG SPEED | XXX rpm |
| COOLAN TEMP/S | XXX °C |
| THRTL POS SEN | XXX V |

SEF179Y

Component Inspection THROTTLE POSITION SENSOR

NDEC0080

NDEC0080S01

④ With CONSULT-II

- 1) Start engine and warm it up to normal operating temperature.
- 2) Stop engine and turn ignition switch "ON".
- 3) Select "DATA MONITOR" mode with CONSULT-II.
- 4) Check voltage of "THRTL POS SEN".

Voltage measurement must be made with throttle position sensor installed in vehicle

SERVICE DATA AND SPECIFICATIONS (SDS)

Fuel Pressure Regulator

Fuel Pressure Regulator

NDEC0371

| Condition | Fuel pressure at idling kPa (kg/cm ² , psi) |
|-----------------------------|--|
| Vacuum hose is connected | Approximately 235 (2.4, 34) |
| Vacuum hose is disconnected | Approximately 294 (3.0, 43) |

Idle Speed and Ignition Timing

NDEC0372

| | | |
|--|------------------------------------|-------------|
| Base idle speed*1 rpm | No-load*4 (in "P" or "N" position) | 700±50 |
| Target idle speed*2 rpm | No-load*4 (in "P" or "N" position) | 750±50 |
| Air conditioner: ON rpm | In "P" or "N" position | 800 or more |
| Ignition timing*3 | In "P" or "N" position | 15°±2° BTDC |
| Throttle position sensor idle position V | | 0.15 - 0.85 |

*1: Throttle position sensor harness connector disconnected or using CONSULT-II "WORK SUPPORT" mode

*2: Throttle position sensor harness connector connected

*3: Throttle position sensor harness connector disconnected

*4: Under the following conditions:

- Air conditioner switch: OFF
- Electrical load: OFF (Lights, heater fan & rear window defogger)
- Steering wheel: Kept in straight-ahead position

Ignition Coil

NDEC0373

| | |
|---------------------------------------|----------------------------|
| Primary voltage | 12V |
| Primary resistance [at 20°C (68°F)] | Approximately 0.49 - 0.59Ω |
| Secondary resistance [at 20°C (68°F)] | Approximately 10 kΩ |

Mass Air Flow Sensor

NDEC0374

| | |
|--------------------------------------|---|
| Supply voltage | Battery voltage (11 - 14)V |
| Output voltage at idle | 1.0 - 1.7V |
| Mass air flow (Using CONSULT or GST) | 3.3 - 4.8 g·m/sec at idle* 12.0 - 14.9 g·m/sec at 2,500 rpm* |

*: Engine is warmed up sufficiently and running under no-load.

Engine Coolant Temperature Sensor

NDEC0375

| Temperature °C (°F) | Resistance kΩ |
|---------------------|---------------|
| 20 (68) | 2.1 - 2.9 |
| 50 (122) | 0.68 - 1.00 |
| 90 (194) | 0.236 - 0.260 |

Heated Oxygen Sensor 1 Heater (Front)

NDEC0377

| | |
|-----------------------------|------------|
| Resistance [at 25°C (77°F)] | 2.3 - 4.3Ω |
|-----------------------------|------------|

Fuel Pump

NDEC0378

| | |
|-----------------------------|------------|
| Resistance [at 25°C (77°F)] | 0.2 - 5.0Ω |
|-----------------------------|------------|

IACV-AAC Valve

NDEC0379

| | |
|-----------------------------|---------------------|
| Resistance [at 20°C (68°F)] | Approximately 10.0Ω |
|-----------------------------|---------------------|