

# DODGE RAM 68RFE



## INDEX

<i>IDENTIFICATION TAG INFORMATION &amp; FLUID REQUIREMENTS</i> .....	3
<i>COMPONENT LOCATIONS AND CLUTCH APPLICATION CHART</i> .....	4
<i>SOLENOID OPERATION AND APPLICATION CHART</i> .....	5
<i>ELECTRICAL AND LIMP-IN MODE OPERATION</i> .....	6
<i>SOLENOID DESCRIPTION</i> .....	7
<i>WIRE SCHEMATIC</i> .....	11
<i>CASE CONNECTOR TERMINAL IDENTIFICATION</i> .....	12
<i>CONTROLLER LOCATION</i> .....	13
<i>CONTROLLER CONNECTOR TERMINAL IDENTIFICATION</i> .....	14
<i>CLUTCH VOLUME INDEX INFORMATION</i> .....	16
<i>AIR PRESSURE TESTS</i> .....	18
<i>EXTERNAL SENSOR LOCATIONS</i> .....	19
<i>TRANSMISSION RANGE SENSOR/SOLENOID BODY</i> .....	20
<i>DIAGNOSTIC TROUBLE CODES</i> .....	22
<i>CHECKBALL LOCATIONS</i> .....	25
<i>PRESSURE TAP LOCATIONS AND TEST PROCEDURES</i> .....	26
<i>ACCELERATOR PEDAL POSITION SENSOR INFORMATION, 6.7L DIESEL</i> .....	28
<i>CONVERTER CLUTCH OPERATION</i> .....	29
<i>CASE &amp; OIL PUMP PASSAGE IDENTIFICATION</i> .....	30
<i>TRANSMISSION DISASSEMBLY</i> .....	32
<b>COMPONENT REBUILD SECTION</b>	
<i>EXTENSION HOUSING</i> .....	44
<i>TRANSMISSION CASE ASSEMBLY</i> .....	44
<i>LOW/REVERSE CLUTCH HOUSING ASSEMBLY</i> .....	46
<i>2-4 CLUTCH RETAINER ASSEMBLY</i> .....	53
<i>GEAR TRAIN ASSEMBLY</i> .....	56
<i>INPUT CLUTCH HOUSING ASSEMBLY</i> .....	60
<i>OIL PUMP ASSEMBLY</i> .....	72
<i>VALVE BODY ASSEMBLY</i> .....	78
<i>TRANSMISSION FINAL ASSEMBLY</i> .....	90
<i>SETTING REAR TRANSMISSION END-PLAY</i> .....	95
<i>SETTING FRONT TRANSMISSION END-PLAY</i> .....	97
<i>CLEARANCE SPECIFICATIONS AND BOLT IDENTIFICATION</i> .....	105
<i>THRUST BEARING IDENTIFICATION</i> .....	106
<i>TORQUE SPECIFICATIONS</i> .....	108
<i>SPECIAL TOOLS</i> .....	109
<i>HEAVY DUTY LOW ROLLER CLUTCH</i> .....	112

# Technical Service Information

## **DODGE RAM TRUCKS 68RFE TRANSMISSION** **FOUND BEHIND 5.9L (L6) and 6.7L Diesel Engines**

*Bar Code Label*



*ID Numbers Also Etched Into  
Case Pan Rail Here*

**1777 20548 P52119704AB**  
Build Date Serial Number Part Number

**6 = Six Forward Speeds**

**8 = Relative Torque Capacity**

**R = Rear Wheel Drive**

**FE = Fully Electronic**

**Fluid Requirements**  
**"Mopar® ATF+4"**

Figure 1

# Technical Service Information

## OUTPUTS FROM THE TCM

**Transmission Control Relay** - is located in the Integrated Power Distribution Module (IPDM), as shown in Figure 8, and receives a ground signal from terminal (C1) 18 at the TCM to close the relay. Refer to the wiring schematic in Figure 10.

**Underdrive Solenoid** - is *normally applied* and controls oil to the Underdrive Clutch in 1st, 2nd, 3rd, and 4th gears of the transmission.

**Overdrive Solenoid** - is *normally vented* and controls oil to the Overdrive Clutch in 4th, 5th, and 6th gears in the transmission.

**4th Clutch Solenoid** - is *normally vented* and controls oil to the 4th clutch in 3rd and 5th gears in the transmission.

**2nd Clutch Solenoid** - is *normally vented* and controls oil to the 2nd clutch in 2nd and 6th gears in the transmission.

**Low/Reverse Solenoid** - is *normally vented* and is used to apply the Low/Reverse clutch in 1st gear from Park or Neutral, or a coast down to 1st gear. This solenoid also controls oil pressure for the converter clutch engagement based on switch valve position.

**Multi-Select Solenoid** - is *normally applied* and controls the Overdrive Clutch in 4th gear Limp-in, and the Low/Reverse clutch for reverse block. This solenoid is Off below 8 MPH, On above 8 MPH.

**Line Pressure Solenoid** - is *normally vented* and is used to control all oil pressures in the transmission.

**Note:** Refer to Page 20 for a solenoid resistance chart for all solenoids.

## DIAGNOSIS AND SERVICE INFORMATION

You have been provided with the 23-way case connector pin cavity identification and pin function in Figure 11. The 38-way Diesel NGC/TCM connector pin cavity identification and pin function is shown in Figure 13 and 14. A complete transmission wiring schematic is provided in Figure 10, and transmission control relay location in the power distribution center is shown in Figure 9.

Special tools that might be needed are illustrated on Page 26 and 27, along with the identification of the pressure taps that are available on the main valve body. Air pressure test passage identification is provided for you in Figure 17.




Figure 8

# Technical Service Information

## 68RFE OIL PUMP BODY AND GEARS




Figure 16



# Technical Service Information

## 68RFE CASE PASSAGE IDENTIFICATION





Figure 30



# Technical Service Information




Figure 37

## TRANSMISSION DISASSEMBLY (CONT'D)

9. Remove the 12 extension housing to case retaining bolts using a 15mm socket and then remove the extension housing, as shown in Figure 37.
10. Remove the park gear snap ring from the output shaft and remove the park gear, as shown in Figure 37.
11. Using a dial indicator, measure and record the output shaft end-play reading, as shown in Figure 38, to use as a reference for re-assembly.  
**Note: Use screwdriver and small wood block to move gear train up and down, as shown in Figure 38.**

Continued on Page 35





Figure 38

# Technical Service Information

## LOW/REVERSE CLUTCH HOUSING AND LOW SPRAG, EXPLODED VIEW



- 175 LOW/REVERSE CLUTCH HOUSING BUSHINGS (2 REQUIRED).
- 176 LOW/REVERSE CLUTCH HOUSING.
- 177 LOW/REVERSE CLUTCH HOUSING BLEED ORIFICE.
- 178 LOW/REVERSE CLUTCH "MOLDED" APPLY PISTON.
- 179 LOW/REVERSE CLUTCH BELLVILLE PLATE.
- 180 LOW/REVERSE CLUTCH BELLVILLE PLATE "SPLIT" RETAINER.
- 181 L/R CLUTCH SINGLE SIDED *EXTERNAL* SPLINE PLATES (7 REQ.).
- 182 L/R CLUTCH SINGLE SIDED *INTERNAL* SPLINE PLATES (7 REQ.).

- 183 LOW/REVERSE CLUTCH BACKING PLATE.
- 184 LOW/REVERSE CLUTCH "SELECTIVE" SNAP RING.
- 185 LOW SPRAG OUTER RACE.
- 186 LOW SPRAG THRUST PLATES (2 REQUIRED).
- 187 LOW SPRAG END BEARINGS (2 REQUIRED).
- 188 LOW SPRAG ASSEMBLY (36 ELEMENTS).
- 189 LOW SPRAG INNER RACE.
- 190 LOW SPRAG RETAINING SNAP RING.

Figure 66



# Technical Service Information

## 2-4 CLUTCH RETAINER ASSEMBLY (CONT'D)

4. Lubricate seal surfaces of 2nd clutch piston and retainer with small amount of Trans-Jel®.
5. Install the "molded" 2nd clutch piston into the 2-4 clutch retainer, as shown in Figure 81.
6. Install the 2nd clutch piston bellville plate on top of the piston, as shown in Figure 80.
7. Using a suitable shop press, compress bellville spring until the snap ring is engaged into the snap ring groove in 2-4 retainer, and ensure that it is fully seated (See Figure 81).

8. Lubricate seal surfaces of 4th clutch piston and retainer with small amount of Trans-Jel®.
9. Install the "molded" 4th clutch piston into the 2-4 clutch retainer, as shown in Figure 82.
10. Install 4th clutch piston return spring assembly on top of piston, as shown in Figure 82.
11. Position the retaining snap ring on top of the return spring (See Figure 82).
12. Using a suitable shop press, compress the return spring and install the snap ring into the groove in the 2-4 retainer.
13. Ensure that the snap rings of 4th clutch and the 2nd clutch return springs are fully seated.

Continued on Page 55




Figure 81





Figure 82

# Technical Service Information

## INPUT CLUTCH HOUSING COMPONENTS EXPLODED VIEW



See Legend Figure 93

Figure 92

# Technical Service Information

## INPUT CLUTCH HOUSING ASSEMBLY (CONT'D)

46. Install the number 4 thrust bearing into reverse clutch hub, in the direction shown in Figure 106, and retain with small amount of TransJel®.
47. Install the reverse clutch hub assembly into the input housing over both shafts, as shown in Figure 106.




Figure 106

48. Re-install the reverse clutch pack completely, as described on Page 68, and illustrated in Figure 103.

**Note:** Pry up on backing plate to allow reverse clutch hub to turn freely.

49. The number 5 thrust bearing is equipped with a selective spacer that snaps onto the bearing, as shown in Figure 107, and is used to adjust front transmission end-play.

**Note:** Ensure that selective spacer is snapped onto number 5 thrust bearing properly.

Continued on Page 71




Figure 107

# Technical Service Information

## COMPONENT REBUILD (CONT'D)

### OIL PUMP ASSEMBLY (CONT'D)

8. Install the alignment dowels into oil pump body, if they were removed, as shown in Figure 113.
9. Dip all 3 of the pump gears into Mopar® +4 fluid and install them in their *original* locations, shown in Figure 113.
10. Install the shuttle valve into the oil pump body in the location shown in Figure 113.
11. Ensure the shuttle valve is seated and install the oil pump spacer plate over the alignment dowels, as shown in Figure 114.
12. Install the two spacer plate retaining screws, as shown in Figure 114, and torque the screws to 4.5N·m (40 in.lb.).

**Note:** Leaving these two screws out will create a "No Engagement" condition.

Continued on Page 76




Figure 113




Figure 114



# Technical Service Information

## VALVE BODY ASSEMBLY

1. Clean and inspect all components. Replace any parts that show evidence of wear or damage.
2. Lubricate the valves, springs and bore plugs with clean transmission fluid (Mopar® +4).
3. Install the solenoid switch valve and 3 plugs in the valve body, **exactly** as shown in Figure 123, and then install the plastic retainer.

**Note:** Use small amount of Trans-Jel® to keep plastic retainer in place.

4. Install the low/reverse switch valve into valve body as shown in Figure 123, followed by the bore plug.

**Note:** Some manuals illustrate a bore plug wire retainer for this location. Our unit did not have one, nor is it needed as the accumulator cover retains this valve train (See Figure 123).

5. Install the accumulator pistons and springs into the valve body in their proper locations, shown in Figure 123.

**Note:** All accumulators have two springs, except the overdrive, which has only one.

6. Install the accumulator cover onto valve body using the 7 retaining screws (See Figure 123).
  7. Torque the screws to 4.5 Nm (40 in lbs).
  8. Ensure that the solenoid switch valve and the 3 plugs are free in the bore, and that solenoid switch valve plastic retainer is still in place, as shown in Figure 124.
- Note:** This retainer can easily fall out while maneuvering the valve body as it is not spring loaded.
9. Ensure that low/reverse switch valve is free in its bore.
  10. Lay the valve body down on a flat surface and install the 7 checkballs into the proper pockets as shown in Figure 124.

Continued on Page 83

### VALVE BODY CHECKBALL LOCATIONS




Figure 124



# Technical Service Information

## VALVE BODY ASSEMBLY (CONT'D)

27. Install the TRS/Solenoid Body onto the transfer plate using the remaining 14 valve body screws as shown in Figure 135.
28. Torque the TRS/Solenoid Body screws down to 5.7 Nm (50 in lbs).  
*Note: Tighten the screws nearest the range sensor selector plate first, and work toward the other end. Refer to Figure 135.*
29. Set the completed valve body assembly aside for the final assembly process.

## TRS/SOLENOID BODY

1. The TRS/Solenoid Body is serviced *only* as a complete assembly, which is why we told you not to remove the 7 screws on top that retain the cover plate.
2. However, if someone has not listened, we have provided you with an exploded view of the TRS/Solenoid Body in Figure 136.

*The illustrations in Figure 136 have been provided for reference only. We recommend that the TRS/Solenoid Body NOT be disassembled as none of the internal parts are serviced separately.*

Final Transmission Assembly  
Begins on Page 90




Figure 135

# Technical Service Information




Figure 151




Figure 152

## TRANSMISSION ASSEMBLY (CONT'D)

26. Install the completed oil pump assembly into the transmission case, as shown in Figure 152.
27. Install the 6 retaining bolts and torque them to 28 N·m (20 ft.lb.).
28. Remove one pump bolt to install dial indicator, as shown in Figure 153, and zero dial indicator.
29. Front transmission end-play should be 0.52-0.74 mm (.020"-.029").

*Note: When measuring input shaft end-play, two "stops" will be felt. When input shaft is pushed inward and the dial indicator zeroed, the first stop felt when input shaft is pulled outward is the movement of the input shaft in the input clutch hub. This value should not be included in the end-play measurement and therefore must be recorded and subtracted from the total dial indicator reading.*

30. Change the Number 5 thrust bearing selective spacer as necessary to obtain the correct front transmission end-play.

*Note: The number 5 thrust bearing selective spacer is identified by a number molded or stamped into spacer, as shown in Figure 154.*

31. Remove the dial indicator, re-install the oil pump retaining bolt and torque to 28 N·m (20 ft.lb.).

Continued on Page 98




Figure 153