

| | | | |
|--|--|--|---|
| | Remove Disconnect | | Inlet |
| | Refit Connect | | Exhaust |
| | Dismantle Disassembly | | Operation |
| | Refit Reassemble | | Tolerance Weight difference |
| | Tighten to torque | | Preloading |
| | Tighten to torque plus angle | | Rotation |
| | Tighten fully | | Compression ratio |
| | Stake nut | | Selection Classes |
| | Setting Adjustment | | Oversized Oversized to Maximum Undersized Undersized to Idling |
| | Visual check Examination | | Rpm |
| | Warning | | Ratio |
| | Lubricate Damp | | Pressure |
| | Replace Genuine spare parts | | Temperature |
| | Bleed braking system | | Temperature < 0°C Cold Winter |
| | Surface to be machined After machining | | Temperature > 0°C Warm Summer |
| | Interference Force fit | | Windscreen wiper with windscreen washer pump |
| | Dimension to be measured Measurement - Check Thickness - Clearance | | Rear window wiper with rear window washer pump |
| | Rolling torque | | Engine |

Front suspension independent, MacPherson type with lower track control arms connected by means of two flexible bushes to a crossmember.

Offset coil springs and double acting, hydraulic shock absorbers.

Joints with lifetime lubrication

Anti-roll torsion bar

Coil springs





 16v CF3

| | | |
|--|----------------|------|
| Order number | | N.A. |
| Wire diameter | mm | N.A. |
| Number of effective coils | | N.A. |
| Coil direction | | N.A. |
| Released spring height | mm | N.A. |
| Height under a load of: | mm | N.A. |
| Spring are divided into two categories, identified by markings | | |
| yellow (1) springs are loaded to: | a height of mm | N.A. |
| green (1) springs are loaded to: | a height of mm | N.A. |







(1) Springs of the same type must be fitted.

Dampers

| | | |
|--------------------------------|----|------------|
| Type, telescopic double-acting | | hydraulic |
| Order number | | 1307658080 |
| Travel (beginning of damping) | mm | 186.5 |
| Maximum extension | mm | 510±2 |






| | | | |
|--|---|--|--|
|  581 SPI |  1905 D |  1905 TD |  1905 TD (●) |
|--|---|--|--|


FRONT BRAKES

| | | | Values in mm | |
|--|------------------------|---|--------------|------------|
|  | Disc | \varnothing | 257 | 281 |
| | | s | 20.1-19.8 | 25.9-26.1 |
| | |  | 18.55 | 24.55 |
| | | $s < \text{allowed}$ | 18.2 | 24.2 |
|  | Brake linings | $s < \text{allowed}$ | 1.5 | |
|  | Caliper | \varnothing | 57 | |
|  | Master cylinder (pump) | \varnothing | 23.8 | |
|  | Servo brake | | ISOVAC 10" | ISOVAC 11" |

(●) Van 900 kg

REAR BRAKES


| | | | |
|---|--------------------------|---|-----------------------|
|  | Drum | \varnothing  | 255.2-255.410 |
| | | | 255.6 |
| | | | 256 |
|  | Shoes | $s < \text{allowed}$ | 1.5 |
|  | Wheel cylinders | \varnothing | 19 |
|  | Load proportioning valve | | acting on rear wheels |
| | Ratio (reduction) | | 0.3 |




P4B17AX01



Connect the hoist to tool 1860850000, then carry out the following operations:




P4B17AX02




P4B17AX03

1. loosen the bolt fixing the right power unit mounting bracket;
2. place the lift under pressure to release the weight from the power unit mounting, then loosen the centre nut for the left power unit mounting;
3. undo the two bolts (arrow) fixing the right power unit mounting to the bodyshell;
4. undo the two bolts (arrow) fixing the left power unit mounting to the bodyshell.




P4B17AX04



P4B17AX05


Headlamp alignment – Radio



4B057A101

* Variant connection for versions without A.B.S.

Components of the VALEO 131 4E04 starter motor



- | | |
|---|--------------------------------|
| 1. Solenoid (fixed part) | 7. Casing complete with stator |
| 2. Solenoid return spring (moving part) | 8. Armature |
| 3. Solenoid (moving part) with fork | 9. Brush carrier |
| 4. Front end bracket | 10. Brush carrier cover |
| 5. Pinion | 11. Cover |
| 6. Solenoid and reduction gear supporting plate | 12. Brush pressure devices |

P4B007L01



To refit, reverse the procedure for removal.

DIAGNOSIS OF OPERATING FAULTS ON STARTER MOTOR

A. The motor does not turn

The cause may be:

- battery poles and terminals corroded
- battery-starter motor terminal slack
- terminal on electrical connector block disconnected
- battery fully discharged
- absence of contact on brush commutator or short circuit in one or both brushes
- starter switch contacts corroded, worn or insulated by the interposition of debris
- armature or stator earthed
- armature or commutator centrifuged

B. The motor turns very slowly


The cause may be:

- brushes and commutator blades worn
- some of the rotor winding coils short circuited
- battery poles and terminals corroded
- battery charge very low, or one or several cells are damaged


C. Excessive noise on starting

The cause may be:


- pinion roller clutch mechanism worn
- starter motor not lined up with flywheel
- some flywheel teeth excessively worn on the engagement side




P4B004M01



P4B004M02



P4B004M03



P4B004M04



Refitting

1. When refitting suitably reverse the operations carried out for the removal, taking into account that when fixing the door opening control lever it is necessary to replace the rivets positioning them with a special riveting machine.

WINDOW OPENING DEVICE

Removing

Remove the door panel as described previously.

NOTE Position the window opening handle in the special housing and place the window in the halfway travel position.

2. Release the clip fixing the window to the window opening device, then release the window from its housing;

NOTE Place the window in the end of travel position at the top.


3. undo the bolts shown and remove the window opening device releasing it from the rivets fixing it to the door frame.

Refitting


4. When refitting suitably reverse the operations carried out for the removal, fixing the window opening device to the door with new rivets using the appropriate riveting machine.

Fitting the new part (2)

1. Place the new part on the vehicle and check that it is perfectly aligned with the adjacent parts, then secure it by tacking it from inside with a few spot welds.




P4B26AM01




Welding the new part (2)

1. Carry out the bead fill weld as shown in the figure.
The weld (1) is carried out from inside the vehicle, while the weld (2) is carried out from outside the vehicle.



P4B26AM02




ENGINE OIL LEVEL GAUGE


The engine oil level gauge is located inside the maintenance indicator the oil level is displayed briefly when the engine is switched on

When the ignition key is turned on (M see page 4) after 5 seconds the indicator (A) and the min and max references light up the following conditions appear on the display (B) for 10 seconds


the oil level is maximum when 6 squares are lit up



the oil level is minimum when 1 square is lit up




Version: with A.B.S.
Windscreen wash/wipe – Horn



48031GL01

* Variant connection for two-tone version


Air bag and failure warning light – Pretensioners



55.

Version: with A.B.S.

Electronically-controlled diesel pump device – Injection system failure warning light – Heater plugs and warning light – Water in fuel filter warning light – Speedometer – Rev counter – Low engine oil pressure warning light



Location of components on the car.

Component key

- BB00 Battery
- BF00 Junction unit (vehicle interior)
- BMF2 Maxi fuse control unit
- CA00 Ignition switch
- PSF1 Junction unit (engine compartment)
- R3 Fan engagement remote control switch (high speed)
- R4 Fan engagement remote control switch (low speed)
- R7 Compressor disengagement remote control switch (from injection control unit)
- R9 Compressor disengagement remote control switch
- 0004 Instrument panel
- V0004 General failure warning light
- V1150 Heater plugs warning light
- V1300 Injection system failure warning light
- V4050 Water in fuel filter warning light
- 1020 Alternator
- 1115 Sensor on cylinder
- 1150 Heater plugs control unit
- 1159 Heater plugs
- 1203 Inertia switch
- 1211 Fuel pump/gauge assembly
- 1220 Engine coolant temperature sensor
- 1233 Turbocharger pressure adjustment solenoid valve
- 1253 EGR solenoid valve
- 1261 Accelerator pedal position sensor
- 1263 E.G.R. solenoid valve
- 1264 SWIRL solenoid valve
- 1276 Diesel heater
- 1304 Multiple relay
- 1310 Air flow meter
- 1312 Intake manifold pressure sensor
- 1313 Engine speed sensor
- 1320 Diesel pump electronic control unit
- 1321 Fuel pressure sensor
- 1322 Fuel pressure solenoid valve


- 1331 Injector n° 1
- 1332 Injector n° 2
- 1333 Injector n° 3
- 1334 Injector n° 4
- 1620 Vehicle speed sensor
- 4000 Instrument panel electronic control module
- 4050 Water in fuel filter sensor
- 4110 Switch signalling insufficient engine oil pressure
- 4210 Rev counter
- 4630 Speedometer
- 8007 Three stage pressure switch
- 8016 Compressor disengagement remote control switch
- 8091 Additional heater engagement relay
- 8098 Additional heater

Key to connections


- C001 Diagnostic socket
- IC01E Connection between main and dashboard cables
- IC01H Connection between main and dashboard cables
- IC01I Connection between main and dashboard cables
- IC01J Connection between main and dashboard cables
- IC01L Connection between main and dashboard cables
- IC01M Connection between main and dashboard cables
- IC01R Connection between main and dashboard cables
- IC01U Connection between main and dashboard cables
- IC01 Interconnection between main and dashboard cables
- IC02A Connection between main and engine cables
- IC02B Connection between main and engine cables
- IC55 Connection between main and additional heater cables

Key to earths


- M000 Battery earth
- M001 Battery earth
- MC10 Left front earth
- MC20 Right front earth
- MC23 Right dashboard earth
- N.D. Ultrasound welding taped in cable loom




3S021ML01




3S021ML02




3S029ML01



4B131A04



4B090GL02




4B135A06

55.

VERSION WITH AUTOMATIC TRANSMISSION

FRONT VIEW




4B0041L02

KEY

1. Speedometer (4630)
2. Left direction indicator warning light (green) (V2320)
3. Right direction indicator warning light (green) (V2330)
4. Rev counter (4210)
5. Fuel reserve warning light (yellow) (V4300)
6. Fuel gauge (4310)
7. Instrument panel light dimmer and clock settings adjustment button
8. Seat belt not fastened warning light (red) (V4730)
9. Doors ajar warning light (red) (V4700)
10. Brake pad wear warning light (yellow) (V4430)
11. Air Bag system failure warning light (yellow) (V6560)
12. Injection system failure warning light (yellow) (V1300)
13. Handbrake applied and brake fluid level warning light (red) (V4420)
14. Insufficient engine oil pressure warning light (red) (V4110)
15. General failure warning light (red) (V004)
16. Battery recharging warning light (red) (V1000)
17. Insufficient engine coolant warning light (red) (V4010)
18. ABS anti-lock brakes circuit failure warning light (yellow) (V7000)
19. Rear fog lamps warning light (yellow) (V2000)
20. Fog lights warning light (yellow) (V2660)
21. Main beam headlamps warning light (blue) (V2620)
22. Dipped headlamps warning light (green) (V2610)
23. Heated rear windscreen warning light (yellow) (V8110)
24. Service indicator/trip meter zeroing button
25. Service indicator/trip meter zeroing button, clock
26. Engine coolant overheating warning light (red) (V4020)
27. Engine coolant temperature gauge (4026)
28. Insufficient engine oil level warning light (V4120)
29. Engine oil level gauge (4102)
30. Automatic transmission selector display (4605)/Outside temperature gauge (7226)

Central locking - (See key at end of wiring diagrams)



DESCRIPTION OF SYSTEM

The Scudo with the 1997 JTD engine is equipped with a WEBASTO additional heater connected to the vehicle water and fuel system

This device makes it possible to pre heat the engine coolant and therefore the engine itself

The device secured to a special bracket is located in the engine compartment on the right hand side near the engine management control unit


Its operation is intermittent and completely autonomous (with the engine running) and depends on the temperature of the coolant and the outside temperature

It basically consists of

a heater secured to the engine crankcase

an electric fuel metering pump located on the heater mounting bracket

an exhaust pipe connected in the lower part of the heater



Component key

- | | |
|---|---|
| 1 Additional heater unit | 10 Fuel supply pipe from connector to metering pump |
| 2 Exhaust pipe | 11 Fuel supply pipe from metering pump to additional heater |
| 3 Electric fuel metering pump | 12 Heater/engine management control unit wiring and electrical connection |
| 4 Thermostat unit | 13 Engine management control unit |
| 5 Thermostat unit/heat exchanger water supply pipe | |
| 6 Heat exchanger/additional heater water supply pipe | |
| 7 Additional heater/thermostat unit water return pipe | |
| 8 Fuel supply pipe from tank to engine | |
| 9 Fuel return pipe from the tank supply devices | |