


Under-hood Emissions Control Label



Emission Group Identification (1997 model)

Example:



IMPORTANT VEHICLE INFORMATION

ENGINE FAMILY-VHN2.0JGKEK
DISPLACEMENT-2.0 LITER
EVAPORATIVE FAMILY-VHN1077BYMBP

CATALYST

REFER TO SERVICE MANUAL FOR ADDITIONAL INFORMATION.
TUNE UP CONDITIONS:

ENGINE AT NORMAL OPERATING TEMPERATURE.
ALL ACCESSORIES TURNED OFF. COOLING FAN OFF.
TRANSMISSION IN NEUTRAL

NO OTHER ADJUSTMENTS NEEDED.

| | | |
|-------------------------|------------------------|---------------------|
| IDLE SPEED | AUTOMATIC TRANSMISSION | 750 ± 50 rpm |
| IGNITION TIMING AT IDLE | | 18° ± 2° BTDC |
| VALVE LASH | IN | 0.10 ± 0.02 mm COLD |
| | EX | 0.18 ± 0.02 mm COLD |
| SPARK PLUG | TYPE | NGK: ZFR5F-11 |
| | | ND: KJ16CR-L11 |
| | GAP | 1.1 - 0.1 mm |

THIS VEHICLE CONFORMS TO U.S. EPA REGULATIONS
APPLICABLE TO 1997 MODEL YEAR NEW LIGHT-DUTY TRUCKS.



201JGKEE

HONDA MOTOR CO., LTD.

17275-P3F-A01

LOADED 1/1M TESTING OF PERMANENT FOUR-WHEEL DRIVE OR TRACTION CONTROL-EQUIPPED
VEHICLES MUST BE CONDUCTED ON A FOUR-WHEEL DRIVE SPEED SYNCHRONIZED
DYNAMOMETER.
OTHERWISE, A NON-LOADED TEST PROCEDURE MUST BE PERFORMED.

50ST (50 States):

THIS VEHICLE CONFORMS TO U.S. EPA AND STATE OF
CALIFORNIA REGULATIONS APPLICABLE TO 1997
MODEL YEAR NEW LIGHT DUTY TRUCKS.

49ST (49 States/Federal):

THIS VEHICLE CONFORMS TO U.S. EPA REGULATIONS
APPLICABLE TO 1997 MODEL YEAR NEW LIGHT DUTY
TRUCKS.

CAL (California):

THIS VEHICLE CONFORMS TO U.S. EPA AND STATE OF
CALIFORNIA REGULATIONS APPLICABLE TO 1997
MODEL YEAR NEW TLEV LIGHT DUTY TRUCKS
PROVIDED THAT THIS VEHICLE IS ONLY INTRODUCED
INTO COMMERCE FOR SALE IN THE STATE OF
CALIFORNIA.

Engine and Evaporative Families

Engine Family: VHN2.0JGKEK

Model Year _____

V: 1997

Manufacturer _____

HN: Honda

Displacement _____

Class _____

1: Light Duty Vehicle

Fuel System and Number of Valves _____

J: Electronic Sequential Multiport

Injection (three or more valves per
cylinder)

Fuel Type _____

G: Gasoline

Standard _____

F: 49 or 50 States Tier 1

K: 49 or 50 States Tier 1

1: California Tier 1

2: California TLEV

3: California LEV

4: California ULEV

Catalyst _____

E, F, G, H: Three Way Catalyst

OBD _____

K - T: OBD Equipped

Evaporative Family: VHN1077BYMBP

Model Year _____

V: 1997

Manufacturer _____

HN: Honda

Storage System _____

1: Canister

Canister Working Capacity (grams) _____

Canister Configuration _____

A: Plastic Housing (Closed Bottom)

B: Plastic Housing (Open Bottom)

Fuel System _____

Y: Fuel Injection

Fuel Tank _____

M: Metal

Standard _____

A: Current Evap

B: Enhanced Evap

Wild Card _____

Maintenance Schedule (for 1997 Model)

Normal Conditions

Follow the Normal Conditions Maintenance Schedule if the severe driving conditions specified in the Severe Conditions Maintenance Schedule on pages 3-6 and 3-7 do not apply.


| Service at the indicated distance or time whichever comes first. | miles x 1,000 | | | | | | | | | | | | NOTE | SECTION and PAGE |
|---|--|----|----|----|-----|-----|-----|-----|---|--|--|--|--|------------------|
| | 15 | 30 | 45 | 60 | 75 | 90 | 105 | 120 | | | | | | |
| | 24 | 48 | 72 | 96 | 120 | 144 | 168 | 192 | | | | | | |
| | 12 | 24 | 36 | 48 | 60 | 72 | 84 | 96 | | | | | | |
| Replace engine oil | Every 7,500 miles (12,000 km) or 12 months | | | | | | | | | | | | Capacity for change with filter: 3.8 ℓ (4.0 US qt, 3.3 Imp qt) | 8-4, 5 |
| Replace engine oil filter | ● | ● | ● | ● | ● | ● | ● | ● | ● | | | | 8-5, 6 | |
| Check engine oil and coolant | Check oil and coolant at each fuel stop | | | | | | | | | | | | Check levels and check for leaks. | 8-4, 10-5 |
| Replace air cleaner element | ● | ● | ● | ● | ● | ● | ● | ● | ● | | | | 11-194 | |
| Inspect valve clearance | Adjust only if noisy | | | | | | | | | | | | Intake 0.08 – 0.12 mm (0.003 – 0.005 in) Exhaust 0.16 – 0.20 mm (0.006 – 0.008 in) Measured between the camshaft and rocker arm when cold. | 6-3, 4 |
| Replace spark plugs | ● | ● | ● | ● | ● | ● | ● | ● | ● | | | | 4-21 | |
| Replace timing belt and inspect water pump | ● | ● | ● | ● | ● | ● | ● | ● | ● | | | | 6-10, 11, 10-11 | |
| Inspect and adjust drive belts | ● | ● | ● | ● | ● | ● | ● | ● | ● | | | | 4-34 17-14 22-69 | |
| Inspect idle speed | ● | ● | ● | ● | ● | ● | ● | ● | ● | | | | 11-169, 170 | |
| Replace engine coolant | ● | ● | ● | ● | ● | ● | ● | ● | ● | | | | 10-5 | |
| Replace transmission fluid | ● | ● | ● | ● | ● | ● | ● | ● | ● | | | | 14-161 | |
| Replace rear differential fluid | ● | ● | ● | ● | ● | ● | ● | ● | ● | | | | 15-14 | |
| Inspect front and rear brakes | ● | ● | ● | ● | ● | ● | ● | ● | ● | | | | 19-4, 9, 11 | |
| Replace brake fluid | ● | ● | ● | ● | ● | ● | ● | ● | ● | | | | 19-7 | |
| Check parking brake adjustment | ● | ● | ● | ● | ● | ● | ● | ● | ● | | | | 19-6 | |
| Replace air conditioning filter | ● | ● | ● | ● | ● | ● | ● | ● | ● | | | | 22-50 | |
| Rotate tires (Check tire inflation and condition at least once per month) | Rotate tires every 7,500 miles (12,000 km) | | | | | | | | | | | | The suggested rotation method is shown in the diagram in the Owner's Manual. | — |

Charging System

Troubleshooting (cont'd)

'97 model: Alternator Control System Test (U.S.A. model)

NOTE: Before testing, check proper operation of the ELD by checking for a DTC (see section 11).




Valve Seals

Replacement (cylinder head removal not required) (cont'd)

12. Using an upward motion on the lever arm, compress the valve spring and remove the keepers from the valve stem. Slowly release pressure on the spring.
13. Repeat step 11 for the other valve in that cylinder.
14. Remove the valve seals (see page 6-24).
15. Install the valve seals (see page 6-29).
16. Install the springs, the retainers and the keepers in reverse order of removal.
17. Repeat steps 9 to 16 for the other three cylinders.


Exhaust Valve Seals

18. Using the 6 mm bolts supplied with the tool, mount the two uprights to the cylinder head at the end camshaft holders. The uprights fit as shown.
19. Insert the cross shaft through the bottom hole of the two uprights.




20. Select the 7/8 in. diameter short compressor attachment, and fasten the attachment to the No. 4 hole of the lever arm with the speed pin supplied.
21. Position the piston at TDC, and insert an air adaptor into the spark plug hole. Pump air into the cylinder to keep the valve closed while compressing the springs and removing the valve keepers.

22. Put shop towels over the oil passages to prevent the valve keepers from falling into the cylinder head.



23. Position the lever arm under the cross shaft so the lever is perpendicular to the shaft and the compressor attachment rests on top of the retainer for the spring being compressed. Use the rear position slot on the lever as shown.



24. Using a downward motion on the lever arm, compress the valve spring and remove the keepers from the valve stem. Slowly release pressure on the spring.
25. Repeat step 24 for the other valve in that cylinder.
26. Remove the valve seals (see page 6-24).
27. Install the valve seals (see page 6-29).
28. Install the springs, the retainers and the keepers in reverse order of removal.
29. Repeat steps 21 to 28 on the other three cylinders.

Piston Pins

Inspection

1. Measure the diameter of the piston pin.


Piston Pin Diameter:

Standard (New): 20.996 – 21.000 mm


(0.8266 – 0.8268 in)

Overize: 20.998 – 21.002 mm

(0.8267 – 0.8268 in)



2. Zero the dial indicator to the piston pin diameter.




3. Measure the piston pin-to-piston clearance. If the piston pin clearance is greater than 0.024 mm (0.0009 in), remeasure using an oversized piston pin.

NOTE: All replacement piston pins are oversize.

Piston Pin-to-Piston Clearance:

Standard (New): 0.010 – 0.017 mm

(0.0004 – 0.0007 in)




4. Check the difference between the piston pin diameter and the connecting rod small end diameter.

Piston Pin-to-Connecting Rod Interference:

Standard (New): 0.015 – 0.032 mm


(0.0006 – 0.0013 in)



System Description

Vacuum Connections (cont'd)


'99 – 00 models:



- | | |
|--|--|
| ① PRIMARY HEATED OXYGEN SENSOR (PRIMARY HO ₂ S, SENSOR 1) | ⑮ AIR CLEANER |
| ② SECONDARY HEATED OXYGEN SENSOR (SECONDARY HO ₂ S, SENSOR 2) | ⑯ RESONATOR |
| ③ MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR | ⑰ POSITIVE CRANKCASE VENTILATION (PCV) VALVE |
| ④ ENGINE COOLANT TEMPERATURE (ECT) SENSOR | ⑱ THREE WAY CATALYTIC CONVERTER (TWC) |
| ⑤ INTAKE AIR TEMPERATURE (IAT) SENSOR | ⑳ EVAPORATIVE EMISSION (EVAP) CONTROL CANISTER |
| ⑥ CRANKSHAFT SPEED FLUCTUATION (CKF) SENSOR | ㉑ EVAPORATIVE EMISSION (EVAP) PURGE CONTROL SOLENOID VALVE |
| ⑦ KNOCK SENSOR (KS) | ㉒ EVAPORATIVE EMISSION (EVAP) CONTROL CANISTER VENT SHUT VALVE |
| ⑧ IDLE AIR CONTROL (IAC) VALVE | ㉓ EVAPORATIVE EMISSION (EVAP) TWO WAY VALVE |
| ⑨ FAST IDLE THERMO VALVE (A/T) | ㉔ EVAPORATIVE EMISSION (EVAP) BYPASS SOLENOID VALVE |
| ⑩ THROTTLE BODY (TB) | ㉕ FUEL TANK PRESSURE SENSOR |
| ⑪ FUEL INJECTOR | ㉖ EVAPORATIVE EMISSION (EVAP) THREE WAY VALVE |
| ⑫ FUEL PULSATION DAMPER | ㉗ PURGE JOINT |
| ⑬ FUEL FILTER | |
| ⑭ FUEL PRESSURE REGULATOR | |
| ⑮ FUEL PUMP | |
| ⑯ FUEL TANK | |
| ⑰ FUEL TANK EVAPORATIVE EMISSION (EVAP) VALVE | |

System Description

System Connectors [Dash and Floor] — '98 – 00 Models



PGM-FI System

Secondary Heated Oxygen Sensor (Secondary HO2S) (Sensor 2) (cont'd)

P0138 The scan tool indicates Diagnostic Trouble Code (DTC) P0138: A high voltage problem in the Secondary Heated Oxygen Sensor (Secondary HO2S) (Sensor 2) circuit.

- The MIL has been reported on.
- DTC P0138 is stored.

Problem verification:

1. Do the ECM/PCM Reset Procedure.
2. Start the engine. Hold the engine at 3,000 rpm with no load (in Park or neutral) until the radiator fan comes on.
3. Check the Secondary HO2S (Sensor 2) output voltage at 3,000 rpm with the scan tool.

Does the voltage stay at 0.6 V or more?

NO

Intermittent failure, system is OK at this time. Check for poor connections or loose wires at C127 (located on ECM/PCM bracket), C721 (Secondary HO2S, Sensor 2) and at the ECM/PCM.

YES

Check for an open in the Secondary HO2S:

1. Turn the ignition switch OFF.
2. Disconnect the Secondary HO2S (Sensor 2) 4P connector.
3. Connect the Secondary HO2S (Sensor 2) 4P connector terminals No. 1 and No. 2 with a jumper wire.
4. Turn the ignition switch ON (II).
5. Check the Secondary HO2S (Sensor 2) output voltage with the scan tool.

Is there 0.6 V or more?

NO

Replace the Secondary HO2S (Sensor 2).

YES

('97 model)

Check for an open in the wires (SHO2S, SG2 lines):

1. Turn the ignition switch OFF.
2. Connect PCM connector terminals D14 and D13 with a jumper wire.
3. Turn the ignition switch ON (II).
4. Check the Secondary HO2S (Sensor 2) output voltage with the scan tool.


Is there 0.6 V or more?

NO

Repair open in the wire between the PCM (D14 or D13) and the Secondary HO2S (Sensor 2).


YES

SECONDARY HO2S (Sensor 2) 4P CONNECTOR (C721)



Wire side of female terminals

PCM CONNECTOR D (16P)



Wire side of female terminals

Fuel Supply System

System Description

The fuel supply system consists of a fuel tank, in-tank high-pressure fuel pump, PGM-FI main relay, fuel filter, fuel pressure regulator, fuel injectors, and fuel delivery and return lines. This system delivers pressure-regulated fuel to the fuel injectors and cuts the fuel delivery when the engine is not running.

Fuel Pressure


Relieving

Before disconnecting fuel pipes or hoses, release pressure from the system by loosening the 12 mm banjo bolt on the top of the fuel filter.

⚠ WARNING

- Do not smoke while working on the fuel system. Keep open flames or sparks away from your work area.
- Be sure to relieve fuel pressure while the ignition switch is off.

1. Write down the frequencies for the radio's preset buttons.
2. Disconnect the battery negative cable from the battery negative terminal.
3. Remove the fuel fill cap.
4. Use a box end wrench on the 12 mm banjo bolt at the fuel filter while holding the fuel filter with another wrench.
5. Place a rag or shop towel over the 12 mm banjo bolt.
6. Slowly loosen the 12 mm banjo bolt one complete turn.




NOTE: Replace the washers whenever the 12 mm banjo bolt is loosened or removed.

Inspection


1. Relieve fuel pressure.
2. Remove the 12 mm banjo bolt on the fuel filter while holding the fuel filter with another wrench. Attach the 12 mm fuel pressure adapter bolt and the special tool.

FUEL PRESSURE GAUGE
07406 - 0040001



FUEL PRESSURE REGULATOR

CLAMP



3. Start the engine. Measure the fuel pressure with the engine idling and the vacuum hose of the fuel pressure regulator disconnected from the fuel pressure regulator and pinched. If the engine will not start, turn the ignition switch on (II), wait for two seconds, turn it off, then back on again and read the fuel pressure.

Pressure should be:

'97 - 98 models:

260 - 310 kPa (2.7 - 3.2 kgf/cm², 38 - 46 psi)

'99 - 00 models:

270 - 320 kPa (2.8 - 3.2 kgf/cm², 40 - 47 psi)

4. Reconnect vacuum hose to the fuel pressure regulator.

Pressure should be:

'97 - 98 models:

210 - 250 kPa (2.1 - 2.6 kgf/cm², 30 - 37 psi)

'99 - 00 models:

220 - 260 kPa (2.2 - 2.7 kgf/cm², 31 - 38 psi)

If the fuel pressure is not as specified, first check the fuel pump (see page 11-183). If the fuel pump is OK, check the following:


- If the fuel pressure is higher than specified, inspect for:
 - Pinched or clogged fuel return hose or line.
 - Faulty fuel pressure regulator (see page 11-181).
- If the fuel pressure is lower than specified, inspect for:
 - Clogged fuel filter.
 - Faulty fuel pressure regulator (see page 11-181).
 - Fuel line leakage.

Transfer Assembly

Inspection

⚠ WARNING Make sure lifts, jacks, and safety stands are placed properly (see section 1).


1. Raise the front of the vehicle, and support it with safety stands (see section 1).
2. Set the parking brake, and block both rear wheels securely.
3. Shift to neutral position.
4. Make a reference mark across the propeller shaft and the transfer assembly flanges.



5. Separate the propeller shaft from the transfer assembly.

6. Set a dial indicator on the transfer assembly flange, then measure the transfer gear backlash.

STANDARD: 0.06 – 0.16 mm (0.002 – 0.006 in)



7. If the measurement is out of specification, remove the transfer assembly and adjust transfer gear backlash (see page 13-44 thru 13-61).
8. Check the transfer oil seal for damage and fluid leaks.
9. If oil seal replacement is required, remove the transfer assembly, replace the oil seal, and adjust the total starting torque (see page 13-44 thru 13-61).

NOTE: Do not replace the oil seal when the transfer assembly is installed on the transmission.

Transfer Assembly

Reassembly

Note these items during reassembly:

- While reassembling the transfer assembly:
 - Check and adjust the transfer gear tooth contact.
 - Measure and adjust the transfer gear backlash.
 - Check and adjust the tapered roller bearing starting torque.
- Coat all parts with MTF during reassembly.
- Replace the tapered roller bearing and the bearing outer race as a set if either part is replaced.
- Replace the transfer drive gear and the transfer driven gear shaft as a set if either part is replaced.

Outline of Assembly

1. Select the 35 mm thrust shim.
Perform this procedure if the transfer driven gear shaft or the tapered roller bearing on the transfer driven gear shaft is replaced.
2. Preassemble the parts to check and adjust transfer gear backlash and transfer gear tooth contact.
3. Disassemble the parts, then assemble the transfer driven gear shaft and its related parts.
4. Measure and adjust the starting torque of the transfer driven gear shaft tapered roller bearing.
5. Assemble the transfer shaft and its related parts.
6. Measure and adjust the total starting torque.

35 mm Thrust Shim Selection

1. Select the 35 mm thrust shim if the transfer driven gear shaft or the tapered roller bearing on the transfer driven gear shaft is replaced.

Calculate the thickness of the 35 mm thrust shim using the formula below.

$$\text{FORMULA: } \frac{A}{100} - \frac{B}{100} + C = X$$

A: Number on the existing transfer driven gear shaft

B: Number on the replacement transfer driven gear shaft

C: Thickness of the existing 35 mm thrust shim


X: Thickness needed for the replacement 35 mm thrust shim

NOTE: The number on the transfer driven gear shaft is shown in 1/100 mm.

EXAMPLE:

C: EXISTING 35 mm
THRUST SHIM
Thickness: C=1.05 mm

X: REPLACEMENT 35 mm
THRUST SHIM
Thickness: X=? mm



Number: A=+2



Number: B=-1

A: EXISTING TRANSFER
DRIVEN GEAR SHAFT

B: REPLACEMENT TRANSFER
DRIVEN GEAR SHAFT

$$\begin{aligned} X &= \frac{A}{100} - \frac{B}{100} + C \\ &= \frac{2}{100} - \frac{-1}{100} + 1.05 \\ &= 0.02 + 0.01 + 1.05 \\ &= 1.08 \text{ (mm)} \end{aligned}$$

Select 35 mm thrust shim thickness of 1.08 mm (0.043 in). If the tapered roller bearing on the transfer driven gear shaft is replaced.

Measure the thickness of the replacement bearing and the existing bearing, and calculate the difference of the bearing thickness. Adjust the thickness of the existing 35 mm thrust shim by the amount of difference in bearing thickness, and select the replacement 35 mm thrust shim. Do not use more than one 35 mm thrust shim to adjust the transfer gear backlash.

THRUST SHIM, 35 mm

| Shim No. | Part Number | Thickness |
|----------|-------------------|--------------------|
| A | 41361 - PS3 - 000 | 0.72 mm (0.028 in) |
| B | 41362 - PS3 - 000 | 0.75 mm (0.030 in) |
| C | 41363 - PS3 - 000 | 0.78 mm (0.031 in) |
| D | 41364 - PS3 - 000 | 0.81 mm (0.032 in) |
| E | 41365 - PS3 - 000 | 0.84 mm (0.033 in) |
| F | 41366 - PS3 - 000 | 0.87 mm (0.034 in) |
| G | 41367 - PS3 - 000 | 0.90 mm (0.035 in) |
| H | 41368 - PS3 - 000 | 0.93 mm (0.037 in) |
| I | 41369 - PS3 - 000 | 0.96 mm (0.038 in) |
| J | 41370 - PS3 - 000 | 0.99 mm (0.039 in) |
| K | 41371 - PS3 - 000 | 1.02 mm (0.040 in) |
| L | 41372 - PS3 - 000 | 1.05 mm (0.041 in) |
| M | 41373 - PS3 - 000 | 1.08 mm (0.043 in) |
| N | 41374 - PS3 - 000 | 1.11 mm (0.044 in) |

Description


Hydraulic Flow (cont'd)

N Position

As the engine turns, the ATF pump starts to operate. Automatic transmission fluid (ATF) is drawn from (99) and discharged into (1). Then, ATF flowing from the ATF pump becomes line pressure (1). Line pressure (1) is regulated by the regulator valve. Torque converter inlet pressure (92) enters (94) of the torque converter through the lock-up shift valve and discharges into (90). The torque converter check valve prevents torque converter pressure from rising. Under this condition, hydraulic pressure is not applied to the clutches.

NOTE:

- When used, "left" or "right" indicates direction on the hydraulic circuit.
- The hydraulic circuit shows the '97 – 98 models (7 positions); the '99 – 00 models (6 positions) is similar.



Electrical Troubleshooting ('98 – 00 Models)

Troubleshooting Flowchart — A/T Gear Position Switch (Short) (cont'd)

From page 14-99

Measure ATP NP Voltage:

1. Shift to all positions other than **P** or **N**.
2. Measure the voltage between the D13 and B20 or B22 terminals.


Is there 5 V?

NO

YES

Check for short in the wire between the D13 terminal and the A/T gear position switch, and in the **P** and **N** position signal wires between the A/T gear position indicator and the A/T gear position switch. If wires are OK, check for loose terminal fit in the PCM connectors. If necessary, substitute a known-good PCM and recheck.

PCM CONNECTORS



Wire side of female terminals

Measure ATP D4 Voltage:


1. Shift to all positions other than **D4** ('98) or **D** ('99 – 00).
2. Measure the voltage between the D9 and B20 or B22 terminals.

Is there 5 V?

NO

YES

Check for short in the wire between the D9 terminal and the A/T gear position switch or A/T gear position indicator. If wires are OK, check for loose terminal fit in the PCM connectors. If necessary, substitute a known-good PCM and recheck.




To page 14-101


Seats

Rear Seat Cover Replacement (cont'd)

- Remove the headrest guide and latch knob collar, then remove the seat-back frame.



- Pull back the edge of the seat-back cover all the way around, release the clips, and remove the seat-back cover.




- Installation is the reverse of the removal procedure.

NOTE:


- To prevent wrinkles when installing a seat-back cover, make sure the material is stretched evenly over the pad before securing the hook and clips.
- Replace the released clips with new ones.

Seat cushion cover:

- Remove the seat cushion (see page 20-65).
- Remove the seat cushion latch and seat cushion strap (see page 20-66).
- Pull back the edge of the seat cushion mat, then release all of the clips.



- Pull back the edge of the seat cushion cover all the way around, release the clips, and remove the seat cushion cover.




Airbag/Seat Belt Tensioner

Disposal (cont'd)

7. Connect a 12 volt battery to the tool:
 - If the green light on the tool comes on, the airbag igniter circuit is defective and cannot deploy the airbag. Go to Damaged Airbag Special Procedure.
 - If the red light on the tool comes on, the airbag is ready to be deployed.
8. Push the tool's deployment switch. The airbag should deploy (deployment is both highly audible and visible; a loud noise and rapid inflation of the bag, followed by slow deflation).
 - If the airbags deploy and the green light on the tool comes on, continue with this procedure.
 - If an airbag doesn't deploy, yet the green light comes ON, its igniter is defective. Go to Damaged Airbag Special Procedure.
 - During deployment, the airbag can become hot enough to burn you. Wait thirty minutes after deployment before touching the airbag.
9. Dispose of the complete airbag. No part of it can be reused. Place it in a sturdy plastic bag, and seal it securely.


CAUTION:

- Wear a face shield and gloves when handling a deployed airbag.
- Wash your hands and rinse them well with water after handling a deployed airbag.



Deploying the Airbag: Out-of-vehicle

If an intact airbag has been removed from a scrapped vehicle, or has been found defective or damaged during transit, storage or service, it should be deployed as follows:



1. Confirm that the special tool is functioning properly by following the check procedure on this page or on the tool label.
2. Position the airbag face up, outdoors on flat ground at least thirty feet (10 m) from any obstacles or people.
3. Follow steps 6, 7, 8, and 9 of the in-vehicle deployment procedure.

Damaged Airbag (or Seat Belt Tensioner) Special Procedure

WARNING If an airbag (or Seat Belt Tensioner) cannot be deployed, it should not be treated as normal scrap; it should still be considered a potentially explosive device that can cause serious injury.

1. If installed in a vehicle, follow the removal procedure on page 24-3 and 24-87 through 90.
2. In all cases, make a short circuit by twisting together the two airbag inflator wires.
3. Package the airbag in exactly the same packaging that the new replacement part came in.
4. Mark the outside of the box "DAMAGED AIRBAG (or TENSIONER) NOT DEPLOYED" so it does not get confused with your parts stock.
5. Contact your Honda District Service Manager for how and where to return it for disposal.

Deployment Tool: Check Procedure

1. Connect the yellow clips to both switch protector handles on the tool; connect the tool to a battery.
2. Push the operation switch: green means the tool is OK; red means the tool is faulty.
3. Disconnect the battery and the yellow clips.