



Engine Mechanical System [2.5 TCI]

GENERAL	EM - 2
ENGINE BLOCK	EM -24
MAIN MOVING SYSTEM	EM -35
COOLING SYSTEM	EM -42
LUBRICATION SYSTEM	EM -51
INTAKE AND EXHAUST SYSTEM	EM -56
CYLINDER HEAD ASSEMBLY	EM -70
TIMING SYSTEM	EM -78

GENERAL


GENERAL ELCB0010

[2.5 TCI]



Symptom	Probable cause	Remedy
Piston noise	Excessive clearance due to cylinder wear Piston or piston pin worn Burnt piston Piston ring damaged	Replace piston Install new piston Install new rings
Oil leak	Oil pan drain plug loose Oil pan mounting bolt loose Oil pan gasket broken Crankshaft front oil seal defective Crankshaft rear oil seal defective Rocker cover gasket broken Oil filter loose Oil filter gasket broken	Tighten to torque Tighten to correct torque Install new gasket Install new oil seal Install new oil seal Install new gasket Tighten to correct torque Install new gasket
Oil consumption	Worn, scuffed, or broken rings Carbon in oil ring slot Rings fitted too tight in grooves Worn valve guides Faulty valve stem seals	Hone cylinder bores and install new rings Install new rings Remove the rings. Check grooves. If groove is not proper width, replace piston Install new valve and / or new valve guides with O.S. Install new valve stem seals
Oil pressure drop	Low oil level Slow idle speed Faulty oil pressure switch Clogged oil filter Worn parts in oil pump Thin or diluted oil Excessive bearing clearance Oil relief valve stuck Oil pump cover bent or cracked Oil screen loose or clogged	Check engine oil level Set idle speed to specification Install new switch Install new oil filter Replace worn parts or pump Change oil to correct viscosity Measure bearings for correct clearance Remove valve and inspect, clean and reinstall Install new oil pump Clean or replace screen

7. If not within the standard value, loosen the adjusting screw locking nut and, while turning the adjusting screw, use a thickness gauge to adjust the valve clearance to the standard value.




ECLA003E

8. Block the adjusting screw with a screwdriver, so that it cannot move and tighten the locknut to the specified torque.

Tightening torque :

12 - 18 Nm (120 - 180 kg.cm, 9 - 13 lb.ft)

9. Rotate clockwise the crankshaft one complete turn (360 degree).
10. Check that valve clearance indicated in the diagram (B) is at the standard value.



ECLA019K

Standard value : Hot engine

Intake : 0.25 mm (0.0098 in.)

Exhaust : 0.25 mm (0.0098 in.)

Cold engine

Intake : 0.15 mm (0.0059 in.)

Exhaust : 0.15 mm (0.0059 in.)

11. If not within the standard value, repeat steps 7 to 8 to adjust the valve clearance of remaining valves.

12. When installing the rocker cover assembly to the cylinder head, apply a coating of the specified sealant to the semicircular packing and cylinder head top surfaces, and then tighten at the specified torque

Specified sealant :

3M ART Part No. 8660 or equivalent


Tightening torque :

5 - 7 Nm (50 - 70 kg.cm, 4- 5 lb.ft)



CAUTION

If they are overtorqued, a deformed rocker cover or oil leakage could result.




ECLA003F

ADJUSTMENT OF THE TIMING BELT TENSION

ELCB0150

1. Remove the timing belt upper cover and bring the piston in No. 1 cylinder to top dead center on compression stroke. Check that the timing marks of sprockets are aligned.



ECLA005B

2. Loosen the timing belt tensioner mounting bolts.




CAUTION

Do not loosen the belts more than necessary. They could drop in the lower cover.


CAMSHAFT

1. Check the camshaft journal surfaces and, if damage or seizure is evident, replace the camshaft. If the camshaft journals are seized, check the cylinder head for damage. Check also the cylinder head oil holes for clogging.



ECLA019B

2. Check cam surfaces for abnormal wear and damage. If defects are evident, replace the camshaft, measure the lobe height and, if the limit is exceeded, replace the camshaft.



EDA9260A

Standard value :

Intake and exhaust : 37.05 mm (1.4587 in.)

Limit :

Intake and exhaust : 36.55 mm (1.4389 in.)


REPLACEMENT

ELCB0280

SILENT SHAFT


**NOTE**

Use Bearing Installer Stopper (special tool) only for removal and reinstallation of the right bearing.




ECLA008A

1. Using Bearing Installer Stopper and Silent Shaft Bearing Puller (09212 - 43300, 09212 - 43100), remove two rear bearings from the cylinder block.



ECLA008B

2. Using Bearing Installer Stopper and Silent Shaft Bearing Installer (09212 - 43300, 09212 - 43200), press-fit bearing into cylinder block.




ECLA008C

INSPECTION

ELCB0410

THERMOSTAT

1. Check that valve closes tightly at room temperature.
2. Check for defects or damage.
3. Check for rust on valve. Remove if any.
4. Immerse thermostat in container of water. Stir to raise water temperature and check that thermostat opening valve temperature and the temperature with valve fully open [valve liftover 8.5 mm (0.33 in.)] are at the standard value.



ECLA011C

Standard value :

Opening valve temperature 82° C (180° F)

Full - open temperature 95° C (203° F)

**NOTE**


Measure valve height when fully close. Calculate lift by measuring the height when fully open.

BELT

1. Check the surface for damage, peeling or cracks.
2. Check the surface for presence of oil or grease.
3. Check the rubber for wear or hardening.

WATER PUMP

1. Check each part for cracks, damage or wear, and replace the water pump assembly if necessary.
2. Check the bearing for damage, abnormal noise and sluggish rotation, and replace the water pump assembly if necessary.
3. Check the seal unit for leaks, and replace the water pump assembly if necessary.
4. Check for water leakage. If water leaks from hole "A" seal unit is defective. Replace as an assembly.




ECLA011B

INSTALLATION

ELCB0420

WATER PIPE O - RING

Fit water pipe O-ring in the groove provided at water pipe end, wet the periphery of water pipe O-ring and insert water pipe.




ECLA011E

**CAUTION**

1. Do not apply oil and grease to water pipe O-ring.
2. Keep the water pipe connections free of sand, dust, etc.
3. Insert water pipe until its end bottoms.

COMPONENTS ELCB0610

[TCI]




* Replace the gasket with new ones after removal.

TORQUE : Nm (kg.cm,lb.ft)

CYLINDER HEAD ASSEMBLY

CYLINDER HEAD

COMPONENTS ELCB0800




TORQUE : Nm (kg.cm, lb.ft)

*** Replace the gasket with new ones after removal**

ROCKER ARM

COMPONENTS ELCB0840



*Replace the gasket with new ones after removal.

TORQUE : Nm (kg.cm, lb.ft)


CHECKING COMPRESSION PRESSURE

EDHA1200

1. Before checking the engine compression, check the engine oil level. Also check that the starter motor and battery are all in normal operating condition.
2. Start the engine and wait until the engine coolant temperature reaches 80 - 95°C (176 - 205°F).
3. Stop the engine and disconnect the spark plug cables.
4. Remove the spark plugs.
5. Crank the engine to remove any foreign material in the cylinders.
6. Insert the compression gauge into the spark plug hole.
7. Depress the accelerator pedal to open the throttle fully.
8. Crank the engine and read the gauge.

Standard value : 1,200kpa(12.2 kg/cm² , 170psi)

Limit : 1,050kpa(10.7kg/cm² , 149psi)



EDHA015A

9. Repeat steps 6 to 8 for all cylinders, making sure that the pressure difference for each of the cylinders is within the specified limit.

Limit Max. 100kpa (1.0 kg/cm² , 14psi)

:

between cylinders

10. If a cylinder's compression or pressure differential is outside the specification, add a small amount of oil through the spark plug hole, and repeat steps 6 to 9.

- 1) If the addition of oil causes the compression to rise, it is possible that the piston ring is be worn.

- 2) If the compression remains the same, valve seizure, poor valve seating or a compression leak in the cylinder head gasket are all possible causes.

Tightening torque

Spark plug : 20-30 Nm (200-300 kg.cm, 14-22 lb.ft)

TIGHTENING CYLINDER HEAD

BOLTS


ECBB1300

1. First loosen slightly and then tighten to the specified torque.

Tightening torque

Cylinder head bolts cold [Engine temperature approximately 20°C (68°F)] :

105 - 115 Nm (1050 - 1150 kg.cm, 75 - 82 lb ft.)




EDA9010A

2. Be sure to follow the specific torque sequence as shown in the illustration.

NOTE

Run the engine to normal operating temperature and let it cool, then re-torque the bolts to specifications.




EDA9060B

DISASSEMBLY


EDMB0200

1. Remove intake manifold.
2. Disconnect the breather hose and the engine harness.
3. Remove the power steering pulley, air conditioner pulley, crankshaft pulley, idler pulley and tensioner pulley.
4. Remove the timing belt cover.
5. Loosen the auto tensioner.
6. Remove the timing belt from the camshaft sprocket.
7. Remove the spark plug cables.
8. Loosen the cylinder head cover bolts and then remove it.




EDB9030A

9. Remove the camshaft sprockets.
10. Remove the camshaft bearing caps.



EDB9030B

11. Remove the camshafts.



EDB9030C

INSPECTION

EDMB0210

CAMSHAFTS


1. Check the camshaft journals for wear. If the journals are badly worn out, replace the camshaft.
2. Check the cam lobes for damage. If the lobe is damaged or excessively worn out, replace the camshaft.

Cam height

[Standard]

Intake : 35.098 - 35.298 mm (1.3818 - 1.3897 in.)

Exhaust : 34.81 - 35.01 mm (1.3705 - 1.3783 in.)



EDA9260A

3. Check the cam surface for abnormal wear or damage, and replace if necessary.
4. Check each bearing for damage. If the bearing surface is excessively damaged, replace the cylinder head assembly or camshaft bearing cap, as necessary.

Camshaft end play : 0.1-0.15mm(0.0039-0.0059 in.)

OIL SEAL (CAMSHAFT FRONT)

1. Check the lips for wear. If lip threads are worn out, replace the oil seal with new one.
2. Check a contact surface of oil seal lip on camshaft. If there stratified wear, replace the camshaft.

CAUTION

Do not exceed $750 \pm 1,750$ kg ($1,653 \pm 3,858$ lb) of force when the installing tool seats against the top of the arch.

INSPECTION

ECBB3500

PISTONS AND PISTON PINS

1. Check each piston for scuffing, scoring, wear and other defects. Replace any piston that is defective.
2. Check each piston ring for breakage, damage and abnormal wear. Replace the defective rings. When the piston requires replacement, its rings should also be replaced.
3. Check that the piston pin fits in the piston pin hole. Replace any piston and pin assembly that is defective. The piston pin must be pressed smoothly by hand into the pin hole (at room temperature).

PISTON RINGS

1. Measure the piston ring side clearance. If the measured value exceeds the service limit, insert a new ring in the ring groove to measure the side clearance. If the clearance still exceeds the service limit, replace the piston and rings together. If it is less than the service limit, replace only the piston rings.

Piston ring side clearance

No.1 : 0.04 - 0.08 mm (0.0016 - 0.0031 in.)

No.2 : 0.02 - 0.06 mm (0.0008 - 0.0024 in.)

2. To measure the piston ring end gap, insert a piston ring into the cylinder bore. Position the ring at right angles to the cylinder wall by gently pressing it down with a piston. Measure the gap with a feeler gauge. If the gap exceeds the service limit, replace the piston ring.

Piston ring end gap

[Standard dimensions]

No.1 : 0.30 - 0.45 mm (0.012 - 0.018 in.)

No.2 : 0.45 - 0.60 mm (0.018 - 0.024 in.)

Oil ring side rail : 0.2-0.7 mm (0.0079 - 0.0276)


When replacing the ring without correcting the cylinder bore, check the gap with the ring situated at the lower part of cylinder that is less worn out.

PISTON RING SERVICE SIZE AND MARK

Standard	None
0.25 mm (0.010 in.) O.S	25
0.50 mm (0.020 in.) O.S	50
0.75 mm (0.030 in.) O.S	75
1.00 mm (0.040 in.) O.S	100

NOTE


The mark can be found on the upper side of the ring next to the end.



KFW3037C

CONNECTING RODS

1. When the connecting rod cap is installed, make sure that the cylinder numbers, marked on rod end cap at disassembly, match. When a new connecting rod is installed, make sure that the notches holding the bearing in place are on the same side.
2. Replace the connecting rod if it is damaged at either end of the thrust faces. If it has a stratified wear, or if the surface of the inside diameter of the small end is severely rough, replace the rod.




EDA9047A

RADIATOR


COMPONENTS

EDMB0300



LUBRICATION SYSTEM

OIL PUMP

COMPONENTS EDMB0400

TORQUE : Nm (kg·cm, lb.ft)


INSPECTION EDMB0700**CYLINDER HEAD**

1. Remove scale, sealing compound and carbon deposits. After cleaning oil passages, apply compressed air to make certain that the passages are not clogged.
2. Visually check the cylinder head for cracks, damage or water leakage.
3. Check the cylinder head surface for flatness with a straight edge and feeler gauge as shown in the illustration.

Cylinder head flatness:

Standard dimensions : Max. 0.03mm(0.0059 in.)

Service limit : 0.05mm(0.0020 in.)



KFW3047A

VALVE GUIDES


Check the valve stem-to-guide clearance. If the clearance exceeds the service limit, replace the valve guide with a new oversize guide.

Valve stem-to-guide clearance

Standard value

Intake : 0.02 - 0.05 mm (0.0009 - 0.0020 in.)


Exhaust : 0.050 - 0.085 mm (0.0020 - 0.0033 in.)



ECA9281D

VALVE

1. Replace the valve if its stem is bent, worn or damaged. Also replace it if the stem end (the surface contacting the hydraulic-lash adjuster) is hollowed out.
2. Check the valve face contact area, and recondition or replace as necessary.



ECA9281B


3. Replace the valve if the width of the margin (thickness of the valve head) is less than the minimum specified.

Valve margin

Standard value

Intake : 1.0mm (0.0394 in.)

Exhaust : 1.3mm (0.0512 in.)



EDA9300D

VALVE SPRING

1. Check the free height of each valve spring and replace if necessary.
2. Using a square, test the squareness of each valve spring. If the spring is excessively out-of-square, replace it.

Valve spring

Standard value

Free height : 46.4 mm (1.8268 in.)

Load : 24 kg / 37.9 mm (53 lb / 1.492 in.)

Out - of - square : Max. 2°

Service limit

Free height : .41.5 mm (1.6339 in.)

Load : 55.8 kg / 28.9 mm (123 lb / 1.1378 in.)