

BUMPER

FRONT BUMPER

- Put on gloves to protect your hands.
- Take care not to bend or scratch the cover and other parts.
- Replace any damage clips.



REPLACEMENT EOF7C583

NOTE

- When prying with a flat-tip screwdriver, wrap it with protective tape around the related parts, to prevent damage.

1. After loosening the mounting clips and bolts, remove the front bumper.
2. Installation is the reverse of removal.


Fastener Locations



1. Front bumper cover
2. Front bumper rail

CLUTCH SYSTEM

COMPONENTS E09C3452



TORQUE : Nm (kgf.m, lb-ft)

- | | |
|----------------------------|----------------------------|
| 1. Clutch pedal | 7. Clutch release fork |
| 2. Master cylinder | 8. Clutch cover |
| 3. Reserve hose | 9. Clutch disc |
| 4. Clutch tube | 10. Clutch release bearing |
| 5. Clutch release cylinder | 11. Damper |
| 6. Bolt | |

GENERAL**GENERAL** E12522AB**SPECIFICATION****IGNITION SYSTEM**


Items		Specification	
		1.6 DOHC	1.4 DOHC
Ignition coil	Primary resistance	0.87 ± 10 % (Ω)	
	Secondary resistance	13.0 ± 15 % (kΩ)	
Spark plugs (Unleaded)	NGK	BKR5ES-11	
	CHAMPION	RC10YC4	
	Gap	1.0 ~ 1.1 mm (0.0394 ~ 0.0433in.)	
Spark plugs (Leaded)	NGK	BKR5ES	
	CHAMPION	RC10YC	
	Gap	0.9 ~ 1.0 mm (0.0354 ~ 0.0394in.)	

STARTING SYSTEM

Items			Specification	
			1.6 DOHC	1.4 DOHC
Starter	Rated voltage		12 V, 0.9 kW	
	No. of pinion teeth		8	
	No-load characteristics	Voltage	11.5 V	
		Ampere	60A, MAX	
		Speed	5,500 rpm, MIN	
	Commutator diameter	Standard	33 mm (1.2992in.)	
	Under cut depth	Standard	0.5 mm (0.0197in.)	
		Limit	0.2 mm (0.0079in.)	

INSPECT STARTER BRUSH

Brushes that are worn out, or oil-soaked, should be replaced.




BBGE008A

NOTE

To seat new brushes, slip a strip of #500 or #600 sandpaper, with the grit side up, between the commutator and each brush, and smoothly rotate the armature. The contact surface of the brushes will be sanded to the same contour as the commutator.

STARTER BRUSH HOLDER TEST

1. Check that there is no continuity between the (+) brush holder (A) and (-) brush holder (B). If there is no continuity, replace the brush holder assembly.




ABHE012A

NOTE

Use a pipe (C) of suitable size for the brushes not to get removed from the brush holder.

INSPECT OVERRUNNING CLUTCH

1. Slide the overrunning clutch along the shaft. Replace it if it does not slide smoothly.
2. Rotate the overrunning clutch both ways. Does it lock in one direction and rotate smoothly in reverse? If it does not lock in either direction or it locks in both directions, replace it.



ABHE013A

3. If the starter drive gear is worn or damaged, replace the overrunning clutch assembly. (the gear is not available separately). Check the condition of the flywheel or torque converter ring gear if the starter drive gear teeth are damaged.

CLEANING

1. Do not immerse parts in cleaning solvent. Immersing the yoke assembly and/or armature will damage the insulation. Wipe these parts with a cloth only.
2. Do not immerse the drive unit in cleaning solvent. The overrun clutch is pre-lubricated at the factory and solvent will wash lubrication from the clutch.
3. The drive unit may be cleaned with a brush moistened with cleaning solvent and wiped dry with a cloth.


COMPRESSION PRESSURE INSPECTION

EEF8AA76

NOTE

If there is lack of power, excessive oil consumption or poor fuel economy, measure the compression pressure.

1. Warm up and stop engine.
Allow the engine to warm up to normal operating temperature.
2. Disconnect the ignition coil connectors and the spark plug cables. (Refer to EE group - ignition system)




KCPF020A

3. Remove the spark plugs.
Using a 16mm plug wrench, remove the 4 spark plugs.

4. Check the cylinder compression pressure.

- 1) Insert a compression gauge into the spark plug hole.



KDPC001B

- 2) Fully open the throttle.
- 3) While cranking the engine, measure the compression pressure.

NOTE

Always use a fully charged battery to obtain engine speed of 250rpm or more.

- 4) Repeat step 1) through 3) for each cylinder.

NOTE

This measurement must be done in as short a time as possible.

Compression pressure


Standard : 1,618kPa (16.5kg/cm², 235psi)
(250~400 rpm)

Minimum : 1,471kPa (15.0kg/cm², 213psi)

Difference between each cylinder :

98kPa (1.0kg/cm², 14psi) or less


- 14) Disconnect the water temperature sensor connector (E).



KCPF006A


16. Remove the transaxle wire harness connectors and control cable from transaxle (A/T).

- 1) Disconnect the transaxle range switch connector(A).
- 2) Disconnect the solenoid valve connector(B).
- 3) Disconnect the ATF oil temperature sensor connector (C).



ACJF021A


- 4) Disconnect the vehicle speed sensor connector(A).
- 5) Disconnect the band server switch connector(B).
- 6) Disconnect the pulse generator(A) connector(C).
- 7) Disconnect the pulse generator(B) connector(D).



ACJF022A

- 8) Remove the control cable nut(A) from transaxle range switch.


- 9) Remove the control cable(B).



ACJF023A

17. Disconnect the hose(A) of the PCSV (Purge Control Solenoid Valve) side.


18. Remove the brake booster vacuum hose(B).



ACJF018A

LUBRICATION SYSTEM

COMPONENT E41742E9




TORQUE : N.m (kgf.m, lb-ft)

- | | |
|---------------|---------------|
| 1. Front case | 5. Drain plug |
| 2. Filter | 6. Gasket |
| 3. Gasket | 7. Oil pan |
| 4. Oil screen | |

REMOVAL E5A01FA9


Engine removal is not required for this procedure.

1. Remove the drive belt(A).




ACGF031A

2. Remove the injector(A). (Refer to FLB Gr.)




LCGF003A

3. Remove the cylinder head cover(A).




LCGF004A

4. Remove the engine mounting support bracket.
 - 1) Set the jack to the engine oil pan




LDIF001A

- 2) Remove the engine mounting support bracket(A).



KDPF015A


5. Remove the alternator(A).



LCGF005A


RADIATOR

1. Drain the engine coolant.
Remove the radiator cap to speed draining.
2. Remove the upper radiator hose(A).




KDPF005A

3. Remove the lower radiator hose(A).




KDPF008A

4. Disconnect the fan motor connector(A).




KCPF014A

5. Remove the radiator upper bracket, then pull up the radiator.





KCPF015A

6. Remove the cooling fan assembly (A).



KCPF017A

SIGNAL WAVEFORM & DATA E36D0E92



The HO2S requires a minimum temperature to provide a closed loop fuel control system. So the HO2S contains a heater element to reduce its warm-up time and ensure its performance during all driving conditions. The HO2S heater is controlled ON after engine start except for Cold condition and high speed acceleration. The ECM controls this heater element by duty cycle. The main relay supplies voltage to the heater and the ECM provides a ground circuit for activating the heater.

LFJF318A

MONITOR SCANTOOL DATA E635098A

1. Connect scantool to DLC (Data Link Cable).
2. Warm up the engine to normal operating temperature.
3. Monitor "HO2S(B1S2)" parameter on scantool.

1.2 CURRENT DATA		21/69
× O2S OPERATION(B1/S1)	ON	▲
× O2S OPERATION(B1/S2)	ON	
× OXGEN SENSOR-B1/S1	0.7 V	■
× OXGEN SENSOR-B1/S2	0.8 V	
ANGLE BETWEEN CKP&CMP		
CAMSHAFT POSITION		
CAMSHAFT POSI.-TARGET		
TRANSAXLE RANGE SW		
FIX	PART	FULL
HELP	GRPH	RCRD

EGPF500D

4. Is the "HO2S Heater(B1/S2)" data displayed correctly?

YES

► Fault is intermittent caused by poor contact in the sensor' s and/or ECM' s connector or was repaired and ECM memory was not cleared. Thoroughly check connectors for looseness, poor connection, ending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

NO

DTC P0124 THROTTLE/PEDAL POSITION SENSOR/SWITCH "A" CIRCUIT INTERMITTANT

COMPONENT LOCATION E7185974

Refer to DTC P0121.

GENERAL DESCRIPTION E0A4A648

Refer to DTC P0121.

DTC DESCRIPTION EADC0CFE

If the difference between modeled relative load and measured relative load is over the threshold value according to throttle position under enable conditions, ECM sets DTC P0124.

DTC DETECTING CONDITION EBA6992E



Item	Detecting Condition	Possible Cause
DTC Strategy	<ul style="list-style-type: none"> • Rationality check 	<ul style="list-style-type: none"> • Poor connection • TPS • ECM
Enable Conditions	<ul style="list-style-type: none"> • Rate of change of throttle angle < 0.1221% • Engine speed > 600rpm • Coolant temperature > 75°C • Rate of change of predicted eng. load < 15% • Altitude > 0m • Time in idling > 30s 	
Threshold Value	<ul style="list-style-type: none"> • Difference between modeled relative load and measured relative load > threshold f(throttle position) 	
Diagnostic Time	<ul style="list-style-type: none"> • 2.5sec 	
MIL ON Condition	<ul style="list-style-type: none"> • DTC only 	

SPECIFICATION EA86BF80

Refer to DTC P0121.

SCHEMATIC DIAGRAM E0DFE9D7

Refer to DTC P0121.



1. Primary Coil Control(CYL2,3)
2. Primary Coil Control(CYL1,4)
3. Power

EFP6500Z

3) Is the measured resistance within specifications?

YES

▶ Go to "Timing mark check" procedure.

NO

▶ Substitute with a known - good ignition coil and check for proper operation.

▶ If the problem is corrected, replace ignition coil and go to "Verification of Vehicle Repair" procedure.

6. Timing mark check.

1) Key "OFF".

2) Check the timing mark.

3) Is the timing mark normal?

YES

▶ Go to "Air leakage check" procedure.

NO

▶ Repair and go to "Verification of Vehicle Repair" procedure.

7. Air leakage check.

- 1) Visually/physically inspect the air leakage in intake/exhaust system as following items,
 - Vacuum hoses for splits, kinks and improper connections.
 - Throttle body gasket
 - Gasket between intake manifold and cylinder head
 - Seals between intake manifold and fuel injectors
 - Exhaust system between HO2S and Three way catalyst for air leakage.

2) Has a problem been found in any of the above areas?

YES


▶ Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

NO

▶ Go to "PCV(Positive Crankcase Ventilation) valve check" procedure.

8. PCV(Positive Crankcase Ventilation) valve check.

FIG 4




BFGE501D

● CHECK SHORT CIRCUIT

1. Test Method for Short to Ground Circuit
 - Continuity Check with Chassis Ground

If short to ground circuit occurs as shown in [FIG. 5], the broken point can be found by performing below Step 2 (Continuity Check Method with Chassis Ground) as shown below.

FIG 5



BFGE501E

2. Continuity Check Method (with Chassis Ground)

NOTE

Lightly shake the wire harness above and below, or from side to side when measuring the resistance.


Specification (Resistance)

- 1Ω or less → Short to Ground Circuit
- 1MΩ or Higher → Normal Circuit

- a. Disconnect connectors (A), (C) and measure for resistance between connector (A) and Chassis Ground as shown in [FIG. 6].

The measured resistance of line 1 and 2 in this example is below 1 Ω and higher than 1MΩ respectively. Specifically the short to ground circuit is line 1 (Line 2 is normal). To find exact broken point, check the sub line of line 1 as described in the following step.

FIG 6




BFGE501F

- b. Disconnect connector (B), and measure the resistance between connector (A) and chassis ground, and between (B1) and chassis ground as shown in [FIG. 7].

The measured resistance between connector (B1) and chassis ground is 1Ω or less. The short to ground circuit is between terminal 1 of connector (C) and terminal 1 of connector (B1).


FIG 7



BFGE501G

SCHEMATIC DIAGRAM


EC35B133



EFPF001A

SIGNAL WAVEFORM & DATA

E50AF374



If you release the accelerator pedal suddenly after engine running about 4000 rpm, fuel supply will stop for short period and the O2 sensor service data in the Hi-Scan (Pro) will display values 200mV or lower. When you suddenly press on the accelerator pedal down, the voltage will reach 0.6 ~ 1.0 V. When you let the engine idle again, the voltage will fluctuate between 200 mV or lower and 0.6 ~ 1.0 V. In this case, the O2sensor can be determined as good.

LFJF421A

MONITOR SCANTOOL DATA

E5F261F7

1. Connect scantool to DLC (Data Link Cable).
2. Warm up the engine to normal operating temperature.

SIGNAL WAVEFORM AND DATA E3EB10C4




Fig.1




Fig.2




Fig.3

- Fig. 1) Waveform when variable swirl valve closed at idle. Terminal 1 is (+) and 2 is (-).
- Fig. 2) Waveform when variable swirl valve opened at above 3000RPM. Terminal 1 is (-) and 2 is (+).
- Fig. 3) Waveform of variable swirl control actuator motor position sensor at the point of turning engine OFF.
4.3V at swirl valve closed and 0.3V at swirl valve opened. Swirl valve is opened and closed twice at engine "OFF".

LGJF011H

TERMINAL AND CONNECTOR INSPECTION E2F0DEDA

1. Electrical systems consist of a lot of harness and connectors, poor connection of terminals can cause various problems and damage of component.
2. Perform checking procedure as follows.
 - 1) Check damage of harness and terminals : Check terminals for contact resistance, corrosion and deformation.
 - 2) Check connecting condition of ECM and component connector : Check terminal separation, damage of locking device and connecting condition between terminal and wiring.

NOTE

Disconnect the pin which requires checking at male connector and insert it to the terminal at female connector for checking connecting condition. (after checking, reconnect the pin at correct position.)

3. Is the problem found?