


PRECAUTIONS


NAS0003K

General Precautions


- Do not operate the engine for an extended period of time without proper exhaust ventilation.
Keep the work area well ventilated and free of any inflammable materials. Special care should be taken when handling any inflammable or poisonous materials, such as gasoline, refrigerant gas, etc. When working in a pit or other enclosed area, be sure to properly ventilate the area before working with hazardous materials.
Do not smoke while working on the vehicle.




- Before jacking up the vehicle, apply wheel chocks or other tire blocks to the wheels to prevent the vehicle from moving. After jacking up the vehicle, support the vehicle weight with safety stands at the points designated for proper lifting before working on the vehicle.
These operations should be done on a level surface.
- When removing a heavy component such as the engine or transaxle/transmission, be careful not to lose your balance and drop them. Also, do not allow them to strike adjacent parts, especially the brake tubes and master cylinder.



- Before starting repairs which do not require battery power:
Turn off ignition switch.
Disconnect the negative battery terminal.
- If the battery terminals are disconnected, recorded memory of radio and each control unit is erased.



- To prevent serious burns:
Avoid contact with hot metal parts.
Do not remove the radiator cap when the engine is hot.
- Dispose of drained oil or the solvent used for cleaning parts in an appropriate manner.
- Do not attempt to top off the fuel tank after the fuel pump nozzle shuts off automatically.
Continued refueling may cause fuel overflow, resulting in fuel spray and possibly a fire.
- Clean all disassembled parts in the designated liquid or solvent prior to inspection or assembly.
- Replace oil seals, gaskets, packings, O-rings, locking washers, cotter pins, self-locking nuts, etc. with new ones.
- Replace inner and outer races of tapered roller bearings and needle bearings as a set.
- Arrange the disassembled parts in accordance with their assembled locations and sequence.
- Do not touch the terminals of electrical components which use microcomputers (such as ECM).
Static electricity may damage internal electronic components.
- After disconnecting vacuum or air hoses, attach a tag to indicate the proper connection.
- Use only the fluids and lubricants specified in this manual.



HOW TO USE THIS MANUAL

NAS0003V

GI

Components

- **THE LARGE ILLUSTRATIONS** are exploded views (see the following) and contain tightening torques, lubrication points, section number of the **PARTS CATALOG** (e.g. SEC. 440) and other information necessary to perform repairs.

The illustrations should be used in reference to service matters only. When ordering parts, refer to the appropriate **PARTS CATALOG**.

Components shown in an illustration may be identified by a circled number. When this style of illustration is used, the text description of the components will follow the illustration.

B

C

D

E

F

G

H


I

J

K

L

M



SFIA2959E

- | | | |
|-------------------|----------------------|---------------------------------|
| 1. Union bolt | 2. Copper washer | 3. Brake hose |
| 4. Cap | 5. Bleed valve | 6. Sliding pin bolt |
| 7. Piston seal | 8. Piston | 9. Piston boot |
| 10. Cylinder body | 11. Sliding pin | 12. Torque member mounting bolt |
| 13. Washer | 14. Sliding pin boot | 15. Bushing |
| 16. Torque member | 17. Inner shim cover | 18. Inner shim |
| 19. Inner pad | 20. Pad retainer | 21. Pad wear sensor |
| 22. Outer pad | 23. Outer shim | 24. Outer shim cover |

1: PBC (Poly Butyl Cuprysil) grease 2: Rubber grease or silicone-based grease

: Brake fluid

Refer to GI section for additional symbol definitions.

SYMBOLS


| SYMBOL | DESCRIPTION | SYMBOL | DESCRIPTION |
|--------|---|--------|---|
| | Tightening torque The tightening torque specifications of bolts and nuts may be presented as either a range or a standard tightening torque. | | Always replace after every disassembly. |
| | : N•m (kg-m, ft-lb) : N•m (kg-m, in-lb) | | Apply petroleum jelly. |
| | Should be lubricated with grease. Unless otherwise indicated, use recommended multi-purpose grease. | | Apply molybdenum added petroleum jelly. |
| | Should be lubricated with oil. | | Apply ATF. |
| | Sealing point | | Select with proper thickness. |
| | Sealing point with locking sealant. | | Adjustment is required. |
| | Checking point | | |

SAIA0749E

TIMING CHAIN

2. Install camshaft sprockets.

- Install onto correct side by checking with identification mark on surface.
- Install camshaft sprocket (EXH) by selectively using the groove of dowel pin according to the bank. (Common part used for both banks.)
- Lock the hexagonal part of camshaft in the same way as for removal, and tighten fixing bolts.




3. Install crankshaft sprockets for both banks.


- Install each crankshaft sprocket so that its flange side (the larger diameter side without teeth) faces in the direction shown in figure.

NOTE:

The same parts are used but facing directions are different.



4. Install timing chains and associated parts.



- Align the mating mark on each sprocket and the timing chain for installation.

NOTE:

Before installing chain tensioner, it is possible to change the position of mating mark on timing chain for that on each sprocket for alignment.

ON BOARD REFUELING VAPOR RECOVERY (ORVR)

8. CHECK REFUELING CONTROL VALVE

Refer to [EC-41, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 9.
- NG >> Replace refueling control valve with fuel tank.

9. CHECK REFUELING EVAP VAPOR CUT VALVE

Refer to [EC-41, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 10.
- NG >> Replace refueling EVAP vapor cut valve with fuel tank.

10. CHECK FUEL FILLER TUBE

Check filler neck tube and hose connected to the fuel tank for clogging, dents and cracks.

OK or NG

- OK >> GO TO 11.
- NG >> Replace fuel filler tube.

11. CHECK ONE-WAY FUEL VALVE-I

Check one-way valve for clogging.

OK or NG

- OK >> GO TO 12.
- NG >> Repair or replace one-way fuel valve with fuel tank.


12. CHECK ONE-WAY FUEL VALVE-II

1. Make sure that fuel is drained from the tank.
2. Remove fuel filler tube and hose.
3. Check one-way fuel valve for operation as follows.
When a stick is inserted, the valve should open, when removing stick it should close.

Do not drop any material into the tank.

OK or NG

- OK >> **INSPECTION END**
- NG >> Replace fuel filler tube or replace one-way fuel valve with fuel tank.



NBS001Q1

Component Inspection WATER SEPARATOR


1. Check visually for insect nests in the water separator air inlet.
2. Check visually for cracks or flaws in the appearance.
3. Check visually for cracks or flaws in the hose.

DTC P0037, P0038, P0057, P0058 HO2S2 HEATER

NBS001SB

Wiring Diagram BANK 1

EC-O2H2B1-01





: DETECTABLE LINE FOR DTC
 : NON-DETECTABLE LINE FOR DTC

REFER TO PG-POWER.


HEATED OXYGEN
SENSOR 2
(BANK 1)
(E319)

ECM
(F101)



REFER TO THE FOLLOWING.

(B1) - FUSE BLOCK-JUNCTION BOX (J/B) NO.1



TBWM1221E

DTC P0441 EVAP CONTROL SYSTEM

DTC P0441 EVAP CONTROL SYSTEM


PPF:14950

System Description

NBS001WT

NOTE:

If DTC P0441 is displayed with other DTC such as P2122, P2123, P2127, P2128 or P2138, first perform trouble diagnosis for other DTC.



In this evaporative emission (EVAP) control system, purge flow occurs during non-closed throttle conditions. Purge volume is related to air intake volume. Under normal purge conditions (non-closed throttle), the EVAP canister purge volume control solenoid valve is open to admit purge flow. Purge flow exposes the EVAP control system pressure sensor to intake manifold vacuum.

On Board Diagnosis Logic

NBS001WU

Under normal conditions (non-closed throttle), sensor output voltage indicates if pressure drop and purge flow are adequate. If not, a malfunction is determined.

| DTC No. | Trouble diagnosis name | DTC detecting condition | Possible cause |
|---------------|--|--|--|
| P0441 0441 | EVAP control system incorrect purge flow | EVAP control system does not operate properly, EVAP control system has a leak between intake manifold and EVAP control system pressure sensor. | <ul style="list-style-type: none"> ● EVAP canister purge volume control solenoid valve stuck closed ● EVAP control system pressure sensor and the circuit ● Loose, disconnected or improper connection of rubber tube ● Blocked rubber tube ● Cracked EVAP canister ● EVAP canister purge volume control solenoid valve circuit ● Accelerator pedal position sensor ● Blocked purge port ● EVAP canister vent control valve |

DTC Confirmation Procedure

NBS001WV

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If DTC Confirmation Procedure has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:


Always perform test at a temperature of more than 5°C (41°F).

DTC P1805 BRAKE SWITCH

Wiring Diagram

NBS0025U


EC-BRK/SW-01



REFER TO THE FOLLOWING.

(F105) -SUPER MULTIPLE JUNCTION (SMJ)

(M1) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1



TBWM1249E

TROUBLE DIAGNOSIS FOR SYSTEM

DIAGNOSTIC PROCEDURE


1. CHECK VEHICLE SPEED SENSOR

Ⓟ With CONSULT-II

1. Start engine.
2. Select "DATA MONITOR" mode for "ACT D/SUS" with CONSULT-II.
3. Read out the value of "VHCL SPEED SE".

| Condition | Display value |
|-----------------|--|
| Vehicle stopped | 0 km/h (0 MPH) |
| Vehicle running | Approximately equal to the indication on speedometer (Inside of $\pm 10\%$) |


CAUTION:
Check air pressure of tire under standard condition.



ⓧ Without CONSULT-II

1. Start engine.
2. Check signal between active damper suspension control unit harness connector (A) terminal and ground with oscilloscope.

| Connector | Terminal | Condition | Data (Approx.) |
|-----------|-------------|---------------------------------|---|
| B37 | 22 - Ground | Vehicle speed: 40 km/h (25 MPH) | <p style="text-align: right;">SEIA0775E</p> |




OK or NG

- OK >> GO TO 4.
NG >> GO TO 2.

2. CHECK COMBINATION METER

1. Turn ignition switch "OFF".
2. Disconnect active damper suspension control unit harness connector.
3. Check signal between combination meter harness connector (A) terminal and ground with oscilloscope.

| Connector | Terminal | Condition | Data (Approx.) |
|-----------|-------------|---------------------------------|---|
| M41 | 18 - Ground | Vehicle speed: 40 km/h (25 MPH) | <p style="text-align: right;">SEIA0775E</p> |



Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 3.
NG >> Check combination meter. Refer to [DI-16, "Trouble Diagnosis"](#).

REMOTE KEYLESS ENTRY SYSTEM

NIS000UR

Check Key Switch


1. CHECK KEY SWITCH

With CONSULT-II

Check key switch "IGN KEY SW" in "DATA MONITOR" mode with CONSULT-II.

Key is inserted in ignition key cylinder : IGN KEY SW ON

Key is removed from ignition key cylinder : IGN KEY SW OFF



Without CONSULT-II


Check voltage between BCM connector and ground.

| Connector | Terminal (Wire color) | | Condition | Voltage (V) (Approx.) |
|-----------|-----------------------|--------|-----------------|-----------------------|
| | (+) | (-) | | |
| M4 | 69 (PU/W) | Ground | Key is inserted | Battery Voltage |
| | | | Key is removed | 0 |

OK or NG

OK >> Key switch is OK.

NG >> GO TO 2.



2. CHECK KEY SWITCH CIRCUIT

1. Disconnect BCM connector and key switch connectors.
2. Check continuity between BCM connector M4 terminal 69 and key switch connector M64 terminal 4.

69 (PU/W) – 4 (PU/W) : Continuity should exist.


3. Check continuity between BCM connector M4 terminal 69 and ground.

69 (PU/W) – Ground : Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Repair or replace harness.



SUNROOF


2. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between sunroof motor assembly connector R8 terminal 8 and ground.

8 (B) – Ground : Continuity should exist.

OK or NG

- OK >> Sunroof motor assembly power supply and ground is OK.
 NG >> Repair or replace harness.



Sunroof Motor Assembly Circuit System Check

NIS0010T


1. CHECK HARNESS CONTINUITY

1. Turn the ignition switch OFF.
2. Disconnect sunroof switch and sunroof motor assembly connectors.
3. Check continuity between sunroof switch connector R7 terminals 1, 2, 3, 4, 5, 6 and sunroof motor assembly connector R8 terminals 3, 4, 5, 9, 11, 12.

1 (PU) – 3 (PU) : Continuity should exist.
2 (R) – 9 (R) : Continuity should exist.
3 (L) – 11 (L) : Continuity should exist.
4 (SB) – 5 (SB) : Continuity should exist.
5 (P) – 4 (P) : Continuity should exist.
6 (G) – 12 (G) : Continuity should exist.

OK or NG

- OK >> Check the condition of the harness and the connector.
 NG >> Repair or replace harness.



Door Switch Check

NIS0010U

1. CHECK DOOR SWITCH INPUT SIGNAL

With CONSULT-II

- Check door switch in "DATE MONITOR" mode with CONSULT-II. Refer to [RF-16](#)


When door is opened : DOOR SW ON
When door is closed : DOOR SW OFF

Without CONSULT-II

- Check all door switches in switch monitor mode.
 Refer to Remote keyless entry system [BL-82, "SWITCH MONITOR"](#).


OK or NG

- OK >> Door switch is OK.
 NG >> GO TO 2



POWER SEAT

SE-SEAT-03



| | | | | | | | | |
|----|----|----|-----|----|----|----|----|-----|
| 43 | 36 | 44 | 28 | 26 | 20 | 32 | 22 | B23 |
| 24 | 18 | | 44B | 15 | | | 2 | W |

| | | | | | | | | |
|----|----|-------|----|----|----|----|----|-------|
| 4 | 2 | B162* | 28 | 21 | 36 | 24 | 20 | B163* |
| 15 | 11 | 8 | 5 | 44 | 74 | 32 | 22 | 43 |
| | | | | | 18 | 26 | | W |

| | | | | | |
|----|----|----|----|---|-------|
| 28 | 21 | 36 | 24 | 2 | B168* |
| 15 | 74 | 43 | 11 | 4 | 18 |
| | | | | | W |

| | | | | |
|---|---|---|---|-----|
| 5 | 3 | 6 | 4 | D55 |
| 9 | 7 | 2 | 8 | 1 |
| | | | | W |

REFER TO THE FOLLOWING.
 (B21), (B22) -SUPER MULTIPLE JUNCTION (SMJ)

*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

- through headlamp relay-2 terminal 3
- to daytime light control unit terminals 4 and 5
- to combination meter terminal 48 for the HIGH BEAM indicator.

Ground is supplied

- to daytime light control unit terminals 6 or 7
- through each front combination lamp terminal 13
- to each front combination lamp terminal 14
- through daytime light control unit terminals 9 or 10
- to daytime light control unit terminals 13 and 14
- through lighting switch terminals 6 and 9
- to daytime light control unit terminal 13
- through combination meter terminal 47 for the HIGH BEAM indicator
- to lighting switch terminals 5 and 8
- through grounds M25 and M115.

With power and ground supplied, the high beam headlamps and HIGH BEAM indicator illuminate.

BATTERY SAVER CONTROL

When the ignition switch is turned from ON (or START) to OFF (or ACC) positions while headlamps are illuminated, The RAP signal is supplied to terminal 10 of the headlamp battery saver control unit from BCM terminal 135.

After counting 45 seconds by the RAP signal from the BCM to headlamp battery saver control unit, the ground supply to terminals 1 of headlamp relay-1 and -2 from headlamp battery saver control unit terminals 2 and 8 is terminated.

Then headlamps are turned off.

The headlamps are turned off when driver or passenger door is opened even if 45 seconds have not passed after the ignition switch is turned from ON (or START) to OFF (or ACC) positions while headlamps are illuminated.

When the lighting switch is turned from OFF to 2ND after headlamps are turned to off by the battery saver control, ground is supplied

- to headlamp battery saver control unit terminals 5 and 13 from lighting switch terminal 11, and then
- to headlamp relay-1 and -2 terminals 1 from headlamp battery saver control unit terminals 2 and 8
- through headlamp battery saver control unit terminals 3 and 9, and
- through lighting switch terminal 12.

Then headlamps illuminate again.

AUTO LIGHT OPERATION

For auto light operation, refer to [LT-7, "AUTO LIGHT OPERATION"](#) .

DAYTIME LIGHT OPERATION

With the engine running, the lighting switch in the OFF or 1ST position and parking brake released, power is supplied

- through daytime light control unit terminal 7
- to front combination lamp RH terminal 13
- through front combination lamp RH terminal 14
- to daytime light control unit terminal 9
- through daytime light control unit terminal 6
- to front combination lamp LH terminal 13.
- through front combination lamp LH terminal 14
- to daytime light control unit terminal 10.

Ground is supplied

- to daytime light control unit terminal 16
- through grounds E24, E42 and E62.

Because the high beam headlamps are now wired in series, they operate at half illumination.

STEP LAMP


Terminals and Reference Values for BCM

NKS001AA

| Terminal No. | Wire color | Item | Measuring condition | | Reference value | |
|--------------|------------|---|---------------------|------------------------|-----------------|-----------------|
| | | | Ignition switch | Operation or condition | | |
| 17 | BR/Y | Data link RX | — | — | — | |
| 18 | G/B | Data link TX | — | — | — | |
| 33 | W | Door lock assembly rear LH (door switch) signal | OFF | Rear LH door switch | ON (open) | Approx. 0 V |
| | | | | | OFF (closed) | Battery voltage |
| 37 | W/G | Front door switch (passenger side) signal | OFF | Passenger door switch | ON (open) | Approx. 0 V |
| | | | | | OFF (closed) | Battery voltage |
| 56 | B | Ground | — | — | — | |
| 67 | G/W | Data line A-3 | — | — | — | |
| 68 | W/B | IGN power supply | ON | — | Battery voltage | |
| 105 | Y/L | Battery power supply | OFF | — | Battery voltage | |
| 113 | B | Ground | — | — | — | |
| 142 | W/R | Front door switch (driver side) signal | OFF | Driver door switch | ON (open) | Approx. 0 V |
| | | | | | OFF (closed) | Battery voltage |
| 143 | W/L | Door lock assembly rear RH (door switch) signal | OFF | Rear RH door switch | ON (open) | Approx. 0 V |
| | | | | | OFF (closed) | Battery voltage |

Terminals and Reference Values for Driver Door Control Unit (LCU01)

NKS001AB

| Terminal No. | Wire color | Item | Measuring condition | | Reference value | |
|--------------|------------|--------------------------------|---------------------|------------------------|---|-----------------|
| | | | Ignition switch | Operation or condition | | |
| 3 | R | Step lamp | OFF | Each door switch | ON (open) | Approx. 0 V |
| | | | | | OFF (closed) | Battery voltage |
| 5 | G/OR | Local data line | — | — |  <p style="text-align: right; font-size: small;">SIIA0591J</p> | |
| 8 | G/W | Data line A-3 | — | — | — | |
| 14 | Y/G | Power source (circuit breaker) | OFF | — | Battery voltage | |
| 15 | B | Ground | ON | — | Approx. 0 V | |

VEHICLE INFORMATION AND INTEGRATED SWITCH SYSTEM /WITHOUT NAVIGATION SYSTEM

Terminals and Reference Value for Display

NKS001CN


| Terminal No. (Wire color) | | Item | Signal input/ output | Condition | | Reference value (Approx.) |
|------------------------------|--------|---------------------------------|----------------------------|--------------------|--|---|
| (+) | (-) | | | Ignition switch | Operation | |
| 1 (W/G) | 4 | RGB signal (R: Red) | Input | ON | Select "Display Color Spectrum Bar" of "Display Diagnosis" in Confirmation/Adjustment mode function. | <p style="text-align: right;">SKIA0165E</p> |
| 2 (W/L) | 4 | RGB signal (G: Green) | Input | ON | Select "Display Color Spectrum Bar" of "Display Diagnosis" in Confirmation/Adjustment mode function. | <p style="text-align: right;">SKIA0166E</p> |
| 3 (G) | 4 | RGB signal (B: Blue) | Input | ON | Select "Display Color Spectrum Bar" of "Display Diagnosis" in Confirmation/Adjustment mode function. | <p style="text-align: right;">SKIA0167E</p> |
| 4 | Ground | RGB ground | — | ON | — | 0 V |
| 5 (L/Y) | | Horizontal synchronizing signal | Output | ON | Select "Rearview" in "Confirmation/Adjustment" mode and display the rearview image on the screen. | <p style="text-align: right;">SKIA0163E</p> |
| 6 (OR) | | Vertical synchronizing signal | Output | ON | Select "Rearview" in "Confirmation/Adjustment" mode and display the rearview image on the screen. | <p style="text-align: right;">SKIA0161E</p> |
| 7 (L/R) | | RGB synchronizing signal | Input | ON | Select "Display Color Spectrum Bar" of "Display Diagnosis" in Confirmation/Adjustment mode function. | <p style="text-align: right;">SKIA0164E</p> |
| 8 (LG) | | RGB area signal | Input | ON | Press the "INFO" switch. | <p style="text-align: right;">SKIA0162E</p> |

A
B
C
D
E
F
G
H
I
J
L
M

DI

TROUBLE DIAGNOSES WORK FLOW

[CAN]



- Confirm the unit name that "UNKWN" is displayed on the copy of "CAN DIAG SUPPORT MNTR" screen of "A/T", "VDC" and "ICC" as well as "ENGINE". And then, put a check mark to the check sheet table.

NOTE:

- For "A/T", "UNKWN" is displayed on "METER/M&A" and "AWD/4WD". But put a check mark only to "METER/M&A" because "UNKWN" is listed on the column of reception diagnosis on the check sheet table.
- For "VDC", "UNKWN" is displayed on "METER/M&A" and "STRG". Put check mark to them.
- For "ICC", "UNKWN" is displayed on "METER/M&A", "LANE KEEP", "STRG", "LANE DETECTOR", "TCM(I)" and "BCM/SEC". But put a check mark only to "METER/M&A" because "UNKWN" is listed on the column of reception diagnosis on the check sheet table.

A
B
C
D
E
F
G
H
I
J
LAN
L
M