

TIER 2 CURSOR SERIES

Industrial applications

C78

C78 ENT

C10

C10 ENT

C13

C13 ENT

CURSOR G-DRIVE

CURSOR 78 TE2
































CURSOR 13 TE1

CURSOR 13 TE2









CURSOR 13 TE3

Technical and Repair Manual

Graph and symbols

	Removal Disconnection		Intake
	Refitting Connection		Exhaust
	Removal Disassembly		Operation
	Fitting in place Assembly	ϱ	Compression ratio
	Tighten to torque		Tolerance Weight difference
	Tighten to torque + angle value		Rolling torque
	Press or caulk		Replacement Original spare parts
	Regulation Adjustment		Rotation
	Warning Note		Angle Angular value
	Visual inspection Fitting position check		Preload
	Measurement Value to find Check		Number of revolutions
	Equipment		Temperature
	Surface for machining Machine finish		Pressure
	Interference Strained assembly	$>$	Oversized Higher than.... Maximum, peak
	Thickness Clearance	$<$	Undersized Less than.... Minimum
	Lubrication Damp Grease		Selection Classes Oversizing
	Sealant Adhesive		Temperature < 0 °C Cold Winter
	Air bleeding		Temperature > 0 °C Hot Summer

CLEARANCE DATA


	Type	F2BE0684		F2B0687
		A*B001	A*B002	A*B101
	Compression ratio	16 ± 0.8	16 ± 0.8	16 ± 0.8
	Max. output kW (HP) rpm	265 (360) 2100	265 (360) 2100	220 (300) 2200
	Max. torque Nm (kgm) rpm	1420 (142) 1500	1420 (142) 1500	1250 (125) 1200
	Loadless engine idling rpm	1300	1300	900
	Loadless engine peak rpm	2110	2110	2430
	Bore x stroke Displacement	mm cm ³	115 x 125 7790	115 x 125 7790
	SUPERCHARGING Turbocharger type	Intercooler Direct injection HX40W		
	LUBRICATION Oil pressure (warm engine) - idling - peak rpm	bar bar	Forced by gear pump, relief valve single action oil filter 4 5	
	COOLING Water pump control Thermostat - start of opening °C		Liquid Through belt 85	

NOTE Data, features and performances are valid only if the setter fully complies with all the installation prescriptions provided by Iveco Motors.

Furthermore, the users assembled by the setter shall always be in conformance to couple, power and number of turns based on which the engine has been designed.

EDC control unit PIN-OUT**Connector "A" (Engine)**

Pin	Function
1 -	Engine rev sensor
2 -	Distribution rev sensor
3 -	---
4 -	Air temperature sensor mass
5 -	Engine coolant temperature sensor mass
6 -	Engine oil temperature and fuel temperature sensor ground
7 -	---
8 -	---
9 -	---
10 -	Engine oil temperature sensor signal
11 -	Fuel temperature sensor signal
12 -	Oversupply pressure sensor signal
13 -	Engine rev sensor
14 -	Distribution rev sensor
15 -	---
16 -	---
17 -	Boosting pressure sensor ground
18 -	---
19 -	---
20 -	---
21 -	Air temperature sensor signal
22 -	Engine coolant temperature sensor signal
23 -	Oversupply pressure sensor power supply
24 -	Injector power supply for cylinders 1 / 2 / 3
25 -	Injector power supply for cylinders 4 / 5 / 6
26 -	Cylinder 4 injector control
27 -	Cylinder 6 injector control
28 -	Cylinder 5 injector control
29 -	---
30 -	---
31 -	---
32 -	---
33 -	Cylinder 3 injector control
34 -	Cylinder 2 injector control
35 -	Cylinder 1 injector control

Figure 95

PRE/POST-HEATING RESISTANCE

The resistance is ~ 0,7 Ohm.

Such resistance is placed between the cylinder head and the suction manifold. It is used to heat up air during pre/post-heating operations.

When the ignition key is inserted, should any one of the temperature sensors – water, air, gas oil – detect a value below 10°C, the electronic control unit will activate pre/post-heating and turn on the relevant dashboard warning light for a variable time depending on the temperature.


After that time, the warning light starts blinking thus informing the driver that the engine can be started.

When the engine is running the warning light goes off, while the resistance is being fed for a certain time as a result of post-heating.

If the engine is not started, with the warning light flashing, in 20 / 25 seconds, the operation is cancelled to prevent draining the battery.

On the contrary, if reference temperatures are over 10°C, when the ignition key is inserted the warning light comes on for about 2 seconds and carries out the test and then goes out to signal that the engine can be started.

Figure 105



001256t

Selection of connecting rod half-bearings (rectified pins)

If pins have been rectified, the procedure described must be applied.



In this case, (for each undersizing) determine the tolerance field the new big end pins belong to, and install the half-bearings identified according to the relative table.

Figure 31

red/black =
2.074 to 2.083 mm

green/black =
2.063 to 2.073 mm

-0.127



72.789
72.798


1
green/black
green/black

2
green/black
green/black

3
green/black
green/black

72.799
72.808

2
red/black
red/black



green/black
green/black

72.809
72.818



3
red/black
red/black

red/black
red/black

green/black
green/black

-0.254

red
2.127 to 2.137 mm
green =
2.138 to 2.147 mm



72.671
72.680


1
red
red

2
green
green

3
green
green

72.681
72.691



red
red



green
green

-0.508

red =
2.254 to 2.264 mm
green =
2.265 to 2.274 mm



72.417
72.426


1
red
red

2
green
green

3
green
green

72.427
72.437


red
red



green
green


VIEWS OF ENGINE (F3AE0684D*B001 - F3AE0684G*B003)

Figure 1



LEFT-HAND SIDE VIEW


81852



RIGHT-HAND SIDE VIEW

81853


Figure 13



99363

For types F3AE0684D*B003 and F3AE0684E*B002 only, using tool 99360314 (2), unscrew the oil filters (1).

Figure 14




99273

Disconnect the fuel pipes (1) from the fuel pump (2).

Remove:

- the fuel pump (2);
- the fuel filter unit (3) and pipes (1).


Figure 15



99263

Take out the screws (2) and remove the intake manifold (1).

Figure 16



99264

Remove:

- the starter motor (1);
- the control unit (2) and its support;
- the oil dipstick (3) from the crankcase.

DEFINING THE CLASS OF DIAMETER OF THE MAIN JOURNALS AND CRANKPINS (Journals with nominal diameter)



Main journals and crankpins: determining the class of diameter of the journals.

Three sets of numbers are marked on the crankshaft in the position shown by the arrow (Figure 26 at top):

- The first number, of five digits, is the part number of the shaft.
- Under this number, on the left, a set of six digits refers to the crankpins and is preceded by a single digit showing the status of the journals (1 = STD, 2 = -0.127), the other six digits, taken singly, give the class of diameter of each of the crankpins they refer to (Figure 26 at top).
- The set of seven digits, on the right, refers to the main journals and is preceded by a single digit: the single digit shows the status of the journals (1 = STD, 2 = -0.127), the other seven digits, taken singly, give the class of diameter of each of the main journals they refer to (Figure 26 at bottom).

Figure 26


CLASS	CRANKPIN NOMINAL DIAMETER
1	82.970 to 82.979
2	82.980 to 82.989
3	82.990 to 83.000



CLASS	MAIN JOURNALS NOMINAL DIAMETER
1	92.970 to 92.979
2	92.980 to 92.989
3	92.990 to 93.000

ENGINE FLYWHEEL Fitting engine flywheel

Figure 41



DETAIL OF PUNCH MARKS ON ENGINE FLYWHEEL FOR PISTON POSITIONS


- A = Hole on flywheel with one reference mark, corresponding to the TDC of pistons 3-4.
- B = Hole on flywheel with one reference mark, corresponding to the TDC of pistons 1-6.

- C = Hole on flywheel with one reference mark, corresponding to the TDC of pistons 2-5.
- D = Hole on flywheel with two reference marks, position corresponding to 54°.

NOTE If the teeth of the ring gear mounted on the engine flywheel, for starting the engine, are very damaged, replace the ring gear. It must be fitted after heating the ring gear to a temperature of approx. 200°C.


Position the flywheel (1) on the crankshaft, lubricate the thread of the screws (2) with engine oil and screw them down. Lock rotation with tool 99360351 (3). Lock the screws (2) in three phases.
First phase: pre-tightening with torque wrench (4) to a torque of 120 Nm (12 kgm).

Figure 42
















NOTE The crankshaft has a locating peg that has to couple with the relevant seat on the engine flywheel.

Figure 43



Second phase: 90° corner closing with tool 99395216 (1).

		Type		F3B	
				mm	
	Measuring dimension	X		125	
	Max. connecting rod axis misalignment tolerance		==	0.08	
	Main journals	Ø1		99.970 to 100.000	
	- rated value				
	- class	1		99.970 to 99.979	
	- class	2		99.980 to 99.989	
	- class	3		99.990 to 100.000	
	Crankpins	Ø2		89.970 to 90.000	
	- rated value				
	- class	1		89.970 to 89.979	
	- class	2		89.980 to 89.989	
	- class	3		89.990 to 90.000	
	Main bearing shells	S1			
	Red			3.110 to 3.120	
	Green			3.121 to 3.130	
	Yellow*			3.131 to 3.140	
	Big end bearing shells	S2			
	Red			1.965 to 1.975	
Green			1.976 to 1.985		
Yellow*			1.986 to 1.995		
	Main bearing housings	Ø3		106.300 to 106.330	
	- rated value				
	- class	1		106.300 to 106.309	
	- class	2		106.310 to 106.319	
- class	3		106.320 to 106.330		
	Bearing shells - main journals ○			0.060 to 0.108 *	- 0.061 to 0.119 ** - 0.060 to 0.130 ***
	Bearing shells - big ends ○			0.050 to 0.108 *	- 0.051 to 0.109 ** - 0.050 to 0.098 ***
	Main bearing shells			0.127 - 2.254 - 0.508	
	Big end bearing shells			0.127 - 2.254 - 0.508	
	Main journal, thrust bearing	X1		47.95 to 48.00	
	Main bearing housing, thrust bearing	X2		40.94 to 40.99	
	Thrust washer halves	X3		3.38 to 3.43	
	Crankshaft end float			0.10 to 0.30	
	Alignment		1 - 2	≤ 0.025	
	Ovalization		1 - 2	0.010	
	Taper		1 - 2	0.010	

* Fitted in production only and not supplied as spares

○ Spares provided: * = standard spares - 0.127; ** = 0.254 - 0.508

SAFETY PRESCRIPTIONS

Standard safety prescriptions

Particular attention shall be drawn on some precautions that must be followed absolutely in a standard working area and whose non fulfillment will make any other measure useless or not sufficient to ensure safety to the personnel in-charge of maintenance.

Be informed and inform personnel as well of the laws in force regulating safety, providing information documentation available for consultation.

- Keep working areas as clean as possible, ensuring adequate aeration.
- Ensure that working areas are provided with emergency boxes, that must be clearly visible and always provided with adequate sanitary equipment.
- Provide for adequate fire extinguishing means, properly indicated and always having free access. Their efficiency must be checked on regular basis and the personnel must be trained on intervention methods and priorities.
- Organize and displace specific exit points to evacuate the areas in case of emergency, providing for adequate indications of the emergency exit lines.
- Smoking in working areas subject to fire danger must be strictly prohibited.
- Provide Warnings throughout adequate boards signaling danger, prohibitions and indications to ensure easy comprehension of the instructions even in case of emergency.

Prevention of injury













- Do not wear unsuitable cloths for work, with fluttering ends, nor jewels such as rings and chains when working close to engines and equipment in motion.
- Wear safety gloves and goggles when performing the following operations:
 - filling inhibitors or anti-frost
 - lubrication oil topping or replacement
 - utilization of compressed air or liquids under pressure (pressure allowed: ≤ 2 bar)
- Wear safety helmet when working close to hanging loads or equipment working at head height level.
- Always wear safety shoes when and cloths adhering to the body, better if provided with elastics at the ends.
- Use protection cream for hands.
- Change wet cloths as soon as possible
- In presence of current tension exceeding 48-60 V verify efficiency of earth and mass electrical connections. Ensure that hands and feet are dry and execute working operations utilizing isolating foot-boards. Do not carry out working operations if not trained for.
- Do not smoke nor light up flames close to batteries and to any fuel material.
- Put the dirty rags with oil, diesel fuel or solvents in anti-fire specially provided containers.

- Do not execute any intervention if not provided with necessary instructions.
- Do not use any tool or equipment for any different operation from the ones they've been designed and provided for: serious injury may occur.
- In case of test or calibration operations requiring engine running, ensure that the area is sufficiently aerated or utilize specific vacuum equipment to eliminate exhaust gas. Danger: poisoning and death.

During maintenance


- Never open filler cap of cooling circuit when the engine is hot. Operating pressure would provoke high temperature with serious danger and risk of burn. Wait until the temperature decreases under 50°C.
- Never top up an overheated engine with cooler and utilize only appropriate liquids.
- Always operate when the engine is turned off: whether particular circumstances require maintenance intervention on running engine, be aware of all risks involved with such operation.
- Be equipped with adequate and safe containers for drainage operation of engine liquids and exhaust oil.
- Keep the engine clean from oil tangles, diesel fuel and or chemical solvents.
- Use of solvents or detergents during maintenance may originate toxic vapors. Always keep working areas aerated. Whenever necessary wear safety mask.
- Do not leave rags impregnated with flammable substances close to the engine.
- Upon engine start after maintenance, undertake proper preventing actions to stop air suction in case of runaway speed rate.
- Do not utilize fast screw-tightening tools.
- Never disconnect batteries when the engine is running.
- Disconnect batteries before any intervention on the electrical system.
- Disconnect batteries from system aboard to load them with the battery loader.
- After every intervention, verify that battery clamp polarity is correct and that the clamps are tight and safe from accidental short circuit and oxidation.
- Do not disconnect and connect electrical connections in presence of electrical feed.
- Before proceeding with pipelines disassembly (pneumatic, hydraulic, fuel pipes) verify presence of liquid or air under pressure. Take all necessary precautions bleeding and draining residual pressure or closing dump valves. Always wear adequate safety mask or goggles. Non fulfillment of these prescriptions may cause serious injury and poisoning.

F2B ASSEMBLY CLEARANCE DATA

	Type	F2B
CYLINDER BLOCK AND CRANK MECHANISM COMPONENTS		mm
	Cylinder sleeve bore upper Ø 1 lower	130.200 to 130.225 128.510 to 128.535
	Cylinder liners: outer diameter: upper Ø 2 lower length L	130.161 to 130.186 128.475 to 128.500
	Cylinder sleeve - crankcase bore upper lower	0.014 to 0.064 0.010 to 0.060
	Outside diameter Ø 2	
 * Available dia. class	Cylinder sleeve inside diameter Ø 3 A* inside diameter Ø 3 B* Protrusion X	115.000 to 115.012 115.010 to 115.022 0.035 to 0.065
 <ul style="list-style-type: none">• Class A pistons supplied as spares.•• Class B pistons are fitted in production only and are not supplied as spares.	Pistons: measuring dimension X outside diameter Ø 1 A• outside diameter Ø 1 B•• outside diameter Ø 2	18 114.888 to 114.900 114.898 to 114.910 46.010 to 46.016
	Piston - cylinder sleeve	0.100 to 0.124
	Piston diameter Ø 1	-
	Pistons protrusion X	-
	Gudgeon pin Ø 3	45.994 to 46.000
	Gudgeon pin - pin housing	0.010 to 0.022

High pressure pump-inside structure

Figure 8



1. Cylinder. – 2. Three-lobe element. – 3. Cap intake valve. – 4. Ball delivery valve. – 5. Piston. – 6. Pump shaft. – 7. Low-pressure fuel inlet. – 8. Pumping elements supplying fuel ducts.


Every pumping unit is composed of:

- a piston (5) actuated by a three-lobe element (2) floating on the pump shaft (6). The element (2), being floating on a misaligned part of the shaft (6), when the shaft rotates, does not rotate therewith but is only translated in a circular movement along a wider radius, with the resulting alternate actuation of the three pumping elements;

- cap intake valve (3);
- ball delivery valve (4).

70498

Figure 17




MAIN DATA ABOUT CAMSHAFT BUSHES AND RELATED HOUSINGS


*Height to be obtained after driving the bushes.

Bush replacement

Figure 18




To replace front and rear bushes (1), remove and refit them using the beater 99360362 (2) and the handgrip 99370006 (3).

 When refitting the bushes (1), direct them to make the lubricating holes (2) coincide with the holes on the block housings.

Tappets

Figure 19



MAIN DATA CONCERNING THE TAPPETS AND THE RELEVANT HOUSINGS ON THE ENGINE BLOCK