

INDEX OF SECTIONS

	Section
General	1
Engines	2
Clutch	3
Gearboxes	4
Power take-off	5
Transfer box TC 1800-TC 2200	6
Propeller shafts	7
Axles	8
Front axles	9
Suspensions	10
Wheels and tyres	11
Steering	12
Pneumatic system - Brakes	13
Bodywork and Chassis frame	14
Programmed maintenance	15
Electric/electronic system	16

Aquila Trucks Centres

WHEELBASE

A **A** **A** **B** **B** **C** **C** **D**

VERSION WHEELBASE VERSION WHEELBASE VERSION WHEELBASE VERSION WHEELBASE

C 4 x 2 C 6 x 6	3500	C 8 x 4	4250	C/T 6 x 4	3200	1		
				C 8 x 8 C 8 x 4	4750	C 6 x 4 C 6 x 6	3500	2
C 6 x 6 C 6 x 4	3800	T 4 x 4 T 4 x 2	3800	C 4 x 2 C 4 x 4	3800	C 8 x 4 C 8 x 8	5020	3
				C 8 x 4	5820	C 4 x 2 C 4 x 4 C 6 x 4	4200	4
C 4 x 2 C 6 x 4	4200			C 4 x 2 C 4 x 4 C 6 x 4	4500			5
C 6 x 4	4800							6
C 4 x 2 C 6 x 4	5100							7

C = Chassis cabs
T = Tractors


Aquila Trucks Centres

ASSEMBLING THE ENGINE

Fix the engine block to the stand 99322230 by means of brackets 99361035.

Install the cylinder liners as described in page 56.

Figure 149




47586

Fit the oil spray nozzles (2), so that the dowel coincides with the block hole (3).

Place the half bearings (1) on the main bearings.


Figure 150



47570

Lubricate the half bearings, then install the crankshaft (2) by means of hoist and hook 99360500 (1).


Figure 151



49021

Place the half-bearings (1) on the main bearings in the underblock (2).


Figure 152



47595

By means of suitable equipment (1) apply silicone LOCTITE 5970 IVECO No. 2995644 to the block, as shown in the figure.

Figure 153



47596

Sealant application diagram

NOTE Fit the lower crankcase underblock within 10' of the application of the sealant.

Aquila Trucks Centres

Preliminary measurement of data to select main bearing and big end bearing shells

For each of the journals of the crankshaft, it is necessary to carry out the following operations:

MAIN JOURNALS:

- Determine the class of diameter of the seat in the crankcase.
- Determine the class of diameter of the main journal.
- Select the class of the bearing shells to mount.

CRANKPINS:


- Determine the class of diameter of the seat in the connecting rod.
- Determine the class of diameter of the crankpin.
- Select the class of the bearing shells to mount.

DEFINING THE CLASS OF DIAMETER OF THE SEATS FOR BEARING SHELLS ON THE CRANKCASE

On the front of the crankcase two sets of numbers are marked in the position shown.

- The first set of digits (four) is the coupling number of the crankcase with its base.
- The second set of digits (seven) is the class of diameter of each of the seats referred to.
- Each of these digits may be **1, 2 or 3**.

Figure 87




Aquila Trucks Centres

EPICYCLIC REDUCTION GEAR CONTROL

Reduced speeds

Figure 2/4



86338

PNEUMATIC SYSTEM DIAGRAM OF REDUCED SPEED ENGAGEMENT

The air from the vehicle's pneumatic system is reduced to a pressure of 9.5 bars by the pressure reduction unit (1). It then supplies the inhibitor valve D.

Now, taking the control lever onto the reduced speed position (1st H), the body A, integral with the speed control rod, opens the valve E that, via the pipe F, supplies the cylinder G.

The piston of the cylinder G, moving to the right, activates the ERG.

At the same time, the valve B closes, making it possible for the air from the pipe C to discharge into the atmosphere.

The movement of the piston causes the contact of the electric switch to close, which turns on the indicator light in the cab with the tortoise symbol.


NOTE The reduced speeds can be used in both slow range and fast range conditions, depending on the position of the pre-selector.

Aquila Trucks Centres

SPLITTER CONTROL FORK

Disassembly/Assembly

Figure 62




Remove the small block (2) from the splitter synchronizer connecting fork (1) and assemble the new small blocks.

GEAR CONTROL FORKS

Disassembly

Figure 63



Release and remove the control forks (1) and (4).

NOTE Do not change the control forks (1) and (4). If necessary, check the serial numbers of the packing list.

Remove the ring (3) hindering the simultaneous coupling of the control shaft (2).




Position the ring (3) onto the control shaft. Insert the control forks (1 and 4) into the ring correct position.

SECONDARY SHAFT

Disassembly

Figure 64



Remove the inner rings (5 and 10) of the roller bearings from the secondary shaft (9), using the extractor 99347100 (1), the holds 99347132 (4), the insert 99345057 (10) and suitable brackets (2).

Remove the safety ring (6).


Remove under press the double gear (7) and the gear (8).

NOTE The removal force of each gear can reach 500 kN.

DTC	FMI	Failing component	Type of Failure	Visible failure	Possible Cause	Repair action	Checks to be performed	Measuring conditions	Values to be detected	Remarks
33	0A	CLUTCH ACTUATOR - (Y15) SOLENOID VALVE CLUTCH ENGAGEMENT SLOW	INTERRUPTION	Comfort decreased when starting and manoeuvring; the clutch is controlled by the fast uncoupling valve.		Check the clutch actuator and the integrity of the connections with the gear actuator (electronic control unit)	Measure type: Resistance (Ohm) Measure point 1: Connector for clutch actuator - gearbox side Pin: 7 Measure point 2: Connector for clutch actuator - gearbox side Pin: 16	Connector Not connected; Key +15 OFF;	Min. value: 14 Ohm; Max. value: 20 Ohm;	
34	0A	CLUTCH ACTUATOR - (Y16) SOLENOID VALVE CLUTCH DISENGAGEMENT FAST	INTERRUPTION	Comfort decreased when starting and manoeuvring; the clutch is controlled by the fast uncoupling valve.		Check the clutch actuator and the integrity of the connections with the gear actuator (electronic control unit)	Measure type: Resistance (Ohm) Measure point 1: Connector for clutch actuator - gearbox side Pin: 12 Measure point 2: Connector for clutch actuator - gearbox side Pin: 17	Connector Not connected; Key +15 OFF;	Min. value: 14 Ohm; Max. value: 20 Ohm;	
35	0A	CLUTCH ACTUATOR - (Y14) SOLENOID VALVE CLUTCH ENGAGEMENT FAST	INTERRUPTION	Comfort decreased when starting and manoeuvring; the clutch is controlled by the fast uncoupling valve.		Check the clutch actuator and the integrity of the connections with the gear actuator (electronic control unit)	Measure type: Resistance (Ohm) Measure point 1: Connector for clutch actuator - gearbox side Pin: 8 Measure point 2: Connector for clutch actuator - gearbox side Pin: 17	Connector Not connected; Key +15 OFF;	Min. value: 14 Ohm; Max. value: 20 Ohm;	

Aquila Trucks Centres


Figure 48



39521

Lubricate the shoulder ring (2) and fit on the steering return lever (1) in the position indicated by the arrow (3).


Figure 49



39522

Fit the spacer (3) with the pins (4) positioned as shown in the drawing; fit the seal ring in the safety ring and insert between the yoke support and the stub axle.


Figure 50



39523

Fit the lever (3) on the stub axle. Tighten the screws (2) and use the torque wrench (1) to tighten to the correct value.


Figure 51



39524

Partially extract the upper pin (1) and insert the shim (2).







Figure 52



39525


Insert the upper pin (1). Assemble the brake air piping union support bracket (3) and secure in position with the screws (2).

Aquila Trucks Centres

TOOL NO.	DESCRIPTION
99341020 	Pair of tie rods for grips
99341023 	Grips
99345055 	Reaction block for extractors
99354001 	Wrench for differential gear housing bearing adjustment ring nuts
99354207 	Wrench (94.5 mm) for wheel hub bearings adjusting nut
99355081 	Wrench (60 mm) for differential bevel pinion nut (use with 99370317)

Aquila Trucks Centres


Figure 69



112496

Fit the compression spring (1).


Figure 70



112497

Fit the membrane seat (1).


Figure 71



112498


Fit the fork (1).

Figure 72



Apply some sealer on the piston threading (1). Insert the piston through the fork and the compression spring. Tighten to the prescribed torque.

Figure 73




112500

Insert the sleeve (2) in the fork (1).

Aquila Trucks Centres

Figure 2



39615

REAR SUSPENSION COMPONENTS

1. Clamping U-bolts - 2. Plate - 3. Leaf spring - 4. Nut - 5. Hanger - 6. Screw - 7. Washers - 8. Bushes -
 9. Shackle pins - 10. Nut - 11. Clamping plates - 12. Shackle plates - 13. Hanger - 14. Bump stop

Aquila Trucks Centres

502511 STATIC WHEEL BALANCING

Figure 1





Figure 2



16997

The front wheels can be balanced while on the vehicle using the electronic balancer 99305037; this method has the advantage of balancing the wheel along with the other rotating masses.

The operation must be carried out as follows:

- Jack up the front of the vehicle and check that the wheels can rotate freely.
- Position the pickup unit (1) under the axle near to the wheel, setting the height so that the wheel spinner of unit 99305037 (2) is in contact with the tyre; position an axle stand under the opposite end of the axle and lower the jack.

- Connect the lead (3) of the pickup unit to the balancer 99305037.
- Make a radial reference mark on tyre, using chalk or a strip of adhesive tape.
- Turn switch (2) to the static balancing position and sensitivity switch (4) to notch n° 5 on the graduated scale.
- Turn on switch (5) for the meter light (1) and turn on the strobe lamp (8).
- Turn the wheel spinner switch (6) to the first speed position in order to rotate the wheel.













Turn the wheel spinner switch (6) to the second speed position and push the balancer against the tyre.

As the wheel is spinning, the stroboscopic effect will make the reference mark appear static; the needle on the meter (1) will move from zero to a maximum value and then return to zero. Once the needle has started to fall, withdraw the balancer, switch off the wheel spinner completely (6) and brake the spinner motor by means of the brake lever (7).

The wheel will continue to revolve due to inertia and the new position of the reference mark should be noted.


Read the value shown by the needle on the weight indication meter (1). Multiply this value by ten to obtain the correction weight to be fitted to the rim.

Aquila Trucks Centres

MERITOR DUO-DUPLEX DRUM BRAKES		DRIVE AXLE 5985/2D
	Drum diameter: - Nominal \varnothing mm - 1 st uprating \varnothing mm - 2 nd uprating \varnothing mm	410 \div 410.4 412 \div 412.4 414 \div 414.4
	Brake lining thickness: - Nominal S mm - 1 st uprating S mm - 2 nd uprating S mm - minimum permissible S ₁₊ mm	22.95 23.95 24.95 6.95
	Diameter of brake linings: - Nominal \varnothing mm - 1 st uprating \varnothing mm - 2 nd uprating \varnothing mm	408 \div 409 410 \div 411 412 \div 413
	Width of brake linings: L mm	179 \div 180
	Clearance between brake linings and drum: G mm	0.5 \div 1.2
	Maximum error of concentricity in the drum diameter after turning E mm	0.04
	WHEEL HUBS	
	Wheel hub bearings	Two with tapered rollers SET-RIGHT
	Hub bearing end float mm	Not adjustable
	Hub bearing end float adjustment	Tightening to torque with ring nut
	Wheel hub bearing rolling torque	0.50 max -
	Oil for wheel hub bearings Tutela W 140/M DA Litres Quantity of oil for each hub Kg	- -

Aquila Trucks Centres


Figure 15



49849

GROUND POINT BEHIND THE BODY COMPUTER

Figure 16




73754

GROUND POINT BEHIND THE CLUSTER

Aquila Trucks Centres

Figure 151



72857

Invert the sequence of operations described above for reassembly.

The spiraled contact is supplied spare with its stop key (15) assembled as shown in the figure. After assembly on the steering wheel control support, rotate the key to cause breakage at the point indicated by the arrow and return it to steering wheel seat (5).