

Contents

SECTION 00—General Information

- Group 0001—Safety
- Group 0002—General Specifications
- Group 0003—Torque Values
- Group 0004—Fuels And Lubricants

SECTION 01—Tracks

- Group 0130—Track System

SECTION 02—Axles And Suspension Systems

- Group 0250—Axle Shaft, Bearings, And Reduction Gears
- Group 0260—Hydraulic System

SECTION 04—Engine

- Group 0400—Removal And Installation

SECTION 05—Engine Auxiliary System

- Group 0505—Cold Weather Starting Aids
- Group 0510—Cooling System
- Group 0515—Speed Controls
- Group 0520—Intake System
- Group 0530—External Exhaust Systems
- Group 0560—External Fuel Supply Systems

SECTION 07—Dampener Drive (Flex Coupling)

- Group 0752—Elements

SECTION 16—Electrical System

- Group 1671—Batteries, Support, And Cables
- Group 1672—Alternator, Regulator, And Charging Wiring
- Group 1673—Lighting System
- Group 1674—Wiring Harness And Switches
- Group 1675—System Controls
- Group 1676—Instruments And Indicators

SECTION 17—Frame Or Supporting Structure

- Group 1740—Frame Installation
- Group 1749—Chassis Weights

SECTION 18—Operator's Station

- Group 1800—Removal And Installation

- Group 1810—Operator Enclosure
- Group 1821—Seat
- Group 1830—Heating And Air Conditioning

SECTION 20—Safety And Convenience

- Group 2004—Horn And Warning Devices

SECTION 33—Excavator

- Group 3302—Bucket
- Group 3340—Frames
- Group 3360—Hydraulic System

SECTION 43—Swing Or Pivoting System

- Group 4311—Brakes
- Group 4350—Mechanical Drive Elements
- Group 4360—Hydraulic System

SECTION 99—Dealer Fabricated Tools

- Group 9900—Dealer Fabricated Tools

00

01

02

04

05

07

16

17

18

20

Handle Chemical Products Safely

Direct exposure to hazardous chemicals can cause serious injury. Potentially hazardous chemicals used with John Deere equipment include such items as lubricants, coolants, paints, and adhesives.

A Material Safety Data Sheet (MSDS) provides specific details on chemical products: physical and health hazards, safety procedures, and emergency response techniques.

Check the MSDS before you start any job using a hazardous chemical. That way you will know exactly what the risks are and how to do the job safely. Then follow procedures and recommended equipment.

(See your John Deere dealer for MSDS's on chemical products used with John Deere equipment.)



TS1132 -UN-26NOV90

DX,MSDS,NA -19-03MAR93-1/1

Handle Fluids Safely—Avoid Fires

Handle fuel with care; it is highly flammable. Do not refuel the machine while smoking or when near open flame or sparks. Always stop engine before refueling machine. Fill fuel tank outdoors.



TS202 -UN-23AUG88

TX,05,FF1622 -19-14JUN90-1/2

Store flammable fluids away from fire hazards. Do not incinerate or puncture pressurized containers.

Make sure machine is clean of trash, grease, and debris.

Do not store oily rags; they can ignite and burn spontaneously.




TS227 -UN-23AUG88

TX,05,FF1622 -19-14JUN90-2/2

Service Recommendations for Flat Face O-Ring Seal Fittings

1. Inspect the fitting sealing surfaces. They must be free of dirt or defects.
2. Inspect the O-ring. It must be free of damage or defects.
3. Lubricate O-rings and install into groove using petroleum jelly to hold in place.
4. Push O-ring into the groove with plenty of petroleum jelly so O-ring is not displaced during assembly.
5. Index angle fittings and tighten by hand pressing joint together to insure O-ring remains in place.
6. Tighten fitting or nut to torque value shown on the chart per dash size stamped on the fitting. Do not allow hoses to twist when tightening fittings.



T6243AD -UN-18OCT88


FLAT FACE O-RING SEAL FITTING TORQUE

| Nominal Tube O.D. | | Dash Size | Thread Size in. | Swivel Nut | | Bulkhead Nut | |
|-------------------|-------|-----------|--------------------|------------|-------|--------------|-------|
| mm | in. | | | N•m | lb-ft | N•m | lb-ft |
| 6.35 | 0.250 | -4 | 9/16-18 | 16 | 12 | 5.0 | 3.5 |
| 9.52 | 0.375 | -6 | 11/16-16 | 24 | 18 | 9.0 | 6.5 |
| 12.70 | 0.500 | -8 | 13/16-16 | 50 | 37 | 17.0 | 12.5 |
| 15.88 | 0.625 | -10 | 1-14 | 69 | 51 | 17.0 | 12.5 |
| 19.05 | 0.750 | -12 | 1 3/16-12 | 102 | 75 | 17.0 | 12.5 |
| 22.22 | 0.875 | -14 | 1 3/16-12 | 102 | 75 | 17.0 | 12.5 |
| 25.40 | 1.000 | -16 | 1 7/16-12 | 142 | 105 | 17.0 | 12.5 |
| 31.75 | 1.250 | -20 | 1 11/16-12 | 190 | 140 | 17.0 | 12.5 |
| 38.10 | 1.500 | -24 | 2-12 | 217 | 160 | 17.0 | 12.5 |

NOTE: Torque tolerance is +15 -20%.

04T,90,K67 -19-01AUG94-1/1

26. Install the third planet gears (A) using DFT1095 Planet Gear Assembly Tool and DFT1094 Bearing Pilot Tool. (See Section 99 for instruction to make tools.)



02
0250
29


T7401AH -UN-27JAN92

TX,0250,DX266 -19-11NOV94-8/14

27. Install third planetary carrier (A) on gear shafts (B).
28. Pull carrier down on shafts and bushing using cap screws and washers.
29. Clean cap screw threads using clean and cure primer. Apply thread lock and sealer (medium strength) to threads.
30. Tighten cap screws to 540 N•m (400 lb-ft).

Specification

Cap Screws—Torque 540 N•m (400 lb-ft)



T7626BZ -UN-06DEC91

Continued on next page


TX,0250,DX266 -19-11NOV94-9/14



CAUTION: Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.


2. Drain coolant. Approximate radiator capacity is 34 L (9 gal).



TS281 -UN-23AUG88

TX,04,DY2884 -19-20AUG97-2/12

3. Remove air intake hose (A).
4. Remove upper radiator hose (B) and lower radiator hose (F).
5. Remove eight cap screws to remove upper and lower fan guards (D).
6. Remove six cap screws to remove fan (C).
7. Remove eight cap screws to remove shroud (E).



T7626CV -UN-18DEC91

- A—Air Intake Hose
- B—Upper Radiator Hose
- C—Fan
- D—Fan Guard
- E—Fan Shroud
- F—Lower Radiator Hose

Continued on next page

TX,04,DY2884 -19-20AUG97-3/12

Remove And Install Turbocharger (Serial No. —559602)

CAUTION: Allow exhaust system to cool before removal.


Thoroughly clean exterior of turbocharger and surrounding area to prevent entry of dirt into the air intake system during removal.

1. Remove air intake hose (F) and exhaust adapter (D).
2. Loosen clamps to remove air inlet hose (A).
3. Disconnect lines (C and E).
4. Remove cap screws and nuts (B) and remove turbocharger and gasket.
5. Cap and plug all openings.
6. Inspect parts. Repair or replace as necessary.
7. Install gasket, turbocharger and cap screws. Do not tighten cap screws.
8. Put a small amount of engine oil in oil inlet line. Connect lines.
9. Rotate compressor housing to align with air inlet hose (A). Tighten hose clamps until hose deforms around clamp band.
10. Tighten cap screws (B) to 47 N•m (35 lb-ft).

Specification

Turbocharger (—
559602) Turbocharger-to-Manifold
Cap Screw—Torque 47 N•m (35 lb-ft)

11. Connect hose (F). Tighten clamp until hose deforms around clamp band.
12. Tighten U-bolts until muffler just starts to crush against support.



A—Air Inlet Hose
B—Turbocharger-to-Exhaust Manifold Cap Screw (4 used)
C—Oil Return Line
D—Exhaust Adapter
E—Oil Inlet Line
F—Air Cleaner-to-Turbocharger Hose

T7681FX -JUN-23FEB92

04
0400
61

11. Install cover.

TX,1671,AB42 -19-12APR95-2/2

Adding 12-Volt Battery Accessories

IMPORTANT: This unit has a 24-volt electrical system. Installing 12-volt accessories without addition of 24-volt-to-12-volt converter may cause battery failure. See your John Deere dealer.


When possible, use 24-volt accessories.

| System—Voltage | Specification |
|----------------|---------------|
| | 24 volts |

If 12-volt accessories are added, use a 24-volt-to-12-volt converter. Converters are available from your John Deere dealer (see the Industrial Equipment Attachment Guide) or electronic retail stores. This converter may be wired into the ACC terminal of the ignition switch (see drawing).

Converter capacity requirements depend on the load of the accessories installed. Follow electronic dealer and manufacturer's recommendations to determine the capacity of the converter required and its installation requirements.

DO NOT connect an accessory to one battery. Connecting a 12-volt accessory to one battery will cause one battery to overcharge, and the other battery to undercharge, causing battery failure.



- A—Battery
- B—24 Volts
- C—Ignition Switch
- D—ACC Terminal
- E—Converter
- F—12 Volts
- G—In-Line Fuse
- H—12-Volt Accessory

TX,1671,AB301 -19-13JAN92-1/1

Remove And Install Seat (Serial No. — 538404)


1. Remove cap screws (A) to remove cover (B).
2. Remove the front two cap screws (D).

Tip console up for access to the rear two cap screws.
Lay console on cover behind seat.

3. Remove cap screws (C) from seat base.

⚠ CAUTION: Approximate weight of seat is 34 kg (75 lb).

4. Remove seat.
5. Inspect parts for wear.
6. Install seat.
7. Install cap screws (C).
8. Install consoles and cap screws (D).
9. Install cover (B) and cap screws (A).



T7681AL —UN—08JAN92

- A—Cap Screw (3 used)
- B—Cover
- C—Cap Screw (4 used)
- D—Cap Screw (4 used)

TX,18,DW5013 —19—18JUL97—1/1


Specifications

| Item | Measurement | Specification |
|-----------------|---------------------|-----------------------------|
| Tooth Shank | Preheat Temperature | 204—316°C (400—600°F) |
| | Fillet Weld | 12.7 mm (0.5 in.) |
| | Distance From Edge | 25 ± 6 mm (0.98 ± 0.24 in.) |
| Arm-to-Arm Link | Clearance | 1.5 mm (0.06 in.) |
| Bucket Linkage | Clearance | 0.5 mm (0.020 in.) |
| Item | Measurement | Specification |
| Bucket Linkage | | |
| | Nut | Torque |


TX,3302,DX374 -19-14APR95-1/1

Replacing Bucket Tooth Tip—Heavy-Duty Bucket

- Clean tooth (A) and tooth tip (B).
 - Insert lock removal tool under U-shaped pin (C).
- CAUTION:** Avoid possible injury. Pin may fly after it is released from tooth tip. Keep a firm grip on pin to prevent injury.
- Remove pin.
 - Turn tooth tip counterclockwise and pull it towards you to remove.
 - Clean tooth shank.
 - Replace U-shaped pin at same time you replace tooth tip.
 - Insert tooth tip on shank turning tip clockwise.
 - Install U-shaped pin. Side of pin marked "FRONT" (D) must face tooth tip. Make sure pin is firmly engaged over tooth tip.



T6879EE



A—Tooth
B—Tooth Tip
C—Pin
D—"Front" Mark

T6879EE -JUN-06DEC88

T7527DO -JUN-27JUN91

04T,90,K273 -19-28JAN92-1/1


Remove And Install Hydraulic Pump (Serial No. —559602)

1. Loosen reservoir fill cap to release air pressure from reservoir.
2. Drain reservoir. Approximate capacity is 148 L (39 gal).
3. Remove pump regulator housing (A).
4. Disconnect lines (B—H).


⚠ CAUTION: The approximate weight of hydraulic pump is 125 kg (276 lb).

5. Remove pump.
6. Repair or replace pump as necessary.

- A—Pump Regulator Housing
- B—Drain Port-to-Reservoir
- C—Inlet Port-to-Reservoir
- D—Drain Port-to-Reservoir
- E—Inlet Port-to-Reservoir
- F—Outlet Port-to-Pilot Filter
- G—Outlet Port-to-Control Valve Upper Port
- H—Outlet Port-to-Control Valve Lower Port



T7626CG -UN-18DEC91



T7626CH -UN-18DEC91

Hydraulic Pump And Pilot Pump Line

Continued on next page

TX,33,DY2944 -19-26AUG97-1/3

Hydraulic Oil Filter Inspection Procedure


Pour oil out of filter to inspect for water contamination.

Use an oil filter cutting tool to cut top off filter.

Remove element and inspect for metal particles and debris in bottom of filter can.

Excessive amounts of brass and steel particles can indicate a failed hydraulic pump or a pump failure in process.

A rubber type of material can indicate cylinder packing failure.



33
3360
63

IT4633 -JUN-19JAN90

902525,F4A -19-18JUL94-1/1

13. Remove valve sections and pressure control manifold (B—H) from control valve manifold (A).

14. Repair or replace valve sections and manifold as necessary.


15. Install valve sections.

Specification

| | |
|---|-------------------|
| Swing Valve-to-Manifold—Torque..... | 49 N•m (36 lb-ft) |
| Boom Valve-to-Manifold—Torque | 86 N•m (63 lb-ft) |
| Bucket Valve-to-Manifold— Torque | 86 N•m (63 lb-ft) |
| Left Propel Valve-to-Manifold— Torque | 49 N•m (36 lb-ft) |
| Arm Valve-to-Manifold—Torque | 86 N•m (63 lb-ft) |
| Right Propel Valve-to-Manifold— Torque | 49 N•m (36 lb-ft) |

16. Install valve.

- A—Manifold
- B—Swing Valve
- C—Boom Valve
- D—Bucket Valve
- E—Left Propel Valve
- F—Right Propel Valve
- G—Arm Valve
- H—Pressure Control Manifold




T7681DK -UN-22JAN92

TX,33,DY2960 -19-26AUG97-8/14

17. Install cap screws (A) and tighten to 75 N•m (55 lb-ft).

Specification

| | |
|----------------------------------|-------------------|
| Mounting Cap Screws—Torque | 75 N•m (55 lb-ft) |
|----------------------------------|-------------------|




T7681DJ -UN-22JAN92

Continued on next page

TX,33,DY2960 -19-26AUG97-9/14

Disassemble And Assemble Swing Valve Section



A—Make-Up Valve
B—Ball

C—Balance Valve

D—Pilot Check Valve

E—Pilot Cap Relief Valve (Air Bleed Valve)

Tighten pilot check valve (D) to 9 N•m (80 lb-in.).

Tighten pilot cap relief valve (E) to 6 N•m (55 lb-in.).

Specification

Pilot Check Valve—Torque 9 N•m (80 lb-in.)

Specification


Pilot Cap Relief Valve—Torque..... 6 N•m (55 lb-in.)

T7681EC -UN-27JAN92

Continued on next page

TX,3360,AB397 -19-20APR95-1/6

**Disassemble And Assemble Swing Torque Control Valve
(Serial No. —546276)**



T8455AG (CV)

- | | | | |
|---------------|------------------|-------------|--------------------|
| 1—Plug | 8—Shuttle Spool | 15—O-Ring | 22—Screw |
| 2—Spring Seat | 9—Plug | 16—Sleeve | 23—Nut |
| 3—Spring | 10—Orifice | 17—Piston | 24—Relief Valve |
| 4—Shim | 11—Plug | 18—Spring | 25—Plug |
| 5—Spring | 12—Plug | 19—Retainer | 26—O-Ring (3 used) |
| 6—Spring Seat | 13—Check Valve | 20—O-Ring | 27—O-Ring (2 used) |
| 7—Spool | 14—Shuttle Valve | 21—Plug | |


T8455AG -UN-18APR95

TX,3360,DW602 -19-27AUG97-1/1

9. Remove parts (A—F) from rod (I).

10. Remove O-ring (G).

- A—Cap Screw (Arm cylinder only)
- B—Washer (Arm cylinder only)
- C—Cushion (Arm cylinder only)
- D—Nut
- E—Piston
- F—Cushion
- G—O-Ring
- H—Rod Guide
- I—Cylinder Rod




TX,3360,VV389 -19-25NOV91-6/10

11. Remove parts (A—E) from the piston (F).

12. Remove rod guide from rod.

- A—Wiper Ring (2 used)
- B—Seal Expander
- C—Cap Seal
- D—Backup Ring (2 used)
- E—Wear Ring (2 used)
- F—Piston



Continued on next page

TX,3360,VV389 -19-25NOV91-7/10