

## RECOGNIZE SAFETY INFORMATION

This is the safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe operating practices.



DX,ALERT -19-04JUN90

10  
05  
1  
-UN-07DEC88  
T81389

## UNDERSTAND SIGNAL WORDS

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards.

DANGER or WARNING safety signs are located near specific hazards. General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.



DX,SIGNAL -19-09JAN92

-19-30SEP88  
TS187

## HANDLE FLUIDS SAFELY—AVOID FIRES

When you work around fuel, do not smoke or work near heaters or other fire hazards.

Store flammable fluids away from fire hazards. Do not incinerate or puncture pressurized containers.

Make sure machine is clean of trash, grease, and debris.

Do not store oily rags; they can ignite and burn spontaneously.



DX,FLAME -19-04JUN90

-UN-23AUG88  
TS227

**BASIC ENGINE APPLICATIONS  
CHART—CONTINUED**

**LAWN AND GARDEN TRACTORS**

Machine	Engine Model No.
240 .....	FC420V
245 .....	FC420V
260 .....	FC540V
265 .....	FC540V
GT262 .....	FC540V
GT242 .....	FC420V

**FRONT MOWERS**

Machine	Engine Model No.
F710 .....	FC540V

**GOLF AND TURF EQUIPMENT**

Machine	Engine Model No.
22 Greensmower .....	FG150G
22R Greensmower .....	FG150D
519 Walk-Behind Vertical Mower .....	FA210D
529 Vacuum Blower .....	FA210D
1200 Bunker and Field Rake .....	FE290R

**MISCELLANEOUS**

Machine	Engine Model No.
1000 Generator .....	FA130D
1400 Generator .....	FA130D
Power Pak Material Collection System .....	FA210D

**UTILITY VEHICLES**

Machine	Engine Model No.
AMT600 .....	KF82D/FZ340D
AMT622 .....	FE290D
AMT626 .....	FE290D
Gator 4x2 .....	FE290D

MX,1010A1,A3 -19-21OCT92

# Group 00 Engine Application and Repair Specifications

## ENGINE APPLICATIONS CHART

Refer to the engine application chart to identify product-model/engine type-model relationship.

Machine	Engine Model No.
3K Lawn Edger . . . . .	FA130D-AS16
E35 Lawn Edger . . . . .	FA130D-AS19
1000/1400 Generators . . . . .	FA130D-AN00
20SR7 Reel Mower . . . . .	FA130D-AS16
519 Walk-Behind Vertical Mower . . . . .	FA210D-AS20
529 Vacuum Blower . . . . .	FA210D-AS19-01
Power Pak Material Collection System	
(Engine S.N. —254693) . . . . .	FA210D-AS17
(Engine S.N. 254694—289197) . . . . .	FA210D-BS17
(Engine S.N. 289198— ) . . . . .	FA210D-CS17


MX,2000A1,A1 -19-21OCT92

20  
00  
1

**REMOVE AND INSTALL BLOWER HOUSING—FA130D AND FA210D-AS20**

*NOTE: It is not necessary to remove recoil starter from housing.*

1. Disconnect spark plug cap (A).
2. Remove fuel tank, if equipped. (See this group.)
3. Disconnect wiring lead (C).
4. Remove blower housing (B).
5. Install blower housing.
6. Connect wiring lead.
7. Install fuel tank, if equipped.
8. Connect spark plug cap.



M80242 -UN-11MAR91

20  
10  
1


MX,2010A1,A1 -19-21OCT92

## REMOVE AND INSTALL VALVES AND SPRINGS

1. Remove carburetor. (See Group 05.)
2. Remove cylinder head. (See Group 15.)
3. Remove tappet chamber cover/breather and gasket.

**IMPORTANT: Mark and keep springs and valves together.**

4. Compress valve spring (D) with a spring compressor (A) and move spring retainer (C) so larger hole is around valve stem.
5. Remove compressor, valves, spring and retainers.
6. Inspect and analyze valves. (See Section 100, Group 05.)
7. Inspect springs, valve guides and seats. (See this group.)
8. Check valve-to-tappet clearance. (See this group.)
9. Check that drainback hole (B) is open.
10. Align valve springs and retainers in tappet chamber.
11. Coat valve stems with oil and install in cylinder block.
12. Compress each spring and position retainer so smaller hole is around valve stem.
13. Install tappet chamber cover/breather and new gasket.
14. Install cylinder head.
15. Install carburetor.



A—Spring Compressor  
B—Drainback Hole  
C—Spring Retainer  
D—Valve Spring


M80317 -UN-11MAR91

21  
20  
2

MX,2120A1,A1 -19-21OCT92

## REMOVE AND INSTALL PISTON RINGS

1. Remove piston rings with a piston ring expander.
2. Inspect piston. Clean piston ring grooves. (See this group.)
3. Check piston ring end gap. (See this group.)
4. Install top ring (A) and second ring (B) with R or NPR mark facing up. Rings should turn freely in grooves.
5. Oil ring is an assembly. Install spacer (C), then side rails (D). Put side rail end gaps 180° apart.



A—Top Ring  
B—Second Ring  
C—Spacer  
D—Side Rails

MX,2520A1,A22 -19-21OCT92

M80376 -UN-06APR91


25  
20  
14

## CHECK PISTON RING END GAP

1. Before installing rings on piston, check end gap in cylinder bore.
2. Install each ring squarely in bore approximately 25.4 mm (1.0 in.) down from top of cylinder.
3. Check end gap. Replace ring if end gap is more than specifications.

### END GAP SPECIFICATIONS

Minimum End Gap	0.18 mm (0.007 in.)
Maximum End Gap	0.80 mm (0.032 in.)



M80377 -UN-02APR91

MX,2520A1,A23 -19-21OCT92

8. Hone the cylinder an additional 0.028—0.030 mm (0.0011—0.0012 in.) for final bore specifications. This allows for 0.020 mm (0.0008 in.) shrinkage when cylinder cools.

**IMPORTANT: DO NOT use gasoline or commercial solvents to clean cylinder bores. Solvents will not remove metal particles produced during honing.**


9. Clean the cylinder thoroughly using soap, warm water and clean rags. Continue to clean cylinder until white rags show no discoloration.

10. Dry the cylinder. Apply engine oil to cylinder wall.

M98,2040A,A9 -19-21OCT92

### INSPECT AND REPLACE OIL SLINGER—IF EQUIPPED

1. Remove crankcase cover. (See this group.)
2. Remove oil slinger (A).
3. Inspect oil slinger. Replace if worn or damaged.
4. Install oil slinger.



MX,3020A1,A28 -19-21OCT92

30  
20  
15  
-UN-31AUG88  
M50078

**GROUP 20—CYLINDER BLOCK, VALVES AND INTERNAL COMPONENTS—CONTINUED**

Item	Specification
<b>Piston</b>	
Maximum Ring Groove Clearance . . . . .	0.15 mm (0.006 in.)
Minimum Ring End Gap . . . . .	0.18 mm (0.007 in.)
Maximum Ring End Gap . . . . .	1.00 mm (0.039 in.)
Minimum Pin O.D. . . . .	17.98 mm (0.708 in.)
Maximum Pin Bore I.D. . . . .	18.03 mm (0.710 in.)
Maximum Piston-to-Piston Pin Clearance . . . . .	0.05 mm (0.002 in.)
Piston O.D. . . . .	79.77—79.79 mm (3.140—3.141 in.)
Piston-to-Cylinder Bore Clearance . . . . .	0.195—0.235 mm (0.0077—0.009 in.)
<b>Connecting Rod</b>	
Maximum Crankshaft Bearing I.D. . . . .	32.06 mm (1.262 in.)
Maximum Piston Pin Bearing I.D. . . . .	18.04 mm (0.710 in.)
Maximum Connecting Rod-to-Piston Pin Clearance . . . . .	0.06 mm (0.002 in.)
Maximum Connecting Rod-to-Crankpin Clearance . . . . .	0.11 mm (0.004 in.)
End-Cap Screw Torque . . . . .	21 N·m (186 lb-in.)
<b>Crankshaft</b>	
Minimum Connecting Rod Journal O.D. . . . .	31.95 mm (1.259 in.)
Maximum T.I.R. . . . .	0.05 mm (0.002 in.)
End Play . . . . .	0.05—0.20 mm (0.002—0.008 in.)
<b>Cylinder Block</b>	
Crankcase/Block Stud Torque . . . . .	36 N·m (27 lb-ft)
<b>Cylinder Bore</b>	
Standard Cylinder Bore I.D. . . . .	79.91—79.98 mm (3.146—3.149 in.)
Maximum Cylinder Bore I.D. . . . .	80.09 mm (3.155 in.)
Maximum Out-of-Round . . . . .	0.063 mm (0.0025 in.)
<b>Rebore Cylinder</b>	
Oversize Diameter	
0.50 mm . . . . .	80.46—80.48 mm (3.168—3.169 in.)

**GROUP 30—STARTING SYSTEMS**

**Electric Starter**

See Starter Specifications in this Group.

MX,3500A1,A3 -19-21OCT92

35  
00  
3



## REMOVE, INSPECT AND INSTALL CRANKSHAFT

1. Remove camshaft. (See this group.)
2. Remove piston and connecting rod. (See this group.)
3. Remove balancer. (See this group.)
4. Remove crankshaft.

**IMPORTANT: A bent crankshaft must be replaced; it cannot be straightened.**

5. Check crankshaft alignment (T.I.R.). (See this group.)
6. Clean and inspect crankshaft. Replace if parts are scratched or damaged.
7. Analyze crankshaft and connecting rod wear. (See Section 100, Group 10.)

*NOTE: Crankshaft rotates on ball bearings. Crankshaft main bearing journals are not measured.*

8. Measure connecting rod journal. Replace crankshaft if measurement is less than specifications.
9. Cover keyway on flywheel end of crankshaft with tape to prevent seal damage when installing crankshaft.
10. Apply clean engine oil to crankshaft bearings and journal.
11. Pack lithium based grease in oil seals.
12. Install crankshaft.
13. Install balancer.
14. Install piston and connecting rod.
15. Install camshaft.




M80475 -UN-17MAY91

35  
20  
16

### JOURNAL SPECIFICATIONS (MIN)

Main Bearing Journal		Connecting Rod Journal
PTO Side	Flywheel Side	
—	—	31.95 mm (1.259 in.)

MX,3520A1,A28 -19-21OCT92



- |               |                    |                  |                          |
|---------------|--------------------|------------------|--------------------------|
| 1—Collar      | 11—Plate           | 20—Hose          | 29—Plug                  |
| 2—Collar      | 12—Pilot Jet       | 21—Main Nozzle   | 30—Spring                |
| 3—Seal        | 13—O-Ring          | 22—Bleed Pipe    | 31—Drain Screw           |
| 4—Plate       | 14—Throttle Shaft  | 23—Main Jet      | 32—Fuel Shutoff Solenoid |
| 5—Choke Plate | 15—Throttle Plate  | 24—Float         | 33—Washer                |
| 6—Choke Shaft | 16—Ring            | 25—Gasket        | 34—Float Pin             |
| 7—Spring      | 17—Seal            | 26—Float Chamber | 35—Needle Valve          |
| 8—Idle Screw  | 18—Carburetor Body | 27—O-Ring        | 36—Air Jet               |
| 9—Pilot Screw | 19—Clamp           | 28—Washer        | 37—Pilot Air Jet         |
| 10—Spring     |                    |                  |                          |

FC540V

40  
05  
8

-JUN-09/JAN91  
M80010

## REPLACE BALANCER BUSHINGS

**NOTE:** Remove bushings with a bearing driver or a press.

Remove link rod bushings with oil groove side facing up.


1. Remove bushings.
2. Install link rod bushings with seam (A) at a 90° angle to centerline (C).

**NOTE:** On FC400V, FC420V and FC540V engines, install bushing from opposite side of oil grooves (B).

3. Install bushing below surface to specifications.

### SPECIFICATIONS

Bushing Depth (D) . . . . . 1.00 mm (0.040 in.)



A—Bushing Seam  
B—Oil Grooves  
C—Link Rod Centerline  
D—Measurement

M51681 -UN-31AUG88

MX,4020A1,A14 -19-21OCT92


FC400V, FC420V and FC540V:

4. Align oil hole (A) in bushing and oil passage (B) in weight. Install bushing.

5. Install bushing below surface to specifications.

### SPECIFICATIONS

Bushing Depth (C) . . . . . 0.50 mm (0.020 in.)




M51725 -UN-07SEP88

M98,2030A,A7 -19-21OCT92

40  
20  
10

## REMOVE, INSPECT AND INSTALL OIL FILTER MANIFOLD—IF EQUIPPED

1. Remove oil filter and manifold.
2. Inspect oil filter. Replace if excessively contaminated or damaged.
3. Inspect oil passages for clogs. Clean if needed.
4. Inspect rubber gaskets. Replace if worn or damaged.
5. Install filter and manifold.




M50077 -UN-31AUG88

MX,4020A1,A51 -19-21OCT92

## INSPECT AND REPLACE GOVERNOR

**IMPORTANT:** Removal damages governor. If not damaged, do not remove.

1. Remove crankcase cover. (See this group.)
2. Inspect governor. If necessary to replace, remove with screwdriver.
3. If removed, press shaft (C) back into block until it protrudes 32.2—32.8 mm (1.267—1.291 in.).



M51762 -UN-07SEP88

*NOTE: Assemble sleeve and gear before installing assembly on shaft.*

4. Install sleeve (A) onto governor gear (B).
5. Install governor assembly onto shaft. Push down on assembly until it snaps into place.

MX,4020A1,A52 -19-21OCT92

## REMOVE AND INSTALL CARBURETOR

1. Drain fuel from carburetor.
2. Disconnect hose (B).
3. Disconnect spring (D).
4. Remove duct (A), bracket (E) and gaskets (F).
5. Disconnect linkage (C).
6. Separate carburetor from heat shield (H). Remove carburetor.
7. Remove heat shield (H) and gaskets.
8. Make repairs as necessary. (See procedure in this group.)


*NOTE: Install gasket (I) with tab pointing up on fuel inlet side of carburetor.*

9. Install gaskets and heat shield.
10. Install carburetor.
11. Connect linkage.


*NOTE: Install gaskets (F) with hole (J) pointing away from fuel inlet side of carburetor.*

12. Install gaskets, bracket and duct.
13. Connect return spring.
14. Connect breather hose.


- A—Air Intake Duct
- B—Breather Hose
- C—Throttle Control Linkage
- D—Return Spring
- E—Bracket
- F—Gaskets
- G—Gasket
- H—Heat Shield
- I—Gasket
- J—Hole



M80399 -UN-25APR91



M80400 -UN-25APR91



M80401 -UN-25APR91

## REMOVE, INSPECT AND INSTALL CRANKSHAFT


1. Remove camshaft. (See this group.)
2. Remove piston and connecting rod. (See this group.)
3. Remove balancer. (See this group.)
4. Remove crankshaft.

**IMPORTANT: A bent crankshaft must be replaced; it cannot be straightened.**

5. Check crankshaft alignment (T.I.R.). (See this group.)
6. Clean and inspect crankshaft. Replace if parts are scratched or damaged.
7. Analyze crankshaft and connecting rod wear. (See Section 100, Group 10.)
8. Measure crankshaft main bearing journals and connecting rod journal. Replace crankshaft if measurements are less than specifications.

### JOURNAL SPECIFICATIONS (MIN)

Main Bearing Journal		Connecting Rod Journal
PTO Side	Flywheel Side	
29.92 mm (1.178 in.)	—	35.43 mm (1.395 in.)




M54495 -UN-09JAN91

### INSPECT VALVE SPRINGS

Inspect valve springs. Replace springs if damaged or if free length is less than specification.

#### FREE LENGTH SPECIFICATION (MIN)

Intake .....	43.30 mm (1.710 in.)
Exhaust .....	39.00 mm (1.540 in.)



MX,5020A1,A3 -19-21OCT92

M50036 -UN-31AUG88


### INSPECT VALVE GUIDES

Clean inside of valve guides with valve guide cleaner.

Measure inside diameter of valve guide bushings (A). Replace bushings if inside diameters are greater than specifications. (See this group.)

#### SPECIFICATIONS (MAX) I.D.

Intake and Exhaust .....	8.08 mm (0.318 in.)
--------------------------	---------------------




MX,5020A1,A4 -19-21OCT92

M38126 -UN-29AUG88

### REPLACE VALVE GUIDE BUSHINGS

1. Drive valve guide bushing into tappet chamber (B) using JDG118 Valve Guide Driver (A). Use a locking pliers to crush end of bushing in chamber. Drive remaining part of bushing into chamber and remove.



MX,5020A1,A5 -19-21OCT92


M38127 -UN-29AUG88

2. Use valve guide driver to install new bushing (A).

Drive bushing into cylinder body until distance (B), from valve seat counterbore to top of bushing, is according specifications.

#### SPECIFICATIONS

Distance (B) .....	30 mm (1.178 in.)
--------------------	-------------------



(B)	IN	30MM
	EX	30MM

MX,5020A1,A6 -19-21OCT92

M38128 -UN-29AUG88

50  
20  
4