

1992 Mazda B2200 B2600i Workshop Manual

FOREWORD

This workshop manual is intended for use by service technicians of Authorized Mazda Dealers to help them service Mazda vehicles.

For proper repair and maintenance, a thorough familiarization with this manual is important, and it should always be kept in a handy place for quick and easy reference.

All the contents of this manual, including drawings and specifications, are the latest available at the time of printing. As modifications affecting repair or maintenance occur, relevant information supplementary to this volume will be made available at Mazda dealers. This manual should be kept up-to-date.

Mazda Motor Corporation reserves the right to alter the specifications and contents of this manual without obligation or advance notice.

All rights reserved. No part of this book may be reproduced or used in any form or by any means, electronic or mechanical—including photocopying and recording and the use of any kind of information storage and retrieval system—without permission in writing.


**Mazda Motor Corporation
HIROSHIMA, JAPAN**

APPLICATION:


This manual is applicable to vehicles beginning with the Vehicle Identification Numbers (VIN) shown on the following page.

CONTENTS


Title	Si
General Information	
Pre-Delivery Inspection and Scheduled Maintenance Services	
Engine	B2200
	B2600i
Lubrication System	
Cooling System	
Fuel and Emission Control Systems	Carburetor
	EGI
Engine Electrical System	
Clutch	
Manual Transmission	B2200
	B2600i
	Transfer Case
Automatic Transmission	Hydraulically-Controlled
	Electronically-Controlled
	Transfer Case
Propeller Shaft	
Front and Rear Axles	
Steering System	
Braking System	
Wheels and Tires	
Suspension	
Body	
Body Electrical System	
Heater and Air Conditioner Systems	
Technical Data	
Special Tools	




9MU0B2-144




9MU0B2-145



9BU0B1-066



9BU0B1-067



69G01A-144

- Set the **stopper bolt** (49 L011 005) so that the depth **L** is as specified.

Depth L: 59.5—59.7mm (2.342—2.450 in)

- Tighten the locknut.

- Insert the **SST No.2** into the piston pin as shown and fully screw in the **SST No.1**.
- Apply engine oil to the piston pin.

- Set the piston on the **SST** with the **F** mark facing upward.
- Align the oil hole of the large end of connecting rod and **F** mark on the piston as shown in the figure.

- Press the piston pin into the piston and connecting rod until the **SST** contacts the stopper bolt.
- While inserting the piston pin, check the pressure force. If it is less than specified, replace the piston pin or the connecting rod.

Pressure force:

4,905—14,715 N (500—1,500 kg, 1,100—3,300 lb)

- Check the oscillation torque of the connecting rod. (Refer to page B1-32.)

Piston Ring

- Install the three-piece oil rings on the pistons.
 - Apply engine oil to the oil ring spacer and rails.
 - Install the oil ring spacer so that the opening faces upward.
 - Install the upper rail and lower rail.

Note

- The upper rail and lower rail are the same.
- Each rail can be installed with either face upward.

ASSEMBLY (CYLINDER BLOCK)


1. Clean all parts before reinstallation.
2. Apply new engine oil to all sliding and rotating parts.
3. Replace plain bearings if they are peeling, burned, or otherwise damaged.
4. Tighten all bolts and nuts to the specified torques.

Caution

Do not reuse gaskets or oil seals.

CYLINDER BLOCK Torque Specifications


9MU0E




N-m (m-kg, ft-lb)

9MU0B2-142
B2-53


STEP 6 (1)




STEP 8 (2)




STEP 6 (2)




STEP 9




STEP 7 (1)




STEP 10



STEP 7 (2)




STEP 8 (1)




TROUBLESHOOTING GUIDE


STEP 1



STEP 4





STEP 2





STEP 5



WARNING
BEFORE CONNECTING FUEL PRESSURE GAUGE, RELEASE FUEL PRESSURE FROM FUEL SYSTEM TO REDUCE POSSIBILITY OF INJURY OR FIRE (REFER TO PAGE F2-144)




STEP 3




STEP 6



F2 CARBURETOR




F2 EGI, G6



Output Shaft Components



APPLY INDIVIDUAL PARTS TO SPECIFIED OIL




1BU0J3-001

- 1. Speedometer drive gear
- 2. Bearing
- 3. 2W-4W clutch hub
- 4. 2W-4W hub sleeve
- 5. Drive sprocket
- 6. Needle bearing


- 7. Spacer
- 8. Thrust washer
- 9. Bearing
- 10. Thrust lock washer
- 11. Steel ball
- 12. Low gear

- 13. Needle bearing
- 14. Roll pin
- 15. Output shaft
- 16. Bearing
- 17. Front drive sprocket



9MU0K2-227

9. Install the retaining plate.




9MU0K2-228

Caution

Do not deform the snap ring.

10. Install the snap ring with a screwdriver.



9MU0K2-229


11. Measure the clearance between the snap ring and the retaining plate with a feeler gauge. If not within specificat adjust the clearance by installing the proper retaining pl

Clearance: 0.8—1.05mm (0.031—0.041 in)

Retaining plate sizes

mm


7.8 (0.307)	8.0 (0.315)	8.2 (0.323)
8.4 (0.331)	8.6 (0.339)	8.8 (0.346)



9MU0K2-230

Caution

Apply air for no more than three(3) seconds.



9MU0K2-231

12. Check operation of the piston by applying compressed through the oil passage of the low and reverse brake

Air pressure: 392 kPa (4.0 kg/cm², 57 psi) max.


Vehicle Speed at Shiftpoint Table

Mode	Range	Throttle condition (Throttle sensor voltage)	Shift	Vehicle speed km/h (mph)
Normal (Power)	D	Fully opened (4.4 volt)	D ₁ →D ₂	47—51 (29—32)
			D ₂ →D ₃	87—95 (54—59)
			D ₃ →OD	129—139 (80—86)
		Half throttle (1.6—2.2 volt)	D ₁ →D ₂	39—43 (24—27)
			D ₂ →D ₃	66—72 (41—45)
			Lockup ON (D ₃)	96—104 (60—64)
			D ₃ →OD	111—119 (69—74)
			Lockup ON (OD)	128—136 (79—84)
			Lockup OFF (OD)	96—104 (60—64)
			OD→D ₃	71—79 (44—49)
			Lockup OFF (D ₃)	86—94 (53—58)
			D ₃ →D ₂	42—48 (26—30)
			OD→D ₃	124—134 (77—83)
		Kickdown	OD→D ₂	81—89 (50—55)
			OD→D ₁	41—45 (25—28)
			D ₃ →D ₂	81—89 (50—55)
			D ₃ →D ₁	41—45 (25—28)
			D ₂ →D ₁	41—45 (25—28)
			D ₁ →D ₂	47—51 (29—32)
Normal (Economy)	D	Fully opened (4.4 volt)	D ₂ →D ₃	87—95 (54—59)
			D ₃ →OD	129—139 (80—86)
			D ₁ →D ₂	30—34 (19—21)
		Half throttle (1.6—2.2 volt)	D ₂ →D ₃	52—58 (32—36)
			D ₃ →OD	96—104 (60—64)
			Lockup ON (OD)	96—104 (60—64)
			Lockup OFF (OD)	81—89 (50—55)
			OD→D ₃	43—51 (27—32)
			D ₃ →D ₂	22—28 (14—17)
			OD→D ₃	124—134 (77—83)
		Kickdown	OD→D ₂	81—89 (50—55)
			OD→D ₁	41—45 (25—28)
			D ₃ →D ₂	81—89 (50—55)
			D ₃ →D ₁	41—45 (25—28)
			D ₂ →D ₁	41—45 (25—28)
			S ₁ →S ₂	47—51 (29—32)
Normal	S	Fully opened (4.4 volt)	S ₂ →S ₃	87—95 (54—59)
			S ₃ →S ₂	82—88 (51—55)
			S ₂ →S ₁	41—45 (25—28)
		Half throttle (1.6—2.2 volt)	S ₁ →S ₂	39—43 (24—27)
			S ₂ →S ₃	66—72 (41—45)
			S ₃ →S ₂	41—47 (25—29)
	L	Fully opened (4.4 volt)	L ₁ →L ₂	47—51 (29—32)
		Half throttle (1.6—2.2 volt)	L ₂ →L ₁	41—45 (25—28)
HOLD	D	—	L ₁ →L ₂	39—43 (24—27)
			D ₂ →D ₃	18—22 (11—14)
			D ₃ →D ₂	7—13 (4—8)
	S	Fully closed (0.4 volt)	OD→D ₃	138—148 (86—92)
			S ₃ →S ₂	88—96 (55—60)
			L ₂ →L ₁	44—48 (27—30)


1BUOK2-019

PROPELLER SHAFT

SHORT BED (4x4)



LONG BED (4x4)



Nm (m-kg, ft-lb)


1BUOLX-002


- 1. Nut
- 2. Lock washer
- 3. Bolt
- 4. Front propeller shaft
- Removal page L-7
- Installation page L-7

- 5. Nut
- 6. Lock washer
- 7. Bolt
- 8. Nut
- 9. Washer

- 10. Nut
- 11. Lock washer
- 12. Bolt
- 13. Rear propeller shaft
- Removal page L-7
- Installation page L-7

INDEX





STEERING GEAR AND LINKAGE

On-vehicle Inspection

Steering gear oil level

1. Remove the oil filler port plug.
2. Prepare a simple wire dipstick.
3. Insert the dipstick through the oil filler port.
4. Pull out the dipstick and measure the L dimension.
Add the specified gear oil if necessary.

Standard L dimension: 22mm (0.87 in)

Specified gear oil: API service GL-4 SAE 90

5. Install the oil filler port plug.

Removal, Inspection, and Installation

1. Loosen the wheel lug nuts.
2. Jack up the front of the vehicle and support it with safety stands.
3. Remove the wheels.
4. Remove in the order shown in the figure, referring to **Removal Note**.
5. Install in the reverse order of removal.
6. Install the wheel.


Tightening torque: Non-styled wheel 88—118 N·m (9—12 m·kg, 65—87 ft·lb)

Styled wheel 118—147 N·m (12—15 m·kg, 87—108 ft·lb)

7. Inspect all parts and repair or replace as necessary.

Note

After installation, check the turning angle and toe-in and adjust if necessary. (Refer to Section R.)



SWITCHES

SWITCHES

IGNITION KEY SWITCH

Inspection

Check continuity between terminals of the switch with ohmmeter.

If continuity is not as specified, replace the switch.

Terminal Position	B	ACC	IG1	IG2	ST	L	E	K1
LOCK								○
ACC	○	○						○
ON	○	○	○	○				○
START	○		○		○	○	○	○

○—○: Indicates continuity

Replacement

1. Disconnect the negative battery cable.
2. Remove the column covers.
3. Disconnect the connectors from the wiring harness.
4. Loosen the attaching screw.
5. Install in the reverse order of removal.

COMBINATION SWITCH

Inspection

Check continuity between terminals of the switch with ohmmeter.

If continuity is not as specified, replace the switch.

Turn signal and hazard switch


Terminal	FU	TL	TR	TIG	HBA	FB	SS1	S
Hazard								
Turn								
Left	○	○		○		○		
N				○		○		
Right	○		○	○		○		
ON	○	○	○		○	○	○	○

○—○: Indicates continuity


Light, dimmer, and passing switch

Terminal	BTN	TNS	BA	HL	HU	HE
Position						
Tail, parking	○	○				
Head-light						
Low beam	○	○	○	○		○
High beam	○	○	○		○	○
Passing			○		○	


○—○: Indicates continuity





9BU0TX-008



9BU0TX-061



9BU0TX-009



9BU0TX-010

Item		Transmission	R4AX-EL
Low and reverse brake	Number of drive/driven plates		6/6
	Drive plate thickness mm (in)	Standard	2.0 (0.079)
		Minimum	1.8 (0.071)
	Brake clearance mm (in)	With new drive/driven plates	0.7—1.1 (0.028—0.043)
		When reusing drive/driven plates	0.7—2.3 (0.028—0.091)
	Retaining plate size mm (in)		9.0 (0.354), 9.2 (0.362), 9.4 (0.370), 9.6 (0.378), 9.8 (0.386), 10.0 (0.394)
	Seal ring clearance mm (in)	Standard	0.10—0.25 (0.0039—0.0098)
		Maximum	0.25 (0.0098)
Total end play	Standard mm (in)		0.25—0.55 (0.010—0.022)
	Bearing race size mm (in)		0.8 (0.031), 1.0 (0.039), 1.2 (0.047), 1.4 (0.055), 1.6 (0.063), 1.8 (0.071), 2.0 (0.079)
Reverse clutch drum end play	Standard		0.55—0.90 (0.022—0.035)
	Thrust washer size mm (in)		0.7 (0.028), 0.9 (0.035), 1.1 (0.043), 1.3 (0.051), 1.5 (0.059), 1.7 (0.067), 1.9 (0.075)

Spring Specification


Spring	Item	Outer dia. mm (in)	Free length mm (in)	No. of coil	Wire dia. mm (in)
Upper control valve body	Torque converter relief valve	9.0 (0.354)	38.0 (1.496)	12.7	1.4 (0.055)
	Pressure regulator valve	14.0 (0.551)	44.0 (1.732)	7.9	1.4 (0.055)
	Pressure modifier valve*	A 6.8 (0.268)	31.95 (1.258)	15.5	0.8 (0.031)
		B 6.9 (0.272)	32.60 (1.283)	22.2	0.9 (0.035)
		C 6.9 (0.272)	32.80 (1.291)	15.6	0.9 (0.035)
	Shuttle shift valve D	6.0 (0.236)	26.5 (1.043)	12.0	0.7 (0.028)
	4-2 sequence valve	6.95 (0.274)	29.1 (1.146)	11.0	0.55 (0.022)
	Shift valve B	7.0 (0.276)	25.0 (0.984)	9.5	0.65 (0.026)
	4-2 relay valve	6.95 (0.274)	29.1 (1.146)	11.0	0.55 (0.022)
	Shift valve A	7.0 (0.276)	25.0 (0.984)	9.5	0.65 (0.026)
	Overrunning clutch control valve	7.0 (0.276)	23.6 (0.929)	7.9	0.6 (0.024)
	Overrunning clutch reducing valve	7.0 (0.276)	32.5 (0.984)	12.6	0.85 (0.033)
	Shuttle shift valve S	5.5 (0.217)	43.0 (1.693)	22.2	0.85 (0.033)
	Pilot valve	9.1 (0.358)	25.7 (1.012)	8.3	1.1 (0.043)
	Lockup control valve	13.0 (0.512)	18.5 (0.728)	3.5	0.75 (0.030)
Lower control valve body	Modifier accumulator piston	9.8 (0.386)	30.5 (1.201)	8.75	1.3 (0.051)
	1st reducing valve	6.75 (0.266)	25.4 (1.000)	12.5	0.75 (0.030)
	Servo charger valve	6.5 (0.256)	33.2 (1.307)	12.0	0.5 (0.020)
	3-2 timing valve	6.75 (0.266)	20.55 (0.809)	7.5	0.75 (0.030)
Oil pump	Cam ring	13.7 (0.539)	39.8 (1.567)	7.8	2.3 (0.091)
Accumulator	N-D accumulator piston	18.0 (0.709)	43.0 (1.693)	12.3	2.3 (0.091)
	1-2 accumulator piston	29.3 (1.154)	45.0 (1.772)	3.6	4.0 (0.157)
	2-3 accumulator piston	20.0 (0.787)	66.0 (2.598)	11.4	3.5 (0.138)
	3-4/N-R accumulator piston	17.3 (0.681)	58.4 (2.299)	12.3	2.3 (0.091)
Reverse clutch	Return	11.6 (0.457)	19.69 (0.775)	4.0	1.3 (0.051)
High clutch	Return	11.6 (0.457)	22.10 (0.870)	6.0	1.3 (0.051)
Forward & overrunning clutch	Return	9.7 (0.382)	35.8 (1.409)	10.3	1.3 (0.051)
Low and reverse brake	Return	11.6 (0.457)	23.7 (0.933)	5.0	1.1 (0.043)
Band servo	Return A	34.3 (1.350)	45.6 (1.795)	3.0	2.3 (0.091)
	Return B	40.3 (1.587)	53.8 (2.118)	3.0	2.3 (0.091)
	Return C	27.6 (1.087)	29.7 (1.169)	3.2	2.6 (0.102)

*: Either A, B or C type spring is installed at shipment. Only A type spring is available for replacement.

SPECIAL TOOLS





S


AIR CONDITIONER SYSTEM (CONT'D)

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
0000-41-0804-43 Installer, clutch rotor bearing	A	
0000-41-0810-59 Driver clutch rotor	A	

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
0000-41-0804-12 Remover, O-ring	A	
—	—	—

CHECKER AND OTHER EQUIPMENT

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 H018 9A1 Checker, Self-diagnosis	A	
49 0305 870A Tool set, window	A	
49 G018 901 Adapter harness (Throttle sensor)	A	
49 G019 901A EC-AT tester	A	
49 F018 002 Igniter checker	A	

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 0259 866A Inserting tool, seal pusher & blade	B	
49 G019 901 EC-AT tester 49 H019 902 Adapter unit	A	
49 N018 001 Adapter harness (Igniter checker)	A	
49 9200 162 Monitor, engine signal	A	
49 G018 903 Adapter harness (Engine signal monitor)	A	