

# HOW TO USE THIS MANUAL , ABBREVIATIONS

## HOW TO USE THIS MANUAL

### RANGE OF TOPICS

- This manual indicates only changes/additions, as it is the supplemental for the related materials. Therefore it may not contain the necessary reference service procedures to perform the services indicated in this manual.

A6E20100001A01

## ABBREVIATIONS


### ABBREVIATIONS TABLE

A6E203000011A01

ATF	Automatic transaxle fluid
SST	Special service tool
1st GR	First gear
2nd GR	Second gear
3rd GR	Third gear
4th GR	Forth gear

# AUTOMATIC TRANSAXLE

## Disassembly Components




A6E5714A001

1	Torque converter
2	Oil dipstick and oil filler tube
3	Input/turbine speed sensor
4	Oil pressure switch
5	Transaxle range switch
6	Vehicle speed sensor

7	Connector pipe
8	Oil pan
9	Control valve body component
10	Oil pump
11	End cover

# AUTOMATIC TRANSAXLE




A6E5714A003

1	Manual shaft
2	Servo apply accumulator
3	Forward accumulator
4	Parking rod lever component
5	Band servo
6	Differential
7	Secondary gear and output gear
8	Actuator plate
9	Support actuator
10	Parking pawl shaft

11	Parking pawl
12	Pawl return spring
13	Forward clutch
14	Forward clutch hub
15	Primary gear
16	Bearing race
17	Funnel
18	Oil pipe
19	Oil seal
20	Transaxle case


## AUTOMATIC TRANSAXLE

19. Remove the control valve body.




A6E5714A009

20. Remove the coupler component.




X3U517AAA

21. Remove the accumulator component.  
22. Remove the manual shaft.




A6E5714A010

(1) Remove the roll pin using a pin punch.  
(2) Remove the manual shaft.



A6E5714A011


(3) Remove the O-ring from the manual shaft.



A6E5714A012


## AUTOMATIC TRANSAXLE

40. Remove the snap ring.



X3U517AAV


41. Remove the rear planetary gear component.



X3U517AAW


42. Remove the front sun gear by tapping its end with a flathead screwdriver, etc. as shown in the figure.

43. Remove the forward clutch hub.



A6E5714A020


44. Remove the front planetary gear component.



A6E5714A021

45. Remove the front internal gear and one-way clutch component.

46. Remove the locknut.



X3U517AAZ


K1

# AUTOMATIC TRANSAXLE

## CLUTCH COMPONENT DISASSEMBLY/ASSEMBLY

A6E561419500A01

1. Carry out the preinspection before disassembly. (See [K1-50 Clutch Component Preinspection.](#))
2. Disassemble in the order indicated in the table.
3. Assemble in the reverse order of disassembly.



A6E5714A033

1	Snap ring
2	Rear sun gear plate
3	Bearing
4	3-4 clutch hub
5	Bearing
6	Snap ring
7	Retaining plate
8	Drive and driven plate
9	Snap ring (See <a href="#">K1-19 Snap Ring (3-4 clutch) Disassembly Note</a> )
10	Seal plate
11	Spring and retainer component
12	3-4 clutch piston (See <a href="#">K1-19 3-4 Clutch Piston Disassembly Note</a> )

13	3-4 clutch drum
14	Snap ring
15	Retaining plate
16	Drive and driven plate
17	Dish plate
18	Snap ring (See <a href="#">K1-19 Snap Ring (Reverse clutch) Disassembly Note</a> )
19	Reverse return stopper
20	Piston return spring
21	Reverse piston (See <a href="#">K1-20 Reverse Piston Disassembly Note</a> )
22	2-4 brake drum
23	Bearing

## AUTOMATIC TRANSAXLE

(10) Install the selected snap ring and perform steps (2) to (7) again. Verify that the calculated value satisfies the clearance specification.


13. Inspect the reverse clutch operation.
- (1) Install the 2-4 brake drum to the end cover.
  - (2) Inspect the reverse clutch operation by applying compressed air as shown.

**Air pressure**  
**392—441 kPa {4.0—4.5 kgf/cm<sup>2</sup>, 57—63 psi}**

14. Install the 3-4 clutch.


**Caution**

- **Installing the 3-4 clutch piston may damage its seal. Carefully install the 3-4 clutch piston by pushing evenly around the circumference.**



A6E5714A042

- (1) Apply ATF to the circumference of the 3-4 clutch piston seal, and install the piston in to the 3-4 clutch drum.
- (2) Install the spring and retainer.
- (3) Apply ATF to the 3-4 seal plate, and install it onto the 3-4 clutch drum.




A6E5714A044

- (4) Install the **SST** as shown.

**Caution**


- **Depress the 3-4 seal plate only enough to install the snap ring. Overpressing will damage the 3-4 seal plate assembly edges.**



A6E5714A045

- (5) Compress the spring and retainer component and 3-4 seal plate.
- (6) Install the snap ring.
- (7) Remove the **SST**.
- (8) Install the drive and driven plates in the following order.  
 Driven-Drive-Driven-Drive-Driven-Drive
- (9) Install the retaining plate.

**DRIVE PLATE PART NUMBER:FN11 19 370**




A6E5714A046

**K1**


## AUTOMATIC TRANSAXLE

7. Install the pinion shaft.



X3U517AEW

8. Install the roll pin, and crimp it to prevent it from coming out of the gear case.  
9. Apply ATF to the thrust washers.  
10. Install the thrust washers and side gears into the gear case, then turn the side gears and align them with the drive shaft holes.  
11. Measure the backlash of the side gears as follows:  
(1) Install the left and right drive shafts in the differential.  
(2) Support the drive shafts on V-blocks.



X3U517AEX


- (3) Measure the backlash of both side gears.

### Backlash

**Standard: 0.05—0.15 mm {0.002—0.005 in}**

**Maximum: 0.5 mm {0.020 in}**

12. If the backlash is not within the specification, replace the differential.



A6E5714A060

## AUTOMATIC TRANSAXLE ASSEMBLY

A6E561401030A02

### Precaution

#### General notes


1. Select the adjustment shims, referring to **Bearing Preload**.
2. If the drive plates or 2-4 brake band are replaced with new ones, soak the new part in ATF for at least two hours before installation.
3. Before assembly, apply ATF to all seal rings, rotating parts, O-rings, and sliding parts.
4. All O-rings, seals, and gaskets must be replaced with the new ones included in the overhaul kit.
5. Use petroleum jelly, not grease, when assembling again.
6. When it is necessary to replace a bushing, replace the subassembly that includes that bushing.
7. Assemble the housing within 10 minutes after applying sealant, and allow it to cure for at least 30 minutes after assembly before filling the transaxle with ATF.

### Warning

- Although the stand has a self-locking brake system, there is a possibility that the brake may not hold when the transaxle is held in a lopsided position on the stand. This would cause the transaxle to turn suddenly, causing serious injury. Never keep the transaxle tilted to one side. Always hold the rotating handle firmly when turning the transaxle.



# AUTOMATIC TRANSAXLE



A6E5714A062

1	Transaxle case
2	Oil seal
3	Oil pipe
4	Funnel
5	Bearing race
6	Primary gear
7	Forward clutch hub
8	Forward clutch
9	Pawl return spring
10	Parking pawl

11	Parking pawl shaft
12	Support actuator
13	Actuator plate
14	Secondary gear and output gear
15	Differential
16	Band servo
17	Parking rod lever component
18	Forward accumulator
19	Servo apply accumulator
20	Manual shaft

## AUTOMATIC TRANSAXLE

### Assembly procedure

1. Measure the bushing of the front sun gear.


#### Bushing inner diameter

**Standard: 18.000—18.018 mm**

**{0.70866—0.70936 in}**

**Maximum: 18.038 mm {0.71016 in}**

2. If not as specified, replace the front sun gear.



A6E5714A065

3. Measure the bushing of the end cover.


#### Bushing inner diameter

**Standard: 23.600—23.621 mm**

**{0.92913—0.92995 in}**


**Maximum: 23.641 mm {0.93075 in}**

4. If not as specified, replace the end cover.




A6E5714A066

5. Assemble the **SST**.



A6E5714A005

6. Lift the transaxle case and mount it on the **SST**.
7. Install the oil pipe.




A6E5714A006

K1


## AUTOMATIC TRANSAXLE

- (6) Stake the locknut.
- (7) Remove the **SST**




A6E5714A076

12. Install the front internal gear and one-way clutch.
13. Apply petroleum jelly to the bearing, and secure it to the front planetary gear component.




X3U517AAZ

14. Install the front planetary gear component.
15. Apply petroleum jelly to the bearing, and secure it to the front sun gear.



A6E5714A021

16. Install the front sun gear.




A6E5714A077

17. Install the rear planetary gear.

### Note


- Rotate the engine stand so that the oil pan faces downward. Pull the front internal gear and one-way clutch component a little until the groove for the snap ring appears, then install the snap ring.



X3U517AAW

## AUTOMATIC TRANSAXLE

- (5) Select a bearing race whose thickness is between D mm {in} and C mm {in}.



A6E5714A082

### Bearing race sizes

1.8 {0.071}	2.0 {0.079}	2.2 {0.087}
2.4 {0.094}	2.6 {0.102}	—

mm {in}


### Caution

- The bearing race and end cover may be damaged if the end cover is not installed correctly to the transaxle case. Align the projection of the bearing race within the area of the arrows shown in the figure, and then install the end cover to the transaxle case.

- (6) Remove the end cover, apply petroleum jelly to the selected bearing race, then install it to the end cover.  
 26. Apply ATF to new seal ring, and install it to the end cover.


### Seal ring inner diameter

- A: 47.1 mm {1.854 in}
- B: 55.8 mm {2.197 in}



A6E5714A083

27. Apply a light coat of silicone sealant to the contact surfaces of the transaxle case and the end cover.  
 28. Apply ATF to the O-ring and install it to the transaxle case.




A6E5714A084

29. Install the end cover to the transaxle case.

### Tightening torque

- 19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}




A6E5714A018

## AUTOMATIC TRANSAXLE

42. Install the oil pump.

**Tightening torque**

**19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}**



A6E5714A110


43. Install the parking rod lever component.

**Tightening torque**

**19—25 N·m {1.9—2.6 kgf·m, 14—18 ft·lbf}**


44. Apply ATF to the new O-ring and install it to the manual shaft.

45. Install the manual shaft.




X3U517AAE

(1) Install the manual shaft to the manual plate and detent bracket component.




A6E5714A012

(2) Install the knock pin.



A6E5714A011


46. Install the accumulator component.



A6E5714A010


# AUTOMATIC TRANSAXLE

- (1) Rotate the manual shaft to the N position.




A6E5714A094

- (2) Turn the protrusion a resistance between the terminals B and C become **750 ohms**.



A6E5614W014

- (3) Install the TR switch while aligning the protrusion and groove as shown.  
 (4) hand- tighten the TR switch mounting bolts.




A6E5614W010

- (5) Inspect the resistance between the terminals B and C.  
 • If not as specified, readjust the TR switch.


**Resistance**  
**750 ohms**

- (6) Tighten the TR switch mounting bolts

**Tightening torque**  
**8—11 N·m**  
**{82—112 kgf·cm, 71—97 in·lbf}**



A6E5614W016



A6E5614W010

**K1**


## AUTOMATIC TRANSAXLE

- Inspect the clutch operation by applying compressed air as shown.

### Air Pressure

**392 kPa {4.0 kgf/cm<sup>2</sup>, 57 psi} max.**

- If not as specified, replace parts as necessary. (See [K1-18 CLUTCH COMPONENT DISASSEMBLY/ASSEMBLY](#).)




A6E5714A01

K1

### Reverse clutch clearance

- Measure the reverse clutch clearance.
  - Install the reverse clutch into the end cover, and set the dial gauge.
  - Secure the reverse clutch by lightly pressing down with a press, etc.




A6E5714A041

- Apply compressed air to the part indicated in the figure and let the reverse clutch piston stroke three times.

### Air Pressure

**392—441 kPa {4.0—4.5 kgf/cm<sup>2</sup>, 57—63 psi}**

- Apply compressed air and operate the reverse clutch piston. Read the value when the indicator of the dial gauge stops.
- Release the compressed air and read the dial gauge when the reverse clutch piston is not operating.
- Calculate the reverse clutch clearance according to the following formula: Step (4) value – Step (5) value = Reverse clutch clearance.
- Measure the clearances at four locations (90° apart) by following the steps from (3) to (6). Verify that the average value is within the specification below.




A6E5714A042

### Reverse clutch clearance

**1.00—1.30 mm {0.039—0.051 in}**

- If not as specified, replace parts as necessary. (See [K1-18 CLUTCH COMPONENT DISASSEMBLY/ASSEMBLY](#).)



A6E5714A043