

HOW TO USE THIS MANUAL

PREPARATION

PREPARATION points out the needed SST for the service operation that follows. It is best to gather all necessary SST before beginning work.

Example:

**N TIE-ROD END BOOT AND STEERING GEAR BOOT**

**TIE-ROD END BOOT AND STEERING GEAR BOOT**

**PREPARATION**

49 0118 850C Puller, ball joint	49 H028 301 Installer, boot
------------------------------------	--------------------------------

9MU0NX-030

**SST NUMBER**  
49 H028 301

**SST NAME**  
Installer, boot

**SST ILLUSTRATION**

9MUGIX-033

REPAIR PROCEDURE

1. Most repair operations begin with an overview illustration. It identifies the components, shows how the parts fit together, and visual parts inspections. If a damaged or worn part is found, repair or replace it as necessary.
2. Expendable parts, tightening torques, and symbols for oil, grease, and sealant are shown in the overview illustration.
3. Pages related to service procedures are shown under the illustration. Refer to this information when servicing the related part.

Example:

**SHOWS EXPENDABLE PARTS**

**SHOWS TIGHTENING TORQUE SPECIFICATION \*2**

**SHOWS APPLICATION POINT OF OIL, ETC.**

**SHOWS TIGHTENING TORQUE UNIT**

**SHOWS VISUAL INSPECTION INFORMATION**

**SHOWS RELATED PAGE FOR SERVICE**

1. Bolt	16. Bearing inner race	page M-22
2. Lock plate	Removal	page M-22
3. Bearing cup	Inspect for damage or rough rotation	page M-24
4. Adjusting screw	Installation	page M-24
5. Bearing outer race	17. Spacer	
6. Locknut	18. Drive pinion	
7. Washer	Removal	page M-21
8. Companion flange	Inspect spines and teeth for wear or damage	page M-22
Removal	Adjustment of height	page M-22
Inspect spines	Adjustment	page M-24

\*1: The numbering (ex. ①) shows service procedure.

\*2: Units shown in N-m (m-kg, ft-lb) unless otherwise specified.

**SCHEDULED MAINTENANCE SERVICES**

**MAINTENANCE TABLE (General RHD Models)**

**Chart Symbols**

- I**: Inspect and if necessary correct, clean, or replace
- A**: Adjust
- R**: Replace or change
- T**: Tighten
- L**: Lubricate
- C**: Clean

- After 60,000 km (36,000 miles), continue to follow the prescribed maintenance items at the recommended intervals.
- For items marked \* in this maintenance chart, please pay attention to these points.

- \*1 If the vehicle is operated under the following conditions, it is suggested that the engine oil and oil filter be changed more frequently.
  - a) Driving in dusty conditions
  - b) Extended periods of idling or low-speed operation
  - c) Driving for a prolonged period in cold temperatures, or driving short distances only
- \*2 If the vehicle is operated in very dusty or sandy areas, clean or replace more often than at usual recommended intervals.
- \*3 See page A-21 for detailed information.

**Emission Control and Related Systems**

The ignition and fuel systems are vitally important to the proper operation of the emissions control and related systems, as well as for efficient engine operation. It is strongly recommended that all servicing related to these systems be done by your Authorized Mazda Dealer.

9TF0AX-002

Maintenance interval	Kilometers (miles)													
	x1,000 km (x1,000 miles)	1	5	10	15	20	25	30	35	40	45	50	55	60

**Engine**

Engine valve clearance		I		I		I		I		I		I		I
Cylinder head bolts	HA engine	T				T				T				T
Intake and exhaust manifold		T				T				T				T
Drive belts		A	I	I	I	I	I	I	I	I	I	I	I	I
Engine oil	HA and SL engine	R		R		R		R		R		R		R
	SL Turbo engine	R	R	R	R	R	R	R	R	R	R	R	R	R
Oil filter*1		R		R		R		R		R		R		R
Oil bypass filter	HA and SL engine					R				R				R
	SL Turbo engine			R		R		R		R		R		R

**Cooling System**

Cooling system	I		I		I		I		I		I		I	
Engine coolant	(R) every 12 months													


**REAR OIL SEAL**

**Replacement**

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal, referring to **Installation Note**.

**Steps After Installation**

1. Connect the negative battery cable.
2. Start the engine and perform engine adjustments as necessary.




N·m (m·kg, ft·lb)

9TF0BX-020

- |                              |           |
|------------------------------|-----------|
| 1. Transmission              |           |
| Service.....                 | Section J |
| 2. Clutch cover, clutch disc |           |
| Service.....                 | Section H |


- |                        |           |
|------------------------|-----------|
| 3. Flywheel            |           |
| Removal Note.....      | page B-32 |
| Installation Note..... | page B-32 |
| 4. Oil seal            |           |
| Installation Note..... | page B-32 |



9TF0BX-042


**Main bearing cap**

1. Before removing the main bearing caps, measure the crankshaft end play. (Refer to page B-94.)



05U0BX-116


2. Loosen the main bearing cap bolts in two or three steps in the order shown in the figure.
3. Remove the main bearing caps.



9TF0BX-043

**Crankshaft**

1. Before removing the crankshaft, measure the main bearing oil clearances. (Refer to page B-92.)



9TG0B2-185


**Cylinder liner**

1. Mark the cylinder liner and the cylinder block for proper reassembly.

**Note**

- If necessary, remove the cylinder liner with the SST.

2. Remove the cylinder liner by hand.




9TG0B2-186

# B

## INSTALLATION

### Step 4


1. Connect the hoses shown in the figure.



9TG0B2-442


### Step 5

1. Connect the harness connectors shown in the figure.



## INDEX

### INTAKE DEVICES SL Engine




9TGF2-002

- 1. Fresh air duct  
Removal / Inspection /  
Installation ..... page F2-18
- 2. Air cleaner  
Inspection ..... page F2-13

- 3. Intake shutter valve  
Removal / Installation ..... page F2-18  
Inspection ..... page F2-49
- 4. Intake manifold  
Installation Note ..... page F2-20


### EXHAUST AND EXHAUST CONTROLLED HEATING DEVICES




## CLUTCH FLUID

## PREPARATION

## SST

49 0259 770B		For air bleeding
Wrench, flare nut		

03U0HX-005



03U0HX-006

## REPLACEMENT


## Note

- A common reservoir is used for the clutch and brake system fluids.
- The fluid in the reservoir must be maintained at the 3/4 level or higher during replacement.

## Caution

- Be careful not to spill the fluid on a painted surface. If this should happen, wash it off immediately.
- Do not mix different brands of fluid.
- Do not reuse the clutch fluid that was drained.

1. Drain the brake fluid from the master cylinder through a wheel cylinder.
2. Remove the bleeder cap from the clutch release cylinder and attach a vinyl hose to the bleeder plug.



9TG0HX-005

3. Place the other end of the vinyl hose in a clear container.
4. Slowly pump the clutch pedal several times.
5. With the clutch pedal depressed, loosen the bleeder screw with the **SST** to let the fluid escape. Close the bleeder screw with the **SST**.
6. Repeat Steps 4 and 5 until only clean fluid is seen.
7. Tighten the bleeder screw.

## Tightening torque:


**5.9—8.8 N·m (60—90 cm·kg, 52—78 in·lb)**

8. Add fluid to the MAX mark.
9. Slowly pump the clutch pedal several times.  
Verify that there is no fluid leakage.
10. Verify operation of the clutch system.
11. Verify operation of the brake system.



STRUCTURAL VIEW

WITHOUT SUB-TRANSMISSION



- 1. 1st gear
- 2. 2nd gear
- 3. 3rd gear
- 4. Main drive gear (4th gear)


- 5. Reverse gear
- 6. 5th gear
- 7. Counter 5th gear

- 8. Reverse idler gear
- 9. Countershaft gear
- 10. Speedometer drive gear

9TG0J2-005

## Disassembly / Inspection / Assembly


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect for all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



- |   |  |
|---|--|
| <ol style="list-style-type: none"> <li>1. Locknut<br/>177-225 (18-23, 131-166)</li> <li>2. Pitman arm<br/>Disassembly note..... page N-30<br/>Assembly note ..... page N-36</li> <li>3. Side cover<br/>Disassembly note..... page N-30<br/>Inspect bearing for damage or corrosion<br/>Assembly note ..... page N-34</li> <li>4. Sector shaft<br/>Disassembly note..... page N-30<br/>Inspection..... page N-32<br/>Assembly note ..... page N-34</li> <li>5. Adjusting plug<br/>Disassembly note..... page N-30<br/>Assembly note ..... page N-34</li> </ol> | <ol style="list-style-type: none"> <li>6. Valve housing<br/>Disassembly note..... page N-31<br/>Inspect for damage<br/>Assembly note ..... page N-33</li> <li>7. Worm ball nut assembly<br/>Disassembly note..... page N-31<br/>Inspection..... page N-33<br/>Assembly note ..... page N-32</li> <li>8. Gear housing<br/>Disassembly note..... page N-31<br/>Inspect for damage<br/>Assembly note ..... page N-33, 35</li> </ol> |
|---|--|

## INDEX

### FRONT SUSPENSION



9TF0RX-002

1. Front shock absorber  
Removal / Inspection /  
Installation..... page R-13  
Inspection..... page R-13


2. Front leaf spring  
Removal / Inspection /  
Installation..... page R-14

## RADIATOR GRILLE/FRONT GRILLE

## COMPONENTS

## Removal / Installation

1. Disconnect the negative battery cable.
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.




9TG0SX-026

1. Radiator grille

2. Front grille


### SWITCHES

#### STRUCTURAL VIEW




9TG0TX-018

- |                                   |           |                           |                |
|-----------------------------------|-----------|---------------------------|----------------|
| 1. Engine switch                  |           | 3. Fog light switch       |                |
| Inspection .....                  | page T-17 | Inspection .....          | page T-42      |
| Removal / Installation .....      | page T-17 | 4. Exhaust heating switch |                |
| 2. Combination switch             |           | Service .....             | Section F2, F3 |
| (Including hazard warning switch) |           |                           |                |
| Removal / Installation .....      | page T-18 |                           |                |
| Disassembly / Assembly .....      | page T-18 |                           |                |
| Inspection .....                  | page T-19 |                           |                |




9TG0TX-040



9TG0TX-041

**WARNING SYSTEM**



9TF0TX-014

**Vacuum warning lamp**

**Vacuum warning lamp comes ON with buzzer after engine started**

Connect vacuum gauge between vacuum pump and vacuum tank

Start engine

Check vacuum

- Specified vacuum
  - 440 mmHg (-17.32 inHg)/1,500 rpm
  - 580 mmHg (-22.83 inHg)/3,000 rpm
  - max -700 mmHg (-27.56 inHg) or more



**NO**  
Check vacuum pump (Refer to Section P)  
Vacuum leakage from vacuum hose

**YES**

1. Disconnect vacuum switch connector
  2. Check that lamp goes OFF and buzzer stops
- Goes OFF and buzzer stops

**YES**  
Vacuum switch malfunction

**NO**  
Short-circuit in wire harness (Vacuum switch—Instrument cluster)



9TG0TX-084

**Vacuum warning lamp comes ON without buzzer after engine started**

Check continuity between 2A terminal at instrument cluster and buzzer A terminal as shown in the figure

- Continuity

**NO**  
Instrument cluster malfunction

**YES**

Check buzzer operation (Refer to page T-61)

- Normal

**NO**  
Buzzer malfunction

**YES**  
Short-circuit in instrument cluster

