


Title	Validity	Page
Inspect cylinders with light probe	MODEL 000.001 with ENGINE 457.960	3
Testing compression pressure	MODEL 000.001 with ENGINE 457.960	7
Check engine parts for wear and damage	MODEL 000.001 with ENGINE 457.960	11
During engine repair additional test work at cylinder head and cylinder head gasket	MODEL 000.001 with ENGINE 457.960	13
Remove/install cylinder head cover	MODEL 000.001 with ENGINE 457.960	15
Remove/install oil separator	MODEL 000.001 with ENGINE 457.960	17
Check cylinder head and cylinder head gasket for wear and damage	MODEL 000.001 with ENGINE 457.960	19
Remove/install cylinder head	MODEL 000.001 with ENGINE 457.960	23
Check/face grind cylinder head contact surfaces	MODEL 000.001 with ENGINE 457.960	29
Check cylinder barrel for wear and damage	MODEL 000.001 with ENGINE 457.960	33
Remove/install housing cover at front	MODEL 000.001 with ENGINE 457.960	39
Remove/install cover of camshaft sprocket	MODEL 000.001 with ENGINE 457.960	45
Measure cylinder bores	MODEL 000.001 with ENGINE 457.960	47
Remove/install oil pan	MODEL 000.001 with ENGINE 457.960	51
Remove/install constant-speed throttle	MODEL 000.001 with ENGINE 457.960	53
Remove/install timing case	MODEL 000.001 with ENGINE 457.960	57
Check piston and conrod for wear and damage	MODEL 000.001 with ENGINE 457.960	61
During engine repair additional test work at piston/conrod and at cylinder contact surface	MODEL 000.001 with ENGINE 457.960	67
Remove/install piston	MODEL 000.001 with ENGINE 457.960	69
Remove/install piston rings	MODEL 000.001 with ENGINE 457.960	75
Additional tests when carrying out a repair to the crankshaft, main bearing or connecting rod bearing	MODEL 000.001 with ENGINE 457.960	77
Remove/install race on crankshaft	MODEL 000.001 with ENGINE 457.960	79
Replace front crankshaft radial seal	MODEL 000.001 with ENGINE 457.960	81
Replace rear crankshaft radial seal	MODEL 000.001 with ENGINE 457.960	85
Remove/install crankshaft gear	MODEL 000.001 with ENGINE 457.960	87
Remove/install belt pulley/vibration damper	MODEL 000.001 with ENGINE 457.960	89
Remove/install flywheel	MODEL 000.001 with ENGINE 457.960	95
Check flywheel, re-machine	MODEL 000.001 with ENGINE 457.960	97
Replace ring gear of flywheel	MODEL 000.001 with ENGINE 457.960	99
Remove/install race on flywheel	MODEL 000.001 with ENGINE 457.960	101
Remove/install guide bearing in flywheel	MODEL 000.001 with ENGINE 457.960	103
Remove/install rocker arms assembly	MODEL 000.001 with ENGINE 457.960	105
Assemble/disassemble rocker arms assembly	MODEL 000.001 with ENGINE 457.960	107
Remove/install camshaft sprocket	MODEL 000.001 with ENGINE 457.960	109
Remove/install camshaft	MODEL 000.001 with ENGINE 457.960	111
Replace valve stem seals	MODEL 000.001 with ENGINE 457.960	113
Remove/install valves	MODEL 000.001 with ENGINE 457.960	117
Set valve clearance	ENGINE 457.960 in MODEL 000.001	121
Remove/install nozzle holder combination	MODEL 000.001 with ENGINE 457.960	127
Clean nozzle holder combination	MODEL 000.001 with ENGINE 457.960	131
Remove/install MR/PLD control unit	MODEL 000.001 with ENGINE 457.960	133
Remove MR/PLD unit pump, install	MODEL 000.001 with ENGINE 457.960	135
Remove/install injection lines MR/PLD	MODEL 000.001 with ENGINE 457.960	139
Remove/install air intake hose	MODEL 000.001 with ENGINE 457.960	141
Check turbocharger	MODEL 000.001 with ENGINE 457.960	143
Remove/install exhaust gas turbocharger	MODEL 000.001 with ENGINE 457.960	147
Remove/install charge air pipe	MODEL 000.001 with ENGINE 457.960	149
Remove/install charge air pressure, charge air temperature sensor	MODEL 000.001 with ENGINE 457.960	151
Remove/install charge air manifold	MODEL 000.001 with ENGINE 457.960	153
Remove/install alternator poly-V-belt	MODEL 000.001 with ENGINE 457.960	155

Contents

Title	Validity	Page
Remove/install poly-V-belt fan	MODEL 000.001 with ENGINE 457.960	157
Remove/install poly-V-belt tensioning device	MODEL 000.001 with ENGINE 457.960	159
Remove/install poly-V-Belt tensioning device for fan drive	MODEL 000.001 with ENGINE 457.960	161
Check compressor for oil ejection	MODEL 000.001 with ENGINE 457.960	163
Remove/install compressor	MODEL 000.001 with ENGINE 457.960	167
Remove/install cylinder head compressor	MODEL 000.001 with ENGINE 457.960	169
Remove/install exhaust manifold	MODEL 000.001 with ENGINE 457.960	171
Remove/install engine brake flap fittings	MODEL 000.001 with ENGINE 457.960	175
Remove/ install starter	MODEL 000.001 with ENGINE 457.960	177
Remove/install alternator	MODEL 000.001 with ENGINE 457.960	179
Remove/install belt pulley for alternator	MODEL 000.001 with ENGINE 457.960	181
Remove/install controller for alternator	MODEL 000.001 with ENGINE 457.960	183
Engine: change oil and replace filter	ENGINE 457.960 in MODEL 000.001	185
Check oil pressure	MODEL 000.001 with ENGINE 457.960	189
Fill engine oil circuit	MODEL 000.001 with ENGINE 457.960	191
Remove/install oil spray nozzles (piston)	MODEL 000.001 with ENGINE 457.960	193
Remove/install oil pressure relief valve	MODEL 000.001 with ENGINE 457.960	197
Remove/install oil pump	MODEL 000.001 with ENGINE 457.960	199
Remove/install oil filter housing	MODEL 000.001 with ENGINE 457.960	201
Remove/install oil/water heat exchanger	MODEL 000.001 with ENGINE 457.960	205
Remove/install oil pressure, oil temperature sensor	MODEL 000.001 with ENGINE 457.960	207
Remove/install coolant pump	MODEL 000.001 with ENGINE 457.960	209
Remove/install coolant thermostat	MODEL 000.001 with ENGINE 457.960	211
Remove/install fan	MODEL 000.001 with ENGINE 457.960	213
Remove/install bracket for viscous fan	MODEL 000.001 with ENGINE 457.960	215
Remove/install main fuel filter	MODEL 000.001 with ENGINE 457.960	217
Remove/install fuel pump	MODEL 000.001 with ENGINE 457.960	219
Remove/install bearing for fuel pump drive	MODEL 000.001 with ENGINE 457.960	221
Remove/install fuel heat exchanger	MODEL 000.001 with ENGINE 457.960	223

Attach

- 1 Remove cover (1) on flywheel housing.
- 2 Attach cranking/blocking device (2) with bolts (4) to flywheel housing.
 The cranking/blocking device (2) must be removed before starting engine, otherwise the flywheel or the cranking/blocking device (2) is damaged.
 The cranking/blocking device (2) can be blocked by plugging in pin (3).



W03.30-0001-02


Detach

- 3 Remove cranking/blocking device (2) from the flywheel housing.
- 4 Attach cover (1) with bolts (4) to the flywheel housing.

AH01.40-N-0001-01A	Notes for assessing wear to cylinder wall in the case of dust damage	Engines 401.9, 402.9, 441.9, 442.9, 446.9, 447, 457.9, 489, 541.9, 542.9, 900.9, 902.9, 904.9, 906.9, 924.9, 926.9	
--------------------	--	--	--

Cylinder contact surfaces or cylinder liners without dust damage

The honing pattern is more or less clearly recognizable over the entire running surface. The hone marks may be partially worn away at the travel limit of the first piston ring.




W03.10-0014-01


Cylinder contact surfaces or cylinder liners with dust damage

The traces of processing by honing are only just visible or are no longer visible. If the wear is substantial, a ridge can be felt at the travel limit of the first piston ring.


- Dust and particulate damage are caused by poor sealing, cracks and abrasion in the intake tract's collars, ducts and hoses. Carefully inspect all intake ducts, collars and hoses, even in areas where access is difficult, when performing service and maintenance operations.




W03.10-0015-01



001 589 78 21 00
Compression recorder



904 589 01 21 00
Connection piece



906 589 02 63 00
Extraction tool

AS00.00-Z-0005-01A	<p>Risk of accident as vehicle may start off by itself with the engine running. Risk of injury as working around the engine during start-up or while running may result in contusions and burns</p>	<p>Secure vehicle to prevent it from moving off by itself. Wear closed and close-fitting work clothes. Do not grasp hot or rotating parts.</p>	<p>⚠ Danger!</p>
--------------------	---	--	-------------------------

Possible hazards

Risk of accident

from vehicle starting off during starting operation (e.g. when testing compression pressure) as a result of gear engaged or when engine running, or vehicles with automatic transmission as a result of selector lever position "P" or "N" not engaged (exception: some vehicles do not have a selector lever position "P").

Injury hazard

Severe injuries may be caused by unshielded rotating parts in the area of the running engine. The heat produced by the running engine can result in severe burns if contact is made with individual, unshielded parts.

First aid measures in the event of burns

- Do not rub the skin areas affected; flush with plenty of cold water and cover skin with sterile bandages.
- Consult a doctor without delay.

Procedural guidelines and safety precautions

- As a general rule, carry out work on the running engine only if this is absolutely necessary.
- Before starting the engine, apply parking brake.
- On models with manual transmission move gearshift lever into Neutral position.
- On vehicles with automatic transmission move selector lever into position "P" or "N" (exception: some vehicles do not have a selector lever position "P").
- On models which do not have selector lever position "P", secure selector lever to prevent it from being operated unintentionally.
- Wear closed and close-fitting work clothes.
- All items of jewelry like chains or rings must be taken off.
- Restrain long hair by wearing an appropriate head cover.
- Before commencing any work on the running engine, familiarize yourself with the location of potentially hot parts.
- When carrying out work when starting the engine or when engine is running do not touch any hot and rotating parts.

AR01.40-G-0003CH	Check cylinder barrel for wear and damage	26.5.04
------------------	---	---------

MODEL 000.001 with ENGINE 457.960

	Check		
1	Remove cylinder head		Page 23
2	Clean crankcase sealing surface		
	Information on working sealing surfaces when carrying out engine repairs	Engine 457.9, 541.9, 542.9, 900.9, 902.9, 904.9, 906.9, 924.9, 926.9	Page 16
3	Rotate crankshaft until the piston of the cylinder to be checked is positioned on BDC, then assess the cylinder barrel by means of a visual inspection		
	Notes for evaluation of cylinder contact surface	Engine 457.9, 541.9, 542.9, 902.9, 904.9, 906.9, 924.9, 926.9	Page 34
		If wear or a damage is determined on the piston crown or on the cylinder barrel: ↓ Check piston and cylinder liner matchup Cylinder liner inner dia. Piston dia.	Page 37
		If wear, damage or variation of the specified values was determined: ↓ Install new piston Install new cylinder liner.	Page 69
			BE01.40-N-1001-03K BE03.10-N-1001-02N
4	Install cylinder head		Page 23


Test values of cylinder liner

Number	Designation	Engine 457.960	
BE01.40-N-1001-03K	Cylinder liner inner dia.	Code letter A	mm 127.990...127.995
		Code letter B	mm 127.995...128.005
		Code letter C	mm 128.005...128.010






Test values for pistons


Number	Designation	Engine 457.960	
BE03.10-N-1001-02N	Piston dia.	Group identification BA	mm 127.743...127.751
		BC	mm 127.749...127.757

- 1 Moisten crankshaft flange (7) with engine oil.
- 2 Position crankshaft radial sealing ring (4) on crankshaft flange (7) with installation aid (5).
- 3 Press crankshaft radial sealing ring (4) into front housing cover (6) and remove installation aid (5).




G03.20-3111-11

- 4 Attach  removal and insertion device (1) to crankshaft flange with bolts (2).
 When tightening bolts (2) ensure that the  removal and insertion device (1) does not make contact with the crankshaft radial sealing ring (4), if necessary, unscrew bolt (3).
- 5 Press crankshaft radial sealing ring (4) down to perceptible stop with  removal and insertion device (1) by screwing in bolt (3).
- 6  Remove removal and insertion device (1).



G03.20-3108-11

- 7 Check installation position of the crankshaft radial sealing ring (4).




G03.20-3110-11

AR01.60-G-8200CH	Remove/install timing case	8.6.04
------------------	----------------------------	--------

MODEL 000.001 with ENGINE 457.960


- 1 Timing case
- 2 Oil separator
- 3 Compressed-air line (constant throttle)
- 4 Coolant line (compressor)
- 5 Air intake pipe (compressor)
- 6 Compressed air line (engine brake)
- 7 Vent tube (crankcase ventilation)



W01.60-1004-11

- 1 Timing case
- 8 Locking bush
- 9 O-ring
- 10 Engine wiring harness
- 11 Gasket
- 12 Dowel pins
- 13 Radial seal ring

B15 Crankshaft angle position sensor
 B16 Cylinder 1 TDC sensor



G01.60-3104-06


	Remove/Install		
	Notes on self-locking nuts and bolts	All models	Page 59
	Drain engine oil Engine - oil and filter change		Page 185
2	Remove engine		
3	Attach engine to engine repair stand		WE58.40-Z-1001-11A WE58.40-Z-1015-11A
4	Remove starter		Page 177

AR03.10-G-7021CH	Remove/install piston	8.6.04
------------------	-----------------------	--------

MODEL 000.001 with ENGINE 457.960

- 1 Pistons
- 2 Piston pin
- 3 Circlip
- 4 Conrods
- 5 Connecting rod bearing cap
- 6 Connecting rod bolt
- 7 Connecting rod bearing shell
- 8 Connecting rod bearing shell


- L Shank length of the connecting rod bolt



G03.10-3103-06

- 1 Pistons
- 10 Tensioning strap
- 11 Cranking device

- A Piston projection











G03.10-3104-06

	Remove		
	Information on working sealing surfaces when carrying out engine repairs	Engine 457.9, 541.9, 542.9, 900.9, 902.9, 904.9, 906.9, 924.9, 926.9	Page 16
	Notes for assessing piston wear from dust/particulate damage	Engine 401.9, 402.9, 441.9, 442.9, 446.9, 447, 457.9, 489, 541.9, 542.9, 900.9, 902.9, 904.9, 906.9, 924.9, 926.9	Page 73


AR03.20-G-0002CH	Additional tests when carrying out a repair to the crankshaft, main bearing or connecting rod bearing	16.6.04
------------------	---	---------

MODEL 000.001 with ENGINE 457.960

	Check		
1 	Remove oil filter element and check for outer metal abrasion or swollen condition of the oil filter element disks Engine - oil and filter change	 Only if there is advanced wear or damage to engine components.	Page 185
2	Replace oil/water heat exchanger	 Only if metal abrasion is present at oil filter element disks or in the engine oil circuit.	Page 205
3	Remove, disassemble and check oil pump through a visual inspection for wear	 Only remove if reinforced metal abrasion was found at oil filter element. If wear is present, replace oil pump if necessary.	Page 199
4	Fill engine oil circuit	 Only if engine was repaired because of crankshaft bearing damage.	Page 191
5 	Replace engine oil and oil filter element. Engine - oil and filter change	 If metal abrasion or swollen condition of oil filter element (coolant in engine oil circuit):	Page 185

**Belt drive for alternator, coolant pump and AC compressor
(Vehicles with code (H03) Air conditioning in front end)**


- 1 Belt pulley alternator
- 2 Guide pulley
- 3 Belt pulley coolant pump
- 4 Poly-V-belt
- 5 Belt pulley/vibration damper
- 6 Tensioning device with tensioning pulley
- 8 Belt pulley AC compressor



W13.20-1002-02


Belt drive for fan

- 5 Belt pulley/vibration damper
- 9 Tensioning device with tensioning pulley for poly-V-belt for fan
- 10 Guide pulley for poly-V-belt for fan
- 11 Poly-V-belt for fan



W13.20-1003-02


AP13.22-D-1351-01A	Damage patterns for poly V-belt		
--------------------	---------------------------------	--	--



N13.22-2068-01

Wear to flank - ribs wedge-shaped (B) and cord visible in base of rib (C), condition of ribs when new is trapezoidal in shape (A)


Splits across the back (D)
Splits across several ribs (E)



N13.22-2066-01

AR05.20-G-6292CH	Remove/install camshaft	21.7.04
------------------	-------------------------	---------

MODEL 000.001 with ENGINE 457.960




G05.20-3108-09


- | | | | |
|-----|-------------------|---|-----------------|
| 1 | Camshaft | 4 | Guide sleeve |
| 1.1 | Camshaft sprocket | 5 | Crankshaft gear |
| 2 | Roller tappet | 6 | Push rod |
| 3 | Oil spray nozzle | | |

	Removal, installation		
1	Attach engine to engine assembly bracket	 	WE58.40-Z-1001-11A WE58.40-Z-1015-11A
2	Remove camshaft sprocket (1.1)		Page 109
3	Remove timing case		AR01.60-G-8200C
4	Remove MR/PLD unit pumps		Page 135
5	Remove rocker arms assembly		Page 105
6	Pull out push rods (6)	Installation: Oil push rods (6) with engine oil and check whether roller tappets (2) are seated correctly	
7	Turn engine in engine assembly support	Turn engine approx. 180° so that roller tappets (2) loosen from camshaft (1) 	WE58.40-Z-1001-11A WE58.40-Z-1015-11A
8	Tighten guide sleeve (4) to camshaft (1) at front		457 589 00 14 00
9	Pull out camshaft (1)	Carefully pull camshaft (1) out of crankcase to prevent damaging camshaft bearing	


AH05.30-N-1000-01D	General information on adjusting valve clearance	Engine 457.9, 900.9, 902.9, 904.9, 906.9, 924.9, 926.9 Method 2	
--------------------	--	--	--



A01.00-0001-01



N01.00-0347-01



N01.00-0348-01

Engine 457.9

- A Outlet valve
- E Inlet valve
- X Flywheel side

Engines 900.9, 904.9, 924.9

- A Outlet valve
- E Inlet valve
- X Flywheel side

Engines 902.9, 906.9, 926.9

- A Outlet valve
- E Inlet valve
- X Flywheel side

Method 2:

Set inlet and exhaust valves at two crankshaft positions, as shown in the table.

4-cylinder

Position cylinder 4 in the valve overlap TDC (cylinder 1 in ignition TDC), then position cylinder 1 in valve overlap TDC (cylinder 4 in ignition TDC).

6-cylinder

Position cylinder 6 in the valve overlap TDC (cylinder 1 in ignition TDC), then position cylinder 1 in valve overlap TDC (cylinder 6 in ignition TDC).

Motor	Crankshaft position	Cylinder/valves to be set					
		1	2	3	4	5	6
4-cylinder	Cyl. 4 valve overlap TDC	E/A	E	A	-		
	Cyl. 1 valve overlap TDC	-	A	E	E/A		
6-cylinder	Cyl. 6 valve overlap TDC	E/A	E	A	E	A	-
	Cyl. 1 valve overlap TDC	-	A	E	A	E	E/A
















AP05.30-G-0560-01CH	Check and adjust valve clearance		
---------------------	----------------------------------	--	--

Test values for valves

Number	Designation	Engine 457.960	
BE05.30-N-1001-01M	Valve clearance	Inlet	mm 0,40
		Outlet	mm 0,60
BE05.30-N-1002-01M	Inspection tolerance of valve clearance	mm	-0.10/ +0.20

Engine timing - general

Number	Designation	Engine 457.960	
BA05.00-N-1002-01K	Locknut at adjusting bolt of rocker arm	Nm	50


	Remove/install		
⚠ Danger!	Risk of injury to skin and eyes caused by scalding from contact with hot coolant spray. Risk of poisoning from swallowing coolant.	Do not open cooling system unless coolant temperature is below 90°C. Open cap slowly and release the pressure. Do not pour coolant into beverage containers. Wear protective gloves, protective clothing and safety glasses.	Page 26
1	Drain and collect coolant	<p> Only when removing the MR/PLD unit pumps (1) from cylinders 1 to 3.</p> <p> Installation: In line with the coolant regulations, only approved anticorrosion/antifrost agents may be used otherwise engine damage may occur. The following should be observed:</p> <p style="text-align: center;">↓</p>	
 BB	Coolant specifications	Sheet 310.1	BB00.40-P-0310-01A
 BB	Anticorrosion/antifreeze agent	Sheet 325.2	BB00.40-P-0325-02A
2	Detach coolant pipe at crankcase	 Only when removing the MR/PLD unit pumps (1) from cylinders 1 to 3.	
3	Remove charge air manifold		Page 153
⚠ Danger!	Risk of explosion caused by fuel igniting, risk of poisoning caused by inhaling and swallowing fuel as well as risk of injury to eyes and skin caused by contact with fuel.	No fire, sparks, open flames or smoking. Pour fuels only into suitable and appropriately marked containers. Wear protective clothing when handling fuel.	Page 27
4	Remove injection line (5)	 Seal holes at nozzle holder combination and at MR/PLD unit pump (1).	Page 139
5	Take off engine wiring harness (6) at MR/PLD unit pump (1)	 Loosen bolts at solenoid valve and separate both push-fit clips for this step.	
6	Mark MR/PLD unit pump (1) to the relevant cylinder	 Only when removing several or all MR/PLD unit pumps (1).	
7	Loosen bolts (4)	<p> For safety reasons, the bolts (4) must be loosened by around 4 to 5mm only and the MR/PLD unit pump unit (1) tensioned by spring force.</p> <p> Installation: Install MR/PLD unit pump (1) by slowly and alternately screwing bolt (4) into crankcase</p> <p></p>	BA07.15-N-1005-01F
8	Pull MR/PLD unit pump (1) with extractor to stop on bolt heads (4)	<p> Tight MR/PLD unit pumps (1) must not be pressed out at the solenoid valve or at the housing flange, otherwise damage may occur to the MR/PLD unit pumps (1).</p> <p></p>	355 589 01 63 00
9	Completely unscrew bolt (4) and pull out MR/PLD unit pump (1)	 Installation: Lightly grease housing of MR/PLD unit pump (1), surface of black O-rings (2), green O-ring (3) as well as holes in crankcase with high temperature bearing grease. Insert the MR/PLD unit pump (1) with the self-made assembly pins into the crankcase.	BR00.45-Z-1058-06A

AR13.22-G-0003CH	Remove/install alternator poly-V-belt	5.7.04
------------------	---------------------------------------	--------

MODEL 000.001 with ENGINE 457.960

Shown with fan wheel removed

- 1 Poly-V-belt (fan)
- 2 Tensioning device (alternator poly-V-belt)
- 3 Poly-V-belt (alternator)



W20.40-1063-12

	Removal		
Danger!	Injury hazard from pinching when working on springs and spring bodies under tension	Use only approved tensioning devices, if necessary shield hazardous areas additionally Check special tools for damage and proper function (visual inspection). Wear protective gloves.	Page 91
1	Remove poly-V-belt (1)		Page 157
2	Pivot tensioning pulley for tensioning device (2) downward and hold		
3	Remove poly-V-belt (3) from belt pulleys		
4	Pivot back tensioning pulley for tensioning device (2)		
5	Press fan wheel toward front and remove poly-V-belt (3)	Do not damage poly-V-belt (3) when removing	
	Test		
6	Check belt pulleys and tensioning pulleys for damage and smoothness, replace if necessary.		
7	Check poly-V-belt (3) for condition, replace if necessary		
	Damage pattern for poly-V-belt		Page 92
	Installation		
8	Press fan wheel toward front and position poly-V-belt (3) on belt pulley	Observe belt route of poly-V-belt	Page 91
9	Pivot tensioning pulley for tensioning device (2) downward and hold		

5	Remove control line (3)	Nm	BA13.30-N-1006-01J
6	Remove compressor (6) from timing case	Installation: Observe various bolt lengths Nm	BA13.30-N-1001-01J
7	Reinstall in opposite order		
8	Correct engine oil level AP Engine oil and filter change		Page 185
9	Check coolant level, correct is necessary		

Compressor (compressed air system)

Number	Designation	Engine 457.960
BA13.30-N-1001-01J	Bolt, compressor to crankcase	Nm 60
BA13.30-N-1002-01J	Banjo bolt, coolant line to compressor	M16x1.5 Nm 40
		M14X1.51 Nm 35
BA13.30-N-1004-01J	Fittings, compressed air line to compressor	Nm 80
BA13.30-N-1005-01J	Fittings, intake line to compressor	Nm 80
BA13.30-N-1006-01J	Banjo bolt, control line to compressor	Nm 15

AH20.00-N-2080-01A	Notes on coolant	All engines	
--------------------	------------------	-------------	--

Coolant composition

passenger car and commercial vehicle engines (normally)
50 water in % by volume and
50 corrosion/antifreeze agent in % by volume.

Different coolant composition for CV engines, refer to **MB Specifications for Operating Fluids**.

Tasks of corrosion and frost protection

- Corrosion and cavitation protection of all components in cooling system
- Antifreeze protection (frost protection)
- Increase the boiling point so that coolant does not evaporate so rapidly. Avoiding ejection of coolant at high coolant temperatures.

Water

Use water which is clean and not too hard. Drinking water often satisfies requirements, but not always the contents of dissolved substances in the water may be of significance for the occurrence of corrosion. If in doubt, analyze the water.

For fresh water specifications refer to **MB Specifications for Operating Fluids**.

Period of use

The maximum permissible period of use of the coolant can be taken from the maintenance booklet; from the applicable service/maintenance sheet or the **MB-Specifications for Operating Fluids** respectively.

For the period of use for a varying coolant composition for CV engines, refer to **MB Specifications for Operating Fluids**.

Antifreeze protection

50 % by volume of anticorrosion/ antifreeze agent offers antifreeze protection down to approx. -37 °C. A higher concentration is only necessary if the ambient temperatures are even lower. 55 % by volume of anticorrosion/antifreeze agent offers antifreeze protection down to approx. -45 °C.

A concentration of more than 55 % by volume of anticorrosion/ antifreeze agent should not be used as the maximum antifreeze protection is already reached. An even higher concentration once reduces antifreeze protection and impairs heat dissipation. Reduced heat dissipation can lead to damage to components in the cooling system or damage to the engine.

Before pouring in fresh coolant, flush the used coolant out of the cooling system. In the event of high pollution or oil fouling levels, clean the cooling system, otherwise damage can occur to the components of the cooling system.

Disposing of coolants

Pay attention to legal provisions and local wastewater regulations.

For workshops located in the Federal Republic of Germany refer to:

"Environmental Protection Manual for Automotive Repair Workshops"

Publisher: Association of Automotive Industry e.V. (VDA)
60625 Frankfurt am Main, Westendstraße 61