

GROUP 11B

ENGINE OVERHAUL <4A9>

CONTENTS

GENERAL INFORMATION	11B-2	OIL PAN AND TIMING CHAIN CASE	11B-19
GENERAL SPECIFICATIONS	11B-2	REMOVAL AND INSTALLATION	11B-19
SERVICE SPECIFICATIONS	11B-2	TIMING CHAIN	11B-24
TORQUE SPECIFICATIONS	11B-4	REMOVAL AND INSTALLATION	11B-24
SEALANTS	11B-6	INSPECTION	11B-27
SPECIAL TOOLS	11B-7	CAMSHAFT	11B-29
ALTERNATOR AND IGNITION SYSTEM	11B-9	REMOVAL AND INSTALLATION	11B-29
REMOVAL AND INSTALLATION	11B-9	INSPECTION	11B-32
FUEL AND EMISSION PARTS	11B-11	CYLINDER HEAD AND VALVES	11B-33
REMOVAL AND INSTALLATION	11B-11	REMOVAL AND INSTALLATION	11B-33
INLET MANIFOLD	11B-13	INSPECTION	11B-35
REMOVAL AND INSTALLATION	11B-13	PISTON AND CONNECTING ROD	11B-37
EXHAUST MANIFOLD	11B-17	REMOVAL AND INSTALLATION	11B-37
REMOVAL AND INSTALLATION	11B-17	INSPECTION	11B-43
		CRANKSHAFT AND CYLINDER BLOCK	11B-44
		REMOVAL AND INSTALLATION	11B-44
		INSPECTION	11B-50

GENERAL INFORMATION

M1113000100976

Vehicle name	Vehicle model	Engine model	Displacement mL	Specification
Colt	Z23A	4A91	1,499	Double overhead camshaft, 16-valve

GENERAL SPECIFICATIONS

M1113000200962

Item	4A91	
Total displacement mL	1,499	
Bore × stroke mm	75.0 × 84.8	
Compression ratio	10.0	
Combustion chamber	Pentroof type	
Camshaft arrangement	DOHC	
Number of valve	Intake	2
	Exhaust	2
Valve timing	Intake opening	BTDC 31° – ATDC 19°
	Intake closing	ABDC 21° – ABDC 71°
	Exhaust opening	BBDC 39°
	Exhaust closing	ATDC 5°
Fuel system	Electronically controlled multipoint fuel injection	
Rocker arm	None	
Auto-lash adjuster	None	

SERVICE SPECIFICATIONS

M1113000301014

Item		Standard value	Limit
TIMING CHAIN			
Valve clearance mm	Intake	0.22	–
	Exhaust	0.30	–
CAMSHAFT			
Cam height mm	Intake	44.71	44.21
	Exhaust	44.28	43.78
CYLINDER HEAD AND VALVES			
Cylinder head bottom face distortion mm		0.03 or less	0.2
Cylinder head bottom surface grinding limit (Total resurfacing depth of both cylinder head and cylinder block) mm		–	0.2
Cylinder head overall height mm		112.9 – 113.1	–

Item	Standard value	Limit
Cylinder bore mm	75	–
Cylindrically mm	0.007 or less	–
Piston to cylinder clearance mm	0.010 – 0.035	–








TORQUE SPECIFICATIONS

M1113023401788

Items	N-m	
ALTERNATOR AND IGNITION SYSTEM		
Spark plugs	25 ± 5	
Ignition coil bolt	8.4 ± 0.6	
Tensioner pulley bolts	49 ± 9	
Crankshaft pulley bolts	190	
Water pump pulley bolts	8.4 ± 0.65	
Adjust bolt	5.0 ± 1.0	
Alternator brace bolt (M6)	Hexagon bolts	11 ± 1
	Torx bolts	8.4 ± 0.6
Alternator brace bolt (M10)	36.0 ± 3.6	
Alternator nut (M8)	22.5 ± 2.5	
Alternator nut (M10)	47 ± 5	
Oil level gauge guide bolt	7.6 ± 0.6	
FUEL AND EMISSION PARTS		
Delivery pipe and injector assembly bolts	18.4 ± 1.4	
Manifold absolute pressure (MAP) sensor bolts	6.0 ± 0.5	
Throttle body bolts	6.0 ± 0.5	
Solenoid valve nut	7.6 ± 0.6	
Engine hanger bolts	18.4 ± 1.4	
INLET MANIFOLD		
Water inlet pipe bolt	7.6 ± 0.6	
Water inlet fitting bolts	8.4 ± 0.65	
Engine coolant temperature sensor	29.4 ± 9.8	
Crank angle sensor bolts	8.4 ± 0.6	
Camshaft position bolt	8.4 ± 0.6	
Detonation sensor bolt	20 ± 1	
Oil pressure switch bolts	10 ± 2	
Inlet manifold bolts	13.4 ± 6.4	
EGR pipe nuts	18 ± 1	
EGR pipe bolts	7.6 ± 0.6	
Special bolts	13.4 ± 6.4	



SPECIAL TOOLS

M1113000601628

Tool	Number	Name	Use
 <p>D998781</p>	MD998781	Flywheel stopper	Retention of flywheel
 <p>MB991883</p>	MB991883	Flywheel stopper	Retention of flywheel
 <p>D998727</p>	MD998727	Oil pan remover	Removal of oil pan
	MB990699	Differential oil seal installer	Installation of front oil seal
 <p>B991993</p>	MB991993	Crankshaft front oil seal guide	Installation of chain case
 <p>B992000</p>	MB992000	Crankshaft adapter	Turn the crankshaft
 <p>D999597</p>	MD999597	Valve spring compressor	Compression of valve spring

REMOVAL SERVICE POINTS



<<A>> CRANKSHAFT PULLEY BOLT REMOVAL




1. Lock the drive plate or the flywheel with the special tool Flywheel Stopper.
2. Remove the crankshaft bolt.
 - Flywheel Stopper (MD998781)
 - Flywheel Stopper (MB991883)

INSTALLATION SERVICE POINTS

>>A<< CRANKSHAFT PULLEY / WASHER / CRANKSHAFT PULLEY BOLT INSTALLATION



1. Lock the drive plate or the flywheel with the special tool Flywheel Stopper.
 - Flywheel Stopper (MD998781)
 - Flywheel Stopper (MB991883)




2. Clean the threaded holes in the crankshaft.
3. Clean and degrease the crankshaft pulley.

NOTE: Degreasing is required to prevent any remaining oil from compromising the friction coefficient of the pulley belt contact surface.
4. Install the crankshaft pulley.
5. Apply an appropriate minimum amount of engine oil to the threaded portion as well as the flange bottom of the crankshaft.
6. Clean the washer.
7. Tighten the crankshaft bolt to 190 N·m.


INSTALLATION SERVICE POINTS**>>A<< DELIVERY PIPE ASSEMBLY
INSTALLATION****⚠ CAUTION**

Be sure not to allow engine oil entering into the delivery pipe.

1. Lightly coat the injector's O-rings with new engine oil. Insert the injector squarely into the delivery pipe. Do not insert it aslant.
2. Ensure that the injector can rotate smoothly. If not, remove the injector, check the O-ring for damage, replace the O-ring as required, then try to install the injector again.



3. Install the injector support.



4. Install the delivery pipe assembly onto the cylinder head.


Ensure that the injector can rotate smoothly. If not, remove the injector, check the O-ring for damage, replace the O-ring as required, then try to install the injector again.

Align the center of the injector with the center of the injector mounting hole in the delivery pipe and also aligning the protruded portions with each other.


5. The protruded portions can be aligned with each other by rotating the injector.
6. Tighten the delivery pipe assembly fittings to 18.4 ± 1.4 N·m.

**>>B<< MANIFOLD ABSOLUTE
PRESSURE (MAP) SENSOR
INSTALLATION****⚠ CAUTION**

- Be careful not to provide shock to MAP sensor when installing it.
- If MAP sensor is dropped to the floor when installing it, discard it and use a new one.

**>>C<< THROTTLE BODY GASKET
INSTALLATION**

Install the throttle body gasket, facing the gasket's protruded portion in the illustrated direction.

>>D<< THROTTLE BODY INSTALLATION


Install the throttle body onto the inlet manifold, engaging the throttle body's recess with the manifold's protruded portion.

3. Install the crank angle sensor onto the cylinder block by tightening it to 8.4 ± 0.6 N·m.

>>E<< OIL PRESSURE SWITCH INSTALLATION

⚠ CAUTION

Apply sealant correctly so that it will not be squeezed out onto the end of the threaded portion upon assembly.




1. Remove any sealant that may be remaining on the oil pressure switch or the threaded hole in the cylinder block.
2. Apply sealant to the threaded portion of the oil pressure switch as illustrated.


Specified sealant:
LOCTITE 565 or equivalent

3. Install the oil pressure switch onto the cylinder block by tightening it to 10 ± 2 N·m.

>>F<< EGR PIPE GASKET INSTALLATION




1. Install the EGR pipe gasket A, facing the gasket's protruded portion in the illustrated direction.



2. Install the EGR pipe gasket B, facing the gasket's protruded portion in the illustrated direction.


>>G<< EGR VALVE GASKET INSTALLATION



Install the EGR valve gasket, facing the gasket's hollow portion in the illustrated direction.


REMOVAL SERVICE POINTS

<<A>> OIL FILTER REMOVAL



Remove the oil filter using an oil filter wrench (commercially available).


<> OIL PAN REMOVAL



1. Remove the oil pan retaining bolts.
2. Knock the special tool Oil pan cutter (MD998727) between the oil pan and the cylinder block.

INSTALLATION SERVICE POINTS


>>A<< FRONT OIL SEAL INSTALLATION




Install the front oil seal into the timing chain case using the special tool Differential oil seal installer (MB990699).

>>B<< TIMING CHAIN CASE INSTALLATION

1. Remove any liquid gasket remaining on the timing chain case, the cylinder block, and the cylinder head.



2. Install the special tool Oil seal guide (MB991993) onto the crankshaft.



⚠ CAUTION

The timing chain case should be installed within 3 minutes of applying liquid gasket.

3. Apply a 2.0 ± 0.5 mm bead of liquid gasket to location A, and a 1.5 ± 0.5 mm bead of liquid gasket to location B on the timing chain case respectively as illustrated.

Specified sealant:
LOCTITE 5971 or exact equivalent


4. Install the timing chain case.

NOTE: The retaining bolts have different lengths. Be sure to use the correct bolt for each location.

TIMING CHAIN

REMOVAL AND INSTALLATION

M1113026600216



AK402345AE

Removal steps

- >>D<< 1. Timing chain tensioner assembly
- 2. Tensioner lever assembly
- 3. Chain guide assembly
- >>C<< 4. Timing chain
- <<A>> >>B<< 5. Camshaft sprocket bolt

Removal steps (Continued)


- <> >>A<< 6. Camshaft sprocket
- 7. V.V.T. sprocket bolt
- 8. V.V.T. sprocket assembly

INSPECTION


M1113026700075

VALVE CLEARANCE MEASUREMENT

Measure the valve clearance as illustrated.




Set the special tool Crankshaft adapter (MB992000) to the crankshaft, and install the crankshaft pulley bolt and washer.




CAUTION

The crankshaft should always be rotated clockwise.

1. Rotate the crankshaft clockwise until the mark on the camshaft sprocket is aligned with the mark on the upper surface of cylinder head. (Set the No. 1 cylinder to TDC on the compression stroke.)



2. Now, the valve clearance (shown with an arrow) can be measured.




3. Using a thickness gauge, measure the clearance between the cam base circle and the valve tappet.

Standard value (cold engine):


Intake valve 0.22 ± 0.04 mm

Exhaust valve 0.30 ± 0.04 mm


4. If the measured value does not conform to the standard value, record the measured value.



5. Rotate the crankshaft clockwise until the mating mark on the camshaft sprocket comes to the illustrated location. This will bring the No. 4 cylinder to TDC on the compression stroke.



6. Measure the valve clearance at the location shown with an arrow.
7. If the measured value does not conform to the standard value, record the measured value.
8. Replace the valve tappet for the valve whose clearance is out of the standard value.

REMOVAL SERVICE POINTS**<<A>> FRONT CAMSHAFT BEARING CAP / CAMSHAFT BEARING CAP REMOVAL**


In accordance with the numerical order shown in the illustration, remove the front camshaft bearing cap first, and then remove the installation bolt of each camshaft bearing cap.

<> VALVE TAPPET REMOVAL


To facilitate reassembly, attach a tag to each valve tappet removed that shows where it has been assembled.

INSTALLATION SERVICE POINTS**>>A<< VALVE TAPPET INSTALLATION**

Reassemble each valve tappet to the correct location shown on the tag.

>>B<< CAMSHAFT/CAMSHAFT BEARING CAP INSTALLATION

1. Install each camshaft, ensuring that the dowel pin faces the illustrated direction.



2. The No. 2 to No. 5 bearing caps are equally shaped for both the intake and exhaust camshafts. Be sure to correctly install them by referring to the identification marks.

Identification mark (stamped on the front and No. 2 to No. 5 bearing caps)

I: Intake

E: Exhaust

3. In accordance with the numerical order shown in the illustration, tighten each camshaft bearing cap first and then tighten the front camshaft bearing cap in several steps.


>>C<< OIL FEEDER CONTROL VALVE (OCV) FILTER INSTALLATION**⚠ CAUTION**

After checking for foreign matters attached, defects and deformation, install the oil feeder control valve filter.

CYLINDER HEAD AND VALVES

REMOVAL AND INSTALLATION

M1113006900992




AK402342AC

Removal steps

- >>C<< 1. Cylinder head bolt
- 2. Cylinder head bolt washer
- 3. Cylinder head assembly
- 4. Cylinder head gasket
- <<A>> >>B<< 5. Retainer lock
- 6. Valve spring retainer
- 7. Valve spring
- 8. Intake valve
- <<A>> >>B<< 9. Retainer lock
- 10. Valve spring retainer
- 11. Valve spring

Removal steps (Continued)

- 12. Exhaust valve
- >>A<< 13. Valve stem seal
- 14. Valve spring seat
- >>A<< 15. Valve stem seal
- 16. Valve spring seat
- 17. Valve guide
- 18. Valve guide
- 19. Intake valve seat
- 20. Exhaust valve seat
- 21. Cylinder head



3. Measure the valve overall length. If the measured value exceeds the limit, replace with a new valve.

Standard value:

Intake 89.61 mm


Exhaust 90.94 mm

Limit:

Intake 89.11 mm

Exhaust 90.44 mm

VALVE SPRING



1. Measure the valve spring free height. If the measured value exceeds the limit, replace with a new spring.

Standard value: 43.1 mm


Limit: 42.1 mm

2. Measure the valve spring out-of-squareness. If the measured value exceeds the limit, replace with a new spring.

Standard value: 2° or less

Limit: 4°

VALVE GUIDE



Measure the clearance between the valve guide and the valve stem. If the measured value exceeds the limit, replace the valve guide or the valve, or both.

Standard value:

Intake 0.020 – 0.047 mm


Exhaust 0.030 – 0.057 mm

Limit:

Intake 0.10 mm

Exhaust 0.15 mm

VALVE SEAT



With the valve mechanism assembled and the valve face pressed against the seat, measure the valve stem end protrusion over the cylinder head face where the spring seat is located. If the measured value exceeds the limit, replace the cylinder head assembly.

Standard value:

Intake 38.46 mm


Exhaust 38.49 mm

Limit:


Intake 38.96 mm

Exhaust 38.99 mm

>>C<< PISTON RING NO. 2 / PISTON RING NO. 1 INSTALLATION



Use a piston ring expander to install the No. 1 and No. 2 piston rings. The ring identification mark should face upwards.




Identification mark
No. 1 ring: None
No. 2 ring: 2R

NOTE: Each of the available piston rings has a size mark as follows:


Size		Size mark
Standard	No. 1 ring	No mark (Yellow paint on periphery)
	No. 2 ring	No mark (Yellow paint on periphery)
0.25 mm oversize		25

>>D<< PISTON, CONNECTING ROD ASSEMBLY INSTALLATION

1. Apply engine oil sufficiently onto the piston periphery, the piston rings and the oil ring.



2. Align the gaps of the piston rings and the oil ring (side rails, spacer) as illustrated.
3. Insert the piston and connecting rod assembly from above the cylinder block and through the cylinder bore, ensuring that the front mark on the piston top faces the camshaft sprocket.




CAUTION

Do not try to strike hard on the assembly to fit it in place as this will break the piston rings.

4. While firmly holding the piston rings with a ring band, insert the piston and connecting rod assembly into place.

<CVT>



AK401772 AC

Removal steps

- <<A>> >>G<< 1. Drive plate bolt
- 2. Adapter plate
- 3. Drive plate
- 4. Bell housing cover
- >>F<< 5. Oil seal case
- >>E<< 6. Crankshaft bearing cap bolt
- >>E<< 7. Crankshaft bearing cap
- >>D<< 8. Crankshaft bearing, lower

Removal steps (Continued)

- 9. Crankshaft
- >>C<< 10. Crankshaft bearing, upper
- >>B<< 11. Thrust bearing
- >>A<< 12. Crankshaft sensing ring
- 13. Cylinder block