

# SECTION **EM**

## ENGINE MECHANICAL

### CONTENTS

QR			
<b>PRECAUTIONS</b>	<b>5</b>	<b>INTAKE MANIFOLD</b>	<b>17</b>
Precautions for Drain Engine Coolant and Engine Oil	5	Removal and Installation	17
Precautions for Disconnecting Fuel Piping	5	REMOVAL	17
Precautions for Removal and Disassembly	5	INSTALLATION	18
Precautions for Inspection, Repair and Replacement	5	INSPECTION AFTER INSTALLATION	19
Precautions for Assembly and Installation	5	<b>EXHAUST MANIFOLD AND THREE WAY CATALYST</b>	<b>20</b>
Parts Requiring Angle Tightening	5	Removal and Installation	20
Precautions for Liquid Gasket	6	REMOVAL	20
REMOVAL OF LIQUID GASKET SEALING	6	INSPECTION AFTER REMOVAL	21
LIQUID GASKET APPLICATION PROCEDURE	6	INSTALLATION	21
<b>PREPARATION</b>	<b>7</b>	<b>OIL PAN</b>	<b>22</b>
Special Service Tools	7	Removal and Installation	22
Commercial Service Tools	9	REMOVAL	22
<b>NOISE, VIBRATION AND HARSHNESS (NVH)</b>		INSTALLATION	23
<b>TROUBLESHOOTING</b>	<b>11</b>	INSPECTION AFTER INSTALLATION	23
NVH Troubleshooting — Engine Noise	11	<b>IGNITION COIL</b>	<b>25</b>
Use the Chart Below to Help You Find the Cause of the Symptom.	12	Removal and Installation	25
<b>DRIVE BELTS</b>	<b>13</b>	REMOVAL	25
Checking Drive Belt	13	INSTALLATION	25
Tension Adjustment	13	<b>SPARK PLUG (PLATINUM-TIPPED TYPE)</b>	<b>26</b>
Removal and Installation	13	Removal and Installation	26
REMOVAL	13	REMOVAL	26
INSTALLATION	14	INSPECTION AFTER REMOVAL	26
Removal and Installation of Drive Belt Auto-Tensioner	14	INSTALLATION	27
REMOVAL	14	<b>FUEL INJECTOR AND FUEL TUBE</b>	<b>28</b>
INSTALLATION	14	Removal and Installation	28
<b>AIR CLEANER AND AIR DUCT</b>	<b>15</b>	REMOVAL	28
Removal and Installation	15	INSTALLATION	30
REMOVAL	15	INSPECTION AFTER INSTALLATION	32
INSPECTION AFTER REMOVAL	15	<b>ROCKER COVER</b>	<b>33</b>
INSTALLATION	15	Removal and Installation	33
Changing Air Cleaner Filter	16	REMOVAL	33
REMOVAL	16	INSTALLATION	34
INSTALLATION	16	<b>CAMSHAFT</b>	<b>35</b>
		Removal and Installation	35
		REMOVAL	35
		INSPECTION AFTER REMOVAL	37
		INSTALLATION	40


INSPECTION AFTER INSTALLATION .....	43	HOW TO SELECT MAIN BEARING .....	87
Valve Clearance .....	44	Inspection After Disassembly .....	91
INSPECTION .....	44	CRANKSHAFT END PLAY .....	91
ADJUSTMENT .....	45	CONNECTING ROD SIDE CLEARANCE .....	91
<b>TIMING CHAIN .....</b>	<b>47</b>	PISTON TO PISTON PIN OIL CLEARANCE .....	91
Removal and Installation .....	47	PISTON RING SIDE CLEARANCE .....	92
REMOVAL .....	48	PISTON RING END GAP .....	92
INSPECTION AFTER REMOVAL .....	51	CONNECTING ROD BEND AND TORSION .....	93
INSTALLATION .....	51	CONNECTING ROD BIG END DIAMETER .....	93
INSPECTION AFTER INSTALLATION .....	55	CONNECTING ROD BUSHING OIL CLEARANCE .....	93
<b>OIL SEAL .....</b>	<b>56</b>	CYLINDER BLOCK DISTORTION .....	94
Removal and Installation of Valve Oil Seal .....	56	MAIN BEARING HOUSING INNER DIAMETER .....	95
REMOVAL .....	56	PISTON TO CYLINDER BORE CLEARANCE .....	95
INSTALLATION .....	56	CRANKSHAFT MAIN JOURNAL DIAMETER .....	96
Removal and Installation of Front Oil Seal .....	56	CRANKSHAFT PIN JOURNAL DIAMETER .....	97
REMOVAL .....	56	OUT-OF-ROUND AND TAPER OF CRANKSHAFT .....	97
INSTALLATION .....	57	CRANKSHAFT RUNOUT .....	97
Removal and Installation of Rear Oil Seal .....	57	CONNECTING ROD BEARING OIL CLEARANCE .....	97
REMOVAL .....	57	MAIN BEARING OIL CLEARANCE .....	98
INSTALLATION .....	57	MAIN BEARING CRUSH HEIGHT .....	99
<b>CYLINDER HEAD .....</b>	<b>59</b>	CONNECTING ROD BEARING CRUSH HEIGHT .....	99
On-Vehicle Service .....	59	LOWER CYLINDER BLOCK MOUNTING BOLT OUTER DIAMETER .....	99
CHECKING COMPRESSION PRESSURE .....	59	CONNECTING ROD BOLT OUTER DIAMETER .....	99
Removal and Installation .....	60	FLYWHEEL DEFLECTION (M/T MODELS) .....	100
REMOVAL .....	60	MOVEMENT AMOUNT OF FLYWHEEL (M/T MODELS) .....	100
INSPECTION AFTER REMOVAL .....	61	<b>SERVICE DATA AND SPECIFICATIONS (SDS) ...</b>	<b>101</b>
INSTALLATION .....	62	Standard and Limit .....	101
INSPECTION AFTER INSTALLATION .....	62	GENERAL SPECIFICATIONS .....	101
Disassembly and Assembly .....	63	DRIVE BELT .....	101
DISASSEMBLY .....	63	EXHAUST MANIFOLD AND THREE WAY CATALYST ASSEMBLY .....	101
ASSEMBLY .....	64	SPARK PLUG .....	101
Inspection After Disassembly .....	66	CYLINDER HEAD .....	101
VALVE DIMENSIONS .....	66	VALVE .....	102
VALVE GUIDE CLEARANCE .....	66	CAMSHAFT AND CAMSHAFT BEARING .....	106
VALVE GUIDE REPLACEMENT .....	66	CYLINDER BLOCK .....	106
VALVE SEAT CONTACT .....	68	PISTON, PISTON RING AND PISTON PIN .....	108
VALVE SEAT REPLACEMENT .....	68	CONNECTING ROD .....	109
VALVE SPRING SQUARENESS .....	69	CRANKSHAFT .....	109
VALVE SPRING DIMENSIONS AND VALVE SPRING PRESSURE LOAD .....	69	MAIN BEARING .....	111
<b>ENGINE ASSEMBLY .....</b>	<b>70</b>	CONNECTING ROD BEARING .....	112
Removal and Installation .....	70		
REMOVAL .....	71		
INSTALLATION .....	72		
INSPECTION AFTER INSTALLATION .....	72		
<b>CYLINDER BLOCK .....</b>	<b>74</b>		
Disassembly and Assembly .....	74		
DISASSEMBLY .....	75		
ASSEMBLY .....	79		
How to Select Piston and Bearing .....	84		
DESCRIPTION .....	84		
HOW TO SELECT PISTON .....	84		
HOW TO SELECT CONNECTING ROD BEARING .....	85		

## VQ

<b>PRECAUTIONS .....</b>	<b>113</b>
Precautions for Drain Engine Coolant .....	113
Precautions for Disconnecting Fuel Piping .....	113
Precautions for Removal and Disassembly .....	113
Precautions for Inspection, Repair and Replacement .....	113
Precautions for Assembly and Installation .....	113

Parts Requiring Angle Tightening .....	113	
Precautions for Liquid Gasket .....	114	
REMOVAL OF LIQUID GASKET SEALING .....	114	
LIQUID GASKET APPLICATION PROCEDURE .....	114	
<b>PREPARATION .....</b>	<b>115</b>	
Special Service Tools .....	115	
Commercial Service Tools .....	117	
<b>NOISE, VIBRATION AND HARSHNESS (NVH)</b>		
<b>TROUBLESHOOTING .....</b>	<b>119</b>	
NVH Troubleshooting —Engine Noise .....	119	
Use the Chart Below to Help You Find the Cause of the Symptom .....	120	
<b>ENGINE ROOM COVER .....</b>	<b>121</b>	
Removal and Installation .....	121	
REMOVAL .....	121	
INSTALLATION .....	121	
<b>DRIVE BELTS .....</b>	<b>122</b>	
Checking Drive Belts .....	122	
Tension Adjustment .....	122	
Removal and Installation .....	122	
DRIVE BELT .....	122	
INSTALLATION .....	123	
Drive Belt Auto-Tensioner and Idler Pulley .....	123	
REMOVAL .....	123	
INSTALLATION .....	123	
<b>AIR CLEANER AND AIR DUCT .....</b>	<b>124</b>	
Removal and Installation .....	124	
REMOVAL .....	124	
INSPECTION AFTER REMOVAL .....	124	
INSTALLATION .....	124	
Changing Air Cleaner Filter .....	124	
REMOVAL .....	124	
INSTALLATION .....	124	
<b>INTAKE MANIFOLD COLLECTOR .....</b>	<b>125</b>	
Removal and Installation .....	125	
REMOVAL .....	126	
INSTALLATION .....	127	
<b>INTAKE MANIFOLD .....</b>	<b>128</b>	
Removal and Installation .....	128	
REMOVAL .....	128	
INSPECTION AFTER REMOVAL .....	128	
INSTALLATION .....	129	
<b>EXHAUST MANIFOLD AND THREE WAY CATALYST .....</b>	<b>130</b>	
Removal and Installation .....	130	
REMOVAL (LEFT BANK) .....	130	
INSPECTION AFTER REMOVAL .....	131	
INSTALLATION (LEFT BANK) .....	132	
REMOVAL (RIGHT BANK) .....	133	
INSPECTION AFTER REMOVAL .....	133	
INSTALLATION (RIGHT BANK) .....	134	
<b>OIL PAN AND OIL STRAINER .....</b>	<b>135</b>	
Removal and Installation .....	135	A
REMOVAL (LOWER) .....	135	
INSPECTION AFTER REMOVAL .....	136	
INSTALLATION (LOWER) .....	136	EM
INSPECTION AFTER INSTALLATION .....	137	
REMOVAL (UPPER) .....	137	
INSPECTION AFTER REMOVAL .....	138	
INSTALLATION (UPPER) .....	138	C
INSPECTION AFTER INSTALLATION .....	139	
<b>IGNITION COIL .....</b>	<b>140</b>	
Removal and Installation .....	140	D
REMOVAL (LEFT BANK) .....	140	
INSTALLATION (LEFT BANK) .....	140	
REMOVAL (RIGHT BANK) .....	140	E
INSTALLATION (RIGHT BANK) .....	140	
<b>SPARK PLUG (PLATINUM-TIPPED TYPE) .....</b>	<b>141</b>	
Removal and Installation .....	141	F
REMOVAL .....	141	
INSPECTION AFTER REMOVAL .....	141	
INSTALLATION .....	142	
<b>FUEL INJECTOR AND FUEL TUBE .....</b>	<b>143</b>	G
Removal and Installation .....	143	
REMOVAL .....	143	
INSTALLATION .....	146	H
INSPECTION AFTER INSTALLATION .....	148	
<b>ROCKER COVER .....</b>	<b>149</b>	
Removal and Installation .....	149	I
REMOVAL (LEFT BANK) .....	149	
INSTALLATION (LEFT BANK) .....	150	
REMOVAL (RIGHT BANK) .....	151	J
INSTALLATION (RIGHT BANK) .....	152	
<b>FRONT TIMING CHAIN CASE .....</b>	<b>154</b>	
Removal and Installation .....	154	K
REMOVAL .....	154	
INSTALLATION .....	158	
INSPECTION AFTER INSTALLATION .....	161	
<b>TIMING CHAIN .....</b>	<b>163</b>	L
Removal and Installation .....	163	
REMOVAL .....	164	
INSPECTION AFTER REMOVAL .....	171	
INSTALLATION .....	172	M
INSPECTION AFTER INSTALLATION .....	182	
<b>CAMSHAFT .....</b>	<b>183</b>	
Removal and Installation .....	183	
REMOVAL .....	184	
INSPECTION AFTER REMOVAL .....	185	
INSTALLATION .....	188	
INSPECTION AFTER INSTALLATION .....	191	
Valve Clearance .....	192	
INSPECTION .....	192	
ADJUSTMENT .....	195	
<b>OIL SEAL .....</b>	<b>197</b>	
Removal and Installation of Valve Oil Seal .....	197	
REMOVAL .....	197	
INSTALLATION .....	197	
Removal and Installation of Front Oil Seal .....	198	
REMOVAL .....	198	

INSTALLATION .....	198	ANCE .....	234
Removal and Installation of Rear Oil Seal .....	199	CYLINDER BLOCK DISTORTION .....	235
REMOVAL .....	199	MAIN BEARING HOUSING INNER DIAMETER.....	236
INSTALLATION .....	199	PISTON TO CYLINDER BORE CLEARANCE .....	236
<b>CYLINDER HEAD .....</b>	<b>201</b>	CRANKSHAFT MAIN JOURNAL DIAMETER .....	237
On-Vehicle Service .....	201	CRANKSHAFT PIN JOURNAL DIAMETER .....	238
CHECKING COMPRESSION PRESSURE .....	201	CRANKSHAFT OUT-OF-ROUND AND TAPER.....	238
Removal and Installation .....	202	CRANKSHAFT RUNOUT .....	238
REMOVAL .....	202	CONNECTING ROD BEARING OIL CLEAR-	
INSPECTION AFTER REMOVAL .....	203	ANCE .....	238
INSTALLATION .....	204	MAIN BEARING OIL CLEARANCE .....	239
INSPECTION AFTER INSTALLATION .....	205	CRUSH HEIGHT OF MAIN BEARING .....	240
Disassembly and Assembly .....	206	CRUSH HEIGHT OF CONNECTING ROD	
DISASSEMBLY .....	206	BEARING .....	240
ASSEMBLY .....	207	LOWER CYLINDER BLOCK BOLT OUTER	
Inspection After Disassembly .....	208	DIAMETER .....	240
VALVE DIMENSIONS .....	208	CONNECTING ROD BOLT OUTER DIAMETER.....	241
VALVE GUIDE CLEARANCE .....	208	FLYWHEEL DEFLECTION (M/T MODELS) .....	241
VALVE GUIDE REPLACEMENT .....	209	MOVEMENT AMOUNT OF FLYWHEEL (M/T	
VALVE SEAT CONTACT .....	210	MODELS) .....	241
VALVE SEAT REPLACEMENT .....	210	DRIVE PLATE .....	242
VALVE SPRING SQUARENESS .....	211	OIL JET .....	242
VALVE SPRING DIMENSIONS AND VALVE		OIL JET RELIEF VALVE .....	242
SPRING PRESSURE LOAD .....	212	<b>SERVICE DATA AND SPECIFICATIONS (SDS) ...</b>	<b>243</b>
<b>ENGINE ASSEMBLY .....</b>	<b>213</b>	Standard and Limit .....	243
Removal and Installation .....	213	GENERAL SPECIFICATIONS .....	243
REMOVAL .....	214	DRIVE BELT .....	244
INSTALLATION .....	215	INTAKE MANIFOLD COLLECTOR, INTAKE	
INSPECTION AFTER INSTALLATION .....	215	MANIFOLD AND EXHAUST MANIFOLD .....	244
<b>CYLINDER BLOCK .....</b>	<b>216</b>	SPARK PLUG .....	244
Disassembly and Assembly .....	216	CAMSHAFT AND CAMSHAFT BEARING .....	245
DISASSEMBLY .....	217	CYLINDER HEAD .....	247
ASSEMBLY .....	221	CYLINDER BLOCK .....	250
How to Select Piston and Bearing .....	227	PISTON, PISTON RING AND PISTON PIN .....	251
DESCRIPTION .....	227	CONNECTING ROD .....	252
HOW TO SELECT PISTON .....	227	CRANKSHAFT .....	253
HOW TO SELECT CONNECTING ROD BEAR-		MAIN BEARING .....	254
ING .....	228	CONNECTING ROD BEARING .....	255
HOW TO SELECT MAIN BEARING .....	229		
Inspection After Disassembly .....	232		
CRANKSHAFT END PLAY .....	232		
CONNECTING ROD SIDE CLEARANCE .....	232		
PISTON TO PISTON PIN OIL CLEARANCE .....	232		
PISTON RING SIDE CLEARANCE .....	233		
PISTON RING END GAP .....	233		
CONNECTING ROD BEND AND TORSION .....	234		
CONNECTING ROD BIG END DIAMETER .....	234		
CONNECTING ROD BUSHING OIL CLEAR-			




# OIL PAN

[QR]

Tool number : KV10111100 (J-37228)

**CAUTION:**

- Be careful not to damage the mating surfaces.
- Do not insert a screwdriver, this will damage the mating surfaces.




## INSTALLATION

1. Install oil pan with the following procedure:
  - a. Use a scraper to remove old liquid gasket from mating surfaces.
    - Also remove the old liquid gasket from mating surface of cylinder block.
    - Remove old liquid gasket from the bolt holes and threads.

**CAUTION:**

Do not scratch or damage the mating surfaces when cleaning off old liquid gasket.




- b. Apply a continuous bead of liquid gasket using Tool as shown.

Tool number : WS39930000 ( — )


Use Genuine RTV Silicone Sealant or equivalent. Refer to [GI-47, "Recommended Chemical Products and Sealants"](#).

**CAUTION:**

Attaching should be done within 5 minutes after coating.



- c. Tighten bolts in numerical order as shown.
  - Install A/T fluid cooler tube bracket with bolts No.1 and 9 as shown (A/T models).



2. Install oil pan drain plug. Refer to [MA-26, "Changing Engine Oil"](#).
3. Install in the reverse order of removal after this step.

**NOTE:**

Pour engine oil at least 30 minutes after oil pan is installed.

## INSPECTION AFTER INSTALLATION


1. Check the engine oil level, and adjust the level. Refer to [LU-6, "ENGINE OIL LEVEL"](#).

## Valve Lifter Clearance

### VALVE LIFTER OUTER DIAMETER

- Measure the outer diameter of valve lifter with a micrometer.


**Standard : 33.965 - 33.980 mm (1.3372 - 1.3378 in)**



### VALVE LIFTER HOLE DIAMETER

Measure the diameter of valve lifter hole of cylinder head with an inside micrometer.

**Standard : 34.000 - 34.021 mm (1.3386 - 1.3394 in)**



### VALVE LIFTER CLEARANCE

- (Valve lifter clearance) = (Valve lifter hole diameter) – (Valve lifter outer diameter)

**Standard : 0.020 - 0.056 mm (0.0008 - 0.0022 in)**


- If out of the standard, referring to the each standard of valve lifter outer diameter and valve lifter hole diameter, replace either or both valve lifter and cylinder head.

## INSTALLATION

1. Install valve lifters.
  - Install them in the original positions.
2. Install camshafts.
  - Distinction between intake and exhaust camshafts is performed with the different shapes of rear end.

**Intake : Signal plate shape for camshaft position sensor (PHASE)**

**Exhaust : Cone end shape**




10. Remove oil pressure sensor using a suitable tool.

**CAUTION:**

**Do not drop or shock oil pressure sensor.**

11. Remove pilot converter (A/T models) or pilot bushing (M/T models) using Tool.

**Tool number : ST16610001 (J-23907)**



12. Remove piston and connecting rod assembly with the following procedure:

- Before removing piston and connecting rod assembly, check the connecting rod side clearance. Refer to [EM-91, "CONNECTING ROD SIDE CLEARANCE"](#).


13. Position crankshaft pin corresponding to connecting rod to be removed onto the bottom dead center.

14. Remove connecting rod cap.

15. Push piston and connecting rod assembly out to the cylinder head side using suitable tool.

**CAUTION:**

**Be careful not to damage the cylinder wall and crankshaft pin, resulting from an interference of the connecting rod big end.**



16. Remove connecting rod bearings.

**CAUTION:**


**Identify installation positions, and store them without mixing them up.**

17. Remove piston rings from piston; using piston ring expander or suitable tool.

- Before removing piston rings, check the piston ring side clearance. Refer to [EM-92, "PISTON RING SIDE CLEARANCE"](#).

**CAUTION:**

- When removing piston rings, be careful not to damage the piston.**
- Be careful not to damage piston rings by expanding them excessively.**






# SERVICE DATA AND SPECIFICATIONS (SDS)

[QR]

## Valve Seat

Unit: mm (in)



Items		Standard	Oversize [0.5 (0.02)] (Service)
Cylinder head seat recess diameter "D"	Intake	36.500 - 36.516 (1.4370 - 1.4376)	37.000 - 37.016 (1.4567 - 1.4573)
	Exhaust	31.500 - 31.516 (1.2402 - 1.2408)	32.000 - 32.016 (1.2598 - 1.2605)
Valve seat outer diameter "d"	Intake	36.597 - 36.613 (1.4408 - 1.4415)	37.097 - 37.113 (1.4605 - 1.4611)
	Exhaust	31.600 - 31.616 (1.2441 - 1.2447)	32.100 - 32.116 (1.2638 - 1.2644)
Valve seat interference fit	Intake	0.081 - 0.113 (0.0032 - 0.0044)	
	Exhaust	0.084 - 0.116 (0.0033 - 0.0046)	
Diameter "d1"*1	Intake	33.5 (1.319)	
	Exhaust	28.0 (1.102)	
Diameter "d2"*2	Intake	35.1 - 35.3 (1.382 - 1.390)	
	Exhaust	29.9 - 30.1 (1.177 - 1.185)	
Angle "α1"	Intake	60°	
	Exhaust	60°	
Angle "α2"	Intake	88°45' - 90°15'	
	Exhaust	88°45' - 90°15'	
Angle "α3"	Intake	120°	
	Exhaust	120°	
Contacting width "W"*3	Intake	1.05 - 1.35 (0.0413 - 0.0531)	
	Exhaust	1.25 - 1.55 (0.0492 - 0.0610)	
Height "h"	Intake	5.9 - 6.0 (0.232 - 0.236)	5.0 - 5.1 (0.197 - 0.201)
	Exhaust	5.9 - 6.0 (0.232 - 0.236)	4.91 - 5.01 (0.1933 - 0.1972)
Depth "H"		6.0 (0.236)	

\*1 : Diameter made by intersection point of conic angles  $\alpha_1$  and  $\alpha_2$

\*2 : Diameter made by intersection point of conic angles  $\alpha_2$  and  $\alpha_3$

\*3 : Machining data

## INSTALLATION


Installation is in the reverse order of removal.

### CAUTION:

Make sure belt is securely installed around all pulleys.

## Drive Belt Auto-Tensioner and Idler Pulley

EBS00P4J



1. Idler pulley

2. Drive belt auto-tensioner

## REMOVAL

1. Remove the air duct and resonator assembly (inlet). Refer to [EM-124, "REMOVAL"](#).
2. Remove the drive belt. Refer to [EM-122, "Removal"](#).
3. Remove the radiator cooling fan assembly. Refer to [CO-38, "REMOVAL"](#).
4. Remove the drive belt auto-tensioner and idler pulley using power tool.

## INSTALLATION


Installation is in the reverse order of removal.

## OIL PAN AND OIL STRAINER

[VQ]

- Tighten bolts in numerical order as shown.
- There are two types of bolts. Refer to the following for locating bolts.

**M8 × 100 mm (3.97 in)** : 7, 11, 12, 13  
**M8 × 25 mm (0.98 in)** : Except the above




- e. Tighten transmission joint bolts. Refer to [MT-16, "REMOVAL"](#) (FS5R30A), [MT-65, "REMOVAL"](#) (FS6R31A) (4X2), [MT-67, "REMOVAL"](#) (FS6R31A) (4X4), [AT-248, "REMOVAL"](#) (A/T) (4X2), [AT-250, "REMOVAL"](#) (A/T) (4X4).
2. Install oil strainer to oil pan (upper).
  3. Installation of the remaining components is in the reverse order of removal.

### INSPECTION AFTER INSTALLATION


1. Check engine oil level and adjust engine oil. Refer to [LU-18, "ENGINE OIL"](#).
2. Start engine, and check there is no leak of engine oil.
3. Stop engine and wait for 10 minutes.
4. Check engine oil level again. Refer to [LU-18, "ENGINE OIL"](#).

## INSTALLATION


1. Hammer dowel pins (right and left) into front timing chain case up to a point close to taper in order to shorten protrusion length.



2. Install new front oil seal on the front timing chain case.
  - Apply new engine oil to both oil seal lip and dust seal lip.
  - Install it so that each seal lip is oriented as shown.



- Press-fit oil seal until it becomes flush with front timing chain case end face using suitable drift [outer diameter: 60 mm (2.36 in)].
- Make sure the garter spring is in position and seal lip is not inverted.




3. Install water pump cover and chain tensioner cover to front timing chain case, if removed.

- Apply a continuous bead of liquid gasket using Tool to front timing chain case as shown.

**Tool number** : WS39930000 ( — )


**Use Genuine RTV Silicone Sealant or equivalent. Refer to [GI-47, "Recommended Chemical Products and Sealants"](#)**



# TIMING CHAIN

[VQ]

- Press-fit oil seal until it becomes flush with front timing chain case end face using suitable drift [outer diameter: 60 mm (2.36 in)].
- Make sure the garter spring is in position and seal lip is not inverted.




12. Install water pump cover and chain tensioner cover to front timing chain case.

- Apply a continuous bead of liquid gasket using Tool to front timing chain case as shown.

**Tool number** : WS39930000 ( — )

**Use Genuine RTV Silicone Sealant or equivalent. Refer to [GI-47, "Recommended Chemical Products and Sealants"](#)**




13. Install front timing chain case as follows:

- a. Apply a continuous bead of liquid gasket using Tool to front timing chain case back side as shown.

**Tool number** : WS39930000 ( — )


**Use Genuine RTV Silicone Sealant or equivalent. Refer to [GI-47, "Recommended Chemical Products and Sealants"](#)**



2. Measure the camshaft sprocket runout with dial indicator. (Total indicator reading)

**Limit : 0.15 mm (0.0059 in)**


- If it exceeds the limit, replace camshaft sprocket.



## Valve Lifter

Check if surface of valve lifter has any wear or cracks.

- If anything above is found, replace valve lifter. Refer to [EM-246, "Available Valve Lifter"](#).




## Valve Lifter Clearance

### VALVE LIFTER OUTER DIAMETER

- Measure the outer diameter at 1/2 height of valve lifter with micrometer since valve lifter is in barrel shape.

**Standard (Intake and exhaust)**

**: 33.977 - 33.987 mm (1.3377 - 1.3381 in)**




### VALVE LIFTER HOLE DIAMETER

- Measure the inner diameter of valve lifter hole of cylinder head with inside micrometer.

**Standard (Intake and exhaust)**

**: 34.000 - 34.016 mm (1.3386 - 1.3392 in)**



### VALVE LIFTER CLEARANCE

- (Valve lifter clearance) = (Valve lifter hole diameter) – (Valve lifter outer diameter), Refer to [EM-192, "Valve Clearance"](#).

**Standard (Intake and exhaust)**

**: 0.013 - 0.039 mm (0.0005 - 0.0015 in)**

- i. Apply new engine oil to threads and seat surfaces of the bolts.
- ii. Tighten M8 bolts in numerical order as shown from No. 17 to 24.


**Bolts 17 - 24 : 22.1 N-m (2.3 kg-m, 16 ft-lb)**

**CAUTION:**

**Wipe off completely any protruding liquid gasket on rear oil seal installation surface.**

**NOTE:**

There are more processes to complete the tightening bolts. However stop procedure here to install rear oil seal.




- c. Install rear oil seal. Refer to [EM-199, "INSTALLATION"](#).
- d. Restart tightening of lower cylinder block bolts as follows:
- i. Tighten M10 bolts in numerical order as shown from No. 1 to 16.

**NOTE:**

Use TORX socket (size E14) for bolts No. 1 to 16 (M10 bolt).

**Bolts 1 - 16 : 35.3 N-m (3.6 kg-m, 26 ft-lb)**




- ii. Turn M10 bolts 90° clockwise in numerical order from No. 1 to 16 using Tool.

**Tool number : KV10112100 (BT-8653-A)**

**CAUTION:**

**Use angle wrench Tool to check tightening angle. Do not make judgement by visual inspection.**



- After installing the bolts, make sure that crankshaft can be rotated smoothly by hand.
  - Wipe off completely any protruding liquid gasket on front side of the engine.
  - Check the crankshaft end play. Refer to [EM-232, "CRANKSHAFT END PLAY"](#).
8. Inspect the outer diameter of connecting rod bolt. Refer to [EM-241, "CONNECTING ROD BOLT OUTER DIAMETER"](#).
  9. Install piston to connecting rod as follows:
    - a. Install new snap ring to the groove of piston rear side using suitable tool.
      - Insert it fully into groove to install.
    - b. Install piston to connecting rod.
      - Using industrial use drier or similar tool, heat piston until piston pin can be pushed in by hand without excess force [approx. 60° to 70 °C (140° to 158 °F)]. From the front to the rear, insert piston pin into piston and connecting rod.