

NISSAN NV200

MODEL M20 SERIES

QUICK REFERENCE INDEX

A GENERAL INFORMATION	GI General Information
B ENGINE	EM Engine Mechanical
	LU Engine Lubrication System
	CO Engine Cooling System
	EC Engine Control System
	FL Fuel System
	EX Exhaust System
	STR Starting System
	ACC Accelerator Control System
C HYBRID	
D TRANSMISSION & DRIVE-LINE	TM Transaxle & Transmission
	FAX Front Axle
	RAX Rear Axle
E SUSPENSION	FSU Front Suspension
	RSU Rear Suspension
	WT Road Wheels & Tires
F BRAKES	BR Brake System
	PB Parking Brake System
	BRC Brake Control System
G STEERING	ST Steering System
	STC Steering Control System
H RESTRAINTS	SB Seat Belt
	SR SRS Airbag
	SRC SRS Airbag Control System
I VENTILATION, HEATER & AIR CONDITIONER	VTL Ventilation System
	HA Heater & Air Conditioning System
	HAC Heater & Air Conditioning Control System
J BODY INTERIOR	INT Interior
	IP Instrument Panel
	SE Seat
K BODY EXTERIOR, DOORS, ROOF & VEHICLE SECURITY	DLK Door & Lock
	SEC Security Control System
	GW Glass & Window System
	PWC Power Window Control System
	EXT Exterior
	BRM Body Repair Manual
L DRIVER CONTROLS	MIR Mirrors
	EXL Exterior Lighting System
	INL Interior Lighting System
	WW Wiper & Washer
	DEF Defogger
	HRN Horn
M ELECTRICAL & POWER CONTROL	PWO Power Outlet
	BCS Body Control System
	LAN LAN System
	PCS Power Control System
	CHG Charging System
	PG Power Supply, Ground & Circuit Elements
N DRIVER INFORMATION & MULTIMEDIA	MWI Meter, Warning Lamp & Indicator
	WCS Warning Chime System
	SN Sonar System
	AV Audio, Visual & Navigation System
O CRUISE CONTROL	CCS Cruise Control System
P MAINTENANCE	MA Maintenance
Q INDEX	IDX Alphabetical Index

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

Q


HOW TO USE THIS MANUAL

< HOW TO USE THIS MANUAL >

Relation between Illustrations and Descriptions

INFOID:000000012994678

The following sample explains the relationship between the part description in an illustration, the part name in the text and the service procedures.



Components

INFOID:000000012994679

- **THE LARGE ILLUSTRATIONS** are exploded views (see the following) and contain tightening torques, lubrication points, section number of the **PARTS CATALOG** (e.g. SEC. 440) and other information necessary to perform repairs.

The illustrations should be used in reference to service matters only. When ordering parts, refer to the appropriate **PARTS CATALOG**.

Always check with the **PARTS DEPARTMENT** for the latest parts information.

Components shown in an illustration may be identified by a circled number. When this style of illustration is used, the text description of the components will follow the illustration.

CYLINDER BLOCK


< UNIT DISASSEMBLY AND ASSEMBLY >

[MR20DE]

CYLINDER BLOCK

Exploded View

INFOID:000000012995010



1. Crankshaft position sensor (POS)
4. Connector
7. Block heater (for Canada)

2. O-ring
5. gasket
8. Top ring

3. Oil pressure sensor
6. Cylinder block
9. Second ring

[MR20DE]

WORKSHEET SAMPLE

MTBL0017

< DTC/CIRCUIT DIAGNOSIS >

Follow the procedure "With CONSULT" above.

Is 1st trip DTC is detected?

- YES >> Proceed to [EC-196, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000012994040

1. CHECK AIR FUEL RATIO (A/F) SENSOR 1 POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect A/F sensor 1 harness connector.
3. Turn ignition switch ON.
4. Check the voltage between A/F sensor 1 harness connector and ground.

+		–	Voltage
A/F sensor 1			
Connector	Terminal		
F12	4	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK AIR FUEL RATIO (A/F) SENSOR 1 POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R harness connector.
3. Check the continuity between A/F sensor 1 harness connector and IPDM E/R harness connector.

+		-		Continuity
A/F sensor 1		IPDM E/R		
Connector	Terminal	Connector	Terminal	
F12	4	E43	17	Existed

4. Also check harness for short to ground.

Is the inspection result normal?

- YES >> Perform the trouble diagnosis for power supply circuit.
NO >> Repair or replace error-detected parts.

3. CHECK A/F SENSOR 1 INPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between A/F sensor 1 harness connector and ECM harness connector.

+		-		Continuity
A/F sensor 1		ECM		
Connector	Terminal	Connector	Terminal	
F12	1	F11	49	Existed
	2		53	

4. Check the continuity between A/F sensor 1 harness connector and ground, or ECM harness connector and ground.

P2101 ELECTRIC THROTTLE CONTROL FUNCTION


[MR20DE]

< DTC/CIRCUIT DIAGNOSIS >

2. Check if foreign matter is caught between the throttle valve and the housing.

Is the inspection result normal?

- YES >> GO TO 6.
NO >> Remove the foreign matter and clean the electric throttle control actuator inside, then perform throttle valve closed position learning. Refer to [EC-123. "Description"](#).



6.CHECK THROTTLE CONTROL MOTOR

Check the throttle control motor. Refer to [EC-380. "Component Inspection \(Throttle Control Motor\)"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-41. "Intermittent Incident"](#).
NO >> Replace electric throttle control actuator. Refer to [EM-26. "Removal and Installation"](#).

Component Inspection (Throttle Control Motor)

INFOID:0000000012994213

1.CHECK THROTTLE CONTROL MOTOR

1. Turn ignition switch OFF.
2. Disconnect electric throttle control actuator harness connector.
3. Check the resistance between electric throttle control actuator terminals as per the following.

Electric throttle control actuator		Condition		Resistance (Approx.)
+	-			
Terminals				
5	6	Temperature °C (°F)	25 (77)	1 - 15 Ω

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace electric throttle control actuator. Refer to [EM-26. "Removal and Installation"](#).

TRANSAXLE ASSEMBLY

< UNIT REMOVAL AND INSTALLATION >


[CVT: RE0F10D]

INSTALLATION

Installation is in the reverse order of removal.


NOTE:

Write down the serial number of the new transaxle assembly.



CAUTION:

- When replacing an engine or transaxle you must make sure any dowels are installed correctly during re-assembly.
- Improper alignment caused by missing dowels may cause vibration, oil leaks or breakage of drivetrain components.
- Do not reuse O-rings or copper sealing washers.
- When turning crankshaft, turn it clockwise as viewed from the front of the engine.
- When tightening the nuts for the torque converter while securing the crankshaft pulley bolt, be sure to confirm the tightening torque of the crankshaft pulley bolt. Refer to [EM-55, "Removal and Installation"](#).
- After converter is installed to drive plate, rotate crankshaft several turns to check that CVT rotates freely without binding.
- When installing the CVT to the engine, align the matching mark on the drive plate with the matching mark on the torque converter.
- When installing the transaxle assembly to the engine assembly, attach the fixing bolts in accordance with the following.



Insertion direction	Transaxle to engine	Engine to transaxle
Bolt No.	(A)	(B)
Number of bolts	2	7
Bolt length mm (in)	55 (2.17)	50.5 (1.99)
Tightening torque N-m (kg-m, ft-lb)	62(6.3, 46)	

- When installing the drive plate to torque converter nuts, tighten them temporarily. then tighten the nuts to the specified torque.
- Perform "ADDITIONAL SERVICE WHEN REPLACE TRANSAXLE ASSEMBLY". Refer to [TM-78, "Description"](#).

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:0000000012995570

1.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) IGNITION POWER SUPPLY (1)

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Voltage (Approx.)
Connector	Terminal		
E33	32	Ground	0 V

4. Turn the ignition switch ON

NOTE:

Start the engine.

5. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Voltage (Approx.)
Connector	Terminal		
E33	32	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) IGNITION POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Check the 10A fuse (45).
3. Disconnect IPDM E/R harness connector.
4. Check the continuity between ABS actuator and electric unit (control unit) harness connector and IPDM E/R.

ABS actuator and electric unit (control unit)		IPDM E/R		Continuity
Connector	Terminal	Connector	Terminal	
E33	32	E43	16	Yes

5. Check the continuity between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E33	32	Ground	No

Is the inspection result normal?

YES >> Perform trouble diagnosis for ignition power supply.

NO >> Repair / replace harness, connector, or fuse.

3.CHECK MOTOR AND MOTOR RELAY POWER SUPPLY

1. Turn the ignition switch OFF.
2. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Voltage (Approx.)
Connector	Terminal		
E33	1	Ground	Battery voltage

3. Turn the ignition switch ON.

NOTE:

B1148 CURTAIN AIR BAG MODULE RH

< DTC/CIRCUIT DIAGNOSIS >

B1148 CURTAIN AIR BAG MODULE RH

DTC Logic

INFOID:0000000012995310

DTC DETECTION LOGIC

DTC	Display contents of CONSULT	DTC detecting condition	Repair order
B1148	CURTAIN MODULE RH [SHORT]	Curtain air bag module RH circuits are shorted to each other.	1. Visually check the wiring harness connection. 2. Replace the harness if it has visible damage. 3. Replace the air bag diagnosis sensor unit. 4. Replace the RH side curtain air bag module. 5. Replace the related harness.

DTC CONFIRMATION PROCEDURE (With CONSULT)

1.CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check for DTC using CONSULT.

Is the DTC detected?

YES (Current DTC)>>Refer to [SRC-135, "Diagnosis Procedure"](#).

YES (Past DTC)>>GO TO 2.

NO >> Inspection End.

2.ERASE SELF-DIAG RESULT

Erase the DTC using CONSULT.

Can the DTC be erased?

YES >> Inspection End.

NO >> Refer to [SRC-135, "Diagnosis Procedure"](#).

DTC CONFIRMATION PROCEDURE (Without CONSULT)

1.CHECK SELF-DIAG RESULT

1. Turn ignition switch ON.
2. Check the air bag warning lamp status. Refer to [SRC-17, "Trouble Diagnosis without CONSULT"](#).

NOTE:

SRS will not enter diagnosis mode if no malfunction is detected in user mode.

Is the DTC detected?

YES >> Refer to [SRC-135, "Diagnosis Procedure"](#).

NO >> Inspection End.

Diagnosis Procedure

INFOID:0000000012995311

1.HARNESS CONNECTOR

Visually inspect all applicable harness connectors for the following:

- Visible damage to connector or terminal
- Loose terminal
- Poor connection

NOTE:

All harness connectors should be inspected from the air bag diagnosis unit to the end component (including in-line connectors).

Is the inspection result normal?

YES >> GO TO 2.

- NO >> Perform one of the following repairs:
- Visible damage: Replace the harness.
 - Loose terminal: Secure the terminal.
 - Poor connection: Secure the connection.

2.CONFIRM DTC

DOOR LOCK ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

- Check voltage between BCM harness connector and ground.

(+)		(-)	Condition		Voltage (Approx.)
BCM					
Connector	Terminal				
M19	54	Ground	Door lock and unlock switch	Lock	12 V
	41			Unlock	

Is the inspection result normal?

YES >> Check for internal short of each door lock actuator.

NO >> Replace BCM. Refer to [BCS-50, "Removal and Installation"](#).

PASSENGER SIDE

PASSENGER SIDE : Component Function Check

INFOID:0000000012996397

1.CHECK FUNCTION

- Select DOOR LOCK of BCM using CONSULT.
- Select DOOR LOCK in ACTIVE TEST mode.
- Touch ALL LCK or ALL ULK to check that it works normally.

Is the inspection result normal?

YES >> Door lock actuator is OK.

NO >> Refer to [DLK-51, "PASSENGER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:0000000012996398

Regarding Wiring Diagram information, refer to [DLK-20, "Wiring Diagram"](#).

1.CHECK DOOR LOCK ACTUATOR INPUT SIGNAL

- Turn ignition switch OFF.
- Disconnect front door lock actuator RH connector.
- Check voltage between front door lock actuator RH harness connector and ground.

(+)		(-)	Condition		Voltage (Approx.)
Front door lock actuator RH					
Connector	Terminal				
D114	1	Ground	Door lock and unlock switch	Unlock	12 V
	2			Lock	

Is the inspection result normal?

YES >> Replace front door lock actuator RH.

NO >> GO TO 2.

2.CHECK DOOR LOCK ACTUATOR CIRCUIT

- Disconnect BCM connector and all door lock actuator connectors.
- Check continuity between BCM harness connector and front door lock actuator RH harness connector.

BCM		Front door lock actuator RH		Continuity
Connector	Terminal	Connector	Terminal	
M19	54	D114	2	Yes
	53		1	

- Check continuity between BCM harness connector and ground.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

Diagnostic Worksheet

INFOID:000000012995979





Dear Customer:

We are concerned about your satisfaction with your vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your vehicle right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service advisor or technician to ensure we confirm the noise you are hearing.

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.


SYSTEM

< SYSTEM DESCRIPTION >

SYSTEM

System Diagram

INFOID:0000000012995827



System Description

INFOID:0000000012995828

FRONT WIPER CONTROL (BASIC)

1. BCM detects the combination switch position by the combination switch reading function.
2. BCM transmits the front wiper request signal to the IPDM E/R using CAN communication.
3. IPDM E/R controls the integrated front wiper relay and front wiper high relay based on the status of the front wiper request signal.
4. IPDM E/R provides power to operate the front wiper motor.

LOW SPEED OPERATION

1. Ignition switch ON.
2. Front wiper switch in LO or MIST position.
3. BCM reads the combination switch position and transmits the front wiper request signal (LO) to IPDM E/R using CAN communication.
4. IPDM E/R turns ON the front wiper relay.

HIGH SPEED OPERATION

1. Ignition switch ON.
2. Front wiper switch in HI.
3. BCM reads the combination switch position and transmits the front wiper request signal (HI) to IPDM E/R using CAN communication.
4. IPDM E/R turns ON the front wiper relay and the front wiper high relay.

INTERMITTENT OPERATION

1. Ignition switch ON.
2. Front wiper switch INT.
3. BCM reads the combination switch position. BCM calculates the delay interval based on the table below and then transmits the front wiper request signal (INT) to IPDM E/R using CAN communication.
4. IPDM E/R turns ON the front wiper relay only once.
5. BCM detects stop position of the front wiper motor based on the front wiper stop position signal received from the IPDM E/R.
6. BCM transmits the front wiper request signal (INT) again after the delay interval.

REMOVAL AND INSTALLATION

BCM (BODY CONTROL MODULE)

Removal and Installation

INFOID:0000000012995105

REMOVAL

CAUTION:

Before replacing BCM, perform "READ CONFIGURATION" to save or print current vehicle specification. Refer to [BCS-40, "CONFIGURATION \(BCM\) : Description"](#).


1. Disconnect the negative battery terminal. Refer to [PG-67, "Removal and Installation \(Battery\)"](#).
2. Remove the glove box assembly. Refer to [IP-25, "Removal and Installation"](#).
3. Release the tabs (A) and remove the BCM (1) from the steering member.

NOTE:

Shown with low tire pressure warning control unit removed for clarity.

⇐: Front

4. Disconnect the harness connectors (B) from the BCM.



INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Perform "CONFIGURATION (BCM)" when replacing BCM. Refer to [BCS-40, "CONFIGURATION \(BCM\) : Description"](#)
- Be sure to perform the system initialization (NATS) when replacing BCM. Refer to [BCS-39, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT \(BCM\) : Description"](#).
- When replacing BCM, if new BCM does not come with keyfobs attached, all existing keyfobs must be re-registered.

BATTERY POWER SUPPLY CONNECTORS

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	-

Connector No.	M78
Connector Name	WIRE TO WIRE
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W	-

Connector No.	E9
Connector Name	FUSIBLE LINK BOX (BATTERY)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	G	-
2	W	-

Connector No.	E10
Connector Name	FUSIBLE LINK BOX (BATTERY)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
3	W	-
4	R	-

Connector No.	E11
Connector Name	WIRE TO WIRE
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W	-

Connector No.	E42
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK








Terminal No.	Color of Wire	Signal Name
1	R	F/L USM
2	G	F/L MAIN

ABMIA6796GB

AUDIO SYSTEM

< ECU DIAGNOSIS INFORMATION >

[BASE AUDIO]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	—	Signal name	Input/ Output	Ignition switch	Operation	
16 (Y)	15 (B)	Steering switch signal B	Input	ON	Press  switch	0 V
					Press  switch	0.7 V
					Press  switch	1.3 V
					Except for above	3.3 V
18 (W)	Ground	Speed signal	Input	ON	When vehicle speed is approx 25 mph (40 km/hr)	 <small>SKIA6649J</small>
19 (R)	Ground	Battery power supply	Input	OFF	—	Battery voltage
25 (SB)	—	M-CAN H (terminated)	—	—	—	—
26 (SB)	—	M-CAN H	—	—	—	—
27 (LG)	—	M-CAN L	—	—	—	—
32 (R)	Ground	Telephone ON	Output	ON	—	—
33 (LG)	—	M-CAN L (terminated)	—	—	—	—
34 (B)	35 (W)	Tel Voice signal	Input	ON	With Bluetooth® transmitting tel-voice signals to the audio unit	 <small>SKIB3609E</small>
36	—	Shield	—	—	—	—
37 (B)	Ground	Antenna amp. ON	Output	ON	—	Battery voltage
38 (B)	Ground	Antenna signal	Input	ON	—	5.0 V