


## HOW TO USE THIS MANUAL

- The captions **WARNING** and **CAUTION** warn you of steps that must be followed to prevent personal injury and/or damage to some part of the vehicle.  
**WARNING** indicates the possibility of personal injury if instructions are not followed.  
**CAUTION** indicates the possibility of component damage if instructions are not followed.  
**BOLD TYPED STATEMENTS** except **WARNING** and **CAUTION** give you helpful information.
- **ALPHABETICAL INDEX** is provided at the end of this manual so that you can rapidly find the item and page you are searching for.
- **A QUICK REFERENCE INDEX**, a black tab (e.g. **BR**) is provided on the first page. You can quickly find the first page of each section by matching it to the section's black tab.
- **THE CONTENTS** are listed on the first page of each section.
- **THE TITLE** is indicated on the upper portion of each page and shows the part or system.
- **THE PAGE NUMBER** of each section consists of two letters which designate the particular section and a number (e.g. "BR-5").
- **THE LARGE ILLUSTRATIONS** are exploded views (See below.) and contain tightening torques, lubrication points, section number of the **PARTS CATALOG** (e.g. SEC. 440) and other information necessary to perform repairs.  
The illustrations should be used in reference to service matters only. When ordering parts, refer to the appropriate **PARTS CATALOG**.



- **THE SMALL ILLUSTRATIONS** show the important steps such as inspection, use of special tools, knacks of work and hidden or tricky steps which are not shown in the previous large illustrations. Assembly, inspection and adjustment procedures for the complicated units such as the automatic transaxle or transmission, etc. are presented in a step-by-step format where necessary.
- The **UNITS** given in this manual are primarily expressed as the SI UNIT (International System of Unit), and alternatively expressed in the metric system and in the yard/pound system.

**"Example"**

**Tightening torque:**

**59 - 78 N•m (6.0 - 8.0 kg-m, 43 - 58 ft-lb)**

- **TROUBLE DIAGNOSES** are included in sections dealing with complicated components.

## PERIODIC MAINTENANCE (FOR EUROPE)

*Maintenance Schedule for Diesel Engines (Annual Mileage < 30,000 km/year) (Cont'd)*

### CHASSIS AND BODY MAINTENANCE

=NJMA0043S0202

Abbreviations: R = Replace I = Inspect: Correct or replace if necessary

MAINTENANCE OPERATION		MAINTENANCE INTERVAL						Reference pages	
		km x 1,000 (miles x 1,000) Months	20 (12) 12	40 (24) 24	60 (36) 36	80 (48) 48	100 (60) 60		120 (72) 72
<b>Underhood and under vehicle</b>									
Headlamp aiming			I	I	I	I	I	I	EL-65
Wheel alignment (if necessary, balance & rotate wheels)			I	I	I	I	I	I	SU-14 SU-7
Brake pads, rotors & other brake components★			I	I	I	I	I	I	BR-27 BR-28
Foot brake, parking brake & clutch (for free play, stroke & operation)			I	I	I	I	I	I	BR-12 BR-48 CL-9
Brake booster vacuum hoses, connections, check valve				I		I		I	BR-21
Brake & clutch, systems and fluid (for level and leaks)			I	I	I	I	I	I	BR-8
Brake fluid★				R		R		R	BR-8
Power steering fluid and lines (for level and leaks)			I	I	I	I	I	I	ST-7
Supplemental air bag systems	See NOTE (1)								RS-25
Ventilation air filter★			R	R	R	R	R	R	HA-96
Manual transaxle gear oil (check for leakage. Use genuine NISSAN XZ gear oil or exact equivalent)			I	I	I	I	I	I	MT-14 MT-15
Steering gear & linkage, axle & suspension parts, drive shafts, exhaust system★				I		I		I	ST-7 SU-6 SU-18 FE-32
Body corrosion	See NOTE (3)								BT-6

**NOTE:**

(1) Inspect after 10 years, then every 2 years.

(2) Check expiration date of the tyre sealant bottle. Replace if necessary.

(3) Inspect once per year.

★ Maintenance items with “★” should be performed more frequently according to “Maintenance Under Severe Driving Conditions”.

## NVH Troubleshooting — Engine Noise

NJEM0005S01


Use the chart below to help you find the cause of the symptom.

1. Locate the area where noise occurs.
2. Confirm the type of noise.
3. Specify the operating condition of engine.
4. Check specified noise source.





If necessary, repair or replace these parts.

Location of noise	Type of noise	Operating condition of engine						Source of noise	Check item	Reference page
		Before warm-up	After warm-up	When starting	When idling	When racing	While driving			
Top of Engine Rocket Cover Cylinder Head	Ticking or click	C	A	—	A	B	—	Tappet noise	<ul style="list-style-type: none"> <li>● Valve clearance</li> </ul>	EM-44
	Rattle	C	A	—	A	B	C	Camshaft bearing noise	<ul style="list-style-type: none"> <li>● Camshaft journal clearance</li> <li>● Camshaft runout</li> </ul>	EM-38
Crankshaft Pulley Cylinder block (Side of Engine) Oil pan	Slap or knock	—	A	—	B	B	—	Piston pin noise	<ul style="list-style-type: none"> <li>● Piston and piston pin clearance</li> <li>● Connecting rod bushing clearance</li> </ul>	EM-56, 61
	Slap or rap	A	—	—	B	B	A	Piston slap noise	<ul style="list-style-type: none"> <li>● Piston-to-bore clearance</li> <li>● Piston ring side clearance</li> <li>● Piston ring end gap</li> <li>● Connecting rod bend and torsion</li> </ul>	EM-56, 57, 58
	Knock	A	B	C	B	B	B	Connecting rod-bearing noise	<ul style="list-style-type: none"> <li>● Connecting rod bearing clearance (Big end)</li> <li>● Connecting rod bushing clearance (Small end)</li> </ul>	EM-60, 61
	Knock	A	B	—	A	B	C	Main bearing noise	<ul style="list-style-type: none"> <li>● Main bearing oil clearance</li> <li>● Crankshaft runout</li> </ul>	EM-59
Front of Engine Timing Chain Cover	Tapping or ticking	A	A	—	B	B	B	Timing chain and chain tensioner noise	<ul style="list-style-type: none"> <li>● Timing chain cracks and wear</li> <li>● Timing chain tensioner operation</li> </ul>	EM-27
Front of Engine	Squeak or fizzing	A	B	—	B	—	C	Other drive belts (sticking or slipping)	<ul style="list-style-type: none"> <li>● Drive belts deflection</li> </ul>	EM-16
	Creaking	A	B	A	B	A	B	Other drive belts (slipping)	<ul style="list-style-type: none"> <li>● Idler pulley bearing operation</li> </ul>	
	Squall or creak	A	B	—	B	A	B	Water pump noise	<ul style="list-style-type: none"> <li>● Water pump operation</li> </ul>	LC-14

A: Closely related B: Related C: Sometimes related —: Not related



SEM937F



**Engine Fuel & Emission Control System**


=NJE0004

- Always use a 12 volt battery as power source.
- Do not attempt to disconnect battery cables while engine is running.
- Before connecting or disconnecting the ECM harness connector, turn ignition switch OFF and disconnect negative battery terminal. Failure to do so may damage the ECM because battery voltage is applied to ECM even if ignition switch is turned off.
- Do not disassemble ECM.
- If a battery terminal is disconnected, the memory will return to the ECM value. The ECM will now start to self-control at its initial value. Engine operation can vary slightly when the terminal is disconnected. However, this is not an indication of a problem. Do not replace parts because of a slight variation.
- When connecting or disconnecting ECM harness connector, use lever as shown. When connecting, fasten connector securely with lever moved until it stops.
- When connecting or disconnecting pin connectors into or from ECM, take care not to damage pin terminals (bend or break). Make sure that there are not any bends or breaks on ECM pin terminals when connecting pin connectors.
- Securely connect ECM harness connectors. A Poor connection can cause an extremely high (surge) voltage to develop in coil and condenser, thus resulting in damage to ICs.
- Keep ECM harness at least 10 cm (4 in) away from adjacent harness, to prevent an ECM system malfunctions due to receiving external noise, degraded operation of ICs, etc.
- Keep ECM parts and harness dry.

## Engine Control Component Parts Location

NJEC0009

For more details of ECM location, refer to "ELECTRICAL UNIT LOCATION" in EL section (EL-517).




\*: where fitted


View with engine cover removed

## TROUBLE DIAGNOSIS — BASIC INSPECTION

QG

Basic Inspection/Sedan (Cont'd)

6	<b>CHECK VACUUM HOSE</b>	
<p>1. Stop engine. 2. Remove the vacuum hose. 3. Check the vacuum hose for splits, kinks and clogging.</p> <div style="text-align: center;">  <p style="margin-left: 100px;">Split</p> <p style="margin-left: 100px;">Clogging</p> <p style="margin-left: 100px;">Improper connection</p> </div> <p style="text-align: right;">SEF109L</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	1. Clean vacuum port by blowing air. 2. GO TO 4.
NG	▶	1. Replace vacuum hose. 2. GO TO 4.



7	<b>CHECK THROTTLE DRUM OPERATION</b>	
<p>Confirm that throttle drum moves to contact the stopper.</p> <div style="text-align: center;">  <p style="margin-left: 100px;">Throttle drum stopper (Never adjust.)</p> <p style="margin-left: 100px;">Throttle wire</p> <p style="margin-left: 100px;">Throttle drum</p> </div> <p style="text-align: right;">SEF850Y</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 10.
NG	▶	GO TO 8.

8	<b>CHECK ACCELERATOR WIRE INSTALLATION</b>	
<p>1. Stop engine. 2. Check accelerator wire for slack.</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 9.
NG	▶	1. Adjust accelerator wire. Refer to FE-3, "Adjusting Accelerator Wire". 2. GO TO 7.

# DTC P0133 HEATED OXYGEN SENSOR 1 (FRONT) (RESPONSE MONITORING)

QG

Diagnostic Procedure (Cont'd)

<b>5</b>	<b>CLEAR THE SELF-LEARNING DATA</b>													
<p> <b>With CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Start engine and warm it up to normal operating temperature.</li> <li>2. Select "SELF-LEARN CONTROL" in "WORK SUPPORT" mode with CONSULT-II.</li> <li>3. Clear the self-learning control coefficient by touching "START".</li> </ol>														
<table border="1" style="margin: auto; border-collapse: collapse;"> <tr> <td colspan="3" style="padding: 2px;">WORK SUPPORT</td> </tr> <tr> <td style="padding: 2px;">SELF-LEARNING CONT</td> <td style="padding: 2px;"></td> <td style="padding: 2px;">B1 100%</td> </tr> <tr> <td colspan="3" style="height: 100px;"></td> </tr> <tr> <td colspan="3" style="text-align: center; padding: 2px;">CLEAR</td> </tr> </table>			WORK SUPPORT			SELF-LEARNING CONT		B1 100%				CLEAR		
WORK SUPPORT														
SELF-LEARNING CONT		B1 100%												
CLEAR														
<p>4. Run engine for at least 10 minutes at idle speed.</p> <p style="text-align: right;">SEF215Z</p> <p><b>Is the 1st trip DTC P0171 or P0172 detected? Is it difficult to start engine?</b></p>														
<p> <b>Without CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Start engine and warm it up to normal operating temperature.</li> <li>2. Turn ignition switch "OFF".</li> <li>3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.</li> <li>4. Stop engine and reconnect mass air flow sensor harness connector.</li> <li>5. Make sure 1st trip DTC P0100 is displayed.</li> <li>6. Erase the 1st trip DTC memory. Refer to "How to Erase Emission-related Diagnostic Information", EC-70.</li> <li>7. Make sure DTC P0000 is displayed.</li> <li>8. Run engine for at least 10 minutes at idle speed.</li> </ol> <p><b>Is the 1st trip DTC 0171 or 0172 detected? Is it difficult to start engine?</b></p> <p style="text-align: center;"><b>Yes or No</b></p>														
Yes	▶	Perform trouble diagnosis for DTC P0171, P0172. Refer to EC-297, 305.												
No	▶	GO TO 6.												

<b>6</b>	<b>CHECK INPUT SIGNAL CIRCUIT</b>	
<ol style="list-style-type: none"> <li>1. Disconnect heated oxygen sensor 1 (front) harness connector and ECM harness connector.</li> <li>2. Check harness continuity between ECM terminal 62 and heated oxygen sensor 1 (front) harness connector terminal 2. Refer to wiring diagram. <b>Continuity should exist.</b></li> <li>3. Check harness continuity between ECM terminal 62 (or terminal 2) and ground. <b>Continuity should not exist.</b></li> <li>4. Also check harness for short to power.</li> </ol> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 7.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.


<b>7</b>	<b>CHECK HEATED OXYGEN SENSOR 1 HEATER (FRONT)</b>	
<p>Refer to "Component Inspection", EC-257.</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 8.
NG	▶	Replace heated oxygen sensor 1 (front).



# CRANKSHAFT POSITION SENSOR (POS)

QG

## Component Description



## Component Description

NJEC1741

The crankshaft position sensor (POS) is located on the right-rear wall of the cylinder block in relation to the signal plate at the rear end of the crankshaft.


The sensor consists of a permanent magnet, and hall IC.

When the engine is running, the high and low parts of the teeth cause the gap with the sensor to change.

The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.

The ECM receives the voltage signal and detects the fluctuation of the engine revolution.



## ECM Terminals and Reference Value

NJEC1742

Specification data are reference values and are measured between each terminal and ground.

### CAUTION:



Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.



TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (AC Voltage)
85	R	Crankshaft position sensor (POS)	[Engine is running] <ul style="list-style-type: none"> <li>• Warm-up condition</li> <li>• Idle speed</li> </ul>	3 - 4V <p>SEF979W</p>
			[Engine is running] <ul style="list-style-type: none"> <li>• Engine speed is 2,000 rpm</li> </ul>	3 - 4V <p>SEF980W</p>



# DTC P1217 OVER HEAT


**YD**

Diagnostic Procedure (Cont'd)


<b>6</b>	<b>CHECK COOLING FAN RELAYS-2 AND -4</b>											
<p>Check continuity between cooling fan relay-2, -3 terminals 3 and 4, 3 and 5 under the following conditions.</p>												
<div style="display: flex; align-items: flex-start;"> <div style="flex: 1;">  </div> <div style="flex: 1;">  </div> <div style="flex: 2;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th rowspan="2" style="text-align: center;">Conditions</th> <th colspan="2" style="text-align: center;">Continuity</th> </tr> <tr> <th style="text-align: center;">terminals 3 and 4</th> <th style="text-align: center;">terminals 3 and 5</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">12V direct current supply between terminals 1 and 2</td> <td style="text-align: center;">No</td> <td style="text-align: center;">Yes</td> </tr> <tr> <td style="text-align: center;">No current supply</td> <td style="text-align: center;">Yes</td> <td style="text-align: center;">No</td> </tr> </tbody> </table> </div> </div>		Conditions	Continuity		terminals 3 and 4	terminals 3 and 5	12V direct current supply between terminals 1 and 2	No	Yes	No current supply	Yes	No
Conditions	Continuity											
	terminals 3 and 4	terminals 3 and 5										
12V direct current supply between terminals 1 and 2	No	Yes										
No current supply	Yes	No										
SEF900Y												
<b>OK or NG</b>												
OK	▶ GO TO 7.											
NG	▶ Replace cooling fan relays.											

<b>7</b>	<b>CHECK COOLING FAN RELAY-3</b>						
<p>Check continuity between cooling fan relay-3 terminals 3 and 5 under the following conditions.</p>							
<div style="display: flex; align-items: flex-start;"> <div style="flex: 1;">  </div> <div style="flex: 1;">  </div> <div style="flex: 2;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Conditions</th> <th style="text-align: center;">Continuity</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">12V direct current supply between terminals 1 and 2</td> <td style="text-align: center;">Yes</td> </tr> <tr> <td style="text-align: center;">No current supply</td> <td style="text-align: center;">No</td> </tr> </tbody> </table> </div> </div>		Conditions	Continuity	12V direct current supply between terminals 1 and 2	Yes	No current supply	No
Conditions	Continuity						
12V direct current supply between terminals 1 and 2	Yes						
No current supply	No						
SEF901Y							
<b>OK or NG</b>							
OK	▶ GO TO 8.						
NG	▶ Replace cooling fan relay.						


<b>8</b>	<b>CHECK COOLING FAN MOTORS</b>
<p>Supply battery voltage between the following terminals and check operation.</p>	
<div style="display: flex; align-items: center;"> <div style="flex: 1;">  </div> <div style="flex: 1;"> <p>Cooling fan motor-1 harness connector</p> </div> <div style="flex: 1;">  </div> </div>	
SEF902Y	
<b>OK or NG</b>	
OK	▶ GO TO 9.
NG	▶ Replace cooling fan motors.



14. Install 5th gear bushing with its flange surface facing the 4th main gear side.




15. Install 5th needle bearing, 5th main gear, and 5th gear baulk ring onto mainshaft.




16. Being careful of the following points, install spread spring, shifting insert, and 5th & reverse synchronizer hub onto 5th & reverse coupling sleeve.

- Pay attention to the shape of spread spring and shifting insert for correct assembly. Do not install spread spring hook onto the same shifting insert.



- Install synchronizer hub with its three grooves facing the front side (5th main gear side).

**CAUTION:**  
Do not reuse 5th & reverse synchronizer hub.



- Install 5th & reverse coupling sleeve with its chamfered surface facing the reverse main gear side.

# SHIFT SOLENOID VALVE B



EXCEPT FOR EURO-OBD

Wiring Diagram — AT — SSV/B

## Wiring Diagram — AT — SSV/B

NJAT0211

### AT-SSV/B-01




HAT080

# DTC BATT/FLUID TEMP SEN (A/T FLUID TEMP SENSOR CIRCUIT AND TCM POWER SOURCE)


**EURO-OBD**

*Description*



## Description

The A/T fluid temperature sensor detects the A/T fluid temperature and sends a signal to the TCM. NJAT0319



## CONSULT-II REFERENCE VALUE IN DATA MONITOR MODE

Remarks: Specification data are reference values. NJAT0319S01

Monitor item	Condition	Specification	
A/T fluid temperature sensor	Cold [20°C (68°F)]	Approximately 1.5V	Approximately 2.5 kΩ
	↓ Hot [80°C (176°F)]	↓ Approximately 0.5V	↓ Approximately 0.3 kΩ

## TCM TERMINALS AND REFERENCE VALUE



Remarks: Specification data are reference values. NJAT0319S02

Terminal No.	Wire color	Item	Condition	Judgement standard	
10	BR/R	Power source		When turning ignition switch to "ON".	Battery voltage
				When turning ignition switch to "OFF".	1V or less
19	BR/R	Power source	Same as No. 10		
28	R/B	Power source (Memory back-up)		When turning ignition switch to "OFF".	Battery voltage
			or 	When turning ignition switch to "ON".	Battery voltage
42	B	Ground (A/T fluid temperature sensor)	—		
47	BR	A/T fluid temperature sensor		When ATF temperature is 20°C (68°F).	Approximately 1.5V
				When ATF temperature is 80°C (176°F).	Approximately 0.5V

# TROUBLE DIAGNOSES FOR SYMPTOMS

Wiring Diagram — AT — NONDTC/EURO-OB D (Cont'd)

## AT-NONDTC-06




REFER TO THE FOLLOWING.


- (M1), (M2) - FUSE BLOCK-JUNCTION BOX (J/B)
- (F56) - ELECTRICAL UNITS

# BATTERY

## How to Handle Battery (Cont'd)



- Remove the cell plug using a suitable tool.
- Add distilled water up to the MAX level.




## Sulphation

NJSC0003S0201

A battery will be completely discharged if it is left unattended for a long time and the specific gravity will become less than 1.100. This may result in sulphation on the cell plates.

To determine if a battery has been "sulphated", note its voltage and current when charging it. As shown in the figure, less current and higher voltage are observed in the initial stage of charging sulphated batteries.

A sulphated battery may sometimes be brought back into service by means of a long, slow charge, 12 hours or more, followed by a battery capacity test.



## SPECIFIC GRAVITY CHECK

NJSC0003S03

1. Read hydrometer and thermometer indications at eye level.

2. Convert into specific gravity at 20°C (68°F).

Example:

- When electrolyte temperature is 35°C (95°F) and specific gravity of electrolyte is 1.230, converted specific gravity at 20°C (68°F) is 1.240.
- When electrolyte temperature is 0°C (32°F) and specific gravity of electrolyte is 1.210, converted specific gravity at 20°C (68°F) is 1.196.