

HOW TO USE THIS MANUAL

- **ALPHABETICAL INDEX** is provided at the end of this manual so that you can rapidly find the item and page you are searching for.
- **A QUICK REFERENCE INDEX**, a black tab (e.g. **BR**) is provided on the first page. You can quickly find the first page of each section by matching it to the section's black tab.
- **THE CONTENTS** are listed on the first page of each section.
- **THE TITLE** is indicated on the upper portion of each page and shows the part or system.
- **THE PAGE NUMBER** of each section consists of two letters which designate the particular section and a number (e.g. "BR-5").
- **THE LARGE ILLUSTRATIONS** are exploded views (See below.) and contain tightening torques, lubrication points, section number of the **PARTS CATALOG** (e.g. SEC. 440) and other information necessary to perform repairs.
The illustrations should be used in reference to service matters only. When ordering parts, refer to the appropriate **PARTS CATALOG**.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS


BT

HA

SC

EL

IDX



- **THE SMALL ILLUSTRATIONS** show the important steps such as inspection, use of special tools, knacks of work and hidden or tricky steps which are not shown in the previous large illustrations. Assembly, inspection and adjustment procedures for the complicated units such as the automatic transaxle or transmission, etc. are presented in a step-by-step format where necessary.
- The **UNITS** given in this manual are primarily expressed as the SI UNIT (International System of Unit), and alternatively expressed in the metric system and in the yard/pound system.

"Example"

Tightening torque:
59 - 78 N·m (6.0 - 8.0 kg·m, 43 - 58 ft·lb)

- **TROUBLE DIAGNOSES** are included in sections dealing with complicated components.
- **SERVICE DATA AND SPECIFICATIONS** are contained at the end of each section for quick reference of data.
- The following **SYMBOLS AND ABBREVIATIONS** are used:


HOW TO READ WIRING DIAGRAMS

Description (Cont'd)

REFERENCE AREA

-NIG10003S0207

The Reference Area of the wiring diagram contains references to additional electrical reference pages at the end of the manual. If connector numbers and titles are shown in the Reference Area of the wiring diagram, these connector symbols are not shown in the Connector Area.



Super multiple junction (SMJ)

In a wiring diagram, the SMJ connectors include a letter of the alphabet in the terminal number.

SMJ connector numbers are shown in the Reference Area of the wiring diagram. SMJ terminal arrangement can be found on the electrical reference pages at the end of the manual. For terminal arrangement of these connectors, refer to the "SUPER MULTIPLE JUNCTION (SMJ)" electrical reference page at the end of the

DTC P1130 SWIRL CONTROL VALVE CONTROL SOLENOID VALVE

QG18DE (EXC CALIF CA)

Diagnostic Procedure (Cont'd)

9 CHECK SWIRL CONTROL VALVE CONTROL SOLENOID VALVE

With CONSULT-II

1. Reconnect the disconnected harness connectors.
2. Start engine and let it idle.
3. Remove vacuum hose connected to swirl control valve actuator.
4. Select "SWIRL CONT SOL/V" in "ACTIVE TEST" mode with CONSULT-II.
5. Touch "ON" and "OFF" on CONSULT-II screen.
6. Check vacuum existence and operation delay time under the following conditions.

PCM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.

CAUTION:


DO NOT USE PCM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE PCM'S TRANSISTOR. USE A GROUND OTHER THAN PCM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
59	P/L	SWIRL CONTROL VALVE CONTROL VACUUM CHECK SWITCH	ENGINE RUNNING AT IDLE SPEED WITH ENGINE COOLANT TEMPERATURE BETWEEN 15°C (59°F) AND 50°C (122°F).	APPROX. 5V
			ENGINE RUNNING AT IDLE SPEED WITH ENGINE COOLANT TEMPERATURE ABOVE 55°C (131°F).	0 - 1V

SEF764Y

Without CONSULT-II

1. Reconnect PCM harness connector.
2. Remove vacuum hose connected to swirl control valve actuator.
3. Start engine and let it idle.
4. Apply 12V of direct current between swirl control valve control solenoid valve terminals 1 and 2.
5. Check vacuum existence and operation delay time under the following conditions.




SEF763Y

OK or NG


OK	▶	GO TO 10.
NG	▶	Replace intake manifold collector assembly.

ASSEMBLY


Transaxle Case (Cont'd)




- a. Using block gauge, scale, and dial gauge, measure dimension "O1" between transaxle case end face and mounting face of adjusting shim.




- b. Using block gauge, scale, and dial gauge as shown in the figure, measure dimension "O2" between clutch housing case end face and end face of input shaft rear bearing.
7. Install selected input shaft rear bearing adjusting shim onto input shaft.



8. Install oil gutter into transaxle case.



9. Clean mating surfaces of clutch housing and transaxle case. Check for cracks and damage. Then, apply Three Bond TB1215, Loctite Part No. 51813 or equivalent.



10. Install transaxle case onto clutch housing, and tighten mounting bolts with specified torque.

Tightening torque:

Refer to "Case Components", [MT-17](#).

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

TRUNK LID KEY CYLINDER SWITCH CHECK

=NIEL0123S08

1 CHECK TRUNK LID KEY CYLINDER SWITCH INPUT SIGNAL (UNLOCK SIGNAL)

With CONSULT-II
 Check trunk lid key cylinder switch ("TRUNK KEY SW") in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
TRUNK KEY SW	OFF

When key in key cylinder is at Neutral position:
TRUNK KEY SW OFF

When key in key cylinder is at Unlock position:
TRUNK KEY SW ON

SEL358W

Without CONSULT-II
 Check voltage between smart entrance control unit harness connector terminal 42 and ground.

Continuity exists

Smart entrance control unit connector (M39)

Terminals		Key position	Voltage [V]
(+)	(-)		
42	Ground	Neutral	Approx. 5
		Unlock	0

Refer to wiring diagram in [EL-266](#).

LEL536

OK or NG

OK	▶	Trunk lid key cylinder switch is OK.
NG	▶	GO TO 2.

2 CHECK TRUNK LID KEY CYLINDER SWITCH

- Disconnect trunk lid key cylinder switch connector.
- Check continuity between trunk lid key cylinder switch terminals.

Trunk lid key cylinder switch (B43)

Key position	Continuity
Neutral	No
Unlock	Yes

LEL537


OK or NG

OK	▶	<p>Check the following.</p> <ul style="list-style-type: none"> Trunk lid key cylinder switch ground circuit Harness for open or short between smart entrance control unit and trunk lid key cylinder switch
NG	▶	Replace trunk lid key cylinder switch.

DTC P1217 ENGINE OVER TEMPERATURE (OVERHEAT)


QG18DE (EXC CALIF CA)

Diagnostic Procedure (Cont'd)

7	CHECK RADIATOR CAP		
Apply pressure to cap with a tester.			
			
<p>Radiator cap relief pressure: 59 - 98 kPa (0.6 - 1.0 kg/cm², 9 - 14 psi)</p>			
OK or NG			
OK		▶	GO TO 8.
NG		▶	Replace radiator cap.

GI
MA
EM
LC
EC

FE
CL

8	CHECK THERMOSTAT		
1. Check valve seating condition at normal room temperatures. It should seat tightly. 2. Check valve opening temperature and valve lift.			
			
<p>Valve opening temperature: 76.5°C (170°F) [standard] Valve lift: More than 9 mm/90°C (0.35 in/194°F)</p>			
3. Check if valve is closed at 5°C (9°F) below valve opening temperature. For details, refer to LC-13 , "Thermostat".			
OK or NG			
OK		▶	GO TO 9.
NG		▶	Replace thermostat

MT
AT
AX
SU
BR
ST
RS
BT
HA

SC

9	CHECK ENGINE COOLANT TEMPERATURE SENSOR		
Refer to "COMPONENT INSPECTION", EC-212 .			
OK or NG			
OK		▶	GO TO 10.
NG		▶	Replace engine coolant temperature sensor.

EL
IDX

DTC P1464 FUEL LEVEL SENSOR CIRCUIT (GROUND SIGNAL)



QG18DE (CALIF CA)

Wiring Diagram

Wiring Diagram

NIEC1660

EC-FLS3-01



WEC145A

ECM TERMINALS AND REFERENCE VALUE MEASURED BETWEEN EACH TERMINAL AND GROUND.

CAUTION:



DO NOT USE ECM GROUND TERMINALS WHEN MEASURING INPUT/OUTPUT VOLTAGE. DOING SO MAY RESULT IN DAMAGE TO THE ECM'S TRANSISTOR. USE A GROUND OTHER THAN ECM TERMINALS, SUCH AS THE GROUND.

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
80	G	FUEL LEVEL SENSOR	IGN ON	APPROX. 0 - 4.8V
79	B/W	FUEL LEVEL SENSOR GROUND	ENGINE RUNNING AT IDLE SPEED	APPROX. 0V


POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-03



REFER TO THE FOLLOWING.



13. CHECK MASS AIR FLOW SENSOR

 **With CONSULT-II**

Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT-II.

at idling: 1.4 - 4.0 g-m/sec

at 2,500 rpm: 5.0 - 10.0 g-m/sec

 **With GST**

Check mass air flow sensor signal in MODE 1 with GST.

at idling: 1.4 - 4.0 g-m/sec

at 2,500 rpm: 5.0 - 10.0 g-m/sec

OK or NG

OK >> GO TO 14.

NG >> Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to [EC-172](#) .

14. CHECK SYMPTOM MATRIX CHART

Check items on the rough idle symptom in [EC-101, "Symptom Matrix Chart"](#) .

OK or NG

OK >> GO TO 15.

NG >> Repair or replace.

15. ERASE THE 1ST TRIP DTC

Some tests may cause a 1st trip DTC to be set.

Erase the 1st trip DTC from the ECM memory after performing the tests. Refer to [EC-73, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#) .

>> GO TO 16.


16. CHECK INTERMITTENT INCIDENT

Perform [EC-147, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

A
EC
C
D
E
F
G
H
I
J
K
L
M

5. Make sure that "COOLAN TEMP/S" indicates more than 70°C (158°F).
6. Select "HO2S2 (B1) P1147" of "HO2S2" in "DTC WORK SUPPORT" mode with CONSULT-II.
7. Start engine and following the instruction of CONSULT-II.



8. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS".
 If "NG" is displayed, go to [EC-1655, "Diagnostic Procedure"](#) .
 If "CAN NOT BE DIAGNOSED" is displayed, perform the following.
 - a. Stop engine and cool down until "COOLAN TEMP/S" indicates less than 70°C (158°F).
 - b. Turn ignition switch "ON".
 - c. Select "DATA MONITOR" mode with CONSULT-II.
 - d. Start engine.
 - e. Return to step 6 again when the "COOLAN TEMP/S" reaches to 70°C (158°F).

Overall Function Check


UBS00218

Use this procedure to check the overall function of the heated oxygen sensor 2 circuit. During this check, a 1st trip DTC might not be confirmed.

CAUTION:
 Always drive vehicle at a safe speed.

WITH GST

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Set voltmeter probes between ECM terminal 95 [HO2S2 (B1) signal] and engine ground.
4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
 (Depress and release accelerator pedal as soon as possible.)
The voltage should be above 0.63V at least once during this procedure.
If the voltage can be confirmed in step 4, step 5 is not necessary.
5. Keep vehicle idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in "D" position with "OD" OFF (A/T), 3rd gear position (M/T).
The voltage should be above 0.63V at least once during this procedure.
6. If NG, go to [EC-1655, "Diagnostic Procedure"](#) .



QUICK REFERENCE CHART: SENTRA (EQUIPPED WITH 2.5L, QR ENGINE)

2004

Wheel turning angle Full turn*2	Inside	Minimum	29° (29.0°)
		Nominal	32° (32.0°)
		Maximum	33° (33.0°)
	Outside	Nominal	27° (27.0°)

*1: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.

*2: On power steering models, wheel turning force (at circumference of steering wheel) of 98 to 147 N (10 to 15 kg, 22 to 33 lb) with engine idle.

Rear Wheel Alignment (Unladen*)

ELS000LJ

Unit: degree minute (decimal degree)

Camber		Minimum	-1°45' (-1.75°)
		Nominal	-1°00' (-1.00°)
		Maximum	-0°15' (-0.25°)
Total toe-in	Distance	Minimum	-3 mm (-0.12 in)
		Nominal	1 mm (0.04 in)
		Maximum	5 mm (0.20 in)
	Angle (left plus right)	Minimum	-16' (-0.27°)
		Nominal	5'30" (0.09°)
		Maximum	26' (0.43°)

*: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.

Brake

ELS000LK

Unit: mm (in)

Front brake	Brake model	CL25VB	OPB27VA
	Cylinder bore diameter	57.2 (2.252)	38 (1.50) x 2 + 44 (1.73) x 2
	Pad length x width x thickness	125.6 x 46.0 x 11.0 (4.94 x 1.811 x 0.433)	117.1 x 53.3 x 9.3 (4.61 x 2.098 x 0.366)
	Rotor outer diameter x thickness	280 x 22 (11.02 x 0.87)	324 x 30.0 (12.76 x 1.181)
Rear brake	Brake model	CL9HC	
	Cylinder bore diameter/caliper bore diameter	33.96 (1 11/32)	
	Lining length x width x thickness	89.1 x 39.5 x 10 (3.508 x 1.555 x 0.39)	
	Drum inner diameter/Disc diameter x thickness	258 x 9 (10.16 x 0.35)	
Master cylinder	Cylinder bore diameter	23.81 (15/16)	
Control valve	Valve model	Dual proportioning valve	
	Split point	2,942 kPa (30 kg/cm ² , 427 psi)] x 0.2 reducing ratio	
Brake booster	Booster model	M215T	
	Diaphragm diameter	Primary: 230 (9.06) Secondary: 205 (8.07)	
Brake fluid	Recommended brake fluid	Genuine NISSAN Super Heavy Duty Brake Fluid or equivalent DOT 3 (US FMVSS No. 116)	

Disc Brake - Repair Limits

Unit: mm (in)

Brake model	CL25VB (Front)	OPB27VA (Front)	CL9HC (Rear)
Pad wear limit Minimum thickness	2.0 (0.079)	2.0 (0.079)	2.0 (0.079)
Rotor repair limit Minimum thickness	20 (0.79)	28.4 (1.118)	8.0 (0.31)



REFRIGERANT PRESSURE SENSOR

[QR25DE]

Wiring Diagram

UBS002MP

EC-RP/SEN-01



Refer to the following.
 (F57) - ELECTRICAL UNITS

REMOTE KEYLESS ENTRY SYSTEM

KEYFOB BATTERY AND FUNCTION CHECK

1. CHECK KEYFOB BATTERY

Remove battery (refer to [BL-62, "Keyfob Battery Replacement"](#)) and measure voltage across battery positive and negative terminals, (+) and (-).


Voltage [V] : 2.5 - 3.0

NOTE:

Keyfob does not function if battery is not set correctly.

OK or NG

- OK >> GO TO 2.
- NG >> Replace battery.



2. CHECK KEYFOB FUNCTION

With CONSULT-II

Check keyfob function ("LK BUTTON/SIG", "UN BUTTON/SIG", "TRUNK BTN/SIG", "PANIC BTN", "UN BUTTON ON" and "LK/UN BTN ON") in "DATA MONITOR" mode with CONSULT-II. When pushing each button of keyfob, the corresponding monitor item should be turned as follows.

Condition	Monitor item	
Pushing LOCK	LK BUTTON/SIG	ON
Pushing UNLOCK	UN BUTTON/SIG	ON
Pushing TRUNK	TRUNK BTN/SIG	ON
Pushing PANIC	PANIC BTN/SIG	ON
Pushing UNLOCK within 5 seconds after pushing UNLOCK	UN BUTTON ON	ON
Pushing LOCK and UNLOCK at the same time	LK/UN BTN ON	ON

DATA MONITOR	
MONITOR	
LK BUTTON/SIG	ON
UN BUTTON/SIG	ON
TRUNK BTN/SIG	ON
PANIC BTN	ON
UN BUTTON ON	ON
LK/UN BTN ON	ON

OK or NG

- OK >> Keyfob is OK. Further inspection is necessary. Refer to [BL-43, "SYMPTOM CHART"](#) .
- NG >> Replace keyfob. Refer to [BL-59, "ID Code Entry Procedure"](#) .

DTC P1272 A/F SENSOR 1

[QG18DE]

3. Check "A/F SEN1 (B1)" indication.
If the indication is constantly approx. 4.5V, go to [EC-488, "Diagnostic Procedure"](#).
If the indication is not constantly approx. 4.5V, go to next step.
4. Select "A/F SEN1 (B1) P1278/P1279" of "A/F SEN1" in "DTC WORK SUPPORT" mode.
5. Touch "START".

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
A/F SEN1 (B1)	XXX V

SEF581Z

6. When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen.

ENG SPEED	1,000 - 3,200 rpm
Vehicle speed	More than 40 km/h (25 MPH)
B/FUEL SCHDL	1.5 - 9.0 msec
Selector lever	<ul style="list-style-type: none"> ● D position with "OD" ON (A/T) ● 4th position (M/T)

If "TESTING" is not displayed after 20 seconds, retry from step 2.

A/F SEN1 (B1) P1278/P1279	
OUT OF CONDITION	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h

PBIB0756E

7. Following the instructions of CONSULT-II screen, set D position with "OD" OFF (A/T) or 3rd position (M/T) and release accelerator pedal fully.

A/F SEN1 (B1) P1278/P1279	
TESTING	
SELECT 3RD GEAR AND THEN RELEASE ACCELERATOR PEDAL OFF	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h

PBIB0757E

8. Make sure that "TESTING" changes to "COMPLETED".
If "TESTING" changed to "OUT OF CONDITION", retry from step 6.
9. Touch "BACK" and "MODE", then select "SELF-DIAG RESULT" mode.
If P1272 is displayed, go to [EC-488, "Diagnostic Procedure"](#).
If another DTC is displayed, go to the corresponding Diagnostic Procedure.

A/F SEN1 (B1) P1278/P1279	
COMPLETED	

PBIB0758E


Overall Function Check

UBS00BDL


Use this procedure to check the overall function of the A/F sensor 1 circuit. During this check, a 1st trip DTC might not be confirmed.

WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Drive the vehicle at a speed of 80 km/h (50 MPH) for a few minutes in D position with "OD" OFF (A/T) or 3rd position (M/T).



3. Check ignition timing.



UBS00J9P

VIN Registration DESCRIPTION

VIN Registration is an operation to registering VIN in ECM. It must be performed each time ECM is replaced.


NOTE:

Accurate VIN which is registered in ECM may be required for Inspection & Maintenance (I/M).

OPERATION PROCEDURE

Ⓜ With CONSULT-II

1. Check the VIN of the vehicle and note it. Refer to [GI-46, "IDENTIFICATION INFORMATION"](#).
2. Turn ignition switch ON and engine stopped.
3. Select "VIN REGISTRATION" in "WORK SUPPORT" mode.
4. Follow the instruction of CONSULT-II display.



UBS00J9Q

Accelerator Pedal Released Position Learning DESCRIPTION

Accelerator Pedal Released Position Learning is an operation to learn the fully released position of the accelerator pedal by monitoring the accelerator pedal position sensor output signal. It must be performed each time harness connector of accelerator pedal position sensor or ECM is disconnected.

OPERATION PROCEDURE

1. Make sure that accelerator pedal is fully released.
2. Turn ignition switch ON and wait at least 2 seconds.
3. Turn ignition switch OFF and wait at least 10 seconds.
4. Turn ignition switch ON and wait at least 2 seconds.
5. Turn ignition switch OFF and wait at least 10 seconds.