


1-Lifting the Vehicle

Erguendo o veículo

RAISING FROM ONE SIDE




Position the axle stand in the location provided for lifting the vehicle using the jack .

NOTE : to have 4 wheels suspended, repeat the operation on the other side . The bar [1] is an optional special tool for lift the vehicle, but you can lift without it.

2-Towing the Vehicle


Rebocando o veículo

FRONT



Hook up to the towing eye (1).

REAR




Hook up to the towing eye (2).

To tow the vehicle, select the **Neutral (N)** gear and release the brakes

ENGINE


TU1M/L/Z TU1M/L/L3 TU1M+ to 2616141	HDY - HDZ
TU1 TR	H3A
TU2.4	M2A - M4A
TU2J2/L/Z	MFZ
TU3A/K TU3A/N	K1C - K1G K1B - K1D - K1H
TU3S/K TU3S/N	K2A K2B
TU3.2/K - TU3F.2/K TU3.2/W TU3.2 TR/K	K2D K2C K5A
TU3 TR	K3A
TU3JP to 2333357	KFX
TU3M/Z - TU3FM/Z TU3M/L/Z - TU3FM/L/Z	KDY - KDZ KDY
TU3MC/L/Z - TU3FMC/L/Z	KDX
TU3J2/K TU3J2/L/Z	K6B KFZ
TU5JP/L/Z	NFZ
TU5J2/L/Z/K'	NFY - NFW

2ND GENERATION



(3)Engine : Aluminium cylinder block .

ENGINE



Camshaft pulley (1) : 1 da.Nm .

cylinder head		
	TU (not TU5J4)	TU (not TU5J4)
special features	aluminium cylinder block	cast-iron cylinder block
(a) pre-tightening (da.Nm)	2	2
(a) slackening	-	-
(a) tightening (da.Nm)	-	-
(a) 1st angular tightening	240°	120°
(a) 2nd angular tightening	-	120°
(a) 3rd angular tightening	-	-
(a) application of a tightening sequence and/or a special product		

(3) Cylinder head cover to cylinder head (M8) : 1.6 da.Nm .


(3) Cylinder head cover to cylinder head (M6) : 0.7 da.Nm .

(4) Compact coil block (Depending on engine type) : 0.8 da.Nm .

(5) The inlet manifold : 1 da.Nm .

The injection pipe : 0.7 da.Nm .


ENGINE




Remove :

- the clutch mechanism (35)
- the clutch plate (36)
- the flywheel (37)
- the oil gallery plug (38)

ALUMINIUM CYLINDER BLOCK




Remove all of the securing bolts (39) and (40) from the main bearing cap casting .



CYLINDER HEAD

NOTE : the standardisation of the (E) valve guides in relation to the other petrol engines has led to the modification of the dimension for positioning the guide in the cylinder head .


VALVE SEATS



inlet : engines - 1st generation						
	engine type : TU9			engine type : TU1 - TU3 (except TU3J2)		
distance (mm)	nominal	repair 1	repair 2	nominal	repair 1	repair 2
ø A + 0,137 + 0,112	36,01	36,31	36,51	38,01	38,31	38,51
B + 0,1 + 0	6,648	7		6,648	7	
à	120°			120°		

	engine type : TU2.4			engine type : TU2J2 - TU3J2 - TU5		
distance (mm)	nominal	repair 1	repair 2	nominal	repair 1	repair 2
ø A + 0,161 + 0,136	40,51	40,81	41,01	40,51	40,81	41,01
B + 0,1 + 0	6,6	7		6,6	7	
à	90°			90°		

CYLINDER HEAD




ALL MODELS

Unscrew all the adjusting bolts (5) to their limit .

Position the engine so that no rocker is under stress on a cam (or so that the stresses are minimal) .


NOTE : the rocker(s) to be removed must be opposite a cam back .



Remove :


- the stud (6)
- the stop bolt (7)

CYLINDER HEAD



Maximum permissible bow = 0,05 mm .

CHECKING CYLINDER HEAD BOLTS BEFORE RE-USE



Y = Maximum length below head : 176,5 mm .


Replace the oil seal using tool [6] .

Fit the camshaft gear .

Tightening torque 8 da.Nm ; Using the tool [7] .

Check that the camshaft turns freely in its bearings .


FINAL ADJUSTMENTS AND REASSEMBLY THE ENGINE



Oil the pistons .

Fit the ring collar .


Moderately tighten .



Position the piston on the liner to obtain on fitting :

- the alignment of the liner/cylinder block marks
- the direction of the piston arrow on the timing side

TIMING AND ENGINE DRESS (ALTERNATOR, COMPRESSOR, OIL FILTER...)




Slacken the nut (4) retaining the roller tensioner (5) to slacken the belt (6) .

Remove the timing belt (6) .

REFITTING

TU ENGINE

Flywheel and camshaft gear pegged .




Check that the roller tensioner (5) turns freely (no tight spot) .

INSIDE THE GEARBOX

- (6) Sleeve .
- (7) Hub .
- (8) Ball .
- (9) Finger .
- (10) Ball seat .
- (11) Spring .

CONVENTIONAL SYNCHRONISER : 3RD/4TH/5TH




- (12) Sleeve .
- (13) Hub .
- (14) Ball .
- (15) Spring .
- (16) Finger .

DISMANTLING

IMPERATIVE : mark the relative positions of the hub and sleeve if these parts are to be re-used .


Separate the sleeve from the hub in a container to facilitate retrieval of the balls, springs and fingers .

INSIDE THE GEARBOX



Pre-tighten one bearing nut (5) to 0.5 daN.m .


CLUTCH AND GEAR CONTROL



Check that there is a minimum clearance (X) .

If there is not, adjust the bolt (1) .

NOTE : if the clearance (X) is too great this could result in a creaking sound .



Pull the cable at (B) :

- if the cable moves (minimum 5 mm): the clutch cable is adjusted
- if the cable does not move: replace the clutch cable

Check the travel of the clutch cable .


If $Y \geq 24$ mm :

- adjustment correct

If Y : Less than 24 mm :

- replace the clutch cable

STEERING




Disconnect the connectors (10), (11) .

Release the harnesses clamped on the protector (12) .


Unclip the protector (12) at its lower section (a) .

Remove the protector (12) .



Release the steering universal joint by moving aside the safety clip .

STEERING




Fit the distributor valve (7) using the tools [1], [2] .

WARNING : do not use the valve mounting bolts to fit it .

POWER STEERING

Tighten the bolts (6) to 1.5 daN.m .




ALL MODELS

SUSPENSION

68-Rear Antiroll Bar


Barra Anti Torção Traseira

ON THE RIGHT-HAND SIDE



Remove :

- the bolt (1)
- the washer (2)
- the cap (3)



Coat the thread and the end of the bolt [1] with slip product .

Screw the bolt into the lever until it contacts the bar .

Continue screwing to extract the lever .