

144900

4X2 TRANSMISSION

Dimensions in metres:

(A)	0.822
(B)	2.673
(C)	0.820
(D)	4.315
(E)	1.560
(F) (unladen)	1.690
(G)	1.567
(H)	1.822

Vehicle: Parts and consumables for the repair

Consumables for mechanical repair:

DEFINITION	PACKAGING	PART NUMBER
MECHANICAL SEALANTS		
SILICOR sealing paste	85 g tube	77 11 236 470
MASTIXO Joint face seal	100 g tube	77 11 236 172
BEARING SEALING KIT For crankshaft bearing cap side sealing	Kit	77 11 237 896
SILICONE ADHESIVE SEAL Engine and gearbox sealing paste	100 g cartridge	77 11 227 484
TRANSPARENT SEALING MASTIC	45 g tube	77 11 223 369
SILICOJOINT	90 g tube	77 11 236 469
LOCTITE ADHESIVE 597 Sealing paste for PXX gearboxes	Cartridge	77 11 219 705
RESIN ADHESIVE or SEALING RESIN Sealing resin for engine and gearbox covers	25 ml tube	77 11 237 640
EXHAUST MASTIC For exhaust pipe union seals	1.5 kg tin	77 01 421 161
LEAK DETECTOR	400 ml aerosol	77 11 236 176
ADHESIVES		
FRENETANCHE Sealing the threading at low and medium pressure	50 ml bottle	77 11 236 471
HIGH-STRENGTH THREADLOCK For locking bolts	50 ml bottle	77 11 230 112
SEALING RESIN For locking the bearings	50 ml bottle	77 11 236 472
LUBRICANT CLEANERS		
NÉTELEC Avoid bad contacts in electrical circuits	150 ml aerosol	77 11 225 871

FUEL MIXTURE

Air filter: Removal - Refitting

12A

K9K


REMOVAL

I - REMOVAL PREPARATION OPERATION

- ❑ Remove the air filter unit (see 12A, Fuel mixture, Air filter unit: Removal - Refitting, page 12A-6) .


II - OPERATION FOR REMOVAL OF PART CONCERNED

1 - First fitting of air filter unit




- ❑ Remove the 4 bolts (1) from the air filter unit.
- ❑ Pivot the hinged cover (2) of the air filter unit in relation to the air filter unit tank.
- ❑ Move aside the air filter unit cover (2) .

2 - Second fitting of air filter unit



- ❑ Remove the 9 bolts (3) from the air filter unit.
- ❑ Move aside the air filter unit cover (4) .



- ❑ Remove the air filter (5) from the air filter unit cover.

REFITTING

I - REFITTING PREPARATION OPERATION


- ❑ Clean the air filter unit.

JR5

Special tooling required

Emb. 880

Pin extractor tool.



- (1) Big securing clip
- (2) Small securing clip
- (3) Driveshaft gaiter
- (4) Ball hub
- (5) Stub axle bowl
- (6) Ball race
- (7) Driveshaft
- (8) Balls
- (9) Lock ring

IMPORTANT



Wear leaktight gloves (Nitrile type) for this operation.

REMOVAL


I - REMOVAL PREPARATION OPERATION

- ☐ Remove the front driveshaft on the side concerned (see 29A, Driveshafts, Front right-hand drive-shaft: Removal - Refitting, page 29A-4) or (see 29A, Driveshafts, Front left-hand driveshaft: Removal - Refitting, page 29A-1) .

II - REMOVAL OPERATION



- ☐ Cut the big securing clip (1) and the small securing clip (2) using cutting pliers or a metal saw, taking care not to damage the stub axle bowl and the drive-shaft.



143999

1	Main beam headlight bulbs	(see 80B, Headlights, Headlight bulb: Removal - Refitting, page 80B-5)
2	Side light bulb	
3	Direction indicator bulb	
4	Dipped beam headlight bulb	
5	Headlight beam adjustment actuator	(see 80B, Headlights, Remote headlight beam adjustment actuator: Removal - Refitting, page 80B-9)
6	Headlight	(see 80B, Headlights, Headlight: Removal - Refitting, page 80B-2)


REAR LOWER STRUCTURE

Rear floor, rear section: Replacement

41D


1 - Complete replacement

Part in position



2 - Partial replacement along cut A

Part in position



ALP1

No dialogue with the computer

NOTES

Only consult this customer complaint after a complete check with the diagnostic tool.

Try to establish dialogue with a computer on another vehicle to check that **the diagnostic tool** is not faulty. If the tool is not at fault, and dialogue cannot be established with any other computer on the same vehicle, the cause could be a faulty computer interfering on the multiplex network. Check the battery voltage and make the necessary adjustments to obtain a correct voltage (**9.5 V < Battery voltage < 17.5 V**).

Carry out fault finding on the multiplex network using the **diagnostic tool** (see **88B, Multiplexing**).

Check the presence and the condition of the injection fuses in the engine fuse box.
Check the connection of the injection computer connectors, component code **120** and the condition of its connections.
Check the injection computer **earths** (quality, oxidation, earth bolts secure on the battery terminal).
Check that the supply to the computer is correct:
● **NH** or **N** between **earth** and component **120**.
● **AP29** or **AP15** between components **1016** and **120**.

If the connection(s) are faulty and if there is a repair procedure (see **Technical Note 6015A (Renault)** or **Technical Note 9804A (Dacia)**, **Repairing electrical wiring, Wiring: Precautions for repair**), repair the wiring, otherwise replace it.

A

AFTER REPAIR

Carry out a road test followed by a check with the **diagnostic tool**.

DF236 PRESENT OR STORED	<u>SERIOUS INJECTION FAULT WARNING LIGHT CIRCUIT</u> CO: Open circuit CC.0: Short circuit to earth CC.1: Short circuit to + 12 V 1.DEF: Open circuit or short circuit
NOTES	Conditions for applying the fault finding procedure to stored faults: The fault is declared present when the ignition is on or on command AC069 Serious injection fault warning light .
	Special notes: <ul style="list-style-type: none">– CO/CC.1: Level 2 warning light not illuminated.– CC.0: Level 2 warning light constantly illuminated.– Level 1 warning light illuminated if the level 2 warning light is defective.– 1.DEF: for all stored faults.
	Use the Technical Note Wiring Diagrams for H79 .

AFTER REPAIR	Deal with any faults displayed by the diagnostic tool. Clear the computer fault memory. Carry out a road test followed by another check with the diagnostic tool.
---------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------

PETROL INJECTION

Fault finding – Fault Finding Chart

17B

ALP 24	Engine stalls
Check the fuel pump relay by running TEST 1 Petrol supply pump relay check .	
Check the air filter unit.	
Check the inlet manifold air pressure sensor by running TEST 7 Air inlet pressure sensor check .	
Check the air pipes.	
Check the additional fuel circuit solenoid valve by running TEST 5 Checking the additional fuel tank .	
Check the injector rail.	
Check the injectors by running TEST 13 Checking the injectors .	
Check the additional petrol circuit pump by running TEST 12 Additional fuel tank pump check .	
Check the TDC sensor by running TEST 10 TDC sensor check .	
Check the upstream oxygen sensor by running TEST 17 Checking the upstream O2 sensor .	
Check the downstream oxygen sensor by running TEST 18 Checking the downstream O2 sensor .	
Check the camshaft.	
Check the valves.	
Check the timing.	
Check the injection computer.	
Check the injection computer supply relay.	
If the fault is still present, contact the Techline.	

AFTER REPAIR	Carry out a road test, then check with the diagnostic tool .
---------------------	---------------------------------------------------------------------

DF263 CONTINUED

Check for **earth** on the longitudinal accelerometer, component code **1380** between the following connection:

- **44AE** of component **1380**.

Check **the continuity, insulation** and **the absence of interference resistance** of the following connection:

- **44AE** between component **1380** and **118**.

If the connection or connections are faulty and there is a repair procedure (see **Technical Note 6015A, Electrical wiring repair, Wiring: Precautions for repair**), repair the wiring, otherwise replace it.

Check **the continuity, insulation** and **the absence of interference resistance** of the following connection:

- **44AF** between components **1380** and **118**.

If the connection or connections are faulty and there is a repair procedure (see **Technical Note 6015A, Electrical wiring repair, Wiring: Precautions for repair**), repair the wiring, otherwise replace it.

If the fault is still present, contact the Techline.

AFTER REPAIR

Clear the computer memory using command **RZ001 Fault memory**.
Carry out a road test followed by another check with the **diagnostic tool**.

- **Passenger compartment heating resistors (depending on the equipment level):**

The passenger compartment heating resistors (RCH) are electrical heating devices in the air conditioning unit. This system is an additional heating system which operates when the engine is cold (when starting).

- **ACTUATORS**

- **Air distribution flap:**

This flap enables the air flowing into the passenger compartment to be directed.

- **Air mixing flap:**

This flap mixes the air in order to meet the temperature requirements of the occupants.

- **Recirculation flap:**


This flap prevents the entry of exterior air. In this case, the passenger compartment is isolated from the exterior and air is blown in the passenger compartment in a closed circuit.

These three flaps are **controlled by a cable**.

- **OTHERS**

- **Passenger compartment blower unit:**

The passenger compartment fan assembly is controlled by the Resistive Blower Dimmer Module (**MVPR**).



Equipment required:
CLIP diagnostic tool

Access and Safety function configurations in the UCH

Configuration readings available using the **diagnostic tool**:

Configuration reading	Name of configuration	Option	Configuration
LC012	Automatic relocking	WITH OR WITHOUT	SC008 UCH type
LC097	Type of key	ONE BUTTON or TWO BUTTONS	
LC113	Airbag	WITH OR WITHOUT	
LC149	Key locking	WITH OR WITHOUT	
LC165	Seat belt not fastened sensor	ACTIVE or INACTIVE	
LC169	Vehicle locked by RAID* function	YES or NO	
LC170	RAID* function authorisation by diag tool	WITH OR WITHOUT	
LC171	Radiofrequency function	WITH OR WITHOUT	
LC172	Type of central door locking button (CPE)*	1 POSITION or 2 POSITIONS	

* RAID: Renault Anti-Intruder Device.

* CPE: Electric central door locking.

- Check the configurations in the **Read configurations** menu

ALP 3
CONTINUED 1



Check the **condition** and **connection** of the connectors of the **instrument panel**, component code **247** and the **fuel sender**, component code **833** (**Petrol**) or **199** (**Diesel**).

If the connectors are faulty and if there is a repair procedure (see **Technical Note 6015A, Repairing electrical wiring, Wiring: Precautions for repair**), repair the connector, otherwise replace the wiring.

Check the **continuity, insulation and the absence of interference resistance** of the following connections:

- **41A** between components **247** and **833** (**Petrol**) or **199** (**Diesel**),
- **47A** between components **247** and **833** (**Petrol**) or **199** (**Diesel**).

Are the checks correct?

NO → B

YES

Measure the resistance of the sender and the wiring using a multimeter via the connector, on the instrument panel side.

Are the value measured and the value provided by the CLIP tool the same to within $\pm 5 \Omega$?

YES → Contact the Techline.

NO

Replace the instrument panel, component code **247** (see **MR 451, Mechanical, 83A, Instrument panel, Instrument panel: Removal - Refitting**).

Is the fault still present?

NO → The problem disappears.

YES

Contact the Techline.

AFTER REPAIR

Check for correct operation.

ALP 35	The 4X4 warning light remains illuminated Message from: ETC torque distribution computer
--------	---------------------------------------------------------------------------------------------

NOTES	Use the Technical Note Wiring Diagrams for H79.
-------	--------------------------------------------------------

Run fault finding on the ETC front - rear torque distributor (see **26A, Rear final drive**).
Deal with any other faults.

Check the **condition** and **connection** of the connectors of the **ETC front - rear torque distribution computer**, component code **2017** and the **instrument panel**, component code **247**.

If the connectors are faulty and if there is a repair procedure (see **Technical Note 6015A, Repairing electrical wiring, Wiring: Precautions for repair**), repair the connector, otherwise replace the wiring.

Check the **continuity, insulation** and the **absence of interference resistance** of the following connection:

– **85L** between components **2017** and **247**.

If the connection or connections are faulty and there is a repair procedure (see **Technical Note 6015A, Electrical wiring repair, Wiring: Precautions for repair**), repair the wiring, otherwise replace it.

If the fault is still present, contact the Techline.

AFTER REPAIR	Check for correct operation.
--------------	------------------------------

Passive Safety Architecture – Computer with 6 trigger lines.

