

ENGINE 1 SECTION

This service manual has been prepared to provide SUBARU service personnel with the necessary information and data for the correct maintenance and repair of SUBARU vehicles.


This manual includes the procedures for maintenance, disassembling, reassembling, inspection and adjustment of components and diagnostics for guidance of experienced mechanics.

Please peruse and utilize this manual fully to ensure complete repair work for satisfying our customers by keeping their vehicle in optimum condition. When replacement of parts during repair work is needed, be sure to use SUBARU genuine parts.

FUEL INJECTION (FUEL SYSTEMS) FU(SOHC)**EMISSION CONTROL
(AUX. EMISSION CONTROL DEVICES) EC(SOHC)****INTAKE (INDUCTION) IN(SOHC)****MECHANICAL ME(SOHC)****EXHAUST EX(SOHC)****COOLING CO(SOHC)****LUBRICATION LU(SOHC)****SPEED CONTROL SYSTEMS SP(SOHC)****IGNITION IG(SOHC)****STARTING/CHARGING SYSTEMS SC(SOHC)****ENGINE (DIAGNOSTICS) EN(SOHC)**

B: COMPONENT

1. INTAKE MANIFOLD




FU-00377


7. Knock Sensor

A: REMOVAL


- 1) Disconnect the ground cable from battery.



- 2) Remove the air cleaner case. <Ref. to IN(SOHC)-6, REMOVAL, Air Cleaner Case.>
- 3) Disconnect the knock sensor connector.



- 4) Remove the knock sensor from the cylinder block.



B: INSTALLATION


- 1) Install the knock sensor to the cylinder block.

Tightening torque:

24 N·m (2.4 kgf-m, 17.4 ft-lb)


NOTE:

The extraction area of the knock sensor cord must be positioned at a 60° angle relative to the engine rear.




(A) Front side

- 2) Connect the knock sensor connector.



- 3) Install the air cleaner case. <Ref. to IN(SOHC)-6, REMOVAL, Air Cleaner Case.>
- 4) Connect the battery ground cable to battery.



22.Fuel Pump

A: REMOVAL


WARNING:

- Place "NO FIRE" signs near the working area.
- Be careful not to spill fuel.


NOTE:

Fuel pump assembly consists of fuel pump and fuel level sensor.

- 1) Release the fuel pressure. <Ref. to FU(SOHC)-49, RELEASING OF FUEL PRESSURE, OPERATION, Fuel.>
- 2) Open the fuel filler flap lid and remove fuel filler cap.
- 3) Disconnect the ground cable from battery.




- 4) Lift-up the vehicle.
- 5) Drain fuel from the fuel tank. Set a container under the vehicle and remove the drain plug from fuel tank.




- 6) Tighten the fuel drain plug.

Tightening torque:


26 N·m (2.7 kgf-m, 19.2 ft-lb)




- 7) Raise the rear seat and turn floor mat up.
- 8) Remove the access hole lid.



- 9) Disconnect the connector from fuel pump.




- 10) Disconnect the quick connector and then disconnect fuel delivery hose. <Ref. to FU(SOHC)-65, Fuel Delivery, Return and Evaporation Lines.>
- 11) Move the clips, and then disconnect the fuel return hose (A) and jet pump hose (B).




4. Air Intake Duct

A: REMOVAL

- 1) Remove the bolt (A) which installs air intake duct A on the front side of body.
- 2) Remove the clip (B) which connects air intake duct A to resonator chamber.
- 3) Remove the air intake duct A.



- 4) Remove the air intake duct B from resonator chamber and air cleaner case.



B: INSTALLATION

Install in the reverse order of removal.


NOTE:

Refer to "COMPONENT" for tightening torque.
<Ref. to IN(SOHC)-2, COMPONENT, General Description.>

C: INSPECTION

- 1) Inspect for cracks and loose connections.
- 2) Inspect that no foreign objects are mixed in the air intake duct.

6. CRANKSHAFT AND PISTON




ME-00190


ENGINE ASSEMBLY

MECHANICAL


- (3) Remove the pipe with bracket.




- (4) Remove the bolts which install power steering pump bracket.



- (5) Remove the power steering tank from bracket by pulling it upward.




- (6) Place the power steering pump on right side wheel apron.




- 14) Remove the front and center exhaust pipe.
<Ref. to EX(SOHC)-7, REMOVAL, Front Exhaust Pipe.>

- 15) Remove the nuts which hold lower side of transmission to engine.




- 16) Remove the nuts which install front cushion rubber onto front crossmember.



- 17) Separate the torque converter clutch from drive plate. (AT vehicles)

- (1) Lower the vehicle.
- (2) Remove the service hole plug.
- (3) Remove the bolts which hold torque converter clutch to drive plate.
- (4) Remove other bolts while rotating the engine using socket wrench.



3. VALVE GUIDE

1) Check the clearance between valve guide and stem. The clearance can be checked by measuring the outside diameter of valve stem and the inside diameter of valve guide with outside and inside micrometers respectively.

Clearance between the valve guide and valve stem:



Standard

Intake 0.035 — 0.062 mm (0.0014 — 0.0024 in)

Exhaust 0.040 — 0.067 mm (0.0016 — 0.0026 in)

Limit

0.15 mm (0.0059 in)



2) If the clearance between valve guide and stem exceeds the limit, replace the valve guide or valve itself whichever shows greater amount of wear. See the following procedure for valve guide replacement.

Valve guide inner diameter:

6.000 — 6.012 mm (0.2362 — 0.2367 in)

Valve stem outer diameters:

Intake

5.950 — 5.965 mm (0.2343 — 0.2348 in)

Exhaust


5.945 — 5.960 mm (0.2341 — 0.2346 in)

(1) Place the cylinder head on ST1 with the combustion chamber upward so that valve guides enter the holes in ST1.

(2) Insert the ST2 into valve guide and press it down to remove valve guide.

ST1 498267800 CYLINDER HEAD TABLE

ST2 499767200 VALVE GUIDE REMOVER




(3) Turn the cylinder head upside down and place ST as shown in the figure.

Intake side:

ST 499767700 VALVE GUIDE ADJUSTER


Exhaust side:

ST 499767800 VALVE GUIDE ADJUSTER



(A) Valve guide

(4) Before installing new oversize valve guide, make sure that neither scratches nor damages exist on the inside surface of valve guide holes in cylinder head.

D: ASSEMBLY

ME-00392

- | | |
|----------------------------|-----------------|
| (1) Connecting rod bearing | (5) Second ring |
| (2) Connecting rod | (6) Top ring |
| (3) Connecting rod cap | (7) Circlip |
| (4) Oil ring | (8) side mark |

Tightening torque: N·m (kgf-m, ft-lb)
T: 45 (4.6, 33)

1) Apply oil to the surfaces of the connecting rod bearings.

2) Install the connecting rod bearings on connecting rods and connecting rod caps.

3) Position each connecting rod with the marked side facing forward, and then install them.

4) Install the connecting rod cap with connecting rod nut.

Ensure the arrow on connecting rod cap faces the front during installation.

CAUTION:

- Each connecting rod has its own mating cap. Make sure that they are assembled correctly by checking their matching number.
- When tightening the connecting rod nuts, apply oil on the threads.

5) Install the expander, lower rail and upper rail in this order by hand. Then install the second ring and top ring with a piston ring expander.

E: INSPECTION**1. CYLINDER BLOCK**

1) Visually check for cracks and damage. Especially, inspect the important parts by means of red lead check.

2) Check the oil passages for clogging.

3) Inspect the crankcase surface that mates with cylinder head for warping by using a straight edge, and correct by grinding if necessary.

Warping limit:

0.05 mm (0.0020 in)

Grinding limit:

0.1 mm (0.004 in)

Standard height of cylinder block:

201.0 mm (7.91 in)

D: PREPARATION TOOL

1. NON-TURBO MODEL

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
<p>ST-499977400</p>	499977400 (2000 cc model) 499977100 (2500 cc model)	CRANK PULLEY WRENCH	Used for stopping crankshaft pulley when loosening and tightening crankshaft pulley bolts.
<p>ST18231AA010</p>	18231AA010	CAMSHAFT SPROCKET WRENCH (For left side)	<ul style="list-style-type: none"> • Used for removing and installing camshaft sprocket (LH). • Also the CAMSHAFT SPROCKET WRENCH (499207100) can be used.
<p>ST-499207400</p>	499207400	CAMSHAFT SPROCKET WRENCH (For right side)	Used for removing and installing camshaft sprocket (RH).

ACCELERATOR PEDAL

SPEED CONTROL SYSTEMS

2. Accelerator Pedal


A: REMOVAL

- 1) Disconnect the ground cable from battery.
- 2) Remove the lock nut from accelerator cable bracket.
- 3) Separate the accelerator cable from bracket.
- 4) Remove the accelerator cable end from throttle cam.


NOTE:

Be careful not to kink the accelerator cable.

• SOHC MODEL




• DOHC turbo MODEL




- (A) Lock nut
- (B) Accelerator cable bracket
- (C) Accelerator cable
- (D) Throttle cam

- 5) Remove the clip inside engine compartment.


• LHD SOHC MODEL




• RHD SOHC MODEL



• LHD DOHC turbo MODEL



• RHD DOHC turbo MODEL




- (A) Toe board
- (B) Accelerator cable
- (C) To accelerator pedal
- (D) Brake booster
- (E) Clip

- 6) Remove the instrument panel lower cover from instrument panel, and connector.
- 7) Disconnect the connector from kick-down switch. (AT vehicles)
- 8) Remove the accelerator pedal connecting bolt from accelerator pedal bracket.

3. Generator


A: REMOVAL

1) Disconnect the ground cable from battery.




2) Disconnect the connector and terminal from generator.

• SOHC MODEL




• TURBO MODEL




3) Remove the V-belt cover.

• SOHC MODEL




• TURBO MODEL



4) Remove the front side V-belt.

<Ref. to ME(SOHC)-41, FRONT SIDE BELT, REMOVAL, V-belt.> or <Ref. to ME(TURBO)-44, FRONT SIDE BELT, REMOVAL, V-belt.>

5) Remove the bolts which install generator onto bracket.




B: INSTALLATION

Install in the reverse order of removal.

CAUTION:

Check and adjust the V-belt tension. <Ref. to ME(SOHC)-42, INSPECTION, V-belt.> or <Ref. to ME(TURBO)-45, INSPECTION, V-belt.>



13. Drive Cycle

A: OPERATION

There are three drive patterns for the trouble diagnosis. Driving in the specified pattern allows to diagnose malfunctioning items listed below. After the malfunctioning items listed below are repaired, always check whether they correctly resume their functions by driving in the required drive pattern.

1. PREPARATION FOR THE DRIVE CYCLE

- 1) Make sure that the fuel remains approx. half amount [20 — 40 ℓ (5.3 — 10.6 US gal, 4.4 — 8.8 Imp gal)], and battery voltage is 12V or more.
- 2) After performing the diagnostics and cleaning memory, check for any remaining unresolved trouble data. <Ref. to EN(SOHC)-47, Clear Memory Mode.>
- 3) Separate the test mode connector.

NOTE:

- Except for the water temperature specified items at starting, the diagnosis is carried out after engine warm up.
- Carry out the diagnosis which is marked * on DTC twice, then, after finishing first diagnosis, stop the engine and do second time at the same condition.

2. AFTER RUNNING 20 MINUTES AT 80 KM/H (50 MPH), IDLE ENGINE FOR 1 MINUTE.

DTC No.	Item	Condition
*P0030	HO2S Heater Control Circuit Range/Performance (Bank 1 Sensor 1)	—
*P0111	Intake Air Temperature Circuit Range/Performance	Coolant temperature at start is less than 30°C (86°F).
*P0125	Insufficient Coolant Temperature for Closed Loop Fuel Control	Coolant temperature at start is less than 20°C (68°F).
*P0130	O ₂ Sensor Circuit (Bank 1 Sensor 1)	—
*P0133	O ₂ Sensor Circuit Slow Response (Bank 1 Sensor 1)	—
*P0420	Catalyst System Efficiency Below Threshold (Bank 1)	—
P0459	Evaporative Emission Control System Purge Control Valve Circuit High	—
*P0461	Fuel Level Sensor Performance Problem (Travel Distance)	—
*P0464	Fuel Level Sensor Circuit Intermittent	—
*P1137	O ₂ Sensor Circuit (Bank1 Sensor1)	—

LIST OF DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

DTC No.	Item	Index
P1134	A/F Sensor Micro-computer Problem	<Ref. to EN(SOHC)-234, DTC P1134 — A/F SENSOR MICRO-COMPUTER PROBLEM —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1137	O ₂ Sensor Circuit (Bank1 Sensor1)	<Ref. to EN(SOHC)-235, DTC P1137 — O ₂ SENSOR CIRCUIT (BANK1 SENSOR1) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1492	EGR Solenoid Valve Signal #1 Circuit Malfunction (Low Input)	<Ref. to EN(SOHC)-238, DTC P1492 — EGR SOLENOID VALVE SIGNAL #1 CIRCUIT MALFUNCTION (LOW INPUT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1493	EGR Solenoid Valve Signal #1 Circuit Malfunction (High Input)	<Ref. to EN(SOHC)-238, DTC P1493 — EGR SOLENOID VALVE SIGNAL #1 CIRCUIT MALFUNCTION (HIGH INPUT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1494	EGR Solenoid Valve Signal #2 Circuit Malfunction (Low Input)	<Ref. to EN(SOHC)-238, DTC P1494 — EGR SOLENOID VALVE SIGNAL #2 CIRCUIT MALFUNCTION (LOW INPUT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1495	EGR Solenoid Valve Signal #2 Circuit Malfunction (High Input)	<Ref. to EN(SOHC)-238, DTC P1495 — EGR SOLENOID VALVE SIGNAL #2 CIRCUIT MALFUNCTION (HIGH INPUT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1496	EGR Solenoid Valve Signal #3 Circuit Malfunction (Low Input)	<Ref. to EN(SOHC)-238, DTC P1496 — EGR SOLENOID VALVE SIGNAL #3 CIRCUIT MALFUNCTION (LOW INPUT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1497	EGR Solenoid Valve Signal #3 Circuit Malfunction (High Input)	<Ref. to EN(SOHC)-238, DTC P1497 — EGR SOLENOID VALVE SIGNAL #3 CIRCUIT MALFUNCTION (HIGH INPUT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1498	EGR Solenoid Valve Signal #4 Circuit Malfunction (Low Input)	<Ref. to EN(SOHC)-239, DTC P1498 — EGR SOLENOID VALVE SIGNAL #4 CIRCUIT MALFUNCTION (LOW INPUT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1499	EGR Solenoid Valve Signal #4 Circuit Malfunction (High Input)	<Ref. to EN(SOHC)-241, DTC P1499 — EGR SOLENOID VALVE SIGNAL #4 CIRCUIT MALFUNCTION (HIGH INPUT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1510	ISC Solenoid Valve Signal #1 Circuit Malfunction (Low Input)	<Ref. to EN(SOHC)-243, DTC P1510 — IDLE AIR CONTROL SOLENOID VALVE SIGNAL 1 CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1511	ISC Solenoid Valve Signal #1 Circuit Malfunction (High Input)	<Ref. to EN(SOHC)-243, DTC P1511 — IDLE AIR CONTROL SOLENOID VALVE SIGNAL 1 CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1512	ISC Solenoid Valve Signal #2 Circuit Malfunction (Low Input)	<Ref. to EN(SOHC)-243, DTC P1512 — IDLE AIR CONTROL SOLENOID VALVE SIGNAL 2 CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1513	ISC Solenoid Valve Signal #2 Circuit Malfunction (High Input)	<Ref. to EN(SOHC)-243, DTC P1513 — IDLE AIR CONTROL SOLENOID VALVE SIGNAL 2 CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1514	ISC Solenoid Valve Signal #3 Circuit Malfunction (Low Input)	<Ref. to EN(SOHC)-243, DTC P1514 — IDLE AIR CONTROL SOLENOID VALVE SIGNAL 3 CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1515	ISC Solenoid Valve Signal #3 Circuit Malfunction (High Input)	<Ref. to EN(SOHC)-243, DTC P1515 — IDLE AIR CONTROL SOLENOID VALVE SIGNAL 3 CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1516	ISC Solenoid Valve Signal #4 Circuit Malfunction (Low Input)	<Ref. to EN(SOHC)-244, DTC P1516 — IDLE AIR CONTROL SOLENOID VALVE SIGNAL 4 CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1517	ISC Solenoid Valve Signal #4 Circuit Malfunction (High Input)	<Ref. to EN(SOHC)-246, DTC P1517 — IDLE AIR CONTROL SOLENOID VALVE SIGNAL 4 CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
P1518	Starter Switch Circuit Low input	<Ref. to EN(SOHC)-248, DTC P1518 — STARTER SWITCH CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
4 CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR. Measure the voltage between engine coolant temperature sensor connector and engine ground. Connector & terminal (E8) No. 1 (+) — Engine ground (–): Is the measured value more than specified value?	4 V	Go to step 5.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between ECM and engine coolant temperature sensor connector • Poor contact in engine coolant temperature sensor connector • Poor contact in ECM connector • Poor contact in coupling connector • Poor contact in joint connector
5 CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Measure the resistance of harness between engine coolant temperature sensor connector and engine ground. Connector & terminal (E8) No. 2 — Engine ground: Is the measured value less than specified value?	5 Ω	Replace the engine coolant temperature sensor. <Ref. to FU(SOHC)-26, Engine Coolant Temperature Sensor.>	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between ECM and engine coolant temperature sensor connector • Poor contact in engine coolant temperature sensor connector • Poor contact in ECM connector • Poor contact in coupling connector • Poor contact in joint connector