


SECTION INDEX

	SECTION
GENERAL	0
ENGINE TUNE-UP	1
ENGINE OVERHAUL	2
FUEL SYSTEM	3
PCV SYSTEM	4
COOLING SYSTEM	5
LUBRICATION SYSTEM	6
IGNITION SYSTEM	7
STARTING SYSTEM	8
CHARGING SYSTEM	9
SST LIST	10
SERVICE STANDARDS	11

ENGINE VIEWS



4Y Engine Exterior Views

KAJ14-2,6

ABBREVIATIONS

Abbreviation (code)	Meaning	Abbreviation (code)	Meaning
ASSY	Assembly	O/S	Oversize
ABDC	After bottom dead center	OPT	Option
ATDC	After top dead center	RH	Right hand
BBDC	Before bottom dead center	rpm	Revolutions per minute
BTDC	Before top dead center	SST	Special service tool
BDC	Bottom dead center	STD	Standard
EX	Exhaust	SUB-ASSY	Sub-assembly
I/A	Integrated ignition assembly	T =	Tightening torque
IN	Intake	U/S	Undersize
LH	Left hand		

GENERAL RULES OF SERVICING WORK

PREPARATION BEFORE DISASSEMBLY

1. Prepare mechanic tools, necessary measuring instruments and SST before starting operation.
2. When disassembling a complicated assembly, put punch or matching marks at places not affecting function to facilitate reassembly operation. When repairing an electrical system, start operation after disconnecting the cable from the battery negative terminal.

INSPECTION DURING DISASSEMBLY

1. Each time a part is removed, check the part installed state, deformation, damage, roughening state and scratching.

ORDERLY ARRANGEMENT OF DISASSEMBLED PARTS

1. Disassembled parts shall be arranged orderly. Distinguish the parts to be replaced from the parts to be reused.

CLEANING OF DISASSEMBLED PARTS

1. Parts to be reused shall be cleaned and washed thoroughly.

INSPECTION AND MEASUREMENT

1. Detailed inspection and measurement shall be carried out as required for parts to be reused.

INSTALLATION

1. Install good parts according to the correct procedure and observing the determined standards (tightening torques, adjustment values, etc.).
2. Always use genuine parts for replacement of existing parts.
3. Always use new packings, gaskets and cotter pins because they are not meant for reuse.
4. Coat seal packing on gaskets depending on the places, coat oil on the sliding contact places, coat oil or grease at specified places, and coat MP grease on oil seal lips before reassembly.

ADJUSTMENTS AND OPERATION CHECK

1. Adjust to the service standard values by using gages, a multimeter, etc.

IGNITION TIMING INSPECTION AND ADJUSTMENT


1. Engine warm up

Standard:

- Coolant temperature: 80°C or more
- Engine oil temperature: 70°C or more
- Hydraulic oil temperature: 50°C or more

2. Tachometer and timing light installation

- (1) Disconnect the test connector and connect the tachometer measuring lead to the black wire.



Installing the Tachometer

KAJS5

3. Idle speed inspection

Standard: See repair manual for model

4. Ignition timing inspection and adjustment

- (1) Disconnect the vacuum hose from the Distributor (IIA).

- (2) Use the timing light and inspect the ignition timing.


Standard: 7° BTDC/idle speed

- (3) If the standard is not satisfied, loosen the distributor set bolt and turn the distributor for adjustment to the standard value.

- (4) Tighten the set bolt and recheck the ignition timing.

T = 1.85 kg-m (13.4 ft-lb)

- (5) After ignition timing adjustment, seal the distributor set bolt by using the sealing tape.



Inspecting the Ignition Timing

KAJS4

IDLE-UP INSPECTION AND ADJUSTMENT

1. Engine warm up

Standard:

- Coolant temperature: 80°C or more
- Engine oil temperature: 70°C or more
- Hydraulic oil temperature: 50°C or more

2. Tachometer installation (See above.)

3. Idle-up speed inspection and adjustment


- (1) Start the engine. Disconnect the vacuum hose ② from the idle-up actuator ①, and measure the engine speed.

Standard: See repair manual for model

If the standard is not satisfied, turn the adjusting screw ③ for adjustment.


Caution:

Clockwise turn of the adjusting screw increases the engine speed.



Idle-up Actuator

KAJ14-12




Adjusting the Idle-up Speed

KAJ20-9

CYLINDER HEAD

COMPONENTS




- | | | |
|---------------------------------|-----------------------------|--------------------------------|
| 1. Cylinder head cover SUB-ASSY | 12. Intake valve seat | 23. Valve lifter |
| 2. Seal washer | 13. Exhaust valve seat | 24. Stud bolt |
| 3. Cylinder head cover gasket | 14. Ignition plug hole | 25. Stud bolt |
| 4. Oil filler cap SUB-ASSY | 15. Gasket | 26. Valve rocker shaft No. 1 |
| 5. Gasket | 16. Cylinder head gasket | 27. Valve spring retainer lock |
| 6. Cylinder head SUB-ASSY | 17. Gasket | 28. Valve spring retainer |
| 7. Intake valve guide bush | 18. Head rear plate | 29. Valve spring |
| 8. Exhaust valve guide bush | 19. Valve rocker arm, No. 2 | 30. Valve stem oil seal |
| 9. Shaft snap ring | 20. Spring | 31. Spring seat |
| 10. Plug | 21. Valve rocker arm, No. 1 | 32. Intake valve |
| 11. Gasket | 22. Valve push rod | 33. Exhaust valve |

Cylinder Head Components

KAJM3


14. Water pump ASSY removal
- (1) Water inlet hose disconnection
 - (2) Set bolts (4 pcs.)
 - (3) Water pump ASSY



Removing the Water Pump ASSY

KAJ56

15. Cylinder head removal
- (1) Evenly loosen 13 cylinder head bolts in the illustrated order in several steps.
 - (2) Remove the set bolts and remove the rear engine hanger.
 - (3) Remove the cylinder head from the cylinder block.




Removing the Cylinder Head

EM2416

Caution:
Carefully prevent the cylinder head installation surface from any damage.

CYLINDER HEAD DISASSEMBLY


1. Valve removal
- (1) Set the SST to the valve to compress the valve spring, and remove two retainer locks.
SST 09202-76001-71
(SST 09202-43013)
 - (2) Remove spring retainers, springs, seats, valves and oil seals.



Removing the Valve

EM2413

Caution:
Removed parts shall be arranged orderly for each cylinders.



Valve Components

EM0025

13. Valve seat correction

Caution:

- Use a cutter with cement carbide tip for the EX valve seats.
- Always inspect the valve contact position and width during the correction.
- Gradually release the force near the end of cutting to prevent stepping on the cut surface.
- Start the correcting operation after inspecting the valve guide bush.

- (1) Use a 45° cutter and cut the minimum contact width to become wider than the standard.
- (2) Cut so that the contact position comes to the center of the valve face.


- ① If the contact position is deviated to the outside, cut with a 30° cutter.

- ② If the contact position is deviated to the inside, cut with a 60° cutter (for IN) or 65° cutter (for EX).

- (3) Use a compound and lap the valve.
- (4) After lapping, use red lead and check that the valve contact is uniform on the whole circumference.


Caution:

Thoroughly remove the compound after valve lapping.




Correcting the Valve Seat (1)

EM2535




Correcting the Valve Seat (2)

EM0185



Correcting the Valve Seat (3)

EM0186



Lapping the Valve

EM2400

~1998.7


9. Water outlet pipe installation

- (1) Install the water outlet pipe.
- (2) Install the water bypass hose.
- (3) Install 2 set bolts and the union bolt.
Union bolt T = 3.5 kg-m (25 ft-lb)

1998.8~

9. Water bypass hose installation

- (1) Install the water bypass hose and clamp.




Installing the Water Outlet Pipe

KAJ13-5

10. Air governor installation

- (1) Install the fuel insulator plate and heat insulator.
- (2) Install the air governor.
- (3) Install the water hose and ventilation hose.




Installing the Air Governor

KAJ11-36

11. Carburetor installation

- (1) Install the carburetor and tighten 2 set nuts.
T = 1.15 kg-m (8 ft-lb)
- (2) Install the fuel pipe.
- (3) Install the water hose.
- (4) Install the vacuum hose.



Installing the Carburetor


KAJ11-28

12. Air cleaner connector installation

- (1) Install the air cleaner connector and tighten two set bolts.
- (2) Install the ventilation hose.

13. Alternator installation


- (1) Install the alternator and temporarily tighten the fixing and adjusting bolts.
- (2) Install the V-belt and fan pulley.
- (3) Adjust the V-belt tension.
See page 1-3 for the belt tension adjustment procedure.



Installing the Alternator

KAJ11-12

8. Rear oil seal retainer removal
 - (1) Remove five set bolts.
 - (2) Remove the rear oil seal retainer with dust seal and gasket.



Removing the Rear Oil Seal Retainer


KAJ5-29

9. Connecting rod thrust clearance inspection
 - (1) Use a dial gauge and measure the thrust clearance by moving the connecting rod back and forth.

Standard: 0.160 – 0.312 mm
(0.0063 – 0.0123 in.)

Limit: 0.35 mm (0.0138 in.)


If the limit is exceeded, replace the connecting rod ASSY.



Inspecting the Connecting Rod Thrust Clearance

EM0065


10. Connecting rod oil clearance inspection
 - (1) Punch matching mark on the connecting rod and cap.



Punching the Matching Mark

EM2539

- (2) Remove the connecting rod cap nuts.
 - (3) Use a plastic hammer and tap the bolt lightly to remove the connecting rod cap and bearing.



Removing the Connecting Rod Cap

EM0209

CYLINDER BLOCK ASSEMBLY

Caution:


- Thoroughly clean the parts to be assembled.
- Coat engine oil on the sliding contact and rotating surfaces before assembly.
- Replace gaskets, oil seal and other non-reusable parts with new ones.

1. Crankshaft bearing installation

Caution:

Keep the bearing outer surfaces (in contact with the cylinder block or bearing caps) free from oil.


- (1) Install the upper bearing having an oil groove on the whole periphery, with the cylinder block oil hole and lock groove as the guide.
- (2) Install the lower bearing by fitting with the bearing cap lock groove.
- (3) Install the upper thrust washer to the No. 3 journal supporting portion, with the oil grooves facing outward.



Crankshaft Bearing Installation

EM0388

- (4) Install the lower thrust washer to the No. 3 bearing cap, with the oil grooves facing outward.




Installing the Upper Thrust Washer

EM0247

Reference:

Coat engine oil on the rear face of the thrust washer to prevent falling.




Installing the Lower Thrust Washer

EM1703

REMOVAL

1. Fuel pump piping disconnection
 - (1) Disconnect the fuel pump outlet and inlet pipes.


2. Fuel pump ASSY removal
 - (1) Remove two fuel pump set nuts and the fuel pump ASSY.
 - (2) Remove the insulator.



Disconnecting the Piping

KAJS81

2. Fuel pump ASSY removal
 - (1) Remove two fuel pump set nuts and the fuel pump ASSY.
 - (2) Remove the insulator.



Removing the Fuel Pump ASSY

KAJS56

INSPECTION (AIRTIGHTNESS CHECK)

1. Preparation for inspection
 - (1) Supply a small volume of gasoline to the fuel pump to keep the airtightness of the check valve.
 - (2) Operate the arm without blocking the pipe, and check the arm travel and play.


Reference:

The arm travel and play checked in the preparation shall be used as the basis for later inspections.

2. Diaphragm inspection.
 - (1) Block the inlet pipe and outlet union with fingers, and operate the arm to check that the arm movement becomes heavy.


Caution:

Do not operate the arm forcibly.



Preparing for Inspection


KAJS57



Inspecting the Diaphragm

KAJS58

4. Slow jet removal




Removing the Slow Jet

KAJ18-22,23

5. Idle-up actuator removal

- (1) Remove two set screws and remove the idle-up actuator.




Removing the Idle-up Actuator

KAJ18-25

6. Main jet removal

- (1) Remove the main passage plug and gasket.
- (2) Remove the main jet and gasket from the main passage plug hole.



Removing the Main Jet


KAJ18-26,28

7. Accelerating pump diaphragm removal

- (1) Remove four set screws, and remove the accelerating pump cover.
- (2) Remove the diaphragm and spring.

8. Throttle adjusting screw removal

- (1) Throttle adjusting screw
- (2) Spring




Removing the Throttle Adjusting Screw

KAJ18-30

INSPECTION


1. Governor body inspection
 - (1) Inspect the governor body for any corrosion. Remove any or rusting with fine grained sandpaper.
 - (2) Manually move the stabilizer piston. Check smooth sliding without sticking.
 - (3) Inspect the body for distortion. Replace the body if distorted.



Inspecting the Governor Body

KAF22-31


2. Governor spring and ribbon inspection
 - (1) Replace the governor spring if any fatigue, deformation or other abnormality is found.
 - (2) Replace the governor ribbon if any bending, deformation, crack, or other abnormality is found.



Inspecting the Governor Spring and Ribbon

KAF22-33


3. Throttle valve and the valve shaft inspection
 - (1) Damage and deformation of the throttle valve.
 - (2) Assemble the throttle valve shaft to the governor body. Turn the cam manually and check any sticking or looseness caused by wear.
 - (3) Wear (looseness during shaft insertion) or rusting of the governor body needle bearing.



Inspecting the Throttle Valve and Valve Shaft

KAF22-32

4. Adjusting screw and bush inspection
 - (1) Bending of the adjusting screw, and damage of the thread.
 - (2) Damage of the bush thread.




Inspecting the Adjust Screw and the Bush

KAF22-34

INSTALLATION


1. Thermostat installation
 - (1) Install a new gasket to the thermostat, and insert them to the inlet. The jiggle valve ① of the thermostat shall be on the upper side.



Installing the Thermostat


KAJ10-20, KAJS85

2. Water inlet installation
 - (1) Install the water inlet by using two bolts.
T = 1.85 kg-m (13 ft-lb)
3. Radiator outlet hose connection
 - (1) Connect the radiator outlet hose to the water inlet.
4. Coolant filling
 - (1) After checking closing of the radiator drain cock and engine drain plug, fill coolant.
 - (2) Start the engine and check that no leakage from the mounting place occurs.
 - (3) Shut off the engine and perform bleeding of the air from the cooling system by unscrewing the bleeder plug located at the upper part of water pump.



Installing the Water Inlet

KAJ4-35




Bleeding the Air from Water Pump

LAO198-8

OIL PUMP

COMPONENTS



- 1. Oil pump ASSY
- 2. Oil pump body
- 3. Rotor set
- 4. Pump cover
- 5. Relief valve

- 6. Relief valve spring
- 7. Plug
- 8. Oil strainer SUB-ASSY
- 9. Gasket

Oil Pump Components

KAJM18