

| | |
|--|--------------|
| Important Safety Notice..... | ii |
| Foreword and Disclaimer | v |
| Vehicle Identification and VIN Decoder | vi |
| Warnings and Cautions..... | vii |
| R32 Supplement | back of book |
| Index | end of book |

0 Overview, Maintenance

| | |
|----|---|
| 00 | Golf, GTI and Jetta Product Familiarization |
| 0 | Maintenance |

1 Engine

| | | | |
|-----|--|-----|---|
| 1 | General Information | 15c | Cylinder Head and Valvetrain (2.0L Engine) |
| 10 | Engine—Removing and Installing | 15d | Cylinder Head and Valvetrain (2.8L Engine) |
| 13a | Crankshaft/Cylinder Block (4-Cylinder) | 15e | Cylinder Head and Valvetrain (1.9L PD Engine) |
| 13b | Crankshaft/Cylinder Block (6-Cylinder) | 17 | Engine—Lubrication System |
| 15a | Cylinder Head and Valvetrain (1.8L Engine) | 19 | Engine—Cooling System |
| 15b | Cylinder Head and Valvetrain (1.9L Engine) | | |

2 Engine Management, Exhaust, and Engine Electrical

| | | | |
|-----|---------------------------------------|-----|---------------------------------------|
| 2 | General Information | 24c | Fuel Injection—Motronic (2.8L Engine) |
| 20 | Fuel Storage and Supply | 26 | Exhaust System and Emission Controls |
| 21 | Turbocharger and Intercooler | 27 | Engine Electrical |
| 23 | Fuel Injection—Diesel (1.9L Engine) | 28a | Ignition System—Gasoline |
| 24a | Fuel Injection—Motronic (1.8L Engine) | 28b | Ignition System—Diesel |
| 24b | Fuel Injection—Motronic (2.0L Engine) | | |

3 Clutch, Transmission, and Final Drive

| | | | |
|----|---------------------|----|------------------------------|
| 30 | Clutch | 37 | Automatic Transmission |
| 32 | Torque Converter | 39 | Differential and Final Drive |
| 34 | Manual Transmission | | |

4 Suspension, Brakes, and Steering

| | | | |
|----|----------------------------------|----|------------------------------|
| 40 | Front Suspension and Drive Axles | 46 | Brakes—Mechanical Components |
| 42 | Rear Suspension | 47 | Brakes—Hydraulic System |
| 44 | Wheels—Tires, Wheel Alignment | 48 | Steering |
| 45 | Anti-Lock Brakes (ABS) | | |

5 Body—Assembly

| | | | |
|----|---------------|----|-------------|
| 50 | Body—Front | 57 | Front Doors |
| 55 | Hood and Lids | 58 | Rear Doors |

6 Body—Components and Accessories

| | | | |
|----|---------|----|-------------------------|
| 60 | Sunroof | 66 | Body—Exterior Equipment |
| 63 | Bumpers | 69 | Seatbelts, Airbags |

7 Body—Interior Trim

| | |
|----|---------------|
| 70 | Trim—Interior |
| 72 | Seats |

8 Heating and Air Conditioning

| | |
|----|-------------------------|
| 80 | Heating and Ventilation |
| 87 | Air Conditioning |

9 Electrical System

| | | | |
|----|-------------------------|----|-----------------------------------|
| 9 | General Information | 94 | Lights, Accessories—Exterior |
| 90 | Instruments | 96 | Lights, Accessories—Interior |
| 91 | Radio and Communication | 97 | Wiring Diagrams, Fuses and Relays |
| 92 | Wipers and Washers | ST | Scan Tool |

GOLF, GTI AND JETTA PRODUCT FAMILIARIZATION 00-5

Feature Overview

Instrument cluster illumination



Front seat side airbags



New headlight design, Golf




Power windows



New headlight design, Jetta



VR6 engine





- Drain coolant, see **19 Cooling System**.

WARNING —


Hot coolant can scald! Drain the coolant only with engine cold.

- Disconnect coolant hoses at radiator or engine using spring-type pliers or “quick-disconnect” couplings where equipped.

NOTE —

Spring-type hose clamps are used from the factory. Special pliers such as VAG 1921 or VAS 5024 or equivalent are recommended for ease of removal and installation.

- Remove right side inner CV joint protective cover from engine if equipped.
- Remove right side drive shaft and disconnect left side driveshaft at the transmission. See **40 Front Suspension and Drive Axles**.
- Remove front exhaust pipe, see **26 Exhaust System and Emission Controls**.




- Unbolt mounting bolts (arrows **A** and **B**) and remove pendulum support.
- Engine code **BDF**:
 - Remove generator (alternator) and mounting bracket.
 - Remove Secondary Air Injection pump motor bracket from oil pan and cylinder block.

NOTE —


The above step may also be needed for engine code AFP to obtain needed clearance.

- Engine code: **AFP**:

- Modify Volkswagen engine support tool 3395 to fit the bottom of the engine block.
- Deepen and widen slot to the following dimensions:
 - a** = 32 mm (1.26 in)
 - b** = 27 mm (1.06 in)



15e-8 CYLINDER HEAD AND VALVETRAIN (1.9L PD ENGINE)




Camshaft oil seal, replacing

- Remove engine cover by pulling forward edge upward and pulling forward out of rear securing clip (**arrow**).

NOTE —

It is not necessary to remove the engine oil dipstick before removing engine cover.


- Remove timing belt.
- Remove camshaft sprocket, outer and hub.



- Prepare oil seal extractor tool 3240 by unscrewing inner part of tool two full turns, approx. 3 mm ($\frac{1}{8}$ in) from outer part and lock with knurled screw.

- Lubricate threaded tapered end of oil seal extractor. Place it in position and exerting firm pressure, screw it as far as possible into oil seal.

- Loosen knurled screw and turn inner part against camshaft until oil seal is pulled out.
- When installing new seal, do not additionally oil or grease the inner oil seal sealing lip.
- Before installing, remove oil remains from camshaft journals with a clean cloth
- Tape over (for example, with cellophane tape) the groove in the taper of the camshaft to protect the sealing lip.
- Carefully position seal on camshaft and push against cylinder head.




- Press in oil seal with press piece of puller 10-203 and a bolt (M12 x 65). Continue pressing into bore until completely seated.

- Install timing belt, sprockets and hub as given previously.
- Install valve cover.
- Remainder of installation is the reverse of removal.

DIESEL INJECTION SYSTEM (1.9L PD TDI DIESEL)

Diesel injection system, component overview (from 2004 m.y.)

1. Variable intake manifold flap
 - With Motor for intake flap (V157)
2. Exhaust Gas Recirculation (EGR) vacuum regulator solenoid valve (N18)
3. Intake Manifold Runner Control (IMRC) valve (N316)
4. Exhaust Gas Recirculation (EGR) cooler switch-over valve (N345)
5. Wastegate bypass regulator valve (N75)
6. Diesel direct injection system ECM (J248)
 - With BARO (altitude) sensor (F96)
7. Positive Crankcase ventilation (PCV) heating element (N79)
8. Engine coolant temperature sensor (G62)
 - Release pressure in cooling system before removing
9. Mass air flow sensor (G70)
10. Harness connector
 - For pump (unit) injectors (N240, N241, N242, N243)
11. Engine speed sensor (G28)
12. Fuel temperature sensor (G81)
13. Harness connector
 - For Camshaft Position (CMP) (G40)
14. Harness connector
 - For engine speed sensor (G28)
15. Camshaft Position (CMP) sensor (G40)
16. Manifold absolute pressure sensor (G71) and intake air temperature (IAT) sensor (G72)



- A. Brake pedal switch (F47) (not shown)
 - Located in footwell on brake pedal bracket
 - May be in combined housing with brake light switch
- B. Brake light switch (F) (not shown)
 - Located in footwell on brake pedal bracket
 - May be in combined housing with (F47)
- C. Throttle position sensor (G79) (not shown)
 - Located in footwell on throttle pedal support bracket
- D. Clutch pedal switch (F36) (not shown)
 - Located in footwell on clutch pedal support bracket
- E. Malfunction Indicator Light, MIL (K83) and Glow plug warning light (K29)
 - In instrument cluster


Starter, removing and installing

- Disconnect battery ground (GND) strap from battery negative (-) terminal. See **Cautions** at beginning of this repair group regarding battery disconnection.

NOTE —


Be sure to have the anti-theft radio code on hand before disconnecting the battery.

- Remove battery as described earlier. Remove battery tray mounting bolts (**arrows**) and battery tray.


**Vehicles with 5-speed automatic transmission (code: 09A)**

- Remove intake air hose and air filter assembly, see **24 Fuel Injection**.

- Ensure transmission is in "Park" and remove bracket (**arrow**) and pry off shift lever cable end (1) from shift lever (4) with screwdriver. Unclip shifter cable from holder (3) and set aside. Do not remove screw (2) or kink shifter cable.




- Remove plastic nut cover and nut at solenoid terminal 30 (battery positive (+) and remove cable (1). Disconnect electrical connection at terminal 50 (2).



Transmission, transporting (09A)

Due to size, bulk, and especially weight, the transmission is best moved by fitting the lifting hooks, 10-222A/2 and 10-222A/12. Use of this support in conjunction with a suitable shop crane will minimize the chance of damage to the transmission.

- Lift transmission with a suitable shop crane and transport to work area or shipping container to avoid personal injury and/or damage to transmission.



Transmission, installing (09A)



The transmission is installed in the reverse order of removal, noting the following:

- Install torque converter.
- The torque converter is installed correctly when the distance (a) between the transmission housing flange and the machined contact surface for the securing studs is as specified.
 - 21 mm (0.827 in) for 4-cylinder engines
 - 17 mm (0.669 in) for 6-cylinder engines
- If distance (a) is not correct, torque converter is not properly installed. Slide converter out and reposition until correct distance is obtained.

NOTE —


When installing transmission into vehicle, be sure that torque converter does not move. If torque converter slips out, installation distance may change and transmission can not be installed.

- If transmission is to be replaced, unbolt (arrows) original mount (A) and transfer to new unit.
- Before installing transmission, be sure that the dowel sleeves are correctly located.
- When installing transmission, check that torque converter contact is properly positioned on drive plate.
- Replace selector cable locking circlip.
- Adjust selector lever cable, see **Selector lever cable, checking and adjusting (09A)**.



Front brake assembly (FS III caliper)

1. **Screw**
 - Tighten to 4 Nm (35 in-lb)
2. **Brake disc (rotor), vented**
 - Diameter: 280 mm (11.02 in.)
 - Thickness: 22 mm (0.866 in.)
 - Wear limit: 19 mm (0.748 in.)
 - When worn always replace on both sides
 - Remove brake caliper before removing disc
 - Never remove brake discs from hub by using force. If necessary use penetrating fluid, otherwise brake discs can be damaged.
3. **Outer brake pad**
 - Thickness: 19.7 mm (0.775 in.) including backing plate
 - Checking thickness, see **0 Maintenance**
 - Wear limit: 7 mm (0.276 in.) including backing plate
 - Always replace all pads on one axle at same time
4. **Inner brake pad**
 - Thickness: 19.7 mm (0.775 in.) including backing plate
 - Checking thickness, see **0 Maintenance**
 - Wear limit: 7 mm (0.276 in.) including backing plate
 - Always replace all pads on one axle at same time
 - With wear limit indicator, as applicable
 - Warning lamp lights up on instrument panel when lining wear limit is reached, as applicable
5. **Brake caliper**
 - Do not loosen hydraulic line when replacing pads
6. **Guide pin**
 - Tighten to 30 Nm (22 ft-lb)
7. **Protective cap**
8. **Brake hose with union and banjo bolt**
 - Tighten to 35 Nm (26 ft-lb)
9. **Wheel bearing housing**



10. Pad wear sensor connector bracket

- It is not necessary to remove harness connector from bracket when replacing brake pad wear indicator

11. Socket-head bolt

- Tighten to 8 Nm (71 in-lb)

12. ABS wheel speed sensor

- Before inserting sensor, clean hole inner surface and coat with grease (VW part no. G 000 650)

13. Splash shield

14. Bolt

- Tighten to 10 Nm (7 ft-lb)

15. Wheel bearing

- Replace each time after removing
- Pressing out and in, see **40 Front Suspension and Drive Axles**

16. Circlip

17. Wheel hub with rotor


- Removing and installing, see **40 Front Suspension and Drive Axles**

48-26 STEERING

Pressure hose, mounting to automatic transmission


01M 4-speed transmission

1. Starter mounting bolt
2. Mounting bracket
3. Nut
 - Tighten to 22 Nm (16 ft-lb)
4. Clamp
5. Nut
 - Tighten to 22 Nm (16 ft-lb)
6. Pressure hose
7. Securing bolt on transmission




09A 5-speed transmission

1. Pressure hose
2. Mounting bracket
3. Bolt
 - Tighten to 22 Nm (16 ft-lb)
4. Nut
 - Tighten to 9 Nm (6 ft-lb)
5. Bolt
 - Tighten to 22 Nm (16 ft-lb)



Rear cupholder, removing and installing


- Remove rear ashtray.
- Press down retaining hooks (9) and pull cupholder out from center console (1).
- To install, guide cupholder into center console until retaining hooks (10) meet retaining lugs (2).
- Bend up retaining hooks (9) slightly.
- Install ashtray (6).



INTERIOR EQUIPMENT


Front cup holder, removing

- Fold up trim panel (1) for front cup holder.
- Press retaining clips (2 and 3) at sides of cup holder assembly with flat tip screwdriver and unclip.
- Pull out cup holder.



A/C passenger compartment components, overview (Climatronic)

1. Side window air outlet
 - Removing, see 80 Heating and Ventilation
2. Dashboard air outlets
 - Removing, see 80 Heating and Ventilation
3. Defroster air outlet
 - Must remove instrument panel to remove, see 70 Trim -Interior
4. Sunlight photo sensor (G107)
 - Controls temperature flap and fresh air blower speed depending on light intensity
 - Climatronic control module will assume a fixed value in the event of sensor failure
 - Removing, see Sunlight photo sensor, removing
5. Instrument panel temperature sensor (G56) with interior temperature sensor fan (V42)
 - Climatronic control unit, A/C control head and instrument panel temp. sensor with fan are integrated into a single unit which cannot be serviced separately
 - Controls temperature flap and fresh air blower
 - Climatronic control module will assume a fixed value of 24°C (75°F) in the event of sensor failure
6. A/C control head unit
 - Climatronic control unit, A/C control head and instrument panel temp. sensor with fan are integrated into a single unit which cannot be serviced separately
 - Replacing and adjusting: Code Climatronic control module, function 07 and then initiate basic setting, function 04 using VAG scan tool 1551/5051 or equivalent
7. Intermediate duct
8. Instrument panel cross member
 - Loosening and tightening, see 80 Heating and Ventilation




9. Dust and pollen filter
 - With activated charcoal filter
 - Removing and installing, see 80 Heating and Ventilation
10. Fresh air intake duct temperature sensor (G89)
 - Controls temperature flap and fresh air blower
 - If sensor malfunctions, outside temperature sensor value is used instead
 - Replacing: Remove glove box, see 70 Trim-Interior Reach behind heating and A/C unit and turn sensor 90° and pull out
 - Lubricate seal with oil when installing
11. Air flow flap motor (V71)
 - Also operates fresh and recirculating air flap
 - Replacing and adjusting: Initiate basic setting, function 04 using VAG scan tool 1551/5051 or equivalent
12. Fresh air blower fan (V2)
13. Fresh air blower control module (J126)
 - Controls fresh air blower speed depending on voltage signal
 - Replacing, see Control module for fresh air module, removing
14. Heating and A/C unit*
 - Refrigerant must be discharged before removing
 - With heater core and evaporator
15. Central air flap motor (V70)
 - Replacing and adjusting: Initiate basic setting, function 04 using VAG scan tool 1551/5051 or equivalent

(continued on following page)

2.8L - Engine - Motronic Multiport Fuel Injection (MFI)/130 kW, code AFP,

from December 1998

Deviate relay location and fuseplacements as well as the locations of multiple connectors see section "component locations".



97-14163

Relay location on the thirteenfold auxiliary relay panel, above relay panel:

Relay panel:

- 2** Load Reduction Relay (100)
- 4** Fuel Pump (FP) Relay (409)

Note: Number in parentheses indicates production control number stamped on relay housing.


Fuse colors

- 30 A - green
- 25 A - white
- 20 A - yellow
- 15 A - blue
- 10 A - red
- 7.5 A - brown
- 5 A - beige
- 3 A - violet

Edition 12/00
USA.5102.09.21

Repair Manual
page number

97-76



- A - Battery
- B - Starter
- C - Generator (GEN)
- C1 - Voltage Regulator (VR)
- D - Ignition/Starter Switch
- J59 - Load Reduction Relay
- J207 - Starting Interlock Relay
- J226 - Park/Neutral Position (PNP) Relay
- S162 - Fuse -1- (30) in fuse bracket/battery
- S163 - Fuse -2- (30) in fuse bracket/battery
- S176 - Fuse -4- (30) in fuse bracket/battery
- S177 - Fuse -5- (30) in fuse bracket/battery
- T2e - Double Connector, near starter (vehicles without air conditioning)
- T4 - 4-Pin Connector, near starter (vehicles with air conditioning only)

- T6 - 6-Pin Connector, brown, in protective housing for connectors, in plenum chamber, left

- 81 - Ground connection -1-, in instrument panel wiring harness
- 500 - Threaded connection -1- (30) on the relay plate
- 502 - Threaded connection -1- (30a) on the relay plate
- A41 - Plus connection (50), in instrument panel wiring harness



- * - Manual transmission only
- Automatic transmission only

Generator (GEN), starter

Edition 12/00
USA.5102.09.21

Repair Manual
page number

97-77



- G - Fuel Level Sensor
- G32 - Engine Coolant Level (ECL) Sensor
- S232 - Fuse 32 in fuse holder
- S234 - Fuse 34 in fuse holder
- S243 - Fuse 43 in fuse holder
- T6 - 6-Pin Connector, brown, in protective housing for connectors, in plenum chamber, left
- T14a - 14-Pin Connector, near battery

- (269) - Ground connection (sensor ground) -1-, in instrument panel wiring harness
- (A71) - Connector (86), in instrument panel wiring harness
- (A100) - Connector -2- (87), in instrument panel wiring harness



- (B168) - Connection (86) in passenger compartment wiring harness
- * - Vehicles with Multi-Function Indicator (MFI) only

Edition 09/01
USA.5102.11.21

Fuel level sensor, engine coolant level (ECL) sensor

Repair Manual
page number

97-308



- F1 - Oil Pressure Switch
- G22 - Speedometer Vehicle Speed Sensor (VSS)
- H3 - Warning Buzzer
- J285 - Control module with indicator unit in instrument panel insert
- J533 - Data Bus On Board Diagnostic Interface
- K2 - Generator (GEN) Warning Light
- K3 - Oil Pressure Warning Light
- K28 - Engine Coolant Level/Temperature (ECL/ECT) Warning Light
- S5 - Fuse 5 in fuse holder
- S7 - Fuse 7 in fuse holder
- T14a - 14-Pin Connector, near battery
- T32 - 32-Pin Connector, blue
- T32a - 32-Pin Connector, green

- (608) - Ground Connection (in center plenum chamber)
- (A20) - Wire connection (15a), in instrument panel wiring harness
- (B163) - Plus connector -1- (15) in wiring harness interior

Instrument cluster, oil pressure switch, speedometer vehicle speed sensor, generator (GEN) warning light, engine coolant level/temperature (ECL/ECT) warning light

Edition 09/01
USA.5102.11.21

Repair Manual
page number

97-309

2003 m.y. additional electrical wiring diagrams

| | Wiring Diagram page number |
|--|-------------------------------------|
| ● Airbag systems , from October 2000 | 50/1 |
| ● Air conditioning (manual control, not Climatronic) , from May 1999 | |
| 1.9L - Engine - Turbo Diesel Fuel Injection (DFI)/66 kW, code ALH | 38/1 |
| 1.8L - Engine - Motronic Multiport Fuel Injection (MFI)/110 kW, code AWWW | 38/1 |
| 1.8L - Engine - Motronic Multiport Fuel Injection (MFI)/132 kW, code AWP | 38/1 |
| 2.0L - Engine - Motronic Multiport Fuel Injection (MFI)/85 kW, code AVH, AZG | 38/1 |
| 2.8L - Engine - Motronic Multiport Fuel Injection (MFI)/130 kW, code AFP | 38/1 |
| 2.8L - Engine - Motronic Multiport Fuel Injection (MFI)/147 kW, code BDF | 38/1 |
| ● Anti-lock brake system (ABS) , Anti-lock brake system (ABS) with electronic differential lock (EDL) and anti-slip control (ASC) , from August 2000 | 48/1 |
| ● Anti-lock brake system (ABS) with electronic differential lock (EDL), anti-slip regulation (ASR) and electronic stabilization program (ESP) , from May 2002 | 75/1 |
| ● Anti-theft warning system (Jetta Wagon) , from May 2001 | |
| see Comfort System (without power windows) | 55/1 |
| see Comfort System (with power windows) | 56/1 |
| ● Anti-theft warning system (Golf/Jetta Sedan) , from May 2001 | |
| see Comfort System (without power windows) | 57/1 |
| see Comfort System (with power windows) | 58/1 |
| ● Anti-theft immobilizer (Jetta Wagon) , from January 2001 | 51/4 |
| ● Anti-theft immobilizer (Golf/Jetta Sedan) , from May 2000 | 52/4 |

Continued on next page!

2003 m.y. additional electrical wiring diagrams

| | Wiring Diagram page number |
|---|-------------------------------------|
| ● Automatic transmission, 4 speed automatic , from May 1999 | |
| 1.9L - Engine - Turbo Diesel Fuel Injection (DFI)/66 kW, code ALH | 36/1 |
| 1.8L - Engine - Motronic Multiport Fuel Injection (MFI)/110 kW, code AWW | 35/1 |
| ● Automatic transmission, 4 speed automatic , from December 2002 | |
| 2.0L - Engine - Motronic Multiport Fuel Injection (MFI)/85 kW, code AVH, AZG, BBW | 83/1 |
| ● Automatic transmission, 5 speed automatic with Tiptronic , from December 2002 | |
| 1.8L - Engine - Motronic Multiport Fuel Injection (MFI)/132 kW, code AWP | |
| 2.8L - Engine - Motronic Multiport Fuel Injection (MFI)/147 kW, code BDF | |
| 1.9L - Engine - Turbo Diesel Fuel Injection (DFI)/74 kW, code BEW | 84/1 |
| ● CD changer wiring preparation (Radio system) , from September 1998 | 28/1 |
| ● Central locking system with remote control (Jetta Wagon) , from May 2001 | |
| see Comfort System (without power windows) | 55/1 |
| see Comfort System (with power windows) | 56/1 |
| ● Central locking system with remote control (Golf/Jetta Sedan) , from May 1999 | |
| see Comfort System (without power windows) | 57/1 |
| see Comfort System (with power windows) | 58/1 |
| ● Climatronic (automatic climate control) , from May 1999 | |
| 2.8L - Engine - Motronic Multiport Fuel Injection (MFI)/130 kW, code AFP | 39/1 |
| 2.8L - Engine - Motronic Multiport Fuel Injection (MFI)/147 kW, code BDF | 39/1 |
| ● Comfort System (without power windows), Jetta Wagon , from May 2001 | 55/1 |
| ● Comfort System (without power windows), Golf/Jetta Sedan , from May 1999 | 57/1 |
| ● Comfort System (with power windows), Jetta Wagon , from May 2001 | 56/1 |
| ● Comfort System (with power windows), Golf/Jetta Sedan , from May 2001 | 58/1 |
| ● CAN-Bus, Powertrain and Comfort System , from May 2001 | 74/1 |
| ● Coolant Fan, single speed , from September 1998 | 11/1 |
| ● Coolant Fan, two speeds , from September 1998 | 12/1 |
| ● Coolant Fan (with after-run coolant pump) , from May 1999 | |
| 2.8L - Engine - Motronic Multiport Fuel Injection (MFI)/130 kW, code AFP | 37/1 |
| 2.8L - Engine - Motronic Multiport Fuel Injection (MFI)/147 kW, code BDF | 37/1 |
| ● Cruise control | |
| 1.8L - Engine - Motronic Multiport Fuel Injection (MFI)/132 kW, code AWP | 78/13 |
| 1.9L - Engine - Turbo Diesel Fuel Injection (DFI)/66 kW, code ALH, manual transmission | 65/9 |
| 1.9L - Engine - Turbo Diesel Fuel Injection (DFI)/66 kW, code ALH, automatic transmission | 66/9 |
| 2.0L - Engine - Motronic Multiport Fuel Injection (MFI)/85 kW, code AVH, AZG | 79/12 |
| 2.8L - Engine - Motronic Multiport Fuel Injection (MFI)/130 kW, code AFP | 31/9 |
| 2.8L - Engine - Motronic Multiport Fuel Injection (MFI)/147 kW, code BDF | 80/15 |
| Multi-function steering wheel for cruise control and radio | 46/1 |
| ● Daytime running lights , from May 2000 | 61/1 |
| ● Daytime running lights (Golf CL Canada) , from August 2002 | 76/14 |
| ● Fog lights , from May 2000 | 60/1 |
| ● Fuel tank lid unlock system (Jetta Wagon) , from May 2001 | |
| see Comfort System (without power windows) | 55/1 |
| see Comfort System (with power windows) | 56/1 |
| ● Fuel tank lid unlock system (Golf/Jetta Sedan) , from May 2001 | |
| see Comfort System (without power windows) | 57/1 |
| see Comfort System (with power windows) | 58/1 |
| ● Headlight washer , from May 2000 | 59/1 |
| ● Heated seats , from May 1999 | 68/1 |
| ● Heated leather seats , from May 1999 | 69/1 |
| ● Heated outside mirrors (Jetta Wagon) , from May 2001 | |
| see Comfort System (without power windows) | 55/1 |
| see Comfort System (with power windows) | 56/1 |
| ● Heated outside mirrors (Golf/Jetta Sedan) , from May 2001 | |
| see Comfort System (without power windows) | 57/1 |
| see Comfort System (with power windows) | 58/1 |

Continued on next page!

```

Rapid Data Transfer      HELP
Enter Address Word  XX

```

0024594

```

Rapid Data Transfer      HELP
Select Function    XX

```

0024595

```

Basic setting            HELP
Enter display group XXX

```

0024596

```

System in basic setting 098      -->
XXX      XXX%      XXX%      ADP runs

```

0024597

```

System in basic setting 098      -->
XXX      XXX      XXX      ADP OK

```

0024598

Adaptation can be initiated or restored using a suitable scan tool. Follow the scan tool manufacturer's instructions and/or use the procedure outlined below. Shown here is the display from the VAG 1551. Others scan tool displays are similar.

- Connect scan tool to DLC and switch on ignition, but **do not** start engine and **do not** depress accelerator pedal.

➤ Advance scan tool to address word menu and enter **01** for engine electronics.

➤ Advance scan tool to function menu and enter **04** for basic setting.

➤ Advance scan tool to display group menu and enter **098**.

➤ Advance scan tool until system confirms that it is in basic setting mode with four display fields as shown. Display field four should indicate that adaptation is running.

- Depress the **Q** button to confirm the display. During this time, the ECM switches off the voltage to the throttle valve control module to take a measurement and then switches back on to take additional measurements. Voltage will again be switched off allowing a spring to pull the throttle back to a previously measured position.

➤ At the conclusion of this procedure, the ECM will confirm proper stored values from the throttle position sensors in the throttle valve control module with the value in the fourth display field as shown. Display field four should indicate that adaptation is OK.

- Advance scan tool with --> button to function menu and enter **06** to end output.
- Switch off ignition to store values in ECM.
- Remove scan tool.

NOTE —

If display reads ADP ERROR, test conditions may not have been met or procedure was interrupted while running. Confirm proper test conditions and rerun procedure.