



# 1 Engine list

(VIGG000803; Edition 10.2015)

Petrol and diesel engines are listed separately.

The engine codes are listed in alphabetical order.

- ◆ Petrol engines ⇒ [page 1](#)
- ◆ Diesel engines ⇒ [page 6](#)
- ◆ Petrol/hybrid engine ⇒ [page 6](#)

## Petrol engines

Engine code ⇒ <a href="#">page 62</a>	AXX	BGP	BGQ
<b>Capacity in litres</b>	<b>2.0</b>	<b>2.5</b>	<b>2.5</b>
Number of cylinders	4	5	5
Valves per cylinder	4	4	4
Output/kW at rpm	147/5700	110/5200	110/5200
Torque/Nm at rpm	280/2000	228/4000	228/4000
Compression ratio	10.5	9.5	9.5
Injection/ignition	MPI Bosch Motronic T-FSI	MPI Bosch Motronic indirect inj.	MPI Bosch Motronic indirect inj.
RON unleaded, at least	95 also 91 RON, but with reduced power	91 also 87 RON, but with reduced power	91 also 87 RON, but with reduced power
Camshaft drive	Toothed belt	Timing chain	Timing chain

## Petrol engines

Engine code ⇒ <a href="#">page 62</a>	BLG	BLF	BLR
<b>Capacity in litres</b>	<b>1.4</b>	<b>1.6</b>	<b>2.0</b>
Number of cylinders	4	4	4
Valves per cylinder	4	4	4
Output/kW at rpm	125/6000	85/5800	110/6000
Torque/Nm at rpm	240/1750 ... 4500	155/4000	200/3500
Compression ratio	10.0	12.0	11.5
Injection/ignition	Motronic MED 9.5.10 TSI twincharger	Motronic MED 9.5.10 FSI	Motronic MED 9.5.10 FSI
RON unleaded, at least	95 also 91 RON, but with reduced power	98 also 95 RON, but with reduced power	95 also 91 RON, but with reduced power
Camshaft drive	Timing chain	Timing chain	Toothed belt

## Petrol engines

Engine code ⇒ <a href="#">page 62</a>	BMY	BLY	BSE
<b>Capacity in litres</b>	<b>1.4</b>	<b>2.0</b>	<b>1.6</b>
Number of cylinders	4	4	4



## 2.1.4 Service interval display

Introduction of extended servicing intervals (ESI) ⇒ [page 13](#) .

Flexible service interval display (only vehicles with a flexible service) ⇒ [page 13](#) .

Fixed service interval display (only vehicles with a fixed service) ⇒ [page 13](#) .

Service event for service due, up to ▶2013 ⇒ [page 14](#) .

Service event for service due, as of ▶2014 ⇒ [page 14](#) .

Service initial warning, up to ▶2013 ⇒ [page 15](#) .

Service initial warning, as of 2014▶ ⇒ [page 15](#) .

Reading service information using rocker switch on windscreen wiper lever or via buttons in the multifunction steering wheel, up to ▶2013 ⇒ [page 17](#) .

Reading service information using rocker switch on windscreen wiper lever or via buttons in the multifunction steering wheel, as of 2014▶ ⇒ [page 17](#) .

Reading service information using function buttons on dash panel insert, up to ▶2013 ⇒ [page 18](#) .

Reading service information using function buttons on dash panel insert, as of 2014▶ ⇒ [page 18](#) .

Service interval display: reset / recode ⇒ [page 224](#) .

### Introduction of extended servicing intervals (ESI)

To find out whether the extended service interval (ESI) is available for your country, contact your importer.

### Flexible service interval display (only vehicles with a flexible service)

Calculation of service intervals:

- ◆ The service intervals on vehicles with a flexible service is calculated. Input values such as distance travelled, fuel consumption, oil temperature and loading on diesel particulate filter are evaluated by the control unit.
- ◆ The result of the evaluation is a measure of the deterioration of the oil due to thermal load.
- ◆ Oil deterioration is the decisive factor in determining the distance that can still be driven before the next service.



### Note

*For vehicles with a flexible service but which are serviced according to fixed service intervals, the service interval display must be recoded to "non-flexible" ⇒ [page 224](#) .*

### Fixed service interval display (only vehicles with a fixed service)

Calculation of service intervals:

- ◆ The service interval for vehicles with a fixed service is calculated in fixed service intervals. This means that the mileage or time values have been previously determined and specified by Volkswagen.
- ◆ For normal operating conditions achieving these service intervals is technically assured.



- or "OK button" -5- in multifunction steering wheel to revert to normal display.
- ◆ The service initial warning is displayed 20 days before the next service is due.
- ◆ The remaining distance displayed is always rounded to the nearest 100 km or the remaining time rounded to full days.

**Reading service information using rocker switch on windscreen wiper lever or via buttons in the multifunction steering wheel, up to >2013**

**i Note**

- ◆ *The current service information cannot be read until 500 km have been driven after the last service.*
- ◆ *Dashes will appear on display until that time.*

The current service information can always be read with ignition switched on, engine switched off and vehicle stationary.

- Select "Settings" menu using rocker switch on windscreen wiper lever or buttons in multifunction steering wheel.
- In submenu "Service", mark menu option "Info" and press "OK" button in windscreen wiper lever or in multifunction steering wheel.
- ◆ On vehicles without text messages on the dash panel insert display, an overdue service is indicated by a minus sign in front of the mileage or day information.
- ◆ On vehicles with text messages on dash panel insert display, the following appears if service is overdue: "Service since --- km or --- days".


**Reading service information using rocker switch on windscreen wiper lever or via buttons in the multifunction steering wheel, as of 2014▶**

**i Note**

- ◆ *The current service information cannot be read until 500 km have been driven after the last service.*
- ◆ *Dashes will appear on display until that time.*

The current service information can be requested at any time with the ignition switched on, the engine turned off and the vehicle at a standstill.

- Select "Settings" menu using rocker switch on windscreen wiper lever or buttons in multifunction steering wheel.
- Select "Info" command in the "Service" submenu.
- Press "OK button" on windscreen wiper lever or in multifunction steering wheel.
- ◆ On vehicles without text messages on dash panel insert display, the following indications appear: "spanner symbol" and in the upper right corner of the dash panel insert display the number "1" is displayed for the oil change service.
- Press "OK button" on windscreen wiper lever or in multifunction steering wheel again.






### 23 - Bolts

- Fuel rail to cylinder head
- 9 Nm


## 4.2 Removing and installing intake manifold

### Special tools and workshop equipment required

- ◆ Assembly tool - T10118-




- ◆ Hose clip pliers - VAS 6362-



After intake manifold has been removed or renewed, intake manifold flap potentiometer - G336- must be adapted to engine control unit - J623- .


### Removing

- Disconnect battery at battery negative terminal ⇒ Electrical system; Rep. gr. 27 ; Battery; Disconnecting and connecting battery .
- Remove engine cover panel ⇒ [page 38](#) .
- Remove air filter housing -3- ⇒ [page 239](#) .
- Remove radiator cowl ⇒ [page 203](#) .
- Loosen hose clamps -3- and -5-.
- Disconnect connector for charge pressure sender - G31- -arrow-.
- Unscrew bolts -1- and -4-, and remove air pipe downwards.






◆ Removal wedge - 3409-



◆ Piston resetting appliance - T 10145-




Carry out the following work:


**Removing**

- Press piston out of brake caliper using compressed air.

Place a piece of wood in the recess to prevent damage to the piston.



Lever off protective cap from brake caliper using removal wedge - 3409- .





**Caution**

- ◆ *When removing and installing components that are visible (switches/covers/trim), mask off areas in which tools (removal wedge - VAS 3409- / screwdriver) are used to lever out those components using commercially available masking tape.*

**Removing**

- Disconnect battery - A- ⇒ [page 7](#) .
- Remove dash panel end cover on driver side ⇒ General body repairs, interior; Rep. gr. 68 ; Compartments/covers; Removing and installing left dash panel end cover on driver side .
- Remove bolts -1- and take fuse holder -2- out downwards.


**Installing**

Installation is carried out in the reverse order. When installing observe the following:

- Tighten threaded connections to specified torque.
- Reconnect battery - A- ⇒ [page 7](#) .

**Specified torques**

- ◆ ⇒ ["1.1 Fitting locations overview - relay carriers, fuse holders, electronics boxes", page 321](#)



**1.4.2 Removing and installing onboard supply control unit - J519-**

The relay carrier on the onboard supply control unit - J519- is bolted to the central tube of the dash panel and cannot be removed unless the dash panel is removed first.

The individual relay headers cannot be removed unless the relay carrier is removed first.

**Removing**


- Switch off ignition and all electrical consumers, and remove ignition key.
- Remove dash panel end cover on driver side ⇒ General body repairs, interior; Rep. gr. 68 ; Compartments/covers; Removing and installing left dash panel end cover on driver side .
- Pull relays out of relay carrier.

The number of relays depends on the vehicle equipment level.


- Unclip locking lugs -arrows- outwards and then push connectors -2- through relay carrier -1-.

**Installing**

Installation is carried out in the reverse sequence.



High-pressure sender, Air conditioning system control unit



- G65 High-pressure sender
- J301 Air conditioning system control unit
- J680 Terminal 75 voltage supply relay 1
- J681 Terminal 15 voltage supply relay 2
- SA4 Fuse 4 in fuse holder A
- SC13 Fuse 13 on fuse holder C
- SC20 Fuse 20 on fuse holder C
- SC33 Fuse 33 on fuse holder C
- T3c 3-pin connector
- T5 5-pin connector
- T9f 9-pin connector
- T9x 9-pin connector
- T10a 10-pin connector, on heater unit
- T20c 20-pin connector


- 44 Earth point, lower part of left A-pillar
- 367 Earth connection 2, in main wiring harness
- 389 Earth connection 24, in main wiring harness
- A189 Positive connection 5 (30a) in dash panel wiring harness
- A217 Positive connection 8 (15a) in dash panel wiring harness
- B111 Positive connection 1 (30a), in interior wiring harness
- B163 Positive connection 1 (15), in interior wiring harness
- B169 Positive connection 1 (30), in interior wiring harness
- B170 Positive connection 2 (30), in interior wiring harness

- ws = white
- sw = black
- ro = red
- rt = red
- br = brown
- gn = green
- bl = blue
- gr = grey
- li = purple
- vi = purple
- ge = yellow
- or = orange
- rs = pink

- \* see applicable current flow diagram for basic equipment
- \*2 Gradually discontinued
- \*3 Cross-section 16.0 possible
- \*4 Wiring colour depends on equipment
- \*5 Cross-section 6.0 possible

Fuse holder C

- SC Fuse holder C
- SC3 Fuse 3 on fuse holder C
- SC14 Fuse 14 on fuse holder C
- SC16 Fuse 16 on fuse holder C
- SC35 Fuse 35 on fuse holder C
- A199 Positive connection 4 (15a) in dash panel wiring harness
- A201 Positive connection 6 (15a) in dash panel wiring harness
- B169 Positive connection 1 (30), in interior wiring harness
- B172 Positive connection 4 (30), in interior wiring harness
- B315 Positive connection 1 (30a) in main wiring harness
- \* gradual introduction
- \*2 Gradually discontinued



- ws = white
- sw = black
- ro = red
- rt = red
- br = brown
- gn = green
- bl = blue
- gr = grey
- li = purple
- vi = purple
- ge = yellow
- or = orange
- rs = pink





**1 - Navigation connection Japan**

- Not assigned

**2 - Aerial connection**

- DAB
- Aerial systems  
 ⇒ [page 18](#) .

**3 - Multi-pin connector 1, 8-pin, loudspeaker outputs**

- Pin assignment  
 ⇒ [page 99](#) .

**4 - Multi-pin connector 2, 8-pin, CAN bus, voltage supply**

- Pin assignment  
 ⇒ [page 100](#) .

**5 - Multi-pin connector 3, 12-pin, telephone**

- Pin assignment  
 ⇒ [page 100](#) .

**6 - Multi-pin connector 4, 12-pin, connection for external audio sources - R199- , multimedia system control unit - J650-**

- Pin assignment  
 ⇒ [page 100](#) .

**7 - Multi-pin connector 5, 26-pin, for video and LF input**

- Pin assignment  
 ⇒ [page 101](#) .

**8 - Aerial connection GPS aerial - R50-**


- GPS
- Aerial systems ⇒ [page 18](#) .

**9 - Aerial connection**

- FM2
- Aerial systems ⇒ [page 18](#) .


**10 - Aerial connection**


- AM/FM
- Aerial systems ⇒ [page 18](#) .



**Multi-pin connector 1, 8-pin, loudspeaker outputs**

- 1 - Rear right loudspeaker (+)
- 2 - Front right loudspeaker (+)
- 3 - Front left loudspeaker (+)
- 4 - Rear left loudspeaker (+)
- 5 - Rear right loudspeaker (-)
- 6 - Front right loudspeaker (-)
- 7 - Front left loudspeaker (-)
- 8 - Rear left loudspeaker (-)






- 1 - Airbag control unit -J234-
- Connector:
- 2 - 50-pin connector -T50- on wiring harness

Back to overview → [Chapter](#)

**Connector assignment:**



- Drill holes for SG plug weld seam (8 mm Ø).



## 3.1 Tools



### Note


- ◆ *The use of different types and different thicknesses of steel requires that only the welding units (inverters) authorised by Volkswagen AG may be used to carry out repairs properly.*
- ◆ *The welding units (inverters) and body tools authorised by Volkswagen AG can be found in ⇒ ServiceNet, Workshop equipment, EH catalogue, Workshop equipment, Body and paintwork .*

## 3.2 Removing




### Note

- ◆ *Do not damage underlying panels when cutting out.*
- ◆ *If the B-pillar reinforcement is damaged, it must always be renewed.*
- ◆ *For safety reasons »crash safety«, it is not permissible to reweld the B-pillar reinforcement.*





protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by Volkswagen AG. Volkswagen AG does not guarantee or accept any liability for the correctness of information.



- Separate original joint.
- Slightly bend up lower corners of connecting parts -1 and 3- and remove lock carrier -2-.



### 16 - Bolt

- Qty. 2
- Specified torque: 9 Nm

### 17 - Door retaining strap

- Removing and installing ⇒ [page 90](#)

### 18 - Window slot inner seal

- Removing and installing ⇒ [page 106](#)

### 19 - Door window

- Removing and installing ⇒ [page 206](#)


## 2.3 Removing and installing door cover




### Note

*The removal and installation sequence is only for the right cover.  
Removal and installation of the left door cover is analogous.*

### 2.3.1 Removing





### Installing

- Install in reverse order of removal.

### Note

*Before installing, check all fasteners for damage and renew if necessary.*

## 1.8 Removing and installing left trim on seat with manual height adjustment

### Note

*Removal and installation is described for the left seat. Apply the same instructions for removal and installation of the right seat as appropriate.*

**Special tools and workshop equipment required**