

**IDENTIFICATION**

**SERIAL NUMBER**

The serial number of the outboard motor is stamped on the label attached to the port side of the clamp bracket.

**NOTE:**

For USA model:


As an antitheft measure, a special label on which the outboard motor serial number is stamped is bonded to the port side of the clamp bracket. The label is specially treated so that peeling it off causes cracks across the serial number.

- ① Model name
- ② Approved model No.
- ③ Transom height
- ④ Serial number

**STARTING SERIAL NUMBERS**

The starting serial number blocks are as follows:

Model		Approved model code	Starting serial No.
World-wide	USA, CANADA		
9.9FMH	9.9MH	682C	S: 155562~ L: 455181~ SUL: 850196~
9.9FEMH	9.9EH		S: 700301~ L: 600791~ SUL: 900141~
9.9FEMHR	—		S: 630246~ L: 660183~
9.9FEMR	9.9ER		L: 690256~
15FMH	15MH	684C	S: 405497~ L: 153352~ SUL: 830146~
15FEMH	15EH		S: 300231~ L: 600511~ SUL: 900131~
15FEMHR	—		S: 380261~ L: 650243~




- Set the dial gauge to zero at TDC.
- Turn the flywheel counterclockwise until the dial gauge indicates that the piston position is at a specified distance from TDC.



**Piston position:**

**4.22 mm (0.166 in) BTDC**

- Turn the magneto control lever (2) so that it contacts the fully advanced stopper (3).
- Adjust the link joint length so that the timing indicator aligns with the marking (a) on the flywheel.
- Tighten the lock nut.



**3. Check:**

- Fully retard ignition timing  
Incorrect → Adjust.

**Checking steps:**


- Turn the flywheel clockwise so that the its specified marking (a) aligns with the starter cover marking (b).



**Fully retard position:**

**5° ATDC**

- Turn the magneto control lever so that the fully retard screw (1) contacts the fully retard stopper (2).
- Check the timing indicator (c) so that it aligns with the marking (d) on the flywheel.



**4. Adjust:**

- Fully retard screw


**Adjustment steps:**

- Turn the flywheel clockwise until the dial gauge indicates that the piston position is at specified distance from TDC.



**Piston position:**

**0.12 mm (0.005 in) ATDC**



**Spark plug**


1. Inspect:

- Electrode ①  
Wear/Damage → Replace.
- Insulator color ②  
Distinctly different color → Check the engine condition.



**Color guide**

- Medium to light tan color:**  
Normal
- Whitish color:**Lean fuel mixture  
Plugged fuel mixture  
Air leak  
Wrong settings
- Blackish color:**Overly rich mixture  
Electrical malfunction  
Excess oil used  
Defective spark plug



2. Clean:

- Spark plug  
Clean the spark plug with a spark plug cleaner or wire brush.

3. Measure:

- Spark plug gap ①  
Out of specification → Alter gap.  
Use a wire gauge.



**Spark plug gap:**

**0.9 ~ 1.0 mm (0.035 ~ 0.039 in)**


4. Tighten:

- Spark plug



**Spark plug:**

**25 Nm (2.5 m · kg, 18 ft · lb)**




377-004

**NOTE:**

- Before installing a spark plug, clean the gasket surface and plug surface. Also it is suggested to apply a thin film of Anti Seize Compound to the spark plug threads to prevent future thread seizure.
- If a torque wrench is not available, a good estimate of the correct torque is a further 1/4 to 1/2 turns ② on finger tightened ① spark plug.



CARBURETOR REMOVAL  
EXPLODED DIAGRAM






**REMOVAL AND INSTALLATION CHART**

Step	Procedure/Part name	Q'ty	Service points
	<b>POWER UNIT REMOVAL</b>		Follow the left "Step" for removal.
1	Screw (with washer)	1	for remote model
2	Shift lever link	1	
3	Bushing	1	
4	Nut	1	
5	Throttle lever link	1	
6	Plane washer	1	
7	Wave washer	1	
8	Bushing	2	
9	Choke link rod	1	
10	Screw	1	
11	Acceleration rod	1	
12	Link joint	1	
13	Choke knob rod	1	
14	Bolt (with washer)	1	
15	Bolt (with washer)	1	
16	Control pulley bracket assembly	1	
17	Bolt (with washer)	1	
18	Engine stop switch lead	2	Except for remote model
19	Wire harness ground lead	1	for remote model
20	2P connector lead	2	for 2P connector model
21	Wire harness rectifier lead	4	for remote model
22	Wire harness starter relay lead	2	
23	Bolt (with washer)	1	Electrical starter model.
24	Nut	1	
25	Spring washer	1	
26	Battery cable	1	
27	Pilot water hose	1	
28	Fuel hose	1	
29	Bolt (with washer)	6	8 x 30 mm
30	Clip	1	
31	Plane washer	1	
32	Shift lever rod	1	
33	Engine unit	1	
34	Upper case gasket	1	
35	Dowel pin	2	
36	Collar	1	
			Reverse the removal steps for installation.





**FLYWHEEL MAGNETO AND MAGNETO BASE**  
EXPLODED DIAGRAM





**CYLINDER HEAD, THERMOSTAT AND EXHAUST COVER  
EXPLODED DIAGRAM**





**Piston to cylinder clearance**


1. Calculate:

- Piston clearance

Out of specification → Replace piston and piston ring and/or cylinder.

Piston clearance	=	Cylinder bore	-	Piston diameter
------------------	---	---------------	---	-----------------

	<b>Piston clearance:</b> 0.035 ~ 0.040 mm (0.0014 ~ 0.0016 in)
--	--




**Cylinder body and crankcase installation**

1. Install:

- Cylinder body
- Crankshaft and piston

**NOTE:**

- Align the piston ring end gaps with the respective locating pins.
- Fit the bearing locating pins in the cylinder body.



2. Apply:

- Gasket maker  
 Onto the connecting surfaces of the crankcase and cylinder body.

**NOTE:**






- Clean the connecting surfaces of the crankcase and cylinder body before applying the Gasket maker.
- Gasket maker should be so applied that it does not overflow the contacting surface.



**LOWR**



# PROPELLER SHAFT AND REVERSE GEAR



## SERVICE POINTS

### Propeller shaft housing removal

1. Remove:
  - Propeller shaft housing assembly

	<b>Bearing housing puller:</b>	
	YB-06234 .....	①
	90890-06503 .....	③
	<b>Universal puller:</b>	
	YB-06117 .....	②
	<b>Stopper guide plate:</b>	
	90890-06501 .....	④
	<b>Center bolt:</b>	
	90890-06504 .....	⑤

- A** For USA and CANADA  
**B** Except for USA and CANADA

### Propeller shaft housing disassembly

1. Remove:
  - Ball bearing ①

	<b>Slide hammer set:</b>	
	YB-06096 .....	②
	<b>Stopper guide plate:</b>	
	90890-06501 .....	③
	<b>Bearing puller:</b>	
	90890-06535 .....	④
	<b>Stopper guide stand:</b>	
	90890-06538 .....	⑤

- A** For USA and CANADA  
**B** Except for USA and CANADA

2. Remove:
  - Needle bearing

	<b>Driver rod:</b>	
	YB-06071/90890-06604	
	<b>Needle bearing attachment:</b>	
	YB-06081/90890-06616	




**Lower case inspection**

1. Clean:
  - Gear case  
Use a soft brush and solvent.
2. Inspect:
  - Water passage  
Mineral deposits/Corrosion → Clean.
3. Inspect:
  - Lower case  
Crack/Damage → Replace.

**Lower case assembly**


1. Install:
  - Forward gear shim ①
  - Forward gear bearing outer race ②



**Bearing installer:**  
YB-06085/90890-06625


**Driver rod:**  
YB-06071/90890-06605

2. Install:
  - Drive shaft needle bearing



**Depth (a):**  
17.8 mm (0.70 in)

**Depth (b):**  
172.7~173.2 mm (6.80~6.82 in)



**Bearing attachment:**

YB-06230 ..... ①

90890-06617 ..... ④

**Driver rod:**

YB-06229 ..... ②

90890-06602 ..... ⑤

**Driveshaft needle bearing  
depth stop:**

YB-06231 ..... ③

**Bearing depth plate:**

90890-06603 ..... ⑥


- A** For USA and CANADA
- B** Except for USA and CANADA



**SHIM SELECTION (EXCEPT FOR USA AND CANADA)**

**Pinion gear shim**

**NOTE:** \_\_\_\_\_  
 Find pinion gear shim thickness (T3) by selecting shims until the specified measurement is obtained with the special tool.  
 \_\_\_\_\_




1. Measure:
- Measurement (M)

	<b>Digital caliper:</b> <b>90890-06704</b>
---	---


**NOTE:** \_\_\_\_\_  
 Measure the thicknesses (Mv3) of bearing and washer.  
 \_\_\_\_\_


2. Calculate:
- Pinion gear shim thickness (T3)

	<b>Pinion gear shim thickness</b> <b>(T3) = 6.05 - Mv3 mm</b>
---	--

3. Select:
- Pinion gear shim

Calculated numeral		Using shim
more than	or less	
1.13	1.20	1.13
1.20	1.30	1.20

	<b>Available shim thickness:</b> <b>1.13 and 1.20 mm</b>
---	---

**LOWR****SHIMMING****Measuring steps:**

- Set the shift shaft in the reverse position.
- Load the reverse gear by installing the propeller with the front side facing backward, and tighten the propeller nut.

**Propeller nut:**

**5 Nm (0.5 m • kg, 3.6 ft • lb)**

- Attach the backlash indicator on the drive shaft (12.8 mm in diameter).

**Backlash indicator:**

**YB-06265/90890-06706**

- Attach the dial gauge on the lower case, and make the dial gauge stem contact the mark on the indicator.

**Backlash adjusting plate:**

**YB-07003**

**Dial gauge:**

**YU-03097/90890-01252**

**Magnet base:**

**YU-34481/90890-06705**


- While pulling the drive shaft, slowly turn the drive shaft clockwise and counterclockwise; then, measure the backlash when the drive shaft stops at each direction.

**2. Adjust:**

- Reverse gear shim(s)

**NOTE:**


Adjust the shim(s) to be added or removed according to specification.

 Reverse gear backlash	Shim thickness
Less than 0.95 mm	To be decreased by (1.30 - measurement) 2.1
More than 1.65 mm	To be increased by (measurement - 1.30) 2.1
<b>Available shim thickness:</b> <b>0.10, 0.20, 0.30, 0.40 and 0.50 mm</b>	




# BOTTOM COWLING

## BOTTOM COWLING EXPLODED DIAGRAM





STEERING AND SWIVEL BRACKET  
EXPLODED DIAGRAM





# TROUBLE ANALYSIS

## TROUBLE ANALYSIS

**NOTE:**

Following items should be obtained before "trouble analysis".

1. Battery is charged and its specified gravity is in specification.
2. There is no incorrect wiring connection.
3. Wiring connections are surely engaged and without any rust.
4. Lanyard is installed to the engine stop switch.
5. Shift position is in neutral.
6. Fuel is coming to the carburetor.
7. Correct rigging and engine setting are obtained.
8. Engine is free from any "Hull problem".

## TROUBLE ANALYSIS CHART

Trouble mode											Check elements		
ENGINE WILL NOT START	ROUGH IDLING	ENGINE STALLS	ENGINE WILL NOT STOP	POOR PERFORMANCE	OVERHEATING	LOOSE STEERING	HARD SHIFTING	POOR BATTERY CHARGING				Relative part	Reference Chapter
<b>FUEL SYSTEM</b>													
<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>								Fuel hose	4
<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>								Fuel joint	4
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		<input type="checkbox"/>								Fuel filter	4
<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>								Fuel pump	4
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		<input type="checkbox"/>								Carburetor	4
		<input type="checkbox"/>		<input type="checkbox"/>	<input type="checkbox"/>							Pilot screw setting	4
		<input type="checkbox"/>		<input type="checkbox"/>								Idle speed	3
<b>POWER UNIT</b>													
<input type="checkbox"/>	<input type="checkbox"/>			<input type="checkbox"/>								Compression	5
<input type="checkbox"/>	<input type="checkbox"/>			<input type="checkbox"/>								Reed valve	5
<input type="checkbox"/>	<input type="checkbox"/>											Cylinder head gasket	5
<input type="checkbox"/>				<input type="checkbox"/>								Seal	5
<input type="checkbox"/>				<input type="checkbox"/>								Cylinder body	5
<input type="checkbox"/>				<input type="checkbox"/>								Piston ring	5
<input type="checkbox"/>				<input type="checkbox"/>								Crank case	5
<input type="checkbox"/>												Piston	5
	<input type="checkbox"/>			<input type="checkbox"/>								Control unit adjustment	3
				<input type="checkbox"/>								Bearing	5
					<input type="checkbox"/>							Thermostat	5
					<input type="checkbox"/>							Water passage	5