

## HOW TO USE THIS MANUAL

### MANUAL FORMAT

All of the procedures in this manual are organized in a sequential, step-by-step format. The information has been compiled to provide the mechanic with an easy to read, handy reference that contains comprehensive explanations of all disassembly, repair, assembly, and inspection operations.

In this revised format, the condition of a faulty component will precede an arrow symbol and the course of action required will follow the symbol, e.g.,

- Bearings  
Pitting/Damage → Replace.

To assist you to find your way about this manual, the Section Title and Major Heading is given at the head of every page.

An Index to contents is provided on the first page of each Section.

### MODEL INDICATION

Multiple models are shown in this manual. These indications are noted as follows.

Model name	40VMH	40VMHD	40VMHO	40VMO	40VWH	40VE	40VEO	40VEHTO	40VET
USA and CANADA name	C40MH		40MH			C40ER	40ER	P40TH	C40TR
Indication	40VMH	40VMHD	40VMHO	40VMO	40VWH	40VE	40VEO	40VEHTO	40VET
Model name	40VETO	50HMHO	50HMHD	50HMO	50HMDO	50HWHD	50HEDO	50HET	50HETO
USA and CANADA name	40TR						50ER	C50TR	50TR
Indication	40VETO	50HMHO	50HMHD	50HMO	50HMDO	50HWHD	50HEDO	50HET	50HETO

### THE ILLUSTRATIONS

Some illustrations in this manual may differ from the model you have. This is because a procedure described may relate to several models, though only one may be illustrated. (The name of model described will be mentioned in the description).

### REFERENCES

These have been kept to a minimum; however, when you are referred to another section of the manual, you are told the page number to go to.


A80000-0\*

**SPECIAL TOOLS**

The use of correct special tools recommended by Yamaha will aid the work and enable accurate assembly and tune-up. Improvisations and use of improper tools can cause damage to the equipment.

**NOTE:**

- For U.S.A. and Canada, use part number starting with "YB-", "YU-" or "YW-".
- For others, use part number starting with "90890-".





**MAINTENANCE SPECIFICATIONS  
ENGINE**

Item	Unit	Model	
		40 hp	50 hp
<b>CYLINDER HEAD:</b> Warpage limit	mm (in)	0.1 (0.004)	
<b>CYLINDER:</b> Bore size	mm (in)	67.00 ~ 67.02 (2.638 ~ 2.639)	
Wear limit	mm (in)	67.10 (2.642)	
Taper limit	mm (in)	0.08 (0.003)	
Out of round limit	mm (in)	0.05 (0.002)	
<b>PISTON:</b> Identification mark	mm (in)	W	
Piston clearance	mm (in)	0.060 ~ 0.065 (0.0024 ~ 0.0026)	
Limit	mm (in)	0.115 (0.0045)	
Diameter D	mm (in)	66.940 ~ 67.000 (2.6354 ~ 2.6378)	
Measuring point H	mm (in)	10 (0.4)	
Pin boss inside diameter	mm (in)	18.008 ~ 18.015 (0.7090 ~ 0.7093)	
Ring groove clearance (installed)	mm (in)		
top	mm (in)	0.04 ~ 0.08 (0.002 ~ 0.003)	
2nd	mm (in)	0.03 ~ 0.07 (0.001 ~ 0.003)	
Over size piston	mm (in)		
Diameter	mm (in)		
1st*1	mm (in)	67.25 (2.648)	
2nd	mm (in)	67.50 (2.657)	
<b>PISTON PIN:</b> Diameter	mm (in)	17.995 ~ 18.000 (0.7085 ~ 0.7087)	
<b>PISTON RING (1st):</b> Type	mm (in)	Keystone	
Dimensions (B × T)	mm (in)	2.0 × 2.6 (0.08 × 0.10)	
End gap (installed)	mm (in)	0.40 ~ 0.60 (0.016 ~ 0.024)	
Limit	mm (in)	0.80 (0.031)	
<b>PISTON RING (2nd):</b> Type	mm (in)	Keystone	
Dimensions (B × T)	mm (in)	2.0 × 2.6 (0.08 × 0.10)	
End gap (installed)	mm (in)	0.40 ~ 0.60 (0.016 ~ 0.024)	
Limit	mm (in)	0.80 (0.031)	
<b>CONNECTING ROD:</b> Small end diameter	mm (in)	22.005 ~ 22.008 (0.8663 ~ 0.8665)	
<b>CRANK SHAFT ASSEMBLY:</b> Crank width A	mm (in)	53.90 ~ 53.95 (2.122 ~ 2.124)	
Crank width B	mm (in)	32.88 ~ 33.10 (1.294 ~ 1.303)	
Runout limit D	mm (in)	0.03 (0.001)	
Big end side clearance E	mm (in)	0.20 ~ 0.70 (0.008 ~ 0.028)	
Small end axial play limit F	mm (in)	2.0 (0.08)	


\*1: Except for U.S.A.

## MAINTENANCE INTERVAL CHART

The following chart should be considered strictly as a guide to general maintenance intervals. Depending on operating conditions, the intervals of maintenance should be changed.

Item	Remarks	Initial		Every		Refer page
		10 hours (Break-in)	50 hours (3 months)	100 hours (6 months)	200 hours (1 year)	
<b>COWLING:</b>						
Cowling clamp	Inspection				○	—
<b>FUEL SYSTEM:</b>						
Fuel line	Inspection	○		○	○	3-2
Fuel filter	Cleaning	○	○	○		4-3
Carburetor	Cleaning	○	○	○		4-9
<b>POWER UNIT:</b>						
Water leakage	Inspection	○	○	○		—
Motor exterior	Inspection	○	○	○		—
Exhaust leakage	Inspection	○	○	○		—
Cooling water passage	Cleaning		○	○		—
<b>CONTROL SYSTEM:</b>						
Throttle link	Inspection/Adjustment				○	3-2
Throttle cable	Inspection/Adjustment				○	3-3
Shift cable	Inspection/Adjustment				○	3-4
Start-in-gear projection	Inspection/Adjustment	○		○		3-5
Idle speed	Inspection/Adjustment	○		○		3-5
<b>OIL INJECTION SYSTEM:</b>						
Oil tank water drain hose	Cleaning	○	○	○		3-6
Oil pump link	Inspection/Adjustment	○		○		3-6
<b>POWER TRIM AND TILT SYSTEM:</b>						
Power trim and tilt fluid	Inspection	○	○	○	○	3-7
<b>LOWER UNIT:</b>						
Gear oil	Change	○		○		3-8
Lower unit leakage	Inspection				○	3-8
Propeller	Inspection	○	○	○		6-2
<b>GENERAL:</b>						
Anode	Inspection		○	○		3-9
Battery	Inspection	○	○	○		3-9
Spark plug	Cleaning/Adjustment/ Replacement	○	○	○		3-10
Wiring and connector	Adjustment/Reconnect	○	○	○		—
Bolts and nuts	Retightening	○	○	○		—
Grease points	Greasing			○		3-11

CARBURETOR  
EXPLODED DIAGRAM






**REMOVAL AND INSTALLATION CHART**

Step	Procedure/Part name	Q'ty	Service points
	<b>CARBURETOR DISASSEMBLY</b>		Follow the left "Step" for removal. Refer to "CARBURETOR REMOVAL".
1	Drain screw	1	
2	O-ring	1	
3	Screw (with washer)	3	4 × 14 mm
4	Carburetor cover	1	
5	Cover packing	1	
6	Pilot adjusting screw	1	<b>CAUTION:</b> _____ <b>Do not damage the tip of the pilot screw by over-tighten it.</b>
7	Spring	1	
8	Stopping screw	1	} Middle carburetor only
9	Spring	1	
10	Screw (with washer)	4	4 × 14 mm
11	Float chamber	1	
12	Float chamber packing	1	
13	Screw	1	4 mm
14	Arm pin	1	
15	Float	1	<b>NOTE:</b> _____ The float is removed together with the needle valve and the clip.
16	Needle valve	1	
17	Needle valve clip	1	
18	Valve seat	1	
19	O-ring	1	
20	Main jet	1	
21	Main nozzle	1	
22	Cap	1	
23	Pilot jet	1	
24	Carburetor body	1	
			Reverse the removal steps for installation.




**OIL LINE LAYOUT**

- ① Electrothermal valve (EM, E model)
- ② Oil level sensor
- ③ Oil drain hose
- ④ Oil tank
- ⑤ Oil pump





**REED VALVE AND CHECK VALVE  
EXPLODED DIAGRAM**











**Piston ring inspection**

1. Inspect:

- Piston ring  
Breakage/Damage → Replace.



2. Measure:

- End gap  
Use a feeler gauge.  
Out of specification → Replace.

**End gap:**  
**Top: 0.40 ~ 0.60 mm**  
 (0.016 ~ 0.024 in)  
**2nd: 0.40 ~ 0.60 mm**  
 (0.016 ~ 0.024 in)  
**End gap limit:**  
**Top: 0.80 mm (0.031 in)**  
**2nd: 0.80 mm (0.031 in)**  
**Measuring point**  
**20 mm (0.8 in)**


**NOTE:** \_\_\_\_\_  
 Install the piston ring into the cylinder. Push the ring with the piston crown.



3. Measure:

- Side clearance  
Use a thickness gauge.  
Out of specification → Replace piston and/or ring.

**Side clearance:**  
**Top: 0.04 ~ 0.08 mm**  
 (0.002 ~ 0.003 in)  
**2nd: 0.03 ~ 0.07 mm**  
 (0.001 ~ 0.003 in)

**LOWER UNIT REMOVAL  
EXPLODED DIAGRAM**





3. Install:

- Pinion gear shim
- Drive shaft bearing outer race



**Bearing installer:**  
 YB-06110/90890-06627 ..... ①  
**Driver rod:**  
 YB-06071/90890-06606 ..... ②

Drive shaft oil seal housing assembly

1. Install:



- Oil seal ①



**Depth ①:**  
 0.0 ~ 0.5 mm (0.00 ~ 0.02 in)



**Bearing installer:**  
 YB-06167/90890-06628  
**Driver rod:**  
 YB-06071/90890-06605



Forward gear assembly

1. Install:



- Forward gear
- Taper roller bearing



**Bearing installer:**  
 YB-06270-A ..... ①  
 90890-06640 ..... ②

Ⓐ For USA and CANADA

Ⓑ Except for USA and CANADA



Pinion nut installation

1. Install:

- Pinion nut



**Drive shaft holder:**  
 YB-06079/90890-06517 ..... ①  
**Pinion nut wrench:**  
 90890-06505 ..... ②  
**Socket adapter:**  
 90890-06506 ..... ③




**REMOVAL AND INSTALLATION CHART**

Step	Procedure/Part name	Q'ty	Service points
	<b>TILLER HANDLE REMOVAL</b>		Follow the left "Step" for removal.
1	Bolt	2	Steering friction model
2	Clamp	1	E model
3	Screw	1	Steering friction model
4	Bolt	1	
5	Collar	1	
6	Clamp	1	
7	Bolt	1	M model
8	Engine stop switch lead (black)	1	
9	Engine stop switch coupler (blue)	1	
10	Main switch lead coupler	1	E model
11	Oil level sensor lead coupler	1	EHTO/TH model
12	Trim sensor lead coupler	1	
13	Extension wire lead coupler	1	
14	Clip	1	
15	Shift cable	1	
16	Clip	1	
17	Throttle cable	1	
18	Bolt	2	
19	Fitting plate ass'y	1	<p><b>NOTE:</b> _____</p> <p>When installing the fitting plate, lift the tiller handle straight up.</p> <p>_____</p>
20	Clamp	1	M model
21	Engine stop switch lead	1	
22	Main switch lead	1	<p><b>NOTE:</b> _____</p> <p>Align the taped end of the battery cable and the extension wire lead with the end of the grommet.</p> <p>_____</p>
23	Extension wire lead	1	
24	Nut	2	
25	Tiller handle ass'y	1	
	<b>STEERING FRICTION DISASSEMBLY</b>		
①	Bolt (with washer)	2	
②	Plane washer	2	
③	Friction plate ass'y	1	
④	Collar	2	
⑤	Nut	2	
			Reverse the removal steps for installation.



**REMOVAL AND INSTALLATION CHART**

Step	Procedure/Part name	Q'ty	Service points
	<b>CLAMP BRACKET REMOVAL (Manual tilt)</b>		Follow the left "Step" for removal.
	Upper case ass'y		Refer to "UPPER CASE REMOVAL".
1	Spring	1	
2	Circlip	1	
3	Plane washer	2	
4	Tilt stop lever	1	
5	Pin	1	
6	Tilt pin	1	
7	Grease nipple	1	
8	Lead wire	1	
9	Nut	1	
10	Plane washer	1	
11	Bolt	1	
12	Collar	1	
13	Cap	2	
14	Self lock nut	1	
15	Clamp bracket plate	1	
16	Clamp bracket 2 ass'y	1	
17	Plane washer	1	
18	Shallow water drive lever	1	*: Shallow water drive model
19	Spring	1	
20	Tilt lever	1	
21	Swivel bracket ass'y	1	
22	Plane washer	1	
23	Clamp bracket 1 ass'y	1	
24	Clamp bracket bolt	1	
25	Self lock nut	1	
26	Bushing	2	
	<b>CLAMP BRACKET DISASSEMBLY</b>		
①	Circlip	1	
②	Plane washer	1	
③	Clamp bracket plate	1	
④	Wave washer	1	
⑤	Pin	1	
⑥	Circlip	1	
⑦	Plane washer	1	
⑧	Wave washer	1	
⑨	Clamp bracket plate	1	
⑩	Pin	1	
			Reverse the removal steps for installation.




### Inner cylinder assembly

1. Fill:
  - ATF (Dexiron type II) to inner cylinder.

#### NOTE:


Depress the tilt rod fully and fill the inner cylinder with ATF before installing the end screw.



2. Tighten:
  - Inner cylinder end screw



**Tilt cylinder wrench:**  
YB-06175-2B/90890-06544




### Tilt cylinder assembly


1. Install:
  - Ball ①
  - Tilt cylinder ②

#### NOTE:

- Apply the grease to the balls to prevent them from falling down.
- To find any ball that may fall, turn the inner cylinder unit upside down to install the tilt cylinder.




2. Fill:
  - ATF (Dexiron type II) to tilt cylinder.



3. Tighten:
  - Tilt cylinder end screw



**Tilt cylinder wrench:**  
YB-06175-2B/90890-06544



**ELECTRICAL UNIT COMPONENTS  
E, EO MODEL**

- ① Starter motor
- ② Rectifier regulator
- ③ Ignition coil
- ④ Fuse
- ⑤ Starter relay
- Ⓐ Bracket
- Ⓑ Ground terminal

- B : Black
- Br : Brown
- B/O : Black/Orange
- B/W : Black/White
- B/Y : Black/Yellow
- L : Blue
- O : Orange
- O/G : Orange/Green
- P : Pink
- Y/R : Yellow/Red
- W : White

