



Table of Contents

	Section	
Introduction	i	■
Engine and System Identification	E	■
Operating Instructions	1	■
Maintenance Guidelines	2	■
Maintenance Procedures at Daily Interval	3	■
Maintenance Procedures at 250 Hours or 3 Months	4	■
Maintenance Procedures at 500 Hours or 6 Months	5	■
Maintenance Procedures at 1000 Hours or 1 Year	6	■
Maintenance Procedures at 2000 Hours or 2 Years	7	■
Maintenance Procedures at 4000 Hours or 3 Years	8	■
Maintenance Procedures at 5000 Hours or 4 Years	9	■
Adjustment, Repair, and Replacement	A	■
System Diagrams	D	■
Service Literature	L	■
Service Assistance	S	■
Troubleshooting Symptoms	TS	■
Maintenance Specifications	V	■
Warranty	W	■
Back	back	■




NOTE: If the engine dataplate (1) is **not** legible, the engine serial number (2) can be identified on the engine block. It is located on the exhaust side, next to the rear gear housing. Additional engine information is available by reading the engine control module (ECM) dataplate.



Cummins® Engine Nomenclature

The Cummins® Service Engine Model Identification procedure describes how to use the Cummins® Service Model Name to identify an engine. Refer to Procedure 100-005 in Section E.

The Cummins® Product Technology procedure provides the Cummins® Service Model Name and describes the unique technology used by the engine covered by this manual. Refer to Procedure 100-006 in section E.




Fuel Pump Dataplate

The Denso™ fuel pump dataplate is located on the fuel pump. This dataplate contains the following information to assist in servicing or replacement:


- 1 Customer part number
- 2 Denso™ part number
- 3 Production month serial number
- 4 Customer's certification number
- 5 QR code.

Engine Control Module Dataplate



Engine Diagrams

General Information



Rear View

00r00016


- 1 Rear engine lifting bracket
- 2 EGR crossover tube
- 3 Exhaust pressure regulator
- 4 Exhaust manifold
- 5 EGR coolant outlet tube
- 6 Alternator
- 7 EGR cooler
- 8 EGR coolant inlet tube
- 9 Flywheel housing
- 10 Flywheel
- 11 Lubricating oil dipstick
- 12 Intake air connection
- 13 Wiring harness
- 14 ECM
- 15 EGR valve.

SCR System Cleaning Inhibited Lamp

The SCR SYSTEM CLEANING DISABLED (INHIBIT) LAMP indicates that the inhibit switch is active, therefore automatic and manual (non-mission) SCR/exhaust system cleaning can **not** occur.

An illuminated SCR SYSTEM CLEANING DISABLED (INHIBIT) lamp indicates that the inhibit switch is active and automatic or manual (non-mission) SCR/exhaust system cleaning will **not** occur. This can be corrected by switching the inhibit switch to permit mode. Refer to Procedure 101-050 in Section 1.

NOTE: The OEM determines whether or **not** the HIGH EXHAUST SYSTEM TEMPERATURE lamp is installed on the vehicle. The OEM also specifies the temperatures, vehicle speeds, and other conditions at which the lamp illuminates. See equipment manufacturer information for additional information regarding this lamp.



Engine Operating Range

General Information

⚠ CAUTION ⚠

Do not operate the engine at full throttle below peak torque rpm (refer to engine data plate for peak torque rpm) for more than 30 seconds. Operating the engine at full throttle below peak torque will shorten engine life to overhaul, can cause serious engine damage, and is considered engine abuse.



Cummins® engines are designed to operate successfully at full throttle under transient conditions down to peak torque engine speed. This is consistent with recommended operating practices.

⚠ CAUTION ⚠

Do not operate the engine beyond the maximum engine speed. Operating the engine beyond the maximum engine speed can cause severe engine damage. Use proper operating techniques for the vehicle, vessel, or equipment to prevent engine overspeed. The maximum engine speed specification is listed in Maintenance Specifications (Section V).


⚠ CAUTION ⚠

Do not idle the engine for excessively long periods. Long periods of idling, more than 10 minutes, can cause poor engine performance.



Fill the cooling system with coolant. Refer to the markings on the radiator or expansion tank for coolant levels or refer to the OEM manual.

NOTE: Some radiators have two fill necks, both of which **must** be filled when the cooling system is drained.




Fan, Cooling


Inspect for Reuse

⚠ WARNING ⚠

Do not rotate the engine by pulling or prying on the fan. The fan blade(s) can be damaged and cause the fan to fail and cause personal injury or property damage. Use the accessory drive shaft or the crankshaft barring tool to rotate the crankshaft.




A visual inspection of the cooling fan is required daily. Check for cracks, loose rivets, and bent or loose blades. Check the fan to make sure it is securely mounted. Tighten the capscrews, if necessary.




⚠ WARNING ⚠

Do not straighten a bent fan blade or continue to use a damaged fan. A bent or damaged fan blade can fail during operation and cause personal injury or property damage.




Check the location of the drive belt on the belt tensioner pulley. The belt should be centered on, or close to the middle of, the pulley. Misaligned belts, either too far forward or backward, can cause belt wear, belt roll-off malfunctions, or increase uneven tensioner bushing wear.



Remove the drive belt. Refer to Procedure 008-002 in Section A.

With the belt removed, verify the tensioner arm stop is in contact with the spring case stop. If they are **not** touching, the tensioner **must** be replaced.




Preparatory Steps

⚠ WARNING ⚠


Batteries can emit explosive gases. To reduce the possibility of personal injury, always ventilate the compartment before servicing the batteries. To reduce the possibility of arcing, remove the negative (-) battery cable first and attach the negative (-) battery cable last.


- Disconnect the batteries. See equipment manufacturer service information.
- Remove the drive belt. Refer to Procedure 008-002 in Section A.



Remove

Remove the capscrew and belt tensioner from the bracket.





⚠ CAUTION ⚠

Before topping off the cooling system, allow the system temperature to cool to ambient. This will allow an adequate amount of coolant to be available to the water pump during all periods of operation.

⚠ CAUTION ⚠

Engine and component damage may result if adequate cool down time is not given after the cooling system pressure has been relieved in order to top off with coolant. System pressure is only generated with the temperature rise of the coolant. Closing the cooling system while hot will not allow for pressure to build.


⚠ CAUTION ⚠

Do not use water alone for coolant. Damage from corrosion can severely damage the engine cooling system.

Use a mixture of 50-percent water and 50-percent ethylene glycol or propylene glycol antifreeze to fill the cooling system.

Reference the Cummins® Coolant Requirements and Maintenance, Bulletin 3666132, for engine coolant specifications.

Use the following procedure for cooling system capacity. Refer to Procedure 018-018 in Section V.



⚠ WARNING ⚠

Do not remove the pressure cap from a hot engine. Wait until the coolant temperature is below 50°C [122°F] before removing the pressure cap. Heated coolant spray or steam can cause personal injury.


⚠ WARNING ⚠

Do not remove the pressure cap from a hot engine. Wait until the coolant temperature is below 50°C [122°F] before removing the pressure cap. Heated coolant spray or steam can cause personal injury.

Install the pressure cap.

Operate the engine until it reaches a temperature of 80°C [176°F] and check for coolant leaks.

Check the coolant level again to make certain the system is full of coolant or that the coolant level has risen to the hot level in the recovery/expansion tank in the system, if equipped.



Finishing Steps

⚠ WARNING ⚠

Batteries can emit explosive gases. To reduce the possibility of personal injury, always ventilate the compartment before servicing the batteries. To reduce the possibility of arcing, remove the negative (-) battery cable first and attach the negative (-) battery cable last.

- Install the drive belt. Refer to Procedure 008-002 in Section A.
- Connect the batteries. See equipment manufacturer service information.
- Operate the engine to check for proper operation.

Starting Motor



Rotation Check

If the starter solenoid is making a sound, but the engine is **not** rotating, turn the keyswitch to the OFF position, and attempt to bar the crankshaft in both directions.

Bar the engine with barring tool, Cummins® Part Number 3824591.

If the crankshaft will bar over, attempt to start the engine. If the starter motor cranks the engine, check the starter motor pinion gear and flywheel ring gear for damage.

If damage to the starter motor pinion gear and/or flywheel ring gear is found when replacing the components, make sure to measure the distance from the starting motor mounting flange to the forward face of the front side of the flywheel ring gear. Follow the measure step of this procedure.



If the crankshaft does **not** rotate or requires more than the normal effort to bar, check for an internal malfunction or a problem with the drive unit and/or accessories.

13. Termination of License Agreement

a. Cummins may terminate this agreement for cause, such cause including, but not limited to, supporting, diagnosing, repairing, modifying or the maintenance of Cummins engines or any component thereof when such activities are not authorized by the owner of such engines.

b. In the event of termination of this License Agreement, all rights granted by this License Agreement shall revert to Cummins. Upon termination of this License Agreement, Licensee will deliver to Cummins all DVD-ROM Material and other material furnished by Cummins pertaining to the Licensed Software or certify that all such materials have been destroyed.

c. In the event of termination of this License Agreement, Licensee and Cummins shall remain obligated with respect to the provisions of this License Agreement relating to confidentiality of information.

14. Completeness

Licensee and Cummins agree that this License Agreement constitutes the complete agreement and understanding between the parties relating to Licensed Software and Upgrades thereto. This License Agreement supersedes all prior agreements, understandings, and negotiations whether written or verbal with respect to the subject matter hereof. This License Agreement can only be modified by a written agreement signed by both parties.

15. Notices

Any questions concerning this License Agreement, any inquiries related to the Licensed Software, and any notices to Cummins pursuant to this License Agreement should be directed to Cummins Inc., Electronic Publications Support, MC 95030, 1460 National Road, Columbus, IN 47201. Cummins Inc. may direct that notices be sent to a different person and/or address by so requesting in writing to the other party.

16. Export Regulations

Licensee understands that the Export Administration Regulations of the Department of Commerce of the United States may prohibit the export of the Licensed Software to certain countries and agrees to conform to those regulations. Licensee also agrees to conform to these regulations. Licensee shall indemnify Cummins against any loss related to Licensee's failure to conform to those regulations.

17. Governing Law

This License Agreement shall be governed by and construed in accordance with the laws of the State of Indiana.

18. Attorneys' Fees

In the event of any legal action or other proceeding that is brought about to enforce this License Agreement, the prevailing or successful party shall be entitled to recover reasonable attorneys' fees as well as other costs incurred in that action or proceeding in addition to any compensation to which it may be entitled.

19. License Agreement Successors and Assigns

This License Agreement is not assignable by Licensee without the prior written consent of Cummins, and any assignment by Licensee in contravention of this provision shall be void and without effect. The terms and conditions of this License Agreement shall inure to the benefit of and be enforceable by Cummins and the successors and assigns of Cummins' interest in this License Agreement and/or Cummins' ownership of the Licensed Software.

Illinois	Madison	Cummins Mid-South, LLC 222 SR-203 Madison, Illinois 62060 Telephone: (618) 798-9512 FAX: (618) 798-9521
Illinois	Rock Island	Cummins Central Power, LLC 7820 - 42nd Street West Rock Island, IL 61201 Telephone: (309) 787-4300 FAX: (309) 787-4397
Indiana	Indianapolis	Cummins Mid-States Power, Inc. P.O. Box 42917 3762 West Morris Street Indianapolis, IN 46242-0917 Telephone: (317) 243-7979 FAX: (317) 240-1925
Indiana		Cummins Mid-States Power, Inc. P.O. Box 42917 3661 West Morris St Indianapolis, IN 46241 Telephone: (317) 486-5287 FAX: (317) 486-5281
Indiana		Cummins Mid-States Power, Inc. 4301 W. Morris St. 3762 West Morris Street Indianapolis, IN 46241 Telephone: (317) 240-1967 FAX: (317) 240-1975
Indiana	Evansville	Cummins Cumberland, Inc. 7901 Highway 41 North Evansville, IN 47725 Telephone: (812) 867-4400 FAX: (812) 867-4411
Indiana	Ft. Wayne	Cummins Mid-States Power, Inc. 3415 Coliseum Blvd. West (At Jct. I-69 & 30/33) Ft. Wayne, IN 46808 Telephone: (219) 482-3691 FAX: (219) 484-8930
Indiana	Gary	Cummins Northern Illinois, Inc. 1440 Texas Street Gary, IN 46402 Telephone: (219) 885-5591 FAX: (219) 883-4817
Indiana	Indianapolis	Cummins Mid-States Power, Inc. 3661 West Morris St Indianapolis, IN 46241 Telephone: (317) 486-5287 FAX: (317) 486-5281
Iowa	Cedar Rapids	Cummins Central Power, LLC 625 - 33rd Avenue SW Cedar Rapids, IA 52404 Telephone: (319) 366-7537 (24 hours) FAX: (319) 366-7562

Distributors and Branches - China, People's Republic

	Beijing	Cummins Engine (Beijing) Co., Ltd. No. 8, Wan Yuan Street, Beijing Economic and Technology Development Zone, Beijing, 100176, People's Republic of China. Telephone: (86-10) 67882258 Fax: (86-10) 67882285
	Shenyang	Cummins Engine (China) Investment Co., Ltd. ShenYang Workshop & Branch Office. No.5-2 Seventh Street, Shenyang Economic-Technological Development Area, Shenyang, Liaoning 110141, China. Telephone: (86-24) 25506611 Fax: (86-24) 25365599
	Kunming	Cummins (China) Investment Co. Ltd. Kunming Branch. Room 606, Hongta Mansion, No.155 Beijing Road, Kunming, Yunnan 650011, Telephone: (86-871) 3579471/511/579/958 Fax: (86-871) 3579210
	Shanghai	Cummins (China) Investment Co., Ltd. Shanghai Distributor Branch. No. 581, New jin Qiao Road, Pu Dong New Area, Shanghai, Shanghai 201206, China. Telephone: (86-21) 50318966 Fax: (86-21) 50318528
	Urumqi	Cummins Engine (China) Investment Co., Ltd Urumqi Branch. No.7, Shanghai Rd. Urumqi, Xinjiang 830011, China. Telephone: (86-991) 3780332/5/6/7/8/9 Fax: (86-991) 3780334
	Wuhan	Cummins Engine (China) Investment Co., Ltd. Wuhan Branch. No.2 Zhang Po Road, Dong Xi Hu District, A-Kaili Commercial Building, Wuhan, Hubei 430040, China. Telephone: (86-27) 83081677 Fax: (86-27) 83259369 / 83259370
	Guangzhou	Cummins (China) Investment Co., Ltd. Guangzhou. Branch G/F, Unit 1 & 2, Block 5, Xing Hui Yuan, NO. 46, Jinsui Road, Zhu Jiang New City, Guangzhou, Guangdong 510623, China. Telephone: (86-20) 38621009 Fax: (86-20) 38621144

SPANISH GUINEA	- See Spain	Cummins Ventas y Servicio S. A.Torrelaguna, 56 Madrid 28027Spain Telephone: (34-91) 367 20 00 / 367 24 04Fax: (34-91) 407 66 04,
SRI LANKA	Colombo	Trade Promoters Ltd 272/25, Sudharshana MawathaMalabe Sri Lanka Telephone: (94-11) 2413002Fax: (94-11) 5550034,
SUDAN	- See Middle East Regional Office - United Arab Emirates	United Arab EmiratesCummins Middle East FZEUnits ZF 5/6Jebel Ali Free ZoneP.O.Box No 17636DubaiUnited Arab EmiratesTelephone: (971-4) 883 8998Fax: (971-4) 883 7971,
SURINAM		Cummins Power South, LLC9900 N W 77th Ave.Hialeah Gardens, FL 33016 Telephone: (305) 821-4200Fax: (305) 557-2992,
SWAZILAND	- See South Africa	Cummins Diesel South Africa (Pty) Ltd13 Eastern Service RoadKelvin (Neighbourhood), AlexandraGauteng, South AfricaZIP / Postal Code: 2054South AfricaTelephone: (27-11) 321 8700Fax: (27-11) 444 2012,
SWEDEN	Stockholm	Cummins Sweden Maskingata 17CBrista IndustriomadeMärsta, Stockholm 195 60Sweden Telephone: (46-8) 595 133 90Fax: (46-8) 595 133 99,
SWITZERLAND	Regensdorf	AKSA Wurenlos AGGrosszelgstrasse 15Wuerenlos CH-5436Switzerland Telephone: (41-1) 436 77 00Fax: (41-56) 436 77 19,
SYRIA	Damascus	Puzant Yacoubian & Sons Yacoubian BuildingAbou Baker El Saddik StreetDamascusSyriaTelephone: (963-11) 212 8600Fax: (963-11) 212 8611,
TAHITI, ISLAND OF	- See French Polynesia	Cummins MerCruiser Diesel245 Brisbane RoadBiggera Waters, Queensland 4216AustraliaTelephone: (61-7) 5500 9060Fax: (61-7) 5500 9070,
TAIWAN		Cummins Taiwan Pte. Ltd.No.49 Ting Hu RoadTkuei Shan HsiangTaoyuan, Taiwan 104TaiwanTelephone: (886-3) 211-5160Fax: (886-2) 211-4158,
TANZANIA	- See South African Regional Office - Kelvin, South Africa	Cummins Diesel South Africa (Pty) Ltd13 Eastern Service RoadKelvin (Neighbourhood), AlexandraGauteng, South AfricaZIP / Postal Code: 2054South AfricaTelephone: (27-11) 321 8700Fax: (27-11) 444 2012,
THAILAND	Bangkok	DKSH (Thailand) Ltd1696 New Petchburi Road Bangkok 10310Thailand Telephone: (66-2) 254-4900 / 454-2173Fax: (66-2) 253-5560 / 652-9417 / 8 / 9,
TOGO (and BENIN)	Lome	TOGOMAT s.a.Zone Industrielle CNPPMELomeTogo Telephone: (228) 2272395Fax: (228) 2270310,
TONGA, ISLAND OF	-See SOUTH PACIFIC ISLANDS	(Please contact) Cummins2 Caribbean DriveScoresby 3179VictoriaAUSTRALIATelephone: (61-3) 9765-3222Fax: (61-3) 9763-0079,
TRINIDAD and TOBAGO		Cummins Power South, LLC 9900 N W 77th Ave.Hialeah Gardens, FL 33016 Telephone: (305) 821-4200Fax: (305) 557-2992,

Engine Shuts Off Unexpectedly or Dies During Deceleration

Cause

Correction

STEP 1
Engine will **not** restart

Refer to the Engine Difficult to Start or Will **Not** Start troubleshooting symptom tree in Section TS.

OK
Go To Next Step

STEP 2
Fuel level is low in the tank

Fill the supply tank. Refer to equipment manufacturer service information.

OK
Go To Next Step

STEP 3
Electronic fault codes are active or high counts of inactive fault codes

Review instructions for reading active fault codes.

OK
Go To Next Step

STEP 4
Idle Shutdown or power takeoff (PTO) Shutdown features are activated

Check the time limit on Idle Shutdown and PTO Shutdown features with an electronic service tool. Refer to Procedure 101-007 in Section 1.

OK
Go To Next Step

STEP 5
Moisture in the wiring harness connectors

Dry the connectors with electrical contact cleaner, Part Number 3824510.

OK
Go To Next Step

STEP 6
OEM engine protection system is malfunctioning

Isolate the OEM engine protection system. Follow the OEM service manual instructions to check for a malfunction.

OK
Go To Next Step

STEP 7
Battery voltage supply to the engine control module (ECM) is low, interrupted, or open

Check the battery connections, the fuses, and the unswitched battery supply circuit. Refer to equipment manufacturer service information.

OK
Go To Next Step

STEP 8
Air in the fuel system

Check for air in the fuel system. Tighten or replace the fuel connections, fuel lines, fuel tank standpipe, and fuel filters as necessary.

OK
Go To Next Step

STEP 9
Contact a Cummins® Authorized Repair Facility

Engine Will Not Reach Rated Speed (RPM)

Cause

Correction

STEP 1
Vehicle parasitics are excessive

Check the vehicle for brakes dragging, transmission malfunction, cooling fan operation cycle time, and engine-driven units. Refer to equipment manufacturer service information.

OK
Go To Next Step

STEP 2
Electronic fault codes are active or high counts of inactive fault codes

Review instructions for reading active fault codes.

OK
Go To Next Step

STEP 3
Vehicle speed is too low for adequate cooling with high engine load

Reduce the engine load. Increase the engine (fan) rpm by downshifting.

OK
Go To Next Step

STEP 4
Tachometer is **not** calibrated or is malfunctioning

Compare the tachometer reading with a handheld tachometer or an electronic service tool reading. Calibrate or replace the tachometer as necessary. Refer to equipment manufacturer service information.

OK
Go To Next Step

STEP 5
Air-fuel tube leaking, wastegate diaphragm ruptured, or wastegate plumbing damaged

Tighten the fittings, repair the plumbing, and/or replace the wastegate diaphragm. Refer to equipment manufacturer service information or contact a Cummins® Authorized Repair Location.

OK
Go To Next Step

STEP 6
Charge-air cooler restricted, if equipped

Inspect the charge-air cooler for internal and external restrictions. Replace the restricted cooler if necessary. See equipment manufacturer service information.

OK
Go To Next Step

STEP 7
Fuel supply is **not** adequate

Check the flow through the filter to locate the source of the restriction. Refer to equipment manufacturer service information.

OK
Go To Next Step

STEP 8
Exhaust back pressure too high

Measure and correct if above specification. Refer to equipment manufacturer service information or contact a Cummins® Authorized Repair Location.

OK
Go To Next Step

Smoke, White - Excessive

Cause

Correction

STEP 1

Starting procedure is **not** correct

Verify the correct starting procedure. Refer to Procedure 101-014 in Section 1.

OK

Go To Next Step

STEP 2

Engine is cold

Allow the engine to warm to operating temperature. If the engine will **not** reach operating temperature, refer to the Coolant Temperature Below Normal troubleshooting symptom tree in Section TS.

OK

Go To Next Step

STEP 3

Engine is operating at low ambient temperature

Check the winterfront, shutters, and under-the-hood air. Use under-the-hood intake air in cold weather. Refer to Procedure 101-015 in Section 1 or Operation of Diesel Engines in Cold Climates, Bulletin 3379009.

OK

Go To Next Step

STEP 4

Electronic fault codes are active or high counts of inactive fault codes

Review instructions for reading active fault codes.

OK

Go To Next Step

STEP 5

Starting aid is malfunctioning

Check for correct operation of cold-starting aid. Refer to Procedure 101-004 in Section 1 or a Cummins® Authorized Repair Location.

OK

Go To Next Step

STEP 6

Coolant temperature is below specification

Refer to the Coolant Temperature is Below Normal troubleshooting symptom tree in Section TS.

OK

Go To Next Step

STEP 7

Fuel grade is **not** correct for the application or the fuel quality is poor

Operate the engine from a tank of known high quality fuel. Refer to Procedure 018-002 in Section V.

OK

Go To Next Step

STEP 8

Air intake or exhaust leaks

Check for loose or damaged piping connections and missing pipe plugs. Check the turbocharger and exhaust manifold mounting. Refer to Procedure 010-058 in Section 3.

OK

Go To Next Step