

# ENGINE

## SECTION INDEX




### Section 1 - GENERAL INFORMATION

- Group i - INTRODUCTION
- Group E - ENGINE IDENTIFICATION
- Group D - SYSTEM DIAGRAM
- Group T - TROUBLESHOOTING



### Section 2 - DISASSEMBLY-ASSEMBLY

- Group A - ADJUST, REPLACE AND REPAIR
- Group 00 - ENGINE DISASSEMBLY AND ASSEMBLY
- Group 01 - CYLINDER BLOCK
- Group 02 - CYLINDER HEAD
- Group 03 - ROCKER UNIT
- Group 04 - CAM FOLLOWERS AND RODS
- Group 05 - FUEL SYSTEM
- Group 06 - INJECTORS
- Group 07 - LUBRICATING SYSTEM
- Group 08 - ENGINE COOLING SYSTEM
- Group 09 - DRIVE UNITS
- Group 10 - AIR INTAKE SYSTEM
- Group 11 - EXHAUST SYSTEM
- Group 13 - ELECTRICAL EQUIPMENT
- Group 14 - ENGINE TESTING
- Group 16 - MOUNTING ADAPTATIONS



### Section 3 - GENERALITIES

- Group V - ENGINE COMPONENTS SPECIFICATIONS

## Generic Symbols

The following group of symbols have been used in this manual to help communicate the intent of the instructions. When one of the symbols appears, it conveys the meaning defined below.



**WARNING** - Serious personal injury or extensive property damage can result if the warning instructions are not followed.



**CAUTION** - Minor personal injury can result or a part, an assembly or the engine can be damaged if the caution instructions are not followed.



Indicates a **REMOVAL** or **DISASSEMBLY** step.



Indicates an **INSTALLATION** or **ASSEMBLY** step.



**INSPECTION** is required.



**CLEAN** the part or assembly.



**PERFORM** a mechanical or time **MEASUREMENT**.



**LUBRICATE** the part or assembly.



Indicates that a **WRENCH** or **TOOL SIZE** will be given.



**TIGHTEN** to a specific torque.



**PERFORM** an electrical **MEASUREMENT**.




Refer to another location in this manual or another publication for additional information.




The component weighs 23 kg (50 lb) or more. To avoid personal injury, use a hoist or get assistance to lift the component.

## SYSTEM DIAGRAM

### LUBRICATING SYSTEM




LUBRICATING OIL PRESSURE TOO HIGH



TROUBLESHOOTING

ALTERNATOR NOT CHARGING OR INSUFFICIENT CHARGING




## ADJUST, REPLACE AND REPAIR

### 8 mm, 17 mm, and 19 mm

**NOTE:** If individual lines are to be replaced, remove the support clamp from the set of lines containing the line to be replaced.

Disconnect the line(s) from the injectors.




### 19 mm

Disconnect the line(s) from the fuel pump.

**NOTE:** If removed, reinstall the support clamp in the original position and make sure the lines do not contact each other or another component. Install a protective cover on the injectors and fuel delivery valves to prevent the entry of dirt into the system.

Install the lines in the reverse order of removal.

**Torque Value:** (Line Fittings) 24 Nm [18 ft-lb]  
(Support Clamp) 6 Nm [52 in-lb]  
(Support Bracket) 24 Nm [18 ft-lb]




## FUEL DRAIN MANIFOLD - REPLACEMENT

### PREPARATORY STEPS:

- Clean debris.


### 10 mm

Remove the drain line banjo capscrew from the fuel filter head. Remove the capscrew from bracket on the intake cover.



## ADJUST, REPLACE AND REPAIR

Pressurize the element to 690 kPa [100 psi] to check it for leaks.




### 10 mm

Assemble the oil cooler gasket, element, cooler cover gasket and cooler cover to the cylinder block.

NOTE: Be sure to remove the shipping plugs (A) from the new cooler element.


**Torque Value:** 24 Nm [18 ft-lb]



### 16 mm


Connect the turbocharger oil supply line.

**Torque Value:** 35 Nm [26 ft-lb]



Install a new oil filter.

Follow the manufacturer's instructions for tightening.




---

**ENGINE DISASSEMBLY AND ASSEMBLY**


---


Remove the remaining carbon with a Scotch-Brite® cleaning pad or equivalent.



**Warning:** To prevent serious eye damage wear eye protection during this operation.



An alternative method to remove the carbon ridge is to use a high quality steel wire wheel installed in a drill or die grinder.




**NOTE:** An inferior quality wire wheel will lose steel bristles during operation, thus causing additional contamination.

**Do not use the steel wire wheel in the piston travel area. Operate the wheel in a circular motion to remove the deposits.**

### Ridge Reamer


If required, cut the ridge from the top of the cylinders.

**Make sure ridge reamer does not gauge into the cylinder bore or remove more metal than needed.**



Mark each piston with the cylinder number.

During assembly, the piston **must** be installed into the corresponding cylinder number.






# ENGINE DISASSEMBLY AND ASSEMBLY

**Caution:** Be sure the gear backlash is correct if installing a new pump.



Use a dial indicator to measure gear backlash.




Measure gear backlash.



Backlash Limits	
A = mm. 0.08 - 0.33	[.003 to .013 in]
B = mm. 0.08 - 0.33	[.003 to .013 in]


**NOTE:** Prevent movement of adjoining gears when checking backlash or the reading will be the total of both gears.



## Camshaft - Installation (0-75)

Rotate the crankshaft until the number one cylinder is approximately at the TDC position. When properly positioned, the crankshaft gear alignment pin will be positioned in the 12 o'clock position.


**NOTE:** If the crankshaft is not properly positioned, the camshaft may contact the connecting rods during installation.



Lubricate the camshaft bores with Lubriplate.



**NOTE:** If cam bushing has not been installed, refer to Component Section 1 for procedure.




---

**ENGINE DISASSEMBLY AND ASSEMBLY**



---

**10 mm, 13 mm**


Tighten the oil suction tube and brace capscrews.

**Torque Value:** 2.4 daN.m [18 ft-lb]**Oil Pan - Installation (0-83)****Oil Pan Sealing Surfaces**


Use Three Bond 1207-C to fill the joints between the pan rail, gear housing and rear cover.


**10 mm**

Assemble the oil pan and capscrews as illustrated.


**Torque Value:** 2.4 daN.m [18 ft-lb]**17 mm**

Install the drain plug and a new sealing washer.

**Torque Value:** 8.0 daN.m [59 ft-lb]



Lubricate the sealing ring and the center hole with engine oil.



**24 mm**


Install the dual filter head.



Tighten the nut.




**Torque Value:** 3.2 daN.m [24 ft-lb]



Temporarily install fuel filter(s).

**NOTE:** When the engine is ready to be put into service, fill the filter(s) with clean #2 diesel fuel and tighten 1/2 turn after the lubricated gasket contacts the filter head.



### Exhaust Manifold - Installation (0-113)

"Package" the exhaust manifold capscrews and gaskets on the manifold. Apply anti-seize compound to the capscrews.

**NOTE:** The bead on the exhaust manifold gasket can be installed in either direction.



**13 mm**

Install the exhaust manifold and gaskets.




**Torque Value:** 4.3 daN.m [32 ft-lb]

Follow the sequence shown.

**NOTE:** Vertical strokes must be smooth continuous passes along the full length of the bore.


Inspect the bore after 10 strokes.



**Caution:** Be extremely careful not to hone the bore out of specification.


A sizing hone can be used to remove minor grooves or to correct minor out of taper.

**Taper:** 0.076 mm [0.003 in]




Operate the sizing hone similarly to the Flexi-Hone.

Inspect the bore after 10 strokes.




Immediately clean the cylinder bores with a strong solution of laundry detergent and hot water.

After rinsing, use compressed air to dry the block.




Remove the excessive Loctite from the shaft.




Install the three remaining roll pins.


**A** = 2.5 mm [0.09 (3/32) in]



Apply a coat of Loctite 609 to the bearing surfaces.




Slide two new inner races onto the ends of the shafts. The identification marks must be toward the end of the shaft.



# ROCKER UNIT


## Rocker Lever Assembly - Exploded View




F3472

**1 inch (25.4 mm) Drift**


Press the shaft and bearing assembly out of the gear.

**1 inch (25.4 mm) Drift**

Support the bearing assembly and press the shaft from the bearing.

**Accessory Drive Adaptor - Assembly  
(9 - 04)****1.25 inch (31.75 mm) Pipe Coupling**

Support the inner race of the new bearing and press the shaft into the bearing until the shaft bottoms on the inner race.

**2 inch (50.8 mm) Pipe**

**Caution: Press on the outer race of the bearing assembly. Pressing on the inner race will damage the bearing.**

Support the housing and press the bearing and shaft assembly in until it bottoms.

