

**SECTION AND GROUP
CONTENTS**

WORKSHOP MANUAL

SECTION 1 GENERAL INFORMATION

Group 1 Precautions for disassembling and Assembling
Group 2 Tightening
Group 3 Painting
Group 4 Bleeding Air from Hydraulic Oil Tank

SECTION 2 UPPERSTRUCTURE

Group 1 Cab
Group 2 Counterweight
Group 3 Main Frame
Group 4 Pump Device
Group 5 Control Valve
Group 6 Swing Device
Group 7 Pilot Valve
Group 8 Electric Lever
Group 9 Signal Control Valve
Group 10 Travel Shockless Valve
Group 11 Solenoid Valve
Group 12 Pilot Shut-Off Solenoid Valve
Group 13 Steering Valve
Group 14 Brake Valve
Group 15 Accumulator Charging Valve

SECTION 3 UNDERCARRIAGE

Group 1 Swing Bearing
Group 2 Travel Motor
Group 3 Center Joint
Group 4 Transmission
Group 5 Axle
Group 6 Axle Lock Cylinder
Group 7 Operate-Check Valve
Group 8 Solenoid Valve
Group 9 Transmission Changeover Solenoid Valve
Group 10 Propeller Shaft


SECTION 4 FRONT ATTACHMENT

Group 1 Front Attachment
Group 2 Cylinder
Group 3 Hose-Rupture Valve
Group 4 Operate-Check Valve


GENERAL / Precautions for Disassembling and Assembling

Precautions for Using Nylon Sling


1. Follow the precautions below to use nylon slings safely.
 - Attach protectors (soft material) on the corners of the load so that the nylon sling does not directly contact the corners. This will prevent the nylon sling from being damaged and the lifted load from slipping.
 - Lower the temperature of the lifted load to lower than 100 °C (212 °F). If unavoidably lifting a load with a temperature of 100 °C (212 °F) or more, reduce the load weight.
 - Do not lift acid or alkali chemicals.
 - Take care not to allow the sling to become wet. The load may slip.
 - When required to use more than one sling, use slings with the same width and length to keep the lifted load balanced.
 - When lifting a load using an eyehole, be sure to eliminate any gaps between the sling and load. (Refer to the right illustration.) Reduce the load weight so that it is less than 80 % of the sling breaking force.
 - Avoid using twisted, bound, connected, or hitched slings.
 - Do not place any object on twisted or bent slings. (Refer to the right illustration.)
 - When removing the slings from under the load, take care not to damage the nylon slings. Avoid contact with protrusions.
 - Avoid dragging slings on the ground, throwing slings or pushing slings with a metal object.
 - When using with other types of slings (wire rope) or accessories (shackle), protect the joint so that the nylon sling is not damaged.
 - Store the nylon slings indoors so they won't deteriorate with heat, sun light, or chemicals.



W102-04-02-016





W105-04-01-008



W162-01-01-009

GENERAL / Painting





UPPERSTRUCTURE / Cab

Installation of Cab Glass


Procedures to Install Right-Hand Glass, Rear Left-Hand Glass, Lower Door Glass and Rear Glass

1. Cut off residual adhesive at the cab side to make 1 to 2 mm (0.04 to 0.08 in) deep all around by using a cutter knife or similar.

 **NOTE:** Do not damage the cab paint.




W1JB-02-01-009



W1JB-02-01-010

2. Clean the cutting edge of adhesive at cab side by using white spirit.




W1SE-02-01-036


IMPORTANT: Primer should be shaken for about 1 minute and mix thoroughly before opening the cap.

After opening Primer, apply Primer as quickly as possible and replace the cap immediately after using.

After opening Primer, all the contents should be used within 180 days (or 2 hours with the cap off).

3. Apply Primer for paint (Sika Aktivator DM-1) to the cutting edge of adhesive at cab side by using a brush. Wait for about 15 minutes in order to let it dry by itself.


 **NOTE:** The painting primer should be applied evenly in order to leave no blemishes.



W1SE-02-01-038


UPPERSTRUCTURE / Pump Device

DISASSEMBLY OF PUMP DEVICE




WCBE-02-04-014

UPPERSTRUCTURE / Control Valve



WCJB-02-05-004


UPPERSTRUCTURE / Control Valve



(Arm 2 Flow Rate Control Valve) 124


WCJB-02-05-007

Control Valve (Side)




Boom Anti-Drift Valve (Detail C)

W1V1-02-05-031




Arm 2 Flow Rate Control Valve (Detail D)

W1V1-02-05-032



Arm 2 Flow Rate Control Valve (Detail E)

W1V1-02-05-042




Arm 2 Flow Rate Control Valve (Detail F)

W1V1-02-05-034


UPPERSTRUCTURE / Control Valve

19. Remove socket bolts (53) (10 used) from caps (99) (4 used) and cap (100). Remove caps (99) (4 used), cap (100) and O-rings (52) (5 used) from housing (1).

 : 8 mm

- Disassembly of Digging Regenerative Valve and Auxiliary Flow Combiner Valve


20. Remove socket bolts (92) (4 used) from caps (93) (2 used). Remove caps (93) (2 used), O-rings (6) (2 used), spring seats (94) (2 used), springs (95, 97) and spools (96, 98) from housing (1).

 : 5 mm

- Disassembly of Overload Relief Valve (101)


IMPORTANT: Do not disassemble overload relief valve (101). When disassembling the overload relief valve, pressure must be adjusted. (Refer to TROUBLESHOOTING / Operational Performance Test in the separated volume, T/M.)

21. Remove overload relief valves (101) (2 used) from housing (1). Remove O-rings (102) (2 used) from overload relief valves (101) (2 used).

 : 32 mm


- Disassembly of Check Valve

22. Remove socket bolts (8) (2 used) from flange (7). Remove flange (7), O-ring (6), spring (5) and poppet (85) from housing (1).

 : 8 mm

- Disassembly of Arm Anti-Drift Valve


23. Remove socket bolts (8) (4 used) from flange (74). Remove flange (74), O-rings (20) (3 used), O-ring (9), spring (75) and poppet (76) from housing (1).

 : 8 mm

- Disassembly of Arm 1 Flow Rate Control Valve and Auxiliary Flow Rate Control Valve

24. Loosen plugs (58, 65) (2 used for each) from bodies (60) (2 used).

25. Remove socket bolts (57) (8 used) from body (60) (2 used). Remove O-rings (20, 9) (2 used for each) from housing (1).

 : 8 mm


26. Remove plugs (65) (2 used), spring seats (63) (2 used), springs (63, 80) and spools (61, 79) from bodies (60) (2 used). Remove plugs (58) (2 used) from bodies (60) (2 used).


27. Remove O-rings (59, 64) (2 used for each) from plugs (58, 65) (2 used for each).

28. Remove sleeves (66) (2 used), springs (67) (2 used), plugs (68, 81), springs (69, 82) and poppets (70, 71, 83, 84) from housing (1).


UPPERSTRUCTURE / Swing Device


2. Connect hose (19) to center joint (20).

 : 27 mm


 : 78 N·m (8 kgf·m, 58 lbf·ft)

3. Install pressure switch (13) to swing motor (12).

 : 24 mm


 : 16 N·m (1.6 kgf·m, 12 lbf·ft)


4. Connect connector (14) to pressure switch (13).





WCJB-02-06-006

5. Connect hoses (5) (4 used) to swing motor (12).

 : 19 mm


 : 29.5 N·m (3 kgf·m, 22 lbf·ft)


 : 36 mm


 : 175 N·m (18 kgf·m, 129 lbf·ft)

6. Apply grease onto O-rings (9, 11). Install O-rings (9, 11) to hoses (8) (2 used) and swing dampener valve (10).

7. Install swing dampener valve (10) and hoses (8) (2 used) to swing motor (12) with split flanges (6) (4 used) and socket bolts (7) (8 used).


 : 8 mm


 : 50 N·m (5 kgf·m, 37 lbf·ft)




WCJB-02-06-005

8. Install cover (1) to stay (4) with sems bolts (3) (4 used). Shut cover (2).

 : 17 mm

 : 50 N·m (5 kgf·m, 37 lbf·ft)


IMPORTANT: After completing the work, fill the swing motor with hydraulic oil. Check the hydraulic oil level. Start the engine and check for any oil leaks.



WCJB-02-01-002

UPPERSTRUCTURE / Pilot Valve

ASSEMBLY OF FRONT/SWING PILOT VALVES




W1F3-02-07-002


- | | | | |
|-----------------------|--------------------------|----------------------|------------------------------|
| 1 - Screw Joint | 6 - Bushing (4 Used) | 11 - Spring (4 Used) | 16 - Bushing |
| 2 - Cam | 7 - O-Ring (4 Used) | 12 - Washer (4 Used) | 17 - Spring Pin |
| 3 - Universal Joint | 8 - Pusher (4 Used) | 13 - Spool (4 Used) | 18 - Port Plate |
| 4 - Plate | 9 - Spring Seat (4 Used) | 14 - Casing | 19 - Sealing Washer (2 Used) |
| 5 - Oil Seal (4 Used) | 10 - Spring (4 Used) | 15 - O-Ring | 20 - Socket Bolt (2 Used) |

UPPERSTRUCTURE / Solenoid Valve

DISASSEMBLY AND ASSEMBLY OF 4-SPOOL SOLENOID VALVE UNIT



W18G-02-08-012



W18G-02-08-013

- | | | | |
|--------------------------|---------------|--------------|------------------|
| 1 - Socket Bolt (4 Used) | 6 - Solenoid | 11 - Orifice | 16 - O-Ring |
| 2 - Lock Nut | 7 - Spring | 12 - Washer | 17 - Sleeve |
| 3 - O-Ring | 8 - O-Ring | 13 - Spring | 18 - Plate |
| 4 - Adjusting Bolt | 9 - Diaphragm | 14 - O-Ring | 19 - Wave Spring |
| 5 - Spring | 10 - Spool | 15 - O-Ring | |

UNDERCARRIAGE / Swing Bearing


REMOVAL AND INSTALLATION OF SWING BEARING

Before removing and installing the swing bearing, the upperstructure must be removed first. For removal and installation of the upperstructure, refer to the REMOVAL AND INSTALLATION OF MAIN FRAME on W2-3-1.

The procedure starts on the premise that the upperstructure has already been removed.


Removal

1. Put the matching marks on inner race (1) of the swing bearing and track frame (2).



WCJB-02-03-003


2. Remove knock pin (3) from outer race (4) of the swing bearing.
3. Remove bolts (5) (36 used) from track frame (2).
🔧 : 30 mm



WCJB-03-01-003


⚠ CAUTION: Swing bearing weight: 230 kg (510 lb)

4. Install special tools (ST 0050) (3 used) to swing bearing. Attach a wire rope onto special tool. Hoist and remove swing bearing from track frame (2).




W110-03-01-004

UNDERCARRIAGE / Transmission



WCGB-03-04-001

Part A




WCGB-03-04-002

UNDERCARRIAGE / Axle

1 - Axle Casing	15 - Bearing Nut	29 - Planetary Carrier	43 - Knock Pin (4 Used)
2 - O-Ring	16 - Washer	30 - Plug	44 - Backup Ring
3 - Shim	17 - Socket Bolt	31 - O-Ring	45 - U-Ring
4 - Roller Bearing	18 - Sun Gear Shaft	32 - Socket Bolt (2 Used)	46 - U-Ring
5 - Drive Housing	19 - O-Ring	33 - Retaining Ring (3 Used)	47 - Backup Ring
6 - Washer (14 Used)	20 - Shaft Seal	34 - Planetary Gear (3 Used)	48 - Piston
7 - Bolt (14 Used)	21 - Bearing	35 - Washer (3 Used)	49 - Spring (8 Used)
8 - Axle Shaft	22 - Hub Carrier	36 - Roller Bearing (3 Used)	50 - Spring (8 Used)
9 - Plug	23 - Bushing	37 - Washer (3 Used)	51 - Spring Seat (8 Used)
10 - O-Ring	24 - Bearing	38 - Retaining Ring (3 Used)	52 - Bolt (8 Used)
11 - Washer (16 Used)	25 - O-Ring	39 - Retaining Ring (3 Used)	53 - Disc Carrier
12 - Bolt (16 Used)	26 - Friction Plate (6 Used)	40 - Washer	54 - O-Ring
13 - O-Ring	27 - Plate (5 Used)	41 - O-Ring	
14 - Knuckle	28 - Disc Plate	42 - Ring Gear	

UNDERCARRIAGE / Solenoid Valve

STRUCTURE OF SOLENOID VALVE UNIT



T1F3-03-08-001

No.	Part Name	Q'ty	Wrench Size (mm)	Tightening Torque			Remarks
				N·m	(kgf·m)	(lbf·ft)	
1	Solenoid	2					
2	Piston	2					
3	O-Ring	2					1B P14
4	Body	1					
5	Spool	2					
6	Spring	2					