

## SECTION 1 GENERAL

Group 1 Safety Hints .....	1-1
Group 2 Specifications .....	1-9

## SECTION 2 STRUCTURE AND FUNCTION

Group 1 Pump Device .....	2-1
Group 2 Main Control Valve .....	2-9
Group 3 Swing Device .....	2-24
Group 4 Travel Device .....	2-34
Group 5 RCV Lever .....	2-43

## SECTION 3 HYDRAULIC SYSTEM

Group 1 Hydraulic Circuit .....	3-1
Group 2 Main Circuit .....	3-2
Group 3 Pilot Circuit .....	3-5
Group 4 Single Operation .....	3-10
Group 5 Combined Operation .....	3-22

## SECTION 4 ELECTRICAL SYSTEM

Group 1 Component Location .....	4-1
Group 2 Monitoring system .....	4-3
Group 3 Electrical Circuit .....	4-10
Group 4 Electrical Component Specification .....	4-26
Group 5 Connectors .....	4-34

## SECTION 5 TROUBLESHOOTING

Group 1 Before Troubleshooting .....	5-1
Group 2 Hydraulic and Mechanical System .....	5-4
Group 3 Electrical System .....	5-24

## SECTION 6 MAINTENANCE STANDARD

Group 1 Operational Performance Test .....	6-1
Group 2 Major Components .....	6-21
Group 3 Track and Work Equipment .....	6-30

## SECTION 7 DISASSEMBLY AND ASSEMBLY

Group 1	Precaution .....	7-1
Group 2	Tightening Torque .....	7-4
Group 3	Pump Device .....	7-7
Group 4	Main Control Valve .....	7-38
Group 5	Swing Device .....	7-54
Group 6	Travel Device .....	7-75
Group 7	RCV Lever .....	7-101
Group 8	Turning Joint .....	7-115
Group 9	Boom, Arm and Bucket Cylinder .....	7-120
Group 10	Undercarriage .....	7-139
Group 11	Work Equipment .....	7-151

## SECTION 8 COMPONENT MOUNTING TORQUE


Group 1	Introduction Guide .....	8-1
Group 2	Engine System .....	8-2
Group 3	Electric System .....	8-4
Group 4	Hydraulic System .....	8-5
Group 5	Undercarriage .....	8-7
Group 6	Structure .....	8-8
Group 7	Work Equipment .....	8-10

### SUPPORT MACHINE PROPERLY

Always lower the attachment or implement to the ground before you work on the machine. If you must work on a lifted machine or attachment, securely support the machine or attachment.

Do not support the machine on cinder blocks, hollow tiles, or props that may crumble under continuous load.


Do not work under a machine that is supported solely by a jack. Follow recommended procedures in this manual.



### SERVICE COOLING SYSTEM SAFELY

Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands.



### HANDLE FLUIDS SAFELY-AVOID FIRES


Handle fuel with care; It is highly flammable. Do not refuel the machine while smoking or when near open flame or sparks. Always stop engine before refueling machine. Fill fuel tank outdoors.



Store flammable fluids away from fire hazards. Do not incinerate or puncture pressurized containers.

Make sure machine is clean of trash, grease, and debris.

Do not store oily rags; They can ignite and burn spontaneously.



## 8. SPECIFICATIONS FOR MAJOR COMPONENTS


### 1) ENGINE

Item	Specification
Model	Yanmar 4TNV98-EPHYB
Type	4-cycle diesel engine, low emission
Cooling method	Water cooling
Number of cylinders and arrangement	4 cylinders, in-line
Firing order	1-3-4-2
Combustion chamber type	Direct injection type
Cylinder bore × stroke	98 × 110mm(3.85" × 4.33")
Piston displacement	3319cc(203cu in)
Compression ratio	18.5 : 1
Rated gross horse power(SAE J1995)	57Hp at 2400rpm(42.5kW at 2400rpm)
Maximum torque at 1550rpm	20.5kgf · m(148lb · ft)
Engine oil quantity	11.6 l (3.1U.S. gal)
Dry weight	270kg(595lb)
High idling speed	2400+ 50rpm
Low idling speed	1050 ± 100rpm
Rated fuel consumption	175.6g/Hp · hr at 2400rpm
Starting motor	12V-3.0kW
Alternator	12V-80A
Battery	1 × 12V × 100Ah

### 2) MAIN PUMP

Item	Specification
Type	Variable displacement tandem axis piston pumps
Capacity	2 × 26.3cc/rev
Maximum pressure	220kgf/cm <sup>2</sup> (3130psi)
Rated oil flow	2 × 58 l /min (15.3U.S. gpm/ 12.8U.K. gpm)
Rated speed	2200rpm

② Arm roll out operation



R5572MCV11

During arm roll out operation the pilot pressure from RCV is supplied to the port a6 and the a11 and shifts arm1 spool and arm2 spool in the left direction.


The hydraulic fluid from pump P2 flows into arm1 spool through the parallel passage. Then it enters into the arm cylinder rod side through the load check valve and the port A6.

At same time, the hydraulic oil from the pump P1 flows into the arm summation passage in arm 1 spool through the arm 2 spool.

The return flow from the arm cylinder head side returns to the hydraulic tank through the port B60 the arm1 spool and tank passage.

#### 4) HIGH/LOW SPEED CHANGEOVER MECHANISM

(1) At low speed-at pilot pressure of less than 10kgf/cm<sup>2</sup>(0.98Mpa)




R5572TM16

When no pilot pressure is supplied from port (A) at a pressure of 10kgf/cm<sup>2</sup>(0.98Mpa) or less, valve(63) is pressed toward the left by the force of spring(166), the pressurized oil supply port B is shut off, and oil in chamber (C) is released into the motor case via valve(63).

Consequently, swash plate(3) is tilted at a maximum angle( $\theta_1^\circ$ ) and the piston displacement of hydraulic motor becomes maximum, thus leading to low-speed rotation.

(2) At high speed-at pilot pressure of 20kgf/cm<sup>2</sup>(1.96Mpa) or more




R5572TM17

When a pilot pressure is supplied from port (A) at a pressure of 20kgf/cm<sup>2</sup>(1.96Mpa) or more, the pressure overcomes the force of spring(66) and valve(63) is pressed toward the right. The pressurized oil at supply port (B) is then introduced into chamber (C) via valve(63).

Piston(61) pushes up swash plate(3) until it touches side (b) of the holder flange.

At this time, swash plate(3) is tilted at a minimum angle( $\theta_2^\circ$ ) and the piston displacement of hydraulic motor becomes maximum, thus leading to high-speed rotation.

### 3. COMBINED SWING AND ARM OPERATION









R5573HC32

When the swing and arm functions are operated, simultaneously the swing spool and arm spools in the main control valve are moved to the functional position by the pilot oil pressure from the remote control valve.

The oil from the P3 pump flows into the swing motor through swing spool.


The oil from the P1 and P2 pump flows into the arm cylinder through the arm and arm 2 spool.

The superstructure swings and the arm is operated.

Part name	Symbol	Specification	Check
Air cleaner pressure switch	 <p>CD-10</p>	Pressure: 635mmH <sub>2</sub> O (N.O TYPE)	※ Check contact Normal : ∞ Ω
Water temp sensor	 <p>CD-8</p>	12V 0.5A	※ Check contact High level : ∞ Ω Low level : 0 Ω
Fuel sender	 <p>CD-2</p>	-	※ Check resistance Full : 100 Ω Low : 500 Ω Empty warning : 700 Ω
Relay	 <p>CR-2 CR-3 CR-4 CR-5 CR-12 CR-13 CR-33 CR-36 CR-62</p>	12V 20A	※ Check resistance Normal : About 160 Ω (For terminal 85-86) : 0 Ω (For terminal 30-87a) : ∞ Ω (For terminal 30-87)
Relay	 <p>CR-67 CR-68</p>	12V 20A	※ Check resistance Normal : About 0.02 Ω (For terminal 2-4)
Relay	 <p>CR-23 CR-24</p>	12V 60A	※ Rated coil current 1.2±0.3A



# 14) DEUTSCH DT CONNECTORS





※ Modification

- E003 : Standard end cap - gray
- E004 : Color of connector to be black
- E005 : Combination - E004 & E003
- EP04 : End cap
- EP06 : Combination P012 & EP04
- P012 : Front seal enhancement - connectors color to black for 2, 3, 4 & 6pin

No. of pin	Connector(Female)	Connector(Male)
2	<p style="text-align: center;">DT06-2S</p>	<p style="text-align: center;">DT06-2P</p>
3	<p style="text-align: center;">DT06-3S</p>	<p style="text-align: center;">DT06-3P</p>
4	<p style="text-align: center;">DT06-4S</p>	<p style="text-align: center;">DT06-4P</p>

## 11. WHEN STARTING SWITCH IS TURNED ON, WIPER MOTOR DOES NOT OPERATE

- Before disconnecting the connector, always turn the starting switch OFF.
- Before carrying out below procedure, check all the related connectors are properly inserted and the fuse No.7 is not blown out.
- After checking, insert the disconnected connectors again immediately unless otherwise specified.




R557A5TS21

**14) FOR TRAVEL SPEED SELECTING PRESSURE:**

**(1) Preparation**

- ① Stop the engine.
- ② Push the pressure release button to bleed air.
- ③ To measure the speed selecting pressure: Install a connector and pressure gauge assembly to turning joint P port as shown.
- ④ Start the engine and check for on leakage from the adapter.
- ⑤ Keep the hydraulic oil temperature at  $50 \pm 5^{\circ}\text{C}$ .



R55NN7MA15

**(2) Measurement**

- ① Select the following switch positions.  
Travel mode switch : 1 speed  
2 speed
- ② Measure the travel speed selecting pressure in the Hi or Lo mode.
- ③ Lower the bucket to the ground to raise the track off the ground. Operate the travel lever at full stroke and measure the fast speed pressure.
- ④ Repeat steps ② and ③ three times and calculate the average values.

**(3) Evaluation**


The average measured pressure should be within the following specifications.

Unit : kgf / cm<sup>2</sup>

Model	Travel speed mode	Standard	Maximum allowable	Remarks
R55-7A	1 Speed	0	-	
	2 Speed	$30 \pm 5$	-	

**(2) The removal of rotary group**

- ① Lay the pump on the side and take out the rotary group from the shaft.



R55NM7HP11

- ② Remove the plate.



R55NM7HP12

**(3) The removal of the shaft**

- ① Remove the C-type stop ring.  
(Snap ring pliers for hole)



R55NM7HP13

- ② Use two standard screw-drivers to remove the oil seal case.



R55NM7HP14

## GROUP 4 MAIN CONTROL VALVE




### 1. REMOVAL AND INSTALL OF MOTOR

#### 1) REMOVAL


- (1) Lower the work equipment to the ground and stop the engine.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.
- ▲ Escaping fluid under pressure can penetrate the skin causing serious injury.
- ※ When pipes and hoses are disconnected, the oil inside the piping will flow out, so catch it in oil pan.
- (4) Disconnect hydraulic hose.
- (5) Disconnect pilot line hoses.
- (6) Remove links.
- (7) Sling the control valve assembly and remove the control valve mounting bolt.
  - Weight : 40kg(90lb)
- (8) Remove the control valve assembly.  
When removing the control valve assembly, check that all the piping have been disconnected.

#### 2) INSTALL

- (1) Carry out installation in the reverse order to removal.
- (2) Bleed the air from below items.
  - ① Cylinder(Boom, arm, bucket)
  - ② Swing motor
  - ③ Travel motor※ See each item removal and install.
- (3) Confirm the hydraulic oil level and recheck the hydraulic oil leak or not.




- (16) Tighten cover(12) and housing(1) with 12mm hexagonal socket bolt(18).  
 · Tightening torque : 16kgf · m(116lbf · ft)



**(17) Make up valve**

- Assemble check(35) and spring(36) to cover(12) and tighten plug(37) with 14mm hexagonal socket bolt.  
 · Tightening torque : 14kgf · m(101lbf · ft)




**(18) Relief assembly**

- Assemble relief valve assembly(17) to cover(12) with 14mm hexagonal socket bolt.

- Tightening torque : 8kgf · m(58lbf · ft)

※ Be cautious of assembling method.




**(19) Check of assembly**

- Load pilot pressure of 20kgf/cm<sup>2</sup> to brake release port after opening inlet and outlet port.

Check if output shaft is rotated smoothly around torque of 0.5~1kgf · m.

If not rotated, disassemble and check.

This completes assembly.




## GROUP 8 TURNING JOINT

### 1. REMOVAL AND INSTALL

#### 1) REMOVAL

- (1) Lower the work equipment to the ground and stop the engine.
- (2) Operate the control levers and pedals several times to release the remaining pressure in the hydraulic piping.
- (3) Loosen the breather slowly to release the pressure inside the hydraulic tank.
- ▲ Escaping fluid under pressure can penetrate the skin causing serious injury.
- ※ When pipes and hoses are disconnected, the oil inside the piping will flow out, so catch it in oil pan.
- (4) Disconnect all hoses.
- (5) Sling the turning joint assembly (1) and remove the mounting bolt(2).
  - Weight : 30kg(70lb)
  - Tightening torque :  $12.3 \pm 1.3 \text{kgf} \cdot \text{m}$   
( $88.9 \pm 9.4 \text{lb} \cdot \text{ft}$ )
- (6) Remove the turning joint assembly.
- ※ When removing the turning joint, check that all the hoses have been disconnected.



#### 2) INSTALL

- (1) Carry out installation in the reverse order to removal.
  - ※ Take care of turning joint direction.
  - ※ Assemble hoses to their original positions.
  - ※ Confirm the hydraulic oil level and check the hydraulic oil leak or not.

