

This technical manual is written for an experienced technician and contains sections that are specifically for this product. It is a part of a total product support program.

The manual is organized so that all the information on a particular system is kept together. The order of grouping is as follows:

- Table of Contents
- Specifications
- Component Location
- System Schematic
- Theory of Operation
- Troubleshooting Chart
- Diagnostics
- Tests & Adjustments
- Repair

Note: Depending on the particular section or system being covered, not all of the above groups may be used.


Each section will be identified with a symbol rather than a number. The groups and pages within a section will be consecutively numbered.

We appreciate your input on this manual. To help, there are postage paid post cards included at the back. If you find any errors or want to comment on the layout of the manual please fill out one of the cards and mail it back to us.

Safety**Specifications and Information****Diesel Engine****Electrical****Gear Power Train****Hydrostatic Power Train****PowrReverser™ Power Train****Final Drive Power Train****Steering****Brakes****Hydraulics****Miscellaneous**



AVOID INJURY FROM ROTATING BLADES, AUGERS AND PTO SHAFTS



Keep hands and feet away while machine is running. Shut off power to service, lubricate or remove mower blades, augers or PTO shafts.


SERVICE COOLING SYSTEM SAFELY



Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off machine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.

HANDLE CHEMICAL PRODUCTS SAFELY



Direct exposure to hazardous chemicals can cause serious injury. Potentially hazardous chemicals used with John Deere equipment include such items as lubricants, coolants, paints, and adhesives.

A Material Safety Data Sheet (MSDS) provides specific details on chemical products: physical and health hazards, safety procedures, and emergency response techniques. Check the MSDS before you start any job using a hazardous chemical. That way you will know exactly what the risks are and how to do the job safely. Then follow procedures and recommended equipment.

Dispose of Waste Properly

Improperly disposing of waste can threaten the environment and ecology. Potentially harmful waste used with John Deere equipment include such items as oil, fuel, coolant, brake fluid, filters, and batteries. Use leakproof containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them. Do not pour waste onto the ground, down a drain, or into any water source. Inquire on the proper way to recycle or dispose of waste from your local environmental or recycling center, or from your John Deere dealer.

LIVE WITH SAFETY



Before returning machine to customer, make sure machine is functioning properly, especially the safety systems. Install all guards and shields.


CRANKSHAFT AND MAIN BEARINGS

Removal:

1. Check the crankshaft end play. (See "CRANKSHAFT END PLAY CHECK" on page 18.)
2. Remove the rear oil seal. (See "CRANKSHAFT REAR OIL SEAL" on page 44.)
3. Remove the flywheel housing. (See "FLYWHEEL HOUSING" on page 48.)
4. Remove the crankcase extension housing. (See "CRANKCASE EXTENSION HOUSING" on page 43.)
5. Remove the timing gear cover mounting plate. (See "TIMING GEAR COVER" on page 52.)
6. Check the crankshaft rod and main bearing clearance. (See "CONNECTING ROD BEARING CLEARANCE CHECK" on page 17, and "CRANKSHAFT MAIN BEARING CLEARANCE CHECK" on page 18.)

IMPORTANT: Connecting rod end caps must be installed on the same connecting rods from which they were removed. Note alignment marks on caps and rods.

7. Remove the connecting rod bolts and end caps.
8. Push the pistons and connecting rods away from crankshaft.



IMPORTANT: Main bearing caps must be installed on the same main bearings from which they were removed.

9. Remove the main bearing bolts (D), caps (C, E) and cap thrust bearing (F).
10. Remove the crankshaft (A).
11. Remove the block thrust bearing (G) and main bearing inserts (B).
12. Inspect all parts for wear or damage.

Installation:

- Apply clean engine oil on all parts during installation.



IMPORTANT: Do not touch bearing insert surfaces. Oil and acid from your finger will corrode the bearing surface.

1. Install grooved bearing inserts in crankshaft bearing bores, aligning tangs with slots in bores.
2. Install block thrust bearings with oil grooves facing away from engine block.
3. Install crankshaft.
4. Install smooth bearing inserts in main bearing caps, aligning tangs with slots in caps.


NOTE: Main bearing caps have "raised arrows" that are stamped with numbers. Both correspond to their location on the engine block. Install all bearing caps with the "arrow" toward the flywheel end. Install bearing caps beginning with thrust bearing cap (no number), number 1, then 2, etc. The main bearing cap at gear train end does not have a number.

5. Install cap thrust bearings, with oil grooves facing away from cap, in the number "1" main bearing cap.
6. Install the main bearing caps in their original locations with arrows pointing toward flywheel side of engine.


IMPORTANT: DO NOT use high speed power tools or air wrenches to tighten main bearing bolts.

7. Dip entire main bearing bolts in clean engine oil. Install bolts and tighten. DO NOT tighten to specifications.
8. Using a soft-faced hammer, tap the front end of the crankshaft then the rear end of the crankshaft to align the thrust bearings.
9. Tighten main bearing cap bolts to **96 - 100 N•m (71 - 74 lb-ft)**. When tightening, start at center main bearing cap and work your way out, alternating to the ends. Turn crankshaft by hand. If it does not turn easily, disassemble the parts and find the cause.

RELAY WIRE CONNECTIONS





Relay Socket Layout




Relay Schematic

| # | 86 | 85 | 30 | 87 | 87A |
|----|-------------|-------------|-------------|------|-----|
| K1 | 385C | 050B / 050C | 002B | 383 | -- |
| K2 | 518A / 518B | 010E / 010F | 572A / 572B | 309 | -- |
| K3 | 329B | 010F / 010T | 329A / 329B | -- | 319 |
| K4 | 521 | 050C / 050D | 002E | 302B | -- |
| K5 | 573A | 050D / 050E | 546 | 533 | -- |
| K6 | 556 | 050E / 050F | 573B | -- | 533 |
| K7 | 212 | 050F / 050G | 252 | 222 | -- |
| K8 | 238 | 050G | 264A / 264B | 247 | -- |

X13 Trailer Connector
(Option) (from rear)

POWER CIRCUIT - RUN / AID (NEW)



Unswitched Power


Switched Power

Secondary Switched Power

SE1 - STARTING

SE2 - IGNITION

CONTROL PANEL GAUGES ELECTRICAL SCHEMATIC



CHARGE BATTERY

Reason:

To increase battery charge after the battery has been discharged.

Equipment:


- Battery charger (variable rate).

Procedure:

NOTE: See BATTERY TEST in this group before charging battery.



1. Park machine on level surface.
2. Disengage PTO.
3. Turn key switch to OFF position.
4. Engage park brake.
5. Raise hood.
6. Remove engine side covers.
7. Clean cable ends, battery terminals and top of battery.
8. Remove battery. Check water level in each cell.
9. Connect variable rate charger to battery.
10. Start charger at SLOW rate. Increase charge rate ONE setting at a time. Check charger ammeter after 1 minute at each setting. Maintain 10 amp charge rate. Use boost setting as necessary.
11. Check if battery is accepting 10 amp charge rate after 10 minutes at boost setting.



Results:

- If battery WILL NOT accept 10 amp charge after 10 minutes at boost setting, replace battery.
- If battery is accepting 10 amp charge after 10 minutes at boost setting, and battery did NOT need water, go to Steps 12 and 13.
- If battery is accepting 10 amp charge after 10 minutes at boost setting, but battery DID need water or all cells were BELOW 1.175, go to Steps 10 and 11.

12. Set charger at 15 – 25 amps.

IMPORTANT: Decrease charge rate if battery gases or bubbles excessively or becomes too warm to touch.

13. Check specific gravity after 30 minutes (60 minutes for maintenance-free battery).

Results:

- If MORE THAN 50 point variation between cells, replace battery.
- If LESS THAN 50 point variation between cells, go to Step 14.

NOTE: If battery was discharged at slow or unknown rate, charge battery at 10-15 amps for 6-12 hours. (Maintenance-free battery: 4-8 hours).

14. Continue to charge battery until specific gravity is **1.230 – 1.265 points at 26.7°C (80°F)**.
15. Load test battery.
16. Install battery.

LOAD TEST BATTERY

Reason:


To check condition of battery under load.

Equipment:

- JTO5685 Battery Tester


Procedure:

1. Park machine on level surface.
2. Disengage PTO.
3. Turn key switch to OFF position.
4. Engage park brake.
5. Raise hood.
6. Clean cable ends, battery terminals and top of battery.
7. Remove battery.




8. Turn load knob (A) counterclockwise to OFF


MAIN ELECTRICAL SCHEMATIC – 4500 / 4600 / 4700




W6 CRUISE CONTROL MAGNET WIRING HARNESS





W7 TRAILER CONNECTOR WIRING HARNESS





| Circuit Number | Wire Size | Color | Termination Points | Main Harness Connection |
|----------------|-----------|--------|--|-------------------------|
| 010 | 3.0 | Blk | X35 - Pin 3, Ground Wire Socket | X14 (to 010J Blk) |
| 115 | 1.0 | Dk Grn | X35 - Pin 4, RHTurn Signal Light Socket | X13 (to 115E Dk Grn) |
| 118 | 1.0 | Gry | X35 - Pin 5, LH Position Light Pin | X13 (to 118B Gry) |
| 125 | 1.0 | Dk Grn | X35 - Pin 1, LH Turn Signal Light Pin | X13 (to 125E Dk Grn) |
| 128 | 1.0 | Gry | X35 - Pin 7, RH Position Light Pin | X13 (to 128B Gry) |
| 136 | 1.0 | Lt Blu | X35 - Pin 6, LH and RH Brake Lights Socket | X13 (to 136B Lt Blu) |
| 222 | 2.0 | Red | X35 - Pin 2, Power Wire Socket (Accessory) | X14 (to 222 Red) |














29. If equipped, disconnect four work port tubes (W) from SCV (X).



30. Remove cap screws and spacers (Y) that attach tube support bracket to frame. Remove tube support bracket and tubes as an assembly.




31. If not already removed, lay upper brake rods (Z) across bellcrank pivot to prevent them from becoming damaged when separating tractor sections.



32. Remove two cap screws (A) and RH operator's platform support (B).


Split the Tractor:




1. Using cap screws supplied with the splitting stands, secure JTO 7335 splitting stands (C) to the tunnel sections.
2. Adjust splitting stands so that wheels contact the floor, and are parallel to the tractor wheels.
3. Remove nine cap screws and lock washers attaching tunnel section to engine section of tractor. Note length and locations of cap screws when removing.
4. Release park brake and place gear shift in NEUTRAL.

IMPORTANT: Check for, and disconnect any additional accessory wires or hydraulic tubes connecting rear half to front half before splitting tractor.

5. If necessary, use a pry bar to separate the two tractor sections. Lift the steering support slightly to clear the front flange of the tunnel. Split the tractor by rolling the two sections apart.



1. Remove C- clip (F), bearing (G), washer (H), and gear (I).




2. Remove spacer (J) from gear shaft.
3. Inspect all parts, replace as needed.



4. Pry or press bearing off of connecting shaft.



5. Slide 42T gear from shaft. Inspect all parts for wear or damage. Replace as required.



6. Slide 41T gear from stub shaft. Inspect all parts for wear or damage. replace as required.