

# Contents

## SECTION 10—General Information

- Group 05—Safety
- Group 10—General Specifications
- Group 20—Fuel and Lubricants
- Group 25—Serial Number Locations
- Group 30—Features and Accessories

## SECTION 20—Engine Repair

- Group 05—Engine
- Group 10—Cooling System

## SECTION 30—Fuel and Air Repair

- Group 05—Fuel System
- Group 10—Air Intake System
- Group 15—Speed Control Linkage

## SECTION 40—Electrical Repair

- Group 05—Battery, Starter and Alternator
- Group 10—Electrical System Components
- Group 15—Wiring Harness

## SECTION 50—Power Train Repair

- Group 05—Clutch Housing
- Group 10—Clutch Assembly—  
CollarShift/SyncShuttle™ Transmissions
- Group 11—Clutch Assembly—PowrReverser™  
Transmission
- Group 12—PowrReverser™
- Group 15—CollarShift/SyncShuttle™ Transmission
- Group 16—PowrReverser™ Transmission
- Group 20—Rear PTO Drive Shaft
- Group 25—Differential
- Group 30—Final Drives
- Group 31—Hi-Crop Final Drives
- Group 35—Mechanical Front Wheel Drive
- Group 40—Creeper Assembly

## SECTION 60—Steering and Brake Repair

- Group 05—Steering Repair
- Group 10—Brake Repair

## SECTION 70—Hydraulic Repair

- Group 05—Hydraulic Pump and Filter
- Group 06—Hydraulic Oil Cooler

- Group 10—Rockshaft
- Group 15—Selective Control Valve
- Group 20—Hydraulic Mid Mount Control Valve

## SECTION 80—Miscellaneous Repair

- Group 05—Front Axle—2WD
- Group 10—Wheels
- Group 15—3-Point Hitch
- Group 20—Fenders

## SECTION 90—Operator Station Repair

- Group 05—Seat and Support
- Group 06—Control Console and Panel
- Group 10—ROLL-GARD
- Group 15—Cab Components
- Group 16—Isolated Open Operator Station  
Components
- Group 20—Air Conditioning System
- Group 25—Heating System

10

20

30

40

50

60

70

80


90

INDX

## Park Machine Safely

Before working on the machine:

- Lower all equipment to the ground.
- Shift transmission to PARK.
- Engage park brake if equipped.
- Stop the engine and remove the key.
- Disconnect the battery ground strap.
- Hang a "DO NOT OPERATE" tag in operator station.




TS230 -UN-24MAY89

CED,OUO1085,7 -19-26JUL00-1/1

## Support Machine Properly

Always lower the attachment or implement to the ground before you work on the machine. If you must work on a lifted machine or attachment, securely support the machine or attachment.

Do not support the machine on cinder blocks, hollow tiles, or props that may crumble under continuous load. Do not work under a machine that is supported solely by a jack. Follow recommended procedures in this manual.



TS229 -UN-23AUG88

CED,OUO1085,8 -19-26JUL00-1/1


## Wear Protective Clothing

Wear close fitting clothing and safety equipment appropriate to the job.

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.



TS206 -UN-23AUG88

DX,WEAR -19-10SEP90-1/1

### Serial Numbers

When working on machines or components that are covered by warranty, it is IMPORTANT that you include the machine's Product Identification Number and the component serial number on the warranty claim form.

The location of component serial number plates are shown below.

MX,1025FT,A4 -19-15JAN91-1/1

### Product Identification Number Location

The machine's product identification number plate (A) is located on the right-hand side of the front support.

A—Product Identification Number Plate




LV093 -UN-21NOV91

AG,Ouo1085,16 -19-31JUL00-1/1

### Engine Serial Number Location

The engine serial number plate (A) is located on the right-hand side of the engine block, between the starter and the hydraulic pump.

A—Engine Serial Number Plate




LV5093 -UN-23JUN00

AG,Ouo1085,17 -19-31JUL00-1/1

### Fuel Injection Pump Serial Number Location

The fuel injection pump serial number plate (A) is located on the side of the pump.

A—Fuel Injection Pump Serial Number Plate




LV2245 -UN-02JUL97

AG,Ouo1085,18 -19-31JUL00-1/1

6. Remove finger guard (A) and recovery tank (B).
7. Disconnect bracket (C) from both sides of radiator.
8. Remove air cleaner support bracket (D).
9. Disconnect upper radiator hose (E) from radiator.


A—Finger Guard  
 B—Recovery Tank  
 C—Bracket (2 used)  
 D—Air Cleaner Support Bracket  
 E—Upper Radiator Hose



OYO1089,0000327 -19-24APR01-2/4

10. Remove bracket (A) from radiator support.
11. Disconnect lower radiator hose (B) from water pump. Close all openings using caps and plugs.
12. Remove four cap screws (C), two cap screws (D), and radiator support (E) from both sides.

A—Bracket  
 B—Lower Radiator Hose  
 C—Cap Screw (8 used)  
 D—Cap Screw (4 used)  
 E—Radiator Support




Continued on next page

OYO1089,0000327 -19-24APR01-3/4


## Replace Wiper Control Switch

1. Disconnect battery negative (—) cable.
2. Remove right-side dash panel.
3. Disconnect electrical connector (A).
4. Remove wiper switch knob (B) and nut (C).
5. Replace wiper control switch.
6. Install nut (C) and wiper switch knob (B).
7. Connect electrical connector (A).
8. Install right-side dash panel and connect battery negative (—) cable.

A—Electrical Connector  
B—Wiper Switch Knob  
C—Nut



LV6479 -UN-10MAR01




LV6480 -UN-10MAR01

OUO1089,00002B2 -19-02MAR01-1/1




17. Install disconnected red wires on right post of fuse link junction block (A).
18. Connect two main harness wiring connectors (C).
19. Connect battery positive (+) cable to starter terminal (B).
20. Connect A/C compressor ground wire (D) and connector (E).

A—Right Post of Fuse Link Junction Block  
B—Starter Terminal  
C—Main Harness Wiring Connector (2 used)  
D—Ground Wire  
E—Connector



LV7010 -UN-24MAY01



LV7020 -UN-24MAY01

Continued on next page

AG,OUO1085,120 -19-26FEB02-6/9

1—Plug	18—Plate	31—Spool	47—Spool
2—Seal	19—Socket Head Screw (3 used)	32—Spool	48—Spring
3—Filter Spring	20—Spring	33—Spring	49—Spring
4—Filter	21—Spool	34—Pin	50—Spring
5—Valve Body	22—Spool	35—Clutch Arm	51—Spool
6—Gasket (2 used)	23—Valve Body	36—Washer	52—Ring
7—Plate	24—Socket Head Screw (3 used)	37—Seal	53—Seal
8—Bearing	25—Spool	38—Pin	54—Socket Head Screw (4 used)
9—Valve Plate	26—Seal	39—Shift Arm	55—Cover
10—Pin	27—Spring	40—Seal	56—Seal
11—Gasket	28—Socket Head Screw (3 used)	41—Orifice	57—Spool
12—Guide Pin	29—Plate	42—Pin	58—Spring
13—Washer	30—Spring	43—Ring	59—Gasket
14—Spring		44—Valve Sleeve	60—Plug
15—Spring		45—Seal	61—Ball
16—Spring Pin		46—Spring Pin	
17—Piston			

*NOTE: Clutch arm (35) is press fit in plate (9).*

4. Remove parts (35, 36, and 37) using a bushing, bearing, and seal driver set.
5. Separate back valve plate (9) from front valve body (5).
6. Remove gaskets (6) and plate (7).
7. Remove plug (60), gasket (59), springs (58), and balls (61).
8. Remove screws (24) and valve body (23).

**IMPORTANT: Replace all O-rings and seals. Used or damaged O-rings and seals will leak.**

9. Remove parts (11—34) from valve body (23). Inspect for wear or damage. Replace as necessary.
10. Disassemble piston (17) containing parts (12—16). Place piston assembly (17) in a soft-jawed vise. Place a socket or pipe over the head of pin (12) and compress washer (13) and springs (14 and 15). Remove pin (16) using a small punch and hammer.
11. Remove parts (12—15) from piston (17). Inspect all parts for wear or damage. Replace as necessary.


*NOTE: Bearing (8) is press fit in plate (9). Inspect for wear or damage. Replace only if necessary.*

12. Replace bearing (8) using a bushing, bearing, and seal driver set. Install new bearing until centered in bore.
13. Remove shift arm (39) and seal (40) using a punch and soft-faced hammer.
14. Remove orifice (41). Inspect for debris or damage in orifice hole. Clean or replace if necessary.
15. Remove plug (1), seal (2), spring (3), and filter (4). Inspect parts for wear or damage. Replace as necessary.
16. Remove screws (54), cover (55), and seals (53 and 56).
17. Remove spool (57).
18. Remove sleeve (44) containing parts (43 and 45—53) from front valve body (5).

*NOTE: Spring pin (46) is press fit in spool (47). Remove spring pin only if replacement of spool is necessary.*

19. Disassemble sleeve (44) by compressing spool (51) and remove snap ring (52).

## Disassemble, Inspect and Assemble Driven Shaft



**NOTE:** Bearings (A and I) are press fit on shaft (J).

1. Remove bearing (A) using a knife-edged puller and a press.
2. Remove parts (B—H).
3. Remove parts (L, M, and K).

A—Bearing  
 B—Reverse Driven Gear  
 C—Collar (2 used)  
 D—2nd Speed Driven Gear  
 E—1st Speed Driven Gear  
 F—3rd Speed Driven Gear  
 G—Snap Ring  
 H—Spacer  
 I—Bearing  
 J—Driven Shaft  
 K—C Range Driven Gear  
 L—Washer  
 M—Snap Ring



LV482A —UN—18APR96

LV481 —UN—03MAR92

Continued on next page

AG,OUO1085,162 —19—18AUG00—1/2



4. Remove reverse idler shaft (A).

*NOTE: Bearings (B) and (F) are press fit in gear (D).*

5. Remove bearings (B) and (F) using a bearing, bushing, and seal driver set and a press.

6. Inspect all parts for wear or damage. Replace as necessary.

*NOTE: Lubricate all parts with clean transmission/hydraulic oil during assembly.*

7. Assembly parts (B—F). Install bearings using a bearing, bushing, and seal driver set and a press.

8. Apply Thread Lock and Sealer (Medium Strength) to threads of reverse idler shaft (A).


9. Install reverse idler shaft and tighten to specification.

#### Specification

Reverse Idler Shaft—Torque..... 132 N•m (97 lb-ft)

10. Install idler gear assembly, washer (G), and snap ring (H).

11. Install clutch housing to transmission. (See Install Clutch Housing to Transmission—Straddle Mount or Install Clutch Housing to Transmission—Isolated Open Operator Station and Cab Tractors in Group 16.)



- A—Reverse Idler Shaft
- B—Bearing
- C—Spacer
- D—Reverse Idler Gear
- E—Snap Ring
- F—Bearing
- G—Washer
- H—Snap Ring




- AG,OUO1085,185 -19-26FEB02-2/3

## Assemble MFWD Drop Gearbox

**IMPORTANT:** Use new seals and O-rings during assembly. Damaged or used seals and O-rings will leak.

**NOTE:** Lubricate all internal parts with clean transmission/hydraulic oil during assembly.

1. Install bearing (A), if removed, using a piece of pipe and a press.
2. Apply multipurpose grease to balls (D) and spring (C).
3. Install balls and spring in hole in shaft.
4. Install collar (B) over balls with shoulder of collar facing bearing (A).



A—Bearing  
B—Shift Collar  
C—Spring  
D—Ball (2 used)

LV560 -UN-09MAR92


AG,OUO1085,206 -19-22AUG00-1/6

**IMPORTANT:** Small splines on gear (A) must face shift collar.

**Grooves in washer (B) must face gear (A).**

5. Install gear (A), washer (B), and snap ring (C).
6. Press bearing (D) tight against shoulder of shaft.

A—Idler Gear  
B—Washer  
C—Snap Ring  
D—Bearing



LV561 -UN-09MAR92




LV562 -UN-09MAR92

Continued on next page

AG,OUO1085,206 -19-22AUG00-2/6

# Inspect and Replace Steering Hydraulic Lines—Isolated Open Operator Station and Cab Tractors (With Oil Cooler)



Continued on next page


OUO1087,0000B06 -19-26FEB02-1/2

LV6730 -UN-20APR01

## Inspect and Repair Rockshaft Control Assembly—Straddle Mount Tractors

1. Remove rockshaft case. (See Remove and Install Rockshaft Case—Straddle Mount Tractors in this group.)
2. Loosen nuts (H).
3. Remove parts (C—H).

A—Position Control Lever  
 B—Draft Sensing Lever  
 C—Alignment Plate  
 D—Cap Screw (2 used)  
 E—Spring Washer (4 used)  
 F—Washer  
 G—Spacer  
 H—Jam Nut (2 used)



LV6670 -UN-23APR01


OUO1082,00001BF -19-28FEB02-1/5

4. Remove inlet housing. (See Replace Rockshaft Control Valve—Straddle Mount Tractors in this group.)


**NOTE:** To access links inside rockshaft case, rockshaft case must be placed upside down.

5. Turn rockshaft case upside down.
6. Remove E-clips (B). Disconnect links from levers (A).
7. Rotate levers and remove socket head cap screws (C).

A—Lever  
 B—E-Clip  
 C—Socket Head Cap Screw



LV209 -UN-28FEB92



LV210 -UN-28FEB92

Continued on next page


OUO1082,00001BF -19-28FEB02-2/5

7. Place a screw driver through cable pin hole of spool.
8. Clamp screw driver in a soft-jawed vise.
9. Remove parts (H—M) and (P).
10. Inspect all parts for wear or damage. Replace as necessary.
11. Lightly coat detent spring (P), pilot ball (M) and detent balls (L) with multipurpose grease.
12. Install detent spring (P), pilot ball (M) and detent balls (L) into spool.

OUO1082,00001E0 -19-26FEB02-3/7


**NOTE:** *Notched detent is used on 6-groove float spool.  
Stepped detent is used on 5-groove regenerative spool.*

13. Place detent on spool.
14. Using a small allen wrench (A) gently push in pilot ball and detent spring.
15. Carefully slide detent (B) over detent balls (C).



LV7038

LV7038 -19-29MAY01



LV7038 -UN-29MAY01

70  
20  
17

Continued on next page


OUO1082,00001E0 -19-26FEB02-4/7



## Remove and Install Left-Side Upholstery

1. Remove two cap screws (A) from left-side upholstery (B).
2. Pull away left side of floor mat.
3. Remove screw (C) and remove upholstery from tractor.
4. Install upholstery on tractor and install screw (C).
5. Place floor mat back into position on left side of floor.
6. Install cap screws (A).

A—Cap Screw (2 used)  
B—Left-Side Upholstery  
C—Screw



OUO1089,0000344 -19-30AUG01-1/1