

# HYDRAULIC EXCAVATOR

## SHOP MANUAL

model **SK115SR-1ES**  
**SK135SR(LC)-1ES**  
**SK135SRL-1ES**

## INDEX

|   |  |
|---|--|
| 1 | SPECIFICATION SECTION                              |
| 2 | MAINTENANCE SECTION                                |
| 3 | SYSTEM SECTION                                     |
| 4 | DISASSEMBLY SECTION                                |
| 5 | TROUBLESHOOTING                                    |
| 6 | ENGINE SECTION                                     |
| 7 | INSTALLATION PROCEDURES<br>FOR OPTIONAL ATTACHMENT |

SPECIFICATION

MAINTENANCE

SYSTEM

DISASSEMBLING


TROUBLESHOOTING

E/G

# KOBELCO

Book code No. S5YY0007E

# 1. NAME OF COMPONENTS



## 4. PLUG

- (1) Plug for hydraulic pipe joint  
1) Cap nut




Table 4-1

| Applicable pipe<br>O. D : A | Cap nut parts No. | T screw | Opposing flat  |    |
|-----------------------------|-------------------|---------|----------------|----|
|                             |                   |         | H <sub>1</sub> | H  |
| 6                           | ZF83H06000        | M12×1.5 | 14             | 14 |
| 8                           | ZF83H08000        | M14×1.5 | 17             | 17 |
| 10                          | ZF83H10000        | M16×1.5 | 17             | 19 |
| 12                          | ZF83H12000        | M18×1.5 | 19             | 22 |
| 15                          | ZF83H15000        | M22×1.5 | 24             | 27 |
| 18                          | ZF83H18000        | M26×1.5 | 27             | 32 |
| 22                          | ZF83H22000        | M30×1.5 | 32             | 36 |
| 28                          | ZF83H28000        | M36×1.5 | 38             | 41 |

- 2) Plug




Table 4-2

| Applicable pipe<br>O. D : A | Plug parts No. |
|-----------------------------|----------------|
| 6                           | ZF83P06000     |
| 8                           | ZF83P08000     |
| 10                          | ZF83P10000     |
| 12                          | ZF83P12000     |
| 15                          | ZF83P15000     |
| 18                          | ZF83P18000     |
| 22                          | ZF83P22000     |
| 28                          | ZF83P28000     |

- 3) Nut












Table 4-3

| Applicable pipe<br>O. D : A | Nut parts No. | d screw | Opposing flat |
|-----------------------------|---------------|---------|---------------|
| 6                           | ZF93N06000    | M12×1.5 | 14            |
| 8                           | ZF93N08000    | M14×1.5 | 17            |
| 10                          | ZF93N10000    | M16×1.5 | 19            |
| 12                          | ZF93N12000    | M18×1.5 | 22            |
| 15                          | ZF93N15000    | M22×1.5 | 27            |
| 18                          | ZF93N18000    | M26×1.5 | 32            |
| 22                          | ZF93N22000    | M30×1.5 | 36            |
| 28                          | ZF93N28000    | M36×1.5 | 41            |
| 32                          | ZF93N32000    | M42×1.5 | 50            |
| 35                          | ZF93N35000    | M45×1.5 | 55            |
| 38                          | ZF93N38000    | M48×1.5 | 60            |

Table 18 (2/2)

| Procedure   | Multi display on gauge cluster  | Movement of governor motor   |
|---|---|--|
| ③ Keep the buzzer stop switch pressed and when it is let free after 5 to 10 seconds, <b>STEP 1</b> is displayed on the multi display. Then wait till the display changes to <b>STEP 2</b> .   | <div style="border: 1px solid black; padding: 2px; text-align: center;"><b>STEP 1</b></div> CPU START<br><br><div style="border: 1px solid black; padding: 2px; text-align: center;"><b>STEP 2</b></div> |  <p>Self-traveled to the engine stop position (S).</p>  |
| ④ After confirming the <b>STEP 2</b> display, move to the engine room and adjust the rod assy to its standard length <b>135mm(5.31in)</b> so the clearance between the governor lever and the engine stop set bolt becomes 0.1mm (0.004in).<br>Then if the governor motor is replaced, insert the rod assy after the <b>STEP 2</b> indication.                                | <div style="border: 1px solid black; padding: 2px; text-align: center;"><b>STEP 2</b></div> CPU GAP (STOP)  |  <p>Stop at the position<br/>[Tools]<br/>           • Spanner 13mm×2pcs<br/>           • Spanner 6mm<br/>           • Thickness gauge</p> |
| ⑤ Press the buzzer stop switch once, and wait until the <b>STEP 3</b> indication is provided.   | <div style="border: 1px solid black; padding: 2px; text-align: center;"><b>STEP 3</b></div> CPU START E/G   |  <p>Automatically run to the engine available position(A).</p>   |
| ⑥ When <b>STEP 3</b> comes up, start the engine. On that occasion, the accel dial may be in any position.   | <div style="border: 1px solid black; padding: 2px; text-align: center;"><b>STEP 3</b></div> CPU START E/G   |  <p>Stop at the A position</p>  |
| ⑦ If the buzzer stop switch is pressed one time, <b>STEP 4</b> comes up. The controller reads revolution from the A position of governor motor to LOW IDLE and then to HI IDLE. (The required time is approx 3 minutes.)  | <div style="border: 1px solid black; padding: 2px; text-align: center;"><b>STEP 4</b></div> CPU MEMORY  |  <p>Move from A position to Lo idling position, and self-travels from Lo position to high idling (Hi) position.</p>                     |
| ⑧ Wait till the indication on the multi display changes to "FINISH" after reading is completed.<br>When the indication on the display changes, the engine revolution returns automatically to an initial position of the accel dial.<br>Note: If "FINISH" is not indicated, it means that the adjustment has failed. Then turn <b>OFF</b> the starter switch and readjust it. | <div style="border: 1px solid black; padding: 2px; text-align: center;"><b>FINISH</b></div> CPU 2310 rpm.   | <br> <p>(Approx. 5 seconds)</p>                    |

(3) PTO gear case




Fig.1-4 Construction of PTO gear case

Table 1-5

| No. | NAME           | Q'TY | No. | NAME                   | Q'TY |
|-----|----------------|------|-----|------------------------|------|
| 115 | IDLE SHAFT     | 1    | 435 | FLANGE SOCKET : M10×20 | 4    |
| 117 | 2nd GEAR       | 1    | 468 | VP PLUG : PF3/4        | 1    |
| 118 | 3rd GEAR       | 1    | 728 | O RING : 1B P24        | 1    |
| 125 | BALL BEARING   | 2    | 825 | SNAP RING              | 1    |
| 126 | ROLLER BEARING | 1    | 826 | SNAP RING              | 1    |
| 128 | BEARING SPACER | 2    | 827 | SNAP RING              | 1    |
| 326 | GEAR CASE      | 1    | 886 | PIN                    | 2    |

3) Shuttle section

- If pressure is built up at port 1 or 3, the ball is pressed against the seat by the pressure. The pressure goes through from port 1 to port 5 (or from port 3 to port 6).

Only a little leakage occurs from port 2 or 4 as the ball is sealed metalically by the seat.

If pressure occurs at port 2 or 4, the ball is pressed against the body by the pressure. The result is that the pressure connects with port 5 from port 2 (with port 6 from port 4).

Only a little leakage occurs at port 1 or 3 as the ball is sealed metalically against the body.




Fig. 3-5 Shuttle section

#### 4) Auto 2—Speed Changeover Mechanism

##### a) At Low Speed

When no pilot pressure is supplied from port (D), spool (186) is pushed upward by the action of spring (189) and the hydraulic pressure from port (A) or (B) to shut off the pressure at port (C). As the result the oil chamber (P) is released into the motor casing via spool (186).

Consequently, swash plate (103) takes the maximum tilting angle of  $\theta_1$  that maximizes the displacement of the pistons of the hydraulic motor to run it at low speed.




Fig. 13

##### b) At High Speed

When pilot pressure [50kgf/cm<sup>2</sup> (711 psi) or over] is supplied from port (D), it overcomes the action of spring (189) and the pressure through port (A) or (B) and presses spool (186) down. The pressure at port (C) enters chamber (P) via spool (186). Piston (161) then is pushed up till swash plate (103) hits surface X of

spindle (2) and is held on that surface. On that occasion, swash plate (103) takes the minimum tilting angle  $\theta_2$  that minimizes the displacement of the pistons of the hydraulic motor to run it at high speed.





Fig. 14

(6) Replacing the evaporator and the expansion valve


1) Remove the evaporator assy from the bottom of the casing, together with the casing insulator and the expansion valve.

2) Remove the upper and lower casing insulators from the evaporator assy and draw out the evaporator sensor with the sensor holder.

3) Remove the socket head cap screws M5×40 (2 pcs.) from the evaporator. Then separate the expansion valve from the evaporator.

 : 4mm

4) Attach O rings (NFO ring 5/8 and 1/2, one piece each) to a new evaporator. Then install the expansion valve to it.

 : 4mm,

Tightening torque 0.7kgf·m (5.1 lbf·ft)

- When attaching O rings, use care so the O rings are not caught.

(7) Installing the evaporator sensor

Install the evaporation sensor as shown in Fig.21.

- When installing the casing, exercise care so the sensor cord is not caught by the casing.

(8) Replacing the motor actuator

1) Replacing the mode motor actuator

Remove the connector fixed to the motor actuator.

Remove the rod 120 linking the motor actuator with the mode cam, from the rod holder.

Remove three cross-recessed screws T4×14 (T1) fixing the motor actuator. Separate the motor actuator from the unit, together with the rod holder and the lever MAL1. Remove the rod holder and the lever MAL1 from the motor actuator and install them to a new motor actuator. Assembly is the reverse order of disassembly.




Fig. 20




Fig. 21 Installing the evaporator sensor




Fig. 22



## 17. PILOT VALVE (FOR ATT)


### 17.1 PREPARATION FOR REMOVING

The removing procedure for right and left is the same, so the preparation for left side is described here.

(1) Put attachment on ground, stop engine and release pressure in tank.


(2) Remove panel assy referring to Section 4. Instrument Panel.

(3) Remove one sems bolt (12) M5 from lower side of control box.


 : cross recessed screw driver

(4) Remove cover on outer surface.

(5) Remove sems bolt (28) and rubber sheet (29) securing cover and control box on inner surface.

 : cross recessed screw driver

(6) Remove cover on inner surface.


 : cross recessed screw driver

(7) Remove harness connector for horn.

(8) Attach tag to hoses for identification.


### 17.2 REMOVAL

(1) Remove hoses from your side to far side in order.

 : 19mm, 22mm

(2) Shift boots.

(3) Remove four socket bolts (A1) M6.


 : 5mm


(4) Remove pilot valve.

(5) Plug hose ends. Plug PF1/4

### 17.3 INSTALLATION

Install it in the reverse order of removal and tighten it to the below tightening torque.

 : 5mm T=1.5kgf·m (11 lbf·ft)

 : 19mm T=3.0kgf·m (22 lbf·ft)

: 22mm T=5.0kgf·m (36 lbf·ft)




Fig. 17-1 Removing instrument panel




Fig. 17-2 Pilot valve connector




Fig. 17-3 Pilot valve port position (from upper side)

18) Insert outer race of roller bearing

Insert the outer race of roller bearing (444) into valve casing (303), knocking it lightly by means of a steel bar.

- Knock on the outer circumference of the outer race evenly around and fix it so it stops at the step of the valve casing.




Fig. 5-35 Inserting outer race of roller bearing

19) Installing valve plate

Assemble valve plate (131) into valve casing (303) and then fit O ring (472) in place.

- Coat the contact surface of the valve plate with a thin film of grease.  
(To prevent it from falling off.)




Fig. 5-36 Installing valve plate

20) Installing valve casing

Attach valve casing (303) to casing (301) and fasten it with socket bolt (401).

⌒ : 14mm, Tightening torque :  
24kgf·m (170 lbf·ft)

- Beware of the direction of the valve casing.
- Be careful so the valve plate does not come off.
- Use care so the brake spring does not fall down.
- Fasten the socket bolts evenly all around.




Fig. 5-37 Installing valve casing

21) Fitting plunger

Place plunger (351) and spring (355) into valve casing. Fasten RO plug (469) with O ring (488) into valve casing.

⌒ : 10mm, Tightening torque :  
11kgf·m (80 lbf·ft)

- Make sure that the plunger moves smoothly.




Fig. 5-38 Fitting plunger

2) Remove O ring (135),(139) from piston (112).

- Do not reuse removed O ring (135), (139).




Fig. 1-37 Removing piston (112)

(12) Disassembling the hydraulic motor section

- When placing the travel motor on its side, oil spills ; place a container under the travel motor.

- 1) Lay down the travel motor through 90 degrees.
- 2) Drain out the oil of the travel motor.
- 3) Hold cylinder block (104) by hand, turn it both ways a few times alternately and separate shoe (106) from swash plate (103).

- If cylinder block (104) is drawn out in that condition, shoe (106) stays with swash plate (103). Then parts (pistons, shoes, etc.) attached to cylinder block (104) come off from cylinder block (104) and fall into spindle (2). Care should be used about it.

- 4) Hold the cylinder block (104) and remove the shaft (102).

- Also, friction plate (115) and separator plate (116) are also removed with cylinder block (104).

- 5) Remove friction plate (115) and separator plate (116), (117) attached on the removed cylinder block (104).

- 6) Remove piston assy[piston (105) and shoe (106)] and retainer plate (107) from cylinder block (104).

- When removing the cylinder block, hold the retainer plate (107) by both hands and remove it with the piston assy.

- Cylinder block (104) and piston assy [piston (105) and shoe (106)] are the minimum parts unit as cylinder & piston kits. When they have to be replaced, replace the cylinder & piston kit as a set. (Refer to the parts manual.)




Fig. 1-38 Removing cylinder block (104)

(8) Fixings piston assembly [ (161), (162) ]

- 1) Fit piston assy [ (161), (162)] and spring (191) to the piston hole of spindle (2).




Fig. 55




Fig. 56 Installing piston assembly (161), (162)

(9) Fixing steel balls (167)

- 1) Put two steel balls (167) into the steel ball holes in spindle (2).

(10) Assembling parts into cylinder block

- 1) Place washer (110), spring (114) and washer (110) into cylinder block (104) and fit snap ring (145) (for hole).




Fig. 57 Fitting cylinder block (104)

- 2) Place the above-mentioned cylinder block on the press bench. Put holding -down jig (I) against washer (110), hold down spring (114) and fix snap ring (145).



- Cover the sliding surface of the cylinder block with a vinyl sheet for protection.
- Pressing force of spring (114) : more than 100kg.





Fig. 58 Fixing snap ring (45)

## 4. TROUBLESHOOTING

(1)-1


Note: (1)-1 matches the Groupe No. on page 1.



## LUBRICANTS USED

| TYPE OF ENGINE | LUBRICANT TO BE USED |
|----------------|----------------------|
| Without turbo  | API Grade CD         |
| With turbo     | Same as above        |


## ENGINE OIL VISCOSITY CHART



Use engine oils of different viscosity according to atmospheric temperature as the viscosity affects the starting performance, operating performance, oil consumption, and abrasion and seizure of the moving parts.

### 6.3 FIELD COIL

- (1) Check the field coil for continuity, using a circuit tester. The coil is disconnected if there is no continuity between the M terminal of the field coil and the lead on the brush side.
- (2) Check for continuity between the field coil and the yoke. The field coil is satisfactory if there is no continuity between the field coil and the yoke.




### 6.4 OVERRUNNING CLUTCH

Turn the pinion by hand. The clutch is okay if it turns in one direction only. Inspect the pinion tooth surface and replace the pinion that is worn off or damaged.




If the overrunning clutch is all immersed in a cleaning fluid for cleaning purpose, the inside grease comes out and causes seizure.



### 6.5 REDUCTION GEAR

Inspect the reduction gear. It is satisfactory if it shows no excessive wear.



### 6.6 BEARING

Turn the outer race of the bearing by hand and check that it rotates smoothly.

