

HYDRAULIC EXCAVATOR

**SHOP
MANUAL**

model

**SK200-8
SK210LC-8**

INDEX

1	SPECIFICATIONS SECTION
2	MAINTENANCE SECTION
3	SYSTEM SECTION
4	DISASSEMBLY SECTION
5	TROUBLESHOOTING
6	ENGINE SECTION
7	PROCEDURE OF INSTALLING OPTIONS SECTION

SPECIFICATIONS

MAINTENANCE

SYSTEM

DISASSEMBLING

TROUBLESHOOTING

OPT.

KOBELCO



Book Code No. **S5YN0018E03**

1. OUTLINE

- 5) For parts which are required to use jig and tools, don't fail to use the specified jig and tools.
 - 6) For parts which can not be removed in the specified procedure, never force removal. First check for the cause.
 - 7) The removed parts should be put in order and tagged so as to install on proper places without confusion.
 - 8) For common parts, pay attention to the quantity and places.
- (3) Inspecting parts
- 1) Check that the disassembled parts are free from adherence, interference and uneven working face.
 - 2) Measure the wear of parts and clearance, and record the measured values.
 - 3) If an abnormality is detected, repair or replace the parts.
- (4) Reassembling hydraulic equipment
- 1) During the parts cleaning, ventilate the room.
 - 2) Before assembly, clean parts roughly first, and then completely.
 - 3) Remove adhering oil by compressed air, and apply hydraulic oil or gear oil, and then assemble them.
 - 4) Replace the removed O-ring, back-up rings and oil seal with new ones, and apply grease oil on them before assembling.
 - 5) Removes dirt and water on the surface on which liquid sealant are applied, decrease them, and apply liquid sealant on them.
 - 6) Before assembling, remove rust preventives on new parts.
 - 7) Use special tools to fit bearings, bushing and oil seal.
 - 8) Assemble parts matching to the marks.
 - 9) After completion, check that there is no omission of parts.
- (5) Installing hydraulic equipment
- 1) Confirm hydraulic oil and lubrication oil.
 - 2) Air release is required in the following cases ;
 1. Change of hydraulic oil
 2. Replacement of parts on suction pipe side
 3. Removing and attaching hydraulic pump
 4. Removing and attaching swing motor
 5. Removing and attaching travel motor
 6. Removing and attaching hydraulic cylinder

WARNING


If hydraulic oil and lubricating oil are not filled and also air bleed is not performed, the hydraulic equipment may be damaged.

- 3) For air bleed of hydraulic pump and swing motor, loosen drain plug on the upper part, start engine, and run in low idling, then bleed air until hydraulic oil comes out. After completion of comes, tighten plug securely.
- 4) For air bleed of travel motor and hydraulic cylinder, starts engine and operate it for 10 minutes or more at no-load and low speed.


WARNING

For cylinder, don't move it to the stroke end at beginning.

- 5) Air in pilot circuit can be bled out by only operating digging, swing and traveling motions thoroughly.
- 6) Check hydraulic oil level.
Move attachments to hydraulic oil check position, and check hydraulic oil level of tank.
Refill oil if the oil level is lower than the specified level.
How to check oil level of hydraulic oil tank



1.1.4 ELECTRICAL EQUIPMENT




- (1) The disassembly of electrical equipment is not allowed.
- (2) Handle equipment with care so as not to drop it or bump it.
- (3) Connector should be removed by unlocking while holding the connector.
Never stress in tension to the caulked section by pulling wire.
- (4) Check that connector is connected and locked completely.
- (5) Engine key off before removing and connecting connector.


13. MAINTENANCE STANDARD AND TEST PROCEDURE

13.4.3 PRESSURE ADJUSTMENT POSITION

(1) Main control valve



VIEW FROM THE TOP OF THE MACHINE





VIEW FROM THE BOTTOM OF THE MACHINE

Fig. 13-4 Relief valve position on main control valve


24. COMPONENTS SYSTEM

24.1.1.4 CONTROL CURVE OF PUMP



8) Installing valve block

Install valve block (312) to pump casing (271) and fasten them together with socket bolts (401).



: 17 mm

Tightening torque ; 430 N•m (320 lbf•ft)

- Work will be promoted if assembly is started from the rear pump.
- Exercise care so as not to mistake the direction of the valve block (312). (Install it so the regulator comes up as seen from the front side and the suction flange comes on the right.)
- Insert the 1st gear into the valve block beforehand and connect it with the spline of the shaft.





Fig. 33-109 Installing valve block (312)

9) Installing gear pump

Install gear pump (04) and fasten them together with socket bolts (435).



: 6 mm,


Tightening torque ; 17 N•m (12.5 lbf•ft)

10) Installing regulator and PTO cover

Pinch feedback pin of tilting pin in feedback lever of the regulator and PTO cover (326), install the regulator and fasten socket bolt.

(412)(413) (See Fig. 33-111]


Socket bolt (412)(413) For regulator



: 6 mm,

Tightening torque ; 29 N•m (21 lbf•ft)

Socket bolt (414) PTO Cover (326)



: 8 mm,

Tightening torque ; 57 N•m (42 lbf•ft)

- Do not mistake the front regulator for the rear regulator.





Fig. 33-110 Installing regulator and PTO cover

11) Installing drain port plug

The work is complete when drain port VP plugs (466), (468) have been set.



: 19 mm, 36 mm

Tightening torque ; 36 N•m (27 lbf•ft)

Tightening torque ; 170 N•m (125 lbf•ft)

3) Removing ring gear (6)

Attach eye bolts (M10) to the top surface of ring gear (6) and lift the ring gear lightly by a wire sling.

Put a flat-blade screwdriver (n) into the matching surface of ring gear (6) and housing (13) and remove ring gear (6) by lightly tapping the outer circumference of the ring gear with a plastic mallet (k).




Fig. 33-246 Removing ring gear (6)

4) Remove #2 sun gear and #2 spider assy.

Draw out #2 sun gear (4) and remove the #2 spider assy.

Regarding the disassembly of the #2 assy, refer to par. (4) which will come up later.




Fig. 33-247 Removing #2 spider assy

- Particularly if no failure is found, the further disassembly (under condition shown in Fig. 33-248) is not allowed. Check on parts for possible failure according to the inspection procedure shown in item 33.2.5.4.2 separately in this condition. And we recommend that the pinion shaft and housing assy are replaced together as one set. But if it is unavoidably necessary to replace a part of them, follow the procedure shown below.
- If no failure is found in this step, the disassembly later is not required.




Fig. 33-248

5) Remove retaining ring (20) from pinion shaft (1).

47. TROUBLESHOOTING (BY TROUBLE)

Table47-1 Action of optional selector solenoid valve

No.	Engine condition	Safety lock lever SW's input	Safety lock lever relay's output	Work mode	Optional selector valve COMP. MEAS.	Spool position	Selector valve detecting pressure sensor	Warning display	Failure diagnosis display
1	Running	ON	OFF	A	OFF	Nibbler	Normal	—	—
2	Running	ON	OFF	A	ON	Breaker	Normal	"SELECTOR VALVE FAILURE"	[F042] displayed simultaneously
3	Running	ON	OFF	A	OFF	Breaker	Normal	"SELECTOR VALVE FAILURE"	—
4	Running	ON	OFF	A	ON	Nibbler	Normal	—	[F042] displayed
5	Running	ON	OFF	B	ON	Breaker	Normal	—	—
6	Running	ON	OFF	B	OFF	Nibbler	Normal	"SELECTOR VALVE FAILURE"	[F043] displayed simultaneously
7	Running	ON	OFF	B	ON	N&B	Normal	"SELECTOR VALVE FAILURE"	—
8	Running	ON	OFF	B	OFF	Breaker	Normal	—	[F043] displayed
9	Running	ON	OFF	—	—	—	Failure	"SELECTOR VALVE FAILURE"	[B113] displayed
10	Stopping	—	—	—	—	—	—	—	—
11	—	OFF	—	—	—	—	—	—	—
12	—	—	ON	—	—	—	—	—	—

6. How to read explanation details

(1) Part layout

Example


ENGINE MECHANICAL [J08E]

9-17

Timing Gear Cover and Flywheel Housing

Part layout

☆JP04117090402003



☆SAPH041170900182

11308	Flywheel housing	11390	End plate	Description of part name code
11309	Oil seal retainer	9828A	Front oil seal*	
11357	Gasket*	9828B	Rear oil seal*	
11357A	Gasket*			

*Parts not to be reused.

Left: Part name code (nut)

Tightening torque

9069H	M14 : 171.5N m{1, 750kgf cm}	9419A	M16 : 196N m{2, 000kgf cm}
9069J	M12 : 97N m{990kgf cm}	9419B	M16 : 196N m{2, 000kgf cm}

SAPH311990100001

☆:It is the ID number for parts to prepare electronic data. It is not required for repair work.


3. Installation of fuel filter element

⚠ CAUTION • Fuel filter element is not reused.

- (1) The soiling and the foreign material of the clamp face are removed.
- (2) Install the fuel filter element with according to tightening angle in the table below of a turn after the O-ring of the fuel filter element comes into contact with the fuel filter head.

NOTICE • The cross-section shape of the O-ring on the side of the fuel filter element has been changed.

- ⚠ CAUTION**
- Tighten after confirming whether the O-ring is a new or an old one.
 - As the O-ring is included in the element kit, do not use an O-ring again after it has been removed once.
 - Install the O-ring after applying fuel to the surface of the O-ring.
 - Do not use a tool, but tighten by hand.



SAPH311990500010

New/Old	Cross section shape	Tightening angle
Old supply part		3/4 to 1.5 turns
New supply part		1/2 turn


Installation of alternator

JP31199070702004

1. Installation of alternator

- (1) Tighten the alternator temporarily using through bolts and nuts.
- (2) Tighten the adjusting bolts and fixing bolts temporarily.

2. V-belt tension adjustment



Item	When installing a new belt	At the time of inspection
Deflection	8 - 10mm {0.3152 - 0.394in.}	10 - 12mm {0.394 - 0.472in.}
Tension	490 - 570 N {50 - 58 kgf, 110 - 128 lbf}	320 - 400 N {33 - 41 kgf, 72 - 90 lbf}

Special tool : 09444-1210 Compression gauge (used at the time of measuring the deflection amount) [Reference push force 98N {10kgf, 22lbf}]
 95506-00090 (Denso part No.) Belt tension gauge (used at the time of measuring the tension force)

CAUTION • If the V-belt is replaced with a new one, it becomes loose due to initial fitting. Run the engine for three to five minutes and adjust the tension of the belt again.


NOTICE • At the time of inspection, the new V-belt has reached the value after complete initial stretching. A new V-belt completes initial stretching after running the engine for approximately two hours.

- (1) Tighten the through bolt of the commutator end frame.
Tightening torque : Through bolt
83 N·m {850 kgf·cm, 61 lbf·ft}
- (2) Tighten the lock nut on the brace side.
Tightening torque : Adjusting bolt
51 N·m {520 kgf·cm, 38 lbf·ft}
- (3) Tighten the adjusting bolt and make sure the bolt is locked.
Tightening torque : Adjusting bolt
5.9 N·m {60 kgf·cm, 4 lbf·ft}
- (4) Securely connect the ground wire terminal for the alternator.
Tightening torque : Adjusting bolt
4 N·m {40 kgf·cm, 3 lbf·ft}

Main Moving Parts

Part layout

JP31199090402004




SAPH311990900058

11011	Thrust bearing	13260	Connecting rod assembly
11701	Main bearing	13271	Connecting rod bush
11703	Main bearing US 0.25	13411	Crankshaft
11704	Main bearing US 0.50	13450	Flywheel assembly
13005	Piston, Piston ring set	13453	Ring gear
13201	Connecting rod bearing	13470	Crankshaft pulley
13203	Connecting rod bearing US 0.25	13521	Crankshaft gear
13204	Connecting rod bearing US 0.50	9819A	Retainer ring*


*Parts not to be reused.

Tightening torque


13266	69N·m {700kgf·cm, 51lbf·ft} +90°+45°	900125	118N·m {1, 200 kgf·cm, 87lbf·ft}
13455	186N·m {1, 900 kgf·cm, 137lbf·ft}		




SAPH311991300027



SAPH311991300028



SAPH311991300029



SAPH311991300030

2. Inspection of armature assembly

- (1) Turn the armature assembly using a commercially available growler tester and put a piece of steel on the armature assembly. Make sure that the steel piece is not vibrating on the core circumference.

- (2) Make sure that adjacent segments of the commutator have electric continuity using a circuit tester.
- (3) Make sure that there is no discoloration at the coil.

- (4) Measure the resistance between the commutator and the core using a circuit tester and check insulation. When the value is below the service limit, replace it.

Standard value	Service limit
1MΩ or more	1kΩ or less

CAUTION • After cleaning and drying, take measurements.

- (5) Measure the commutator outer diameter using vernier calipers. When the value is below the service limit, replace it.

CAUTION • After removing roughness on the surface (after polishing), take measurements.

Commutator outer diameter

Standard value (mm{in.})	Service limit (mm{in.})
36{1.4173}	34{1.3386} or less


Turbocharger Assembly

Part layout (With air compressor example)

JP31199140402001

NOTICE

- The wheel shovel has with the air compressor.



16691	Coolant pipe	24109	Gasket*
16691A	Coolant pipe	24109A	Gasket*
17159	Exhaust manifold connector	24135	Gasket*
24100	Turbocharger assembly	24135A	Gasket*
24106	Oil inlet pipe	9654-12100	Gasket*
24107	Oil outlet pipe	9659A	Gasket*

*Parts not to be reused.

Tightening torque

9209A	56 N·m {570 kgf·cm, 41lb·ft}	
-------	------------------------------	--

Signal check harness

JP31199170301001

1. Signal check harness


- CAUTION** • When measuring terminal of the engine ECU, connect the signal check harness to prevent damage to the connector. Place the tester rod on the contact box of the signal check harness for measurement.

- NOTICE** • Terminal numbers in the text and the illustrations correspond as shown below in the "Computer pin arrangement".


ECU terminal name

ACC P1	ACC P2	NEU /SW	BK2 /SW	SCBA /SW	EXB /SW	IC /SW	FUEL OUT /SW	EXB -L
PIM 1	AC ASC	KEY /SW	EXB /SW	CRS /SW	ORR /SW	RETG /SW	ST /SW	RHT
	VIMC	KEY /SW	ES RBL	ASC /SW		BK1 /SW	ST /SW	ESC /SW
THN	ASR OUT /SW	DG /SW	ID /SW	RETA DER	ABS	CRM /SW	ES /SW	PGV 2


ECU terminal number



[Example] For A8 terminal



Signal check harness (contact box)




SAPH311991700006

Injector common 1 power source line short (DTC code P1212), Injector common 2 power source line short (DTC code P1215)

JP31199170601022

1 Measurement of voltage between terminals



1. Set the starter key to "OFF" and connect the signal check harness.
2. Disconnect the ECU side connector of the signal check harness and set the starter key to "ON".
3. Measure the voltage between each terminal of the signal check harness and the ECU case ground.

CAUTION • Never start the engine because it may cause failure of the unit or electric shock.

DTC code	Terminal to measure voltage	
	+ side	– side
P1212	D5, D6	ECU case ground
P1215	E6, E7	ECU case ground


Standard value : 14 V or less

NG

[3] Go to measurement of voltage between injector terminals.

OK

2 Check of diagnosis code



1. Set the starter key to "OFF" and connect the ECU side connector of the signal check harness.
2. Start the engine and delete the past failures with the failure diagnosis tool (HinoDX) using PC.
3. If the same failure code is output again, replace the common rail ECU. If the normal code is output, it is considered that a temporary error has occurred.