

CONTENTS

	No. of page
01 GENERAL	01-001
11 STRUCTURE AND FUNCTION	11-001
12 TESTING AND ADJUSTING	12-001
13 DISASSEMBLY AND ASSEMBLY	13-001
14 MAINTENANCE STANDARD	14-001
15 REPAIR AND REPLACEMENT	15-001
19 OTHERS	19-001

PRECAUTIONS FOR DISASSEMBLY AND ASSEMBLY

3. DETERGENTS

1. Precautions for cleaning

- 1) Thoroughly clean disassembled parts and group them by unit for storage. Be especially sure to remove sludge from oil holes and pipes.
- 2) Never use dirty solvents to clean important parts.
- 3) Take extreme care with special chemical agents. Observe the manufacturer's handling instructions and take measures to prevent the agent from coming into contact with your skin or eyes.

2. Selection of detergents

Parts	Detergents
Ordinary parts	Kerosene, light oil, or trichloroethane
Finely machined parts (Bearings etc.)	Clean kerosene or neutral dehydrated light oil
Large castings (Cylinder head, cylinder block etc.)	Alkaline detergent, PH10 – 12. (Immerse in 50 – 70°C detergent for 5 – 10 minutes. Then rinse thoroughly with water.)

3. Detergents for washing rubber parts (O-rings, oil seals etc.)

	Rubber	Nitrile rubber	Ester rubber	Silicon rubber	Fluorine rubber
Detergents	Color				
Trichloroethane		○	○	○	○
Trichloroethylene		○	X	X	○
Gasoline		X	X	X	○
Thinner		X	X	X	X
Light oil		○	○	X	○
Steam		○	X	○	○


- : Immersion allowed for a short time only
X: Detergent detrimental to rubber

4. NUTS AND BOLTS


Unless otherwise specified in the DISASSEMBLY AND ASSEMBLY, tighten all bolts to a torque of page 00-29.

- 1) Use bolts having the exact length required for the parts they are to join.
If too long, the bolt presses against the bottom of the tapped hole; this pressure makes proper tightening impossible. If too short, the bolt lacks the number of threads necessary to hold the parts together.
- 2) Tighten each nut and bolt to the specified torque.
- 3) Tighten bolts evenly and in order.


Tighten mutually opposing bolts alternately.



Tighten in turn on opposite sides.



Tighten from the center outwards and on alternate sides.




FS0003


- 4) The Template Method is prescribed for tightening bolts on certain specific parts of the engine.

The Template Method obtains good fittings of bolts with their seats and of bearings with their races to ensure uniform overall tightening. The bolts are tightened in stages, then loosened, and then tightened once more.

- 3) If the shaft or opening has considerable interference, heat the bearing before installing.
★ Do not heat above 120°C.
- 4) When a non-separable bearing must be fitted with interference for both races, press-fit with the jig shown in the accompanying figure.




- 5) Thoroughly coat the bearing with oil before installing.
- 6) Install the bearing, spacer or washer with its chamfered surface facing the step on the shaft.




6. PRESS FITTING BUSHINGS

Do not drive in a bushing directly with a hammer. Use a press so that pressure is uniform over the entire circumference.

- 1) If no press is available, hammer in the bushing using a driving tool so that the force is distributed evenly.



- 2) If the bushing has an oil hole, bring the hole into exact alignment with the oil hole in the housing.



- 3) When a bushing has been removed, remove all burrs and foreign matter from the mounting hole, and then clean.


7. REMOVING SNAP RINGS

- 1) Use snap ring pliers to remove or install snap rings. Do not overexpand them—especially the smaller ones.
- 2) After installing, check to make sure that the snap ring is firmly in place within its groove.

Engine model		NTA-855-C	
Applicable machine model		WS23-1	
Number of cylinder — Bore x Stroke	(mm)	6 — 139.7 x 152.4	
Total piston displacement	(cc)	14,010	
Firing order		1 — 5 — 3 — 6 — 2 — 4	
Dimensions	Overall length	(mm)	
	Overall width	(mm)	
	Overall height		
	(Excluding exhaust pipe)	(mm)	
	(Including exhaust pipe)	(mm)	
Performance	Flywheel horsepower	(HP/rpm)	364/2,100
	Maximum torque	(kgm/rpm)	140/1,500
	High idling speed	(rpm)	2,250 — 2,350
	Low idling speed	(rpm)	610 — 650
	Minimum fuel consumption ratio	(g/HPh)	175
Dry weight		(kg)	1,570 (Front) 1,520 (Rear)
Fuel pump		Cummins PT fuel pump	
Governor		Cummins VS governor (Centrifugal, all-speed type)	
Lubricating oil capacity (Refill capacity)	(ℓ)	43 (38)	
Cooling water capacity	(ℓ)	125	
Alternator		24V, 35A	
Starting motor		24V, 11kW	
Battery		12V 200Ah x 2	
Turbocharger		Cummins ST-50	
After-cooler		With	
Others		—	

NT-855-C (For PC400-1, PC400LC-1)


INTAKE SYSTEM



- 1. Air cleaner
- 2. Turbocharger
- 3. Intake connector pipe
- 4. Intake manifold
- 5. Electrical intake air heater
- 6. Intake connector pipe
- A. Intake

F6710A003

EXHAUST SYSTEM





- 1. Muffler
- 2. Exhaust connector pipe
- 3. Exhaust manifold
- 4. Turbocharger
- B. Exhaust

F6710A004

FLYWHEEL AND FLYWHEEL HOUSING


N-855-C (For PC300-1, 2 and PC300LC-1, 2)



6710F072-1

1. Flywheel housing
2. Ring gear (No. of teeth: 138)
3. Flywheel

NTA-855-C (HD320 Engine No. 26155099 and up)



6710F083A

1. Cooler cover
2. Cooler housing
3. Cooler element
4. Seal ring
5. Oil filter
6. Cap
7. Valve spring
8. Regulator valve
9. Water pump inlet housing

- A. From oil pump (oil)
- B. From water pump (water)
- C. To regulator valve (oil)
- D. To water manifold (water)
- E. To main gallery (oil)

OIL FILTER

- Filtration area: 0.84 m²

OIL COOLER


- Effective area: 1.37 m²

REGULATOR VALVE

- Set pressure: 4.4 ± 0.4 kg/cm²

WITHOUT AIR COMPRESSOR

NT-855-C (D80, 85-18, D95S-2)




6710F092-1

- | | |
|---|------------------|
| 1. Accessory drive pulley | 6. Drive case |
| 2. Wear sleeve | 7. Thrust washer |
| 3. Accessory drive shaft | 8. Washer |
| 4. Accessory drive gear
(No. of teeth: 36) | 9. Coupling |
| 5. Thrust washer | |

ELECTRICAL INTAKE AIR HEATER


RIBBON TYPE

- SMALL SIZE (For PC300-1, 2, PC300LC-1, 2)



F6710A017

- SMALL SIZE (For PC400-1, PC400LC-1, W170-2, W180-1)



F6710A018

Pump Code	GR-J 144			
Machine Model	PC300-1 and PC300LC-1		Rated	HP/rpm
Engine Model	N855-C		Max. Torque	kgm(ft.lb.)/rpm
			High Idling	rpm
Pump P/N	6712-71-1020			

Application						
1	Vacuum Set	mmHg(in.Hg)/rpm	127(5.0)/1850			
2	Flow Meter Set	kg(lb.)/hour/rpm	122.4(270)/1850			
3	Governor Cut-off	rpm	1970 to 2000 1920 to 1970			
4	Governor Set at 2.8 kg/cm ² (40 psi)		1990 to 2050			
5	Governor Set at 1.4 kg/cm ² (20 psi)		2010 to 2080			
6	Inake Manifold Pressure	kg/cm ² (psi)/rpm	9.1 (130)/1850			
7	Check Point		6.3 to 6.7/1300 (89 to 95)			
8	Weight Assist Set at 800 rpm	kg/cm ² (psi)	3.0 to 3.5 (43 to 50)			
9	Idle Speed Pressure at 500 rpm		1.8 (25)			
10	Throttle Leakage	cc(in. ³)/min./rpm	Non			
11	Air	mmHg(in.Hg)	—			
		kg/cm ² (psi)	—			
	Fuel	rpm	—			
		kg/cm ² (psi)	—			
		kg(lb.)/hour	—			
12	No Air Set	rpm	—			
		kg/cm ² (psi)	—			
		kg(lb.)/hour	—			
Attached Parts	1	Governor Lever	Komatsu P/N	6680-71-3281		
			Cummins P/N	423641		
			Direction	Vertical		
			Place	Left, viewed from coupling		
	2	Fuel Inlet Elbow	Komatsu P/N	6691-71-2570		
			Cummins P/N			
	3	Coupling	Komatsu P/N	6710-71-2470		
			Cummins P/N	212613		
	4	Shut-off Valve	Komatsu P/N	6711-71-4100		
			Cummins P/N	3326200		
	5	Direction of Cooling Elbow		Away from coupling		

Internal Parts					Application	
1	Idle Plunger	Komatsu P/N	6610-71-6550			
		Cummins P/N	140418			
		Code No.	#37			
2	MVS Idle Spring	Komatsu P/N	6710-71-3260			
		Cummins P/N	70778			
3	Governor Plunger	Komatsu P/N	6610-71-1411			
		Cummins P/N	169660			
4	Governor Spring	Komatsu P/N	6610-71-5560			
		Cummins P/N	143252			
		Color Code	Red			
5	Governor Spring Shims	mm(in.) x Q'ty	0.51(0.02) x 1 0.25(0.01) x 1			
6	Torque Spring	Komatsu P/N	Non			
		Cummins P/N	Non			
		Color Code	Non			
7	Torque Spring Shims	mm(in.) x Q'ty	Non			
8	Weight Assist Spring	Komatsu P/N	6610-71-2140			
		Cummins P/N	143847			
		Color Code	Blue			
9	Weight Assist Spring Shims	mm (in.) x Q'ty	Non			
10	Weight Assist Protrusion	mm(in.)	22.3 to 22.8 (0.8 to 0.9)			
11	MVS Governor Spring	Komatsu P/N	6610-71-6230			
		Cummins P/N	107787			
		Color Code	Blue-Yellow			
12	MVS Governor Spring Shims	mm(in.) x Q'ty	Non			
		Komatsu P/N	—			
		Cummins P/N	—			
13	AFC Spring	Color Code	—			

Torque (kgm)	Fuel pressure (kg/cm ²)	Coolant temperature (°C)	Lubricating oil temperature (°C)	Lubricating oil pressure (kg/cm ²)	Exhaust temperature (°C) (t = Intake air temp. -20°C)
—	14.6 — 15.6	70 — 95	80 — 110	3.5 — 5.5	Max. 700 + 3t
138.7 — 146.0	0	70 — 95	80 — 110	—	Max. 700 + 3t
0	0	70 — 95	80 — 110	—	—
0	0	70 — 95	Min. 80	Min. 1.0	—
—	14.6 — 15.6	70 — 95	80 — 110	3.5 — 5.5	Max. 700 + 3t
138.7 — 146.0	0	70 — 95	80 — 110	—	Max. 700 + 3t
0	0	70 — 95	80 — 110	—	—
0	0	70 — 95	Min. 80	Min. 1.0	—
—	12.4 — 13.2	70 — 95	80 — 110	3.5 — 5.5	Max. 650 + 3t
137.1 — 145.5	—	70 — 95	80 — 110	—	Max. 680 + 3t
0	—	70 — 95	80 — 110	—	—
0	—	70 — 95	Min. 80	Min. 1.0	—

17. Abnormal noise emitted.

- ★ When noises indicating internal damaged are being emitted continuing to operate the machine may make the damage worse.
- ★ As far as possible, classify the abnormal noise to make location of the cause easier.

Type of noise;

- Interference
- Abnormal combustion
- Gears
- Internal, external
- Engine, power train

The following symbols are used to indicate the action to be taken when a cause of failure is located.

X: Replace

Δ: Repair

A: Adjust


C: Clean

No.	Problems	Remedy	Cause													
			a	b	c	d	e	f	g	h	i	j	k	l	m	n
			X	X	X	X	ΔX	XΔ	CX	X	A	X	A	X	X	ΔX
1	External or interference engine noise occurs.															○
2	Exhaust gas is black.							○		○	○	○		○		
3	Combustion noise is abnormal.							○	○			○		○		
4	Water temperature does not rise.													○		
5	Vibration damper is not warm to touch after operation; during operation, gear noise is also excessive.												○			
6	Fuel pressure (discharge pressure) is high. Seal of PT pump is abolished.											○				
7	Compression pressure is lack, blow-by is excessive.										○					
8	Valve clearance is too large or too small.									○						
9	Injector function is defective. (Plunger does not move up and down.)								○							
10	Injector injection spray is defective. (Remove it and check.)							○								
11	Remove oil pan. When checking it, internal engine noise is excessive.					○										
12	Remove gear cover. Gear noise is occurred.			○												
13	Remove cam follower housing. It is abnormal.			○												
14	When removing cylinder head, Internal engine noise is excessive.	○														

Unit: mm


No.	Check Item	Criteria				Remedy
2	Outside diameter of crank pin journal	Size	Standard size	Tolerance	Repair limit	Repair by using under size bearing or replace
		STD	79.00	+0.375 +0.337	79.30	
		0.25 U.S	78.75	+0.371 +0.346	79.05	
		0.50 U.S.	78.50	+0.367 +0.342	78.79	
		0.75 U.S.	78.25	+0.363 +0.338	78.54	
		1.00 U.S.	78.00	+0.359 +0.334	78.28	
3	Roundness of journal	Repair limit: Within 0.013 (Total indicator reading)				
4	End play of crankshaft	Standard clearance		Clearance limit		Repair by using over size bearing or replace
		0.18 – 0.43		0.56		
5	Width of journal at thrust journal	Size	Standard size	Tolerance	Repair limit	Repair by using over size bearing or replace.
		STD	76.20	+0.07 +0.02	76.35	
6	Thickness of main bearing	STD	3.10	+0.042 +0.024	3.09	Replace
7	Thickness of thrust bearing	STD	6.20	+0.07 +0.02	Determine by crankshaft end play	
		0.25 O.S.	6.45	+0.08 +0.03		
		0.50 O.S.	6.70	+0.08 +0.03		
8	Clearance of main journal	Standard clearance		Clearance limit		Repair by using under size bearing or replace.
		0.035 – 0.125		0.18		
	Clearance of crank pin journal	0.040 – 0.110		0.18		
9	Bend of crankshaft	Repair limit: 0.09 (Total indicator reading)				
10	Face runout of vibration damper	Repair limit: 0.25 (Total indicator reading)				Repair mounting flange or replace.
	Radial runout of vibration damper	Repair limit: 0.25 (Total indicator reading)				
11	Tightening torque of crankshaft pulley mounting bolt	26.5 ± 1.0 kgm				
12	Tightening torque of vibration damper mounting bolt	8.0 ± 0.2 kgm				

- iii) Adjust the grinder position so that the horizontal center line of grindstone ⑤ is located at the center of valve seat insert (1), then secure the grinder by tightening the set screw.
- iv) Fully open the grinder throttle valve and slowly move the rotating grindstone towards insert (1) until it comes into contact.



6162F505


- v) While pressing the grindstone lightly towards the inner surface of the insert, move the grindstone in a circle and make a groove in the circumference of the inner surface to a depth of about 1 mm.



6162P501


- 2) Using the puller head on valve seat puller A, remove the insert as follows:

- i) Press three claws (a) on puller head ⑥ inside by hand and fit the puller head into insert (1).
- ii) Tighten screw ⑧ so that the three claws will be pressed into the groove on the inside of the insert.
- ★ Stop tightening the screw as soon as the claws fit completely into the groove. If the screw is overtightened, the insert may get damaged and it will be difficult to remove.



6162F506

- iii) Place bridge ⑨ around the outside of the puller head, put plates ⑩ and ⑪ on the bridge, and tighten nut ⑫ until the insert is removed.



6162P502