# **CONTENTS**

01	GENERAL	01-1
10	STRUCTURE AND FUNCTION	10-1
20	TESTING AND ADJUSTMENT	20-1
30	DISASSEMBLY AND ASSEMBLY	30-1
40	MAINTENANCE STANDARD	40-1

LIST OF ORIGINAL, NEW AND REVISED PAGES

MARK	PAGE	REV	MARK	<u>PAGE</u>	REV	MARK	PAGE	REV	MARK	PAGE	REV
	10-179			20-23	1		20-54	1		20-85	1
	10-180			20-24	1		20-55	1		20-86	1
	10-181			20-25	1		20-56	1		20-87	1
	10-182			20-26	1		20-57	1		20-88	①
	10-183			20-27	1		20-58	1	:	20-89	1
	10-184			20-28	1		20-59	<b>①</b>		20-90	1
	10-185			20-29	1		20-60	①		20-91	1
	10-186			20-30	①		20-61	①		20-92	1
				20-31	1		20-62	①		20-93	1
	20-1	1		20-32	1		20-63	1		20-94	1
	20-2	1		20-33	1		20-64	①		<b>20-9</b> 5	•
	20-3	①		20-34	①		20-65	1		20-96	1
	20-4	1		20-35	1		20-66	1	:	20-97	①
	20-5	1		20-36	1		20-67	1		20-98	1
	20-6	•		20-37	1		20-68	1		20-99	1
	20-7	1		20-38	1		20-69	1		20-100	<b>①</b>
	20-8	1		20-39	1		20-70	1		20-101	1
	20-9	①		20-40	1		20-71	1		20-102	<b>①</b>
	20-10	•		20-41	1		20-72	<b>①</b>		20-103	1
	20-11	1		20-42	1		20-73	1		20-104	1
	20-12	①		20-43	1		20-74	1		20-105	①
	20-13	①		20-44	①	:	20-75	1		20-106	1
	20-14	1		20-45	1		20-76	1		20-107	①
	20-15	1		20-46	1		20-77	①		20-108	1
	20-16	1		20-47	①	:	20-78	1		20-109	1
	20-17	1		20-48	①		20-79	①		20-110	1
	20-18	1		20-4 <del>9</del>	1		20-80	①		2 <b>0-1</b> 11	1
	20-19	1		20-50	1		20-81	①		20-112	①
	20-20	1		20-51	1		20-82	1		20-113	①
	20-21	1		20-52	①		20-83	①		20-114	①
	20-22	1		20-53	1		20-84	1		20-115	1


GENERAL WEIGHT TABLE


# PC210LC-6


Unit: kg

Machine model	PC210LC-6
Serial number	A82001 and up
Engine assembly	685
Engine	480
Damper	6
Hydraulic pump	142
Radiator ● oil cooler assembly	144
Hydraulic tank ● filter assembly (excl. oil)	133
Fuel tank assembly (excl. fuel)	114
Revolving frame	1,982
Operator's cab	290
Operator's seat	29
Counterweight	4,730
Swing machinery	205
Control valve	230
Swing motor	9
Travel motor	123 x 2
Center swivel joint	42
Track frame assembly	5,318
Track frame	2,870
Swing circle	280
• Idler	140 x 2
Idler cushion	135 x 2
Carrier roller	21 x 4
Track roller	38 x 18
Travel motor	425 x 2
Track shoe assembly	
Standard triple grouser shoe (600 mm)	1,425 x 2
Standard triple grouser shoe (700 mm)	1,565 x 2
Wide triple grouser shoe (800 mm)	-
Wide triple grouser shoe (900 mm)	-

# MAIN STRUCTURE







X10BH145


- 1. Spool (arm)
- 2. Spool (L.H. travel)
- 3. Spool (swing)
- 4. Spool (boom)
- 5. Spool (R.H. travel)
- 6. Spool (bucket)
- 7. Spool (service 1)
- 8. Spool (service 2)

- 9. Spool (service 3)
- 10. Spool return spring
- 11. Main unload LS relief valve
- 12. Main relief valve (bucket end group)
- 13. Sub-unload valve (bucket end group)
- 14. Main relief valve (arm end group)
- 15. Sub-unload valve (arm end group)

# Operation

- When the arm and boom are operated simultaneously, the swash plate angle for both pumps becomes the maximum. When this happens, the load pressure at the boom RAISE side is higher than at the arm side, so the LS pressure passes through ports E and F of boom spool (8), enters LS shuttle valve (22) and is sent to the LS circuit. This LS pressure is transmitted to port G of arm pressure compensation valve (17), and acts to increase the set pressure of the pressure compensation valve. Because of this, the pressure between port H or arm spool (11) and port I or pressure compensation valve (17) rises, and spool meter-in LS differential pressure (pump pressure - LS pressure =  $\triangle$  **PLS**) becomes the same as that at the boom end.
- 2) Because of the above operation, the oil flow is divided in proportion to the size of the opening area of boom spool (8) and the opening area of arm spool (11). Meter-in differential pressure Δ PLS during boom RAISE + arm IN is Δ PLS < boom LS control pressure, so the main pump swash plate angle is set to maximum.

### 4. AUTO-DECELERATION FUNCTION




X12BV100


## **FUNCTION**


- If all the control levers are at neutral when waiting for work or waiting for a dump truck, the engine speed is automatically reduced to a midrange speed to reduce fuel consumption and noise.
- If any lever is operated, the engine speed returns immediately to the set speed.


# **ADJUSTING TRAVEL LEVER**

- 1. Use bolt (2) to install lever (1) to the PPC valve.
  - ★ When doing this, install so that clearance ⓐ is 35.3 ± 1mm.
- In this condition, move left and right travel levers (3)
  forward and backwards, and check that the levers are
  fitted securely in the stopper (bolt head) of the PPC
  valve.
- 3. Check also that cover (3) is not contacting portion (b).
  - ★ If it is contacting, adjust with the PPC mounting bolt or cover mounting bolt.
- 4. Install damper (4) and adjust so that dimension © is 157.2 ± 1mm when the lever is at neutral.









- C-6 [E2:02] Short circuit in LS select solenoid system is displayed [E2:04] Short circuit in pump merge-divider solenoid system is displayed
  - [E2:05] Short circuit in 2-stage relief solenoid system is displayed [E2:06] Short circuit in travel speed solenoid system is displayed
- ★ This troubleshooting is carried out when there is still an abnormality, so when disconnecting the connector and inserting the T-adapter, or when removing the T-adapter and returning the connector to its original position, if the service code is not displayed, the problem has been removed.
- ★ If the starting switch is turned OFF after an abnormality occurs, turn the starting switch ON and check if any service code is displayed. (If it is not displayed, the problem has been removed.)
- \* Before carrying out troubleshooting, check that all the related connectors are properly inserted.
- ★ Always connect any disconnected connectors before going on to the next step.






Table 1

	Measurement tocation						
Service code	Troubleshooting 2		Troubleshooting 3				
	Between V02 (male) (1) and (2)	20 - 60 Ω	Between C01 (female) (10), (11) and (3)	20 - 60 Ω			
E2:02			Between C01 (female) (3) and chassis	Min. 1 MΩ			
	Between V03	20 - 60 Ω	Between C01 (female) (10), (11), and (4)	20 - 60 Ω			
E2:04	(male) (1) and (2)		Between C01 (female) (4) and chassis	Min. 1 MΩ			
	Between V05	20-60Ω	Between C01 (female) (10), (11) and (14)	20 - 60 Ω			
E2:05	(male) (1) and (2)		Between C01 (female) (14) and chassis	Min. 1 MΩ			
	Between V06	20-60Ω	Between C01 (female) (10), (11) and (6)	20 - 60 Ω			
E2:06	(male) (1) and (2)		Between C01 (female) (6) and chassis	Min. 1 MΩ			

# H-10 Work equipment (boom, arm, bucket) does not move (but travel and swing are normal)




# H-11 Excessive hydraulic drift (boom, arm, bucket)




#### (engine oil level) flashes b)

Use the level gauge to check that the engine oil level is correct before carrying out troubleshooting.



Table

M-7 b) Related electric circuit diagram



YES

NO

Is continuity between P01

(female) (3) -(11)(3) as shown in

• Turn starting switch OFF.

Disconnect P01.

the table?



does display go

Turn starting switch ON.

Disconnect P09.

out?

M-7 c) Related electric circuit diagram

Defective monitor panel

disconnection in wiring harness between P09 (female) (1) - H02 (15) - P01

Defective contact, or

(female) (3)

Replace

Repair or replace

Between P09 (female) and chassis	Continuity	P01(04020) H02(516) P09(X1) - H05(M6) G D	Hydraulic oil level sensor
Connected	Yes	Monitor panel 3	
Disconnected	No		गीर
			X08DD167

# **SPECIAL TOOL LIST**

Nature of work		lodi	Part No. Part Name		Q'ty	Remarks	
Engine ● hydraulic pump     Radiator ● hydraulic oil cooler ● Control pump ● Hydraulic pump ● Removal, installation of TVC ● LS valve assembly	E	3	796-460-1210	Oil stopper	1		
Disassembly of center swivel joint assembly	C	,	790-101-2501	Push-puller	1		
Removal, installation of swing circle	E		790-331-1110	Wrench	1	Tightening	of circle bolt
Disassembly, assembly of swing machinery assembly	F	=	796-426-1120	Push tool	1	Press fitting of bearing	
		1	796-427-1120	Wrench	1		
			796-427-1130	Push tool	1	fittin	
	G		790-101-2510	Block	1		
			792-104-3940	Bolt	2		
		2	01580-11631	Nut	2		
Discounties assembly of Cont			01643-31645	Washer	2		Press fitting of bearing
Disassembly, assembly of final drive assembly			790-105-2100	Jack	1		
			790-101-1102	Pump	1		inner race
			796-570-1110	Plate	1	PC250LC	]
		3	790-331-1110	Wrench	1	PC200 PC200LC	
		4	791-545-1510	Installer	1	PC210LC PC220LC	-
<b>5</b> 0. 0.0			791-580-1510	Installer	1	PC250LC	
	н		791-600-2001 or	Compressor (A)	1		
			794-685-8005	Compressor (B)	1	PC200	
			791-935-3160	Extension	1	PC200LC PC210LC	
		2	790-101-1600	Cylinder (70 ton)	1	PC220LC	
			790-101-1102	Pump	1		Removal, press
Democrat installation of			791-600-2001	Compressor (A)	1		fitting of master pin
Removal, installation of recoil spring assembly			or 791-685-8003	Compressor (B)	1		
			791-935-3160	Extension	1	PC250LC	
			790-101-1600	Cylinder (70 ton)	1	1	
			790-101-1102	Pump	1	1	
			790-201-1500 • 790-201-1620 • 790-101-5021 • 01010-50816	Push tool kit  ■ Plate  ■ Grip  ■ Bolt	1 1 1		of recoil spring dust seal

- 3) Install parking brake spring (25).
- 4) Fit O-ring, align dowel pin with groove portion of brake piston, and install end cover (7).
  - ★ Be extremely careful that the O-ring does not come out or get caught.



Mating surface of motor case: Gasket sealant (LG-7 or LG-5) (Loctite 572/575)




Mounting bolt: 460.9 ± 29.4 Nm (47 ± 3 kgm)

5) Tighten plug (6).

Plug: 419.2 ± 46.6 Nm (42.75 ± 4.75 kgm)

6) Fit backup ring and O-ring, and install safety valve assembly (5).



### 7. Piston plug


Assemble piston (4) and spring (3), then fit O-ring and install plug (2).

- \* Precautions when installing plug.
  - Remove all oil and grease from the plug and male thread (motor case), and dry completely.
  - When coating with adhesive, coat with two drops (approx. 0.04 g) at a point 2-3 mm from the tip of the thread of the plug.



Plug: Thread tightener (Loctite 638/648)

3) Do not apply any pressure to plug for 30 minutes after tightening.





#### 8. Installation of oil seal


- Check that there are no burrs or flashes at the corners of the shaft.
- 2) Using tool T, press fit oil seal (48).
  - ★ Tool T: Push tool (796-465-1130)
    Grip (790-101-5221)
    Bolt (01010-51225)
  - ★ Clean the oil seal lip.





Tip of oil seal (whole circumference) Grease (G2-L1-S)











# DISASSEMBLY OF WORK EQUIPMENT • SWING PPC VALVE ASSEMBLY

- 1. Remove nut (1), then remove disc (2) and boot (3).
- 2. Remove bolt, then remove plate (5).
  - ★ Do not remove joint (4) unless it is to be replaced.
- 3. Remove seal (6) and collar (7).
- 4. Pull out piston (8), and remove retainer (9), springs (10) and (11), and shim (12).
  - ★ Spring (1) consists of a set of two types of springs with different installed loads, so check the mounting position (oil port) and mark with tags to prevent mistakes when installing.
- 5. Pull out valve (13) from body (14).

