


8. Tractors installed with suspended front axle

Depressurise the suspension system by rotating screw on top of the suspension load sense unload valve clockwise. When the tractor has lowered completely onto the front support stops rotate the screw counter clockwise to normal operating position.

Disconnect the pipes to the front axle suspension cylinders.




On tractors with suspended front axle ensure suspension has been fully lowered as described above before disconnecting suspension cylinder hoses.



BSD2232A


9



BSD1957A

10


Remove suspension pipes and guard.



BSD1958A

11


Remove the rear pivot block bolts.



BSD1915A

12

Disconnect and remove front wheel drive shaft universal joint.




50

11. Tractors with Standard Front Wheel Drive Axle


Remove front wheel drive propshaft guard and propshaft

NOTE: The type of driveshaft fitted is dependant on type of axle installed




51

12. Remove driveshaft flange, where fitted.




52

13. Remove engine side rails



53



8

Front Axle Cross-Sections

- | | |
|---|--|
| A. Dog Clutch Differential | 6. Differential gear pin |
| B. Multi Wet Plate Clutch Differential | 7. Differential gears |
| 1. Spring | 8. Pinion cone point adjustment shims |
| 2. Crown wheel bearing adjustment shims | 9. Clutch drive discs |
| 3. Side gear thrust washer shims | 10. Clutch driven discs |
| 4. Side gears | 11. Seal |
| 5. Differential gear thrust washer shims | 12. Pinion bearing adjustment shims |

35 000 GENERAL FAULT FINDING


Before commencing fault finding refer to the initial check fault finding chart which may identify an obvious cause for the concern and prevent unnecessary component disassembly.

IMPORTANT: *If the steering is inoperative, there will be no lubrication to the transmission or PTO clutch and the tractor must not be run for more than 5 minutes at a maximum engine speed of 1000 rev/min.*


Fault finding charts listed in this Chapter are:-

- Initial Fault Finding Check
- Transmission Low Pressure Warning Light 'On'
- Charge Pressure Light Flashing
- Intake Filter Restriction Warning Light 'On'
- Power Steering not Working or Working Incorrectly
- Trailer Brakes not Working
- Hydraulic Lift not Working Correctly
- Remote Control Valves not Working

**Initial Fault Finding Checks
To be Performed Before Proceeding to General Diagnostic Procedure**



PERFORMANCE TEST EXAMPLE 1



21

Performance Test Example 1

- | | |
|--|--|
| 1. High Side Low | 5. Low Side Hose Connected to Low Side Service Connector |
| 2. High Side Hand Valve Closed | 6. Low Side Hand Valve Closed |
| 3. High Side Hose Connected to High Side Service Connector | 7. Low Side Low |
| 4. Not Used | |

PROBLEM:

Little or no cooling.

CAUSE:

Refrigerant slightly low.

CONDITIONS*


Low side pressure too low.
Gauge should read 1–2 bar (15–30 lbf/in²).
High side pressure too low.
Gauge should read 13.3–14.8 bar (194–215 lbf/in²).
Evaporator air not cold.

CORRECTIVE PROCEDURES

1. Leak test the system.
2. Repair leaks. (Discharge and recover the refrigerant from the system; replace lines or components).
3. Check compressor oil to ensure no loss.
4. Evacuate the system.
5. Charge the system.
6. Performance test the system.

DIAGNOSIS: System refrigerant is low. May be caused by a small leak.

NOTE: Test procedure based upon ambient temperature of 35°C (95° F). For proper high side gauge reading for other ambient temperatures, refer to the pressure temperature chart.



ERROR CODE R27 – NO COMMUNICATION BETWEEN THE EHR VALVE 2 AND THE CENTRAL CONTROLLER (XCM)**Effects:**

EHR valve disabled

Possible failure modes:

1. Faulty connector
2. Faulty CAN BUS terminating resistor
3. Faulty harness
4. Faulty EHR valve
5. Faulty central controller (XCM)

Solution:

NOTE: When the cause of the error code has been rectified, clear the error code and test the system for normal operation.

1. Check the EHR valve connector **C280**, extension harness connector **C019**, central controller (XCM) connector **C329**, and the terminating resistor connector **C292**.
 - A. Ensure the connectors are connected, not damaged, the pins are in the correct position and that the fit is tight. Repair or replace as required.
 - B. If the connectors are okay, continue to step 2.
2. Check the CAN BUS.
 - A. Measure the resistance between connector **C277** pin 1 (Y) and **C277** pin 2 (G).

If the resistance indicated is approximately 60 Ohms, continue to step 3.

If the resistance indicated is less than approximately 5 Ohms, there is a short circuit in the CAN BUS wires, repair or replace as required.





If an open circuit is indicated, there is an open circuit in the CAN BUS wires between the central controller (XCM) and the EHR terminating resistor, repair or replace as required.
 - B. If the resistance indicated is approximately 120 Ohms, disconnect connector **C329**.


If an open circuit is now indicated, the CAN BUS to the central controller (XCM) is okay, continue to step 5.

If 120 Ohms is still indicated, the CAN BUS to the central controller (XCM) is not okay, continue to step 6.
3. Check for an open circuit.
 - A. Disconnect **C280** and **C329**. Measure the resistance between connector:
C280 pin 2 (G) and **C329** pin 19 (G)
C280 pin 3 (Y) and **C329** pin 13 (Y)


Wiggle the harness and the connectors to check for an intermittent circuit. If the resistance indicated is greater than 5 Ohms, repair or replace the harness as required.
 - B. If the resistance indicated is less than 5 Ohms, continue to step 4.
4. Check for a short to ground.
 - A. Disconnect all of the EHR valve connectors. Check between connector:
C280 pin 2 (G) and **ground**
C280 pin 3 (Y) and **ground**

Wiggle the harness and the connectors to check for an intermittent circuit. If a short to ground is indicated, repair or replace the harness as required.
 - B. If the harness is okay, remove, replace, and configure the EHR valve.
5. Check for an open circuit.
 - A. Disconnect the EHR terminating resistor connector **C292**. Measure the resistance between connector:
C277 pin 1 (Y) and **C292** pin 1 (Y)
C277 pin 2 (G) and **C292** pin 2 (G)






Hold the downshift button until the engine speed decreases by 50 RPM and the calibration number stops increasing.



18

Release the downshift button (1) to progress to the next clutch. The display will change to "b". Follow the same procedure as clutch A to calibrate clutch B. Then continue in the same manner for clutches C, D, E and F calibration.




19

Calibration "F", moves the two range synchronisers into the neutral position. If all is OK, "CF" will appear.

NOTE:


The two range potentiometers are automatically calibrated during the calibration of the five clutches




20

At this point, the calibration has been completed, and the Key start can be switched off to store the new calibration figures.

When in the calibration mode, it is possible to select any individual clutch for calibration by pressing the upshift button until the required clutch is displayed.



21







ERROR CODE FBD - CLUTCH D SOLENOID OVER VOLTAGE**Possible failure modes:**

1. External power supply connected
2. Faulty charging system
3. Faulty solenoid
4. Faulty harness
5. Faulty secondary controller (CFPS)

Solution:

NOTE: When the cause of the error code has been rectified, clear the error code and test the system for normal operation.

1. Check for other error codes being displayed.
 - A. If any other error code is being displayed, continue to these tests.
 - B. If no other error code is displayed, continue to step 2.
2. Check that the tractor battery power supply has not been connected to an external power supply.
 - A. If an external power supply is connected to the tractor, disconnect and test the system for normal operation.
 - B. If an external power supply is not connected to the tractor, continue to step 3.
3. Check the battery voltage on the instrument cluster.
 - A. Start the engine and run at 2000 rev/min. If the voltage displayed is greater than approximately 15 Volts, continue to test for a fault in the charging system.
 - B. If the battery voltage is okay, continue to step 4.
4. Check clutch A solenoid.
 - A. Turn the keystart OFF. Disconnect clutch D solenoid connector **C025**. Measure the resistance between the solenoid terminal **A** and terminal **B**. If the resistance indicated is not between 8 Ohms – 11 Ohms, remove and replace clutch D solenoid.
 - B. If clutch D solenoid is okay, continue to step 5.
5. Check for +Ve Voltage.
 - A. Disconnect the secondary controller (CFPS) connector **C331**. Turn the keystart ON. Measure the voltage between connector:
C331 pin 5 (L/N/S) and ground
C331 pin 6 (TQ/R/B) and ground
If a voltage is indicated, repair or replace the harness as required.
 - B. If a voltage is not indicated, continue to step 6.
6. Check for a short circuit.
 - A. Turn the keystart OFF. Check between connector **C331 pin 5 (L/N/S)** and **C331 pin 6 (TQ/R/B)**. If a short circuit is indicated, repair or replace the harness as required.
 - B. If the harness is okay, download the correct level of software. If the fault re-occurs, remove and replace the secondary controller (CFPS).



ERROR CODE 24 - PERFORM HYDRAULIC LIFT CALIBRATION

Calibration of Lift Arm Potentiometers and Lift Control Pod

This procedure is required whenever:-

The lift arm position sensing potentiometer, lift control pod or EDC valve have been replaced.

or


The microprocessor has been replaced or its memory has been reset using Diagnostic Menu **H8**.

1. Lower lift arms and disconnect vertical rods from hanger on automatic pick-up hitch (where fitted). This will allow the lift arms to raise to their maximum position.
2. Position raise/work switch to work position.


3. Turn all the EDC operator controls fully clockwise.

NOTE: If the height limit control has not been turned fully clockwise to the maximum height position, the **Error Code HL** will be displayed.


4. Start engine and set speed to 1100 rpm.
5. Move lift control lever forward and fully lower the lift.




137



138



139



140

