



# Cruise Control













# Cruise Control

A72(A), A73(B), A74(C)  
Transmission Control ECU Assembly




# Cruise Control



A72(A), A73(B), A74(C)  
Transmission Control ECU Assembly






A31 Accelerator Pedal Sensor Assembly



C4 Throttle Body Assembly




A38(A), C53(B) ECM




E52 Transmission Control Switch

# Dynamic Radar Cruise Control

## E138 Distance Control ECU Assembly






# Electronically Controlled Transmission and A/T Indicator , Engine Control




# Electronically Transmitted Transmission and A/T Indicator , Engine Control

A31  
Accelerator Pedal Sensor Assembly




Electronically Controlled Transmission and A/T Indicator , Engine Control

\* 1 : Shielded




# Electronically Controlled Transmission and A/T Indicator , Engine Control



Electronically Controlled Transmission and A/T Indicator , Engine Control


A72(A), A73(B), A74(C)  
Transmission Control ECU Assembly




C67  
Electronically Controlled Transmission Solenoid




# Ignition



Back Door Opener , Engine Immobiliser System , Smart Access System with Push-Button Start , Starting , Steering Lock , Theft Deterrent , Wireless Door Lock Control



Back Door Opener , Engine Immobiliser System , Smart Access System with Push-Button Start , Starting , Steering Lock , Theft Deterrent , Wireless Door Lock Control



# Condenser Fan

